

Main Menu Bar



Main Menu Bar

About CSM Server

Install and Download Dashboards

Search for a Host of Interest

Logout


 CSM Server **Home** CCO ▾ Dashboards ▾ Conformance ▾ Tools ▾ Help ▾ 

Lookup Software Information

Available Tools

Navigate Between Hosts

- **Search a host**
 - The Search a host bar provides a quick way to navigate in real-time between managed hosts. When a host is selected, the Host Dashboard is displayed.
 - Further filtering can be done by typing the string matching part of the hostname.



Home

Home

Region: Cisco Telecom West Coast

Display hosts based on the selected region

Schedule installation for multiple hosts

 Schedule Batch Installs

 Filter Hosts by Region ▾

Filter table data

CSM Server	
Server Time	11/05/2015 12:21 PM
Build Date	10/27/2015
Login User	admin
Privilege	Admin

Managed Hosts [Jump Servers](#) [Regions](#) [Server Repositories](#) [Create ▾](#)

10 records per page

Search:

Summary	
Total Regions	18
Total Hosts	52

Launch Host Dashboard

Region Hosts: 11		
Platform ▲	Software ▲	Host ▾
asr9k-px	4.3.4	1
asr9k-px	5.1.3	2
asr9k-px	5.3.1	2

Hostname	Region	TS or IP	Platform	Software	Last Successful Retrieval	Action
ASR9K (Alex)	Cisco Telecom West Coast	172.28.98.2	ASR9K	asr9k-px 5.3.1	76d 13h 18m ago	Install
	Cisco Telecom West Coast	172.28.98.4	ASR9K	asr9k-px 5.3.1	28d 3h 5m ago	Install
ASR9K-PE2-R1	Cisco Telecom West Coast	172.28.98.2	ASR9K	asr9k-px 5.3.1	76d 13h 19m ago	Install
ASR9K-PE3	Cisco Telecom West Coast	172.28.98.6	ASR9K	asr9k-px 5.3.1	76d 13h 18m ago	Install
ASR9K-PE4	Cisco Telecom West Coast	172.28.98.3	ASR9K	asr9k-px 4.3.4	76d 13h 18m ago	Install

Edit Host

Red highlight indicates last software retrieval failed

Home Tab Options



Managed Hosts

Jump Servers

Regions

Server Repositories

Create ▾

▪ Managed Hosts

- Managed hosts are Cisco IOS-XR devices on which scheduling tasks can be performed.
- Each row represents one Cisco device.

▪ Jump Servers (Optional)

- A jump server is the server that CSM logs into in order to connect to the managed hosts.
- Many service provider environments place their devices behind a jump server. CSM first logs into the jump server, then to the router.

▪ Regions

- A region is mapped to multiple server repositories.
- All devices from the same region share the same set of TFTP, FTP, SFTP servers.

▪ Server Repositories

- Where you define the TFTP, FTP, and SFTP server repositories.

▪ Create

- Where you go to create managed hosts, jump servers, regions, and server repositories.

Create a Server Repository - TFTP

- The TFTP Server Path is a complete TFTP URL which is used by the device to load the software package. It must be reachable by the device.
- The File Directory is a Linux file system path which is used by CSM Server to browse software packages since TFTP protocol does not provide file browsing capability. The File Directory should reference the same location as the TFTP Server.



Edit Server Repository

Server Repository Name	<input type="text" value="Building 20 TFTP Server"/>
Server Type	<input type="text" value="TFTP"/>
TFTP Server Path	<input type="text" value="tftp://223.255.254.254/auto/tftp-gud/sit"/>
VRF	<input type="text"/>
File Directory (Used by CSM Server)	<input type="text" value="/auto/tftp-gud/sit"/>

Create a Server Repository – FTP/SFTP

- Specify the FTP/SFTP server address (e.g. ftp.cisco.com or an IP address). Specify the Home Directory where FTP/SFTP client first connects. To identify the Home Directory, log into the server and type 'pwd'.

Edit Server Repository

Server Repository Name	<input type="text" value="RTP-SVS-FTP"/>
Server Type	<input type="text" value="FTP"/>
FTP Server Address	<input type="text" value="10.122.1.10"/>
VRF	<input type="text"/>
Home Directory	<input type="text" value="/home"/> 
Username	<input type="text" value="anonymous"/> 

Create a Server Repository – LOCAL

- A LOCAL server type indicates that the software packages have already been copied onto a device. The device will use the device path information to activate the software packages.
- CSM Server has no visibility on LOCAL server. When scheduling an install, the software packages will need to be manually entered (i.e. file browsing is not supported).

Create Server Repository

Server Repository Name	<input type="text" value="Local Device Storage (Disk 0)"/>
Server Type	<input type="text" value="LOCAL"/>
Device Path (disk0:, harddisk:)	<input type="text" value="disk0:/5.3.1"/>
VRF	<input type="text"/>

Create a Region

- Specify a unique region name.
- Assign server repositories to the region.
- When creating a new host, a region is attached to the host.
- When scheduling an install, CSM Server uses the host's region to display available server repositories. Once a server repository is selected, the software packages reside there may be selected. If no server repository is assigned to a region, all server repositories will be available for selection.
- Assigning server repositories to a region limit how many can be seen and selected.

Edit Region

Region Name

Server Repositories

Available Servers - showing 43

- ACE server
- Alberto ftp
- Alex TFTP Server
- alextang-lnx-v1
- alok_tftp
- BJ-RP-FTP
- Dennis TFTP
- Dsegovia Bldg 18
- Dsegovia Bldg 20
- Eddie SFTP

Selected Servers - showing 2

- Cisco Telecom East Coast TFTP zeppelin-3
- Cisco Telecom East Coast TFTP zeppelin-5

Create a Jump Server

- Specify a unique jump server name.
- Specify a connection type.
- Specify a sever name or the IP address of the server.
- Specify a telnet or ssh port number.
- Specify a username and password.
- A jump server may be assigned to a managed host if the managed host is behind the jump server.

Create Jump Server

Jump Server


Connection Parameters

Connection Type

Name or IP

Port Number

Username

Password 


Create a Host

- Specify a unique host name.
- Select a platform and region for the managed host. Optionally, you may specify the role of the device. This will enable further filtering when creating batch schedule installations.
- If the device is attached to a terminal server, specify the terminal server IP.
- If the device is on the management network, specify the management IP.
- Multiple management IPs (i.e. RSP0 and RSP1) can be entered in the Terminal Server or Mgmt. IP field. Use a comma as the delimiter.
- Multiple terminal server ports can be entered in the Port Number field. Use a comma as the delimiter.

Create Host

Hostname	<input type="text" value="ASR9K-PE2-R1"/>
Platform	<input type="text" value="ASR9K"/>
Region	<input type="text" value="CA-SJ-18-LAB185"/>
Roles	<input type="text" value="Edge Router"/>

Connection Parameters

Connection Type	<input type="text" value="telnet"/>
Terminal Server or Mgmt. IP	<input type="text" value="172.27.82.122"/>
Port Number	<input type="text" value="Leave Blank for Default"/>
Username	<input type="text" value="johnsmith"/>
Password	<input type="password" value="....."/> 
Jump Server	<input type="text" value="None"/>

Connect via Host Console Port

When a host console port is used for the connection, the syslog logging on the console should be disabled. Otherwise, it will interfere with the CSM Server operations when it connects to the device.

- **To disable logging**
 - RP/0/RSP0/CPU0:GW# config
 - RP/0/RSP0/CPU0:GW(config)# logging console disable
 - RP/0/RSP0/CPU0:GW(config)# commit