Transferring Calls Directly to Voice Mail with Cisco CallManager 3.2.2 spD

Document ID: 26862

Introduction

Prerequisites

Requirements

Components Used

Conventions

Overview of the Configuration

Configuration of the Voice Mail Profile

Configuration of the CTI Route Point

Related Information

Introduction

With the release of Cisco CallManager 3.2.2 spD, users have the ability to transfer calls directly to a voice mailbox without ringing that user extension, and without the need to navigate through any opening greetings. This document details the configuration process.

Prerequisites

Requirements

Cisco recommends that you have knowledge of these topics:

- Voice Mail Profile configuration
- Computer Telephony Integration (CTI) route point configuration

Components Used

The information in this document is based on these software and hardware versions:

- Cisco Unity 3.x (Skinny)
- Cisco Digital PBX Adapter (DPA) (Skinny) connected to Octel with use of digital Avaya signaling
- Cisco VG248 Analog Phone Gateway (Skinny) connected to Octel with use of analog signaling and Simplified Message Desk Interface (SMDI)
- Cisco SMDI connected to any voice mail system
- Inter-Cluster Trunk (H.323) with use of any of the above on the destination cluster

The information in this document was created from the devices in a specific lab environment. All of the devices used in this document started with a cleared (default) configuration. If your network is live, make sure that you understand the potential impact of any command.

Conventions

Refer to Cisco Technical Tips Conventions for more information on document conventions.

Overview of the Configuration

If you use the configuration in this document, dialing an asterisk and an extension drops the caller directly into the voice mail box that is associated with that extension. This works by configuring a voice mail box mask on the voice mail profile and associating it with a newly—created CTI route point that matches against the asterisk. The asterisk gets stripped by the voice mail box mask and the extension is placed in the Redirected Dialed Number Identification Service (RDNIS) field before the call goes to voice mail.

Note: Use of an asterisk is not a requirement. The asterisk is used as an example for the purposes of this document. You can use any distinct sequence of numbers in place of the asterisk. The use of a special character like an asterisk to begin the dialing sequence for this feature is often a good plan because most standard dialing plans do not have patterns that begin with the asterisk key. It is usually a good idea to preserve the use of numeric ranges such as 0 through 9.


Configuration of the Voice Mail Profile

As this example shows, a new voice mail profile must be created. The profile has been named TransferToVM in order to distinguish it from the voice mail profile that is associated with user phones. The voice mail pilot should be set to the currently configured pilot number. The voice mail box mask is assigned the wildcard XXXXX to match a five-digit dialing plan. If four-digit dialing is used, set this wildcard to XXXX.

Whatever the dialing plan, this wildcard matches the dialed digits starting from the right. Anything that precedes the digits that are matched by the mask is stripped.



Caution: Do not make this the default voice mail profile for the system.



Configuration of the CTI Route Point

You must create a new CTI route point. The example in this section shows one named TransferToVM. This device is configured just like any other with a device pool, calling search space, and location. This is a CTI route point that will never be registered by any CTI application, and it should not be associated to any users in the directory.

CTI Route Po	Add a New CTI Route Point Back to Find/List CTI Route Points				
Directory Numbers eras Line 1 - *15XXX in -789 Line1	Device: TransferToVM (Transfer directly to VM) Registration: Unknown IP Address:				
erns line 2 - "2XXXX in 1789 line1 "785 line 3 - Add DN	Copy Update Delete Reset CTI Route Point Configuration Device Information				
	Device Name* TransferToVM Description Transfer directly to VM Device Pool* BA Calling Search Space Internal Location < None > * indicates a required item.	(<u>View details</u>)			

The configuration on the CTI route point line makes this all possible. In this example, the Directory Number is set to *15XXX. This setting can just as easily be *XXXXX to forward to all mail boxes, or something as granular as *15654 to forward to just one user mailbox. Choose the voice mail profile that you created in the section Configuration of the Voice Mail Profile for the Voice Mail Profile field, and select **Forward All** to voice mail under Call Forward and Pickup Settings.

Directory Nu	irectory Number Configuration					
Devices using this Directory Number TransferToVM (Line 1)	Directory Number: *15XXX (Line1) Status: Ready Update Delete Reset Devices					
	Directory Numb					
	Directory Number* 15XX					
	Partition Line1					
	Directory Number Settings					
	Voice Mail Profile		TransferToVM (Choose <none> to use default)</none>			
	Calling Search Space		< None >			
	AAR Group		< None >			
	Call Waiting		Not available on this device.			
	Auto Answer Not available on this device.					
	Call Forward and Pickup Settings					
		Voice Mail	Destination	Call Spa	ing Search ce	
	Forward All	ᅜ		< N	one>	
	Forward Busy			< N	one >	
	Forward No Answer	□		< N	one >	
	Forward On Failure			< N	one >	
	Call Pickup Group	< None >		▼		

Now anyone can call a user mailbox directly (or whoever's extension is included in the CTI route point directory number). If there are multiple, separate voice mail servers, such as an Octel and Cisco Unity system, you must create a voice mail profile for each of them. You can use the same CTI route point if you add extra lines. This even works across intercluster trunks.

Note: Do not use the word "Voicemail" as the Alerting Name or Display (Internal Caller ID) for the CTI Route Point Defined. Use of the word "Voicemail" can cause Cisco Unity to process the call as a Direct Call,

Related Information

- Voice Technology Support
- Voice and IP Communications Product Support
- Recommended Reading: Troubleshooting Cisco IP Telephony
- Technical Support & Documentation Cisco Systems

Contacts & Feedback | Help | Site Map

© 2009 – 2010 Cisco Systems, Inc. All rights reserved. Terms & Conditions | Privacy Statement | Cookie Policy | Trademarks of Cisco Systems, Inc.

Updated: Jun 08, 2006 Document ID: 26862