
Cisco ASR 5000/ASR 5500

Mobility Troubleshooting Guide

Azgar Shaik, Balihar Singh, Dave Damerjian, Dennis Lanov, Guilherme Correia, Jamie Turbyne, Jeff Williams, Manoj Adhikari, Mike Lugo, Muhilan Natarajan, Nebojša Kosanović, Nenad Mićić, Solomon Ayyankulankara Kunjan, Steven Loos, Tomonobu Okada



CISCO

Preface 1
Authors and Contributions 3
Authors 5
Dedications 7
Acknowledgments 9
Book Writing Methodology 11
Who Should Read This Book? 13

General Troubleshooting 15
Basic Information for Troubleshooting 17

Hardware Architecture 21
ASR 5000 23
ASR 5500 31

Software Architecture 35
ASR 5000/ASR 5500 Boot Sequence 37
Context 45
Software Managers of ASR 5000/ASR 5500 49
Software/Hardware Redundancy 51

System Verification 57
System Verification and Troubleshooting Overview 59
Initial Data Collection 61
Hardware 73
Local Ethernet and IP Network 91
Call Processing 105
Chassis Fabric 115
Collecting a Show Support Details 123

Platform Troubleshooting 125
CPU/Memory issues 127
Licensing 139
HD RAID 145
Software Crashes 155
ARP Troubleshooting 165
Card and Port Troubleshooting 167
LAG Troubleshooting 177
Switch Fabric & NPU Troubleshooting 189
Session Imbalances 195

CDMA 205
CDMA Overview 207
PDSN / FA 215
HA 241

UMTS 251
UMTS Overview 253
Troubleshooting SGSN 263
Troubleshooting GGSN 301

LTE 327
LTE 329
Troubleshooting MME 341
Troubleshooting SGW 353
Troubleshooting PGW 361
Troubleshooting GTP Path Failure 369
Handover Troubleshooting 375

Session Troubleshooting 381
Overview 383
Protocol Analyzer Utility 391
Generic session debugging commands 393
Session logging 423

Routing Protocol 427
Static Routing 429
OSPF Routing 431
BGP Routing 441

Interchassis Session Recovery 451
Inter Chassis Session Recovery 453
ICSR Troubleshooting 455

Radius 463
Overview 465
Troubleshooting Radius Issues 479

Diameter 505
Diabase 507
Policy Control - Gx 531
Online Charging - Gy 551
Authentication - S6a 569

DNS 579
DNS Client 581
Proxy DNS 591

Active Charging Service 595
Active Charging Service 597
ACS ruledef Optimization 605
FW / NAT 609
X-Header Insertion and Encryption Example 617
Troubleshooting ACS 621

GTPP (CDR's) 629
GTPP/CDR Overview 631
GTPP troubleshooting 639

Bulkstat and KPI 649
Bulkstats 651
Troubleshooting Bulkstats 655
KPIs Overview 661

Preface

Authors and Contributions

This book represents the result of an intense collaborative effort between Cisco's Engineering, Technical Support, Advanced Services employees coming from around the world (Japan, India, Belgium, Canada and USA) to create, in a single week, this collection of methodologies, procedures and troubleshooting techniques.

Authors

This command shows the contributors of this book:

```
[authors]# show authors
Friday May 8, 16:20 UTC 2015
Azgar Shaik – Cisco Technical Services
Balihar Singh – Cisco Advanced Services
Dave Damerjian – Cisco Technical Services
Dennis Lanov – Cisco Technical Services
Guilherme Correia – Cisco Technical Services
Jamie Turbyne – Cisco Engineering
Jeff Williams – Cisco Technical Services
Manoj Adhikari – Cisco Technical Services
Mike Lugo – Cisco Technical Services
Muhilan Natarajan – Cisco Technical Services
Nebojša Kosanović – Cisco Technical Services
Nenad Mićić – Cisco Engineering
Solomon Ayyankulankara Kunjan – Cisco Technical Services
Steven Loos – Cisco Technical Services
Tomonobu Okada – Cisco Technical Services
```

Dedications

This command shows the authors gratitude for support from their loved ones:

```
[authors]# show dedications
Friday May 8, 16:20 UTC 2015


A big thank you to my wife Chika, my sons Yusei and Soshi. Thanks as well to the team for
giving me this great opportunity - Tomo

I would like to dedicate this effort to my beautiful wife Karen and daughters Paityn and
Katie.  Thank you for your patience, support, and love - Mike

Thanks to my father, mother, wife, daughters and brothers that have supported me during all
these years. - Gui

To my wife, son, parents, brother & his family for their continued love, patience, support &
encouragement throughout the years. Thanks to Cisco for this opportunity – Manoj

Dedicated to my parents, my wife Soumya, beautiful sons Allen and Alden. Thanks as well to
Cisco for the opportunity - Solomon

Zahvalio bih se mojoj lijepoj supruzi Tihani, na ljubavi i stalnoj podršci. Zahvalio bih
svojoj obitelji I prijateljima na bezuvjetnoj podršci na svim mojim životnim putevima - Nebojša

Big thanks to my family and colleagues in the Cisco TAC in Brussels for supporting this
intense 1-week onsite book-writing session here in Boxborough – Steven

Dedicated to my Parents Gurdarshan Kaur and Gurdip Singh. But Big thanks to my Wife Mandeep,
daughter and son Gurneet and Lakshveer who supported me a lot. Also thanks to my extended Cisco
Family for the great opportunity - Balihar
```

For the original Grand Theft Auto which, many years ago, inspired my interest in networking and prompted me to set up a LAN that allowed me to play against my friends when the University network was too slow. I would also like to say 'thank you' to all the people in my life, both personal and professional, that put up with me on a daily basis – **Jamie**

Dedicated to my family who put up with my not being around for a whole week while creating this book – **Dave**

For my wife Lee and daughter Lauren and all my extended family, thanks for your support throughout the years. Thanks as well to Cisco for the opportunity, it continues to be a fun ride. – **Jeff**

To my wife, Suba who is always my constant support and a firm believer in my work, without which all of this would have been tough to imagine. Certainly to my daughters Vennila and Meghana, for their own special way of making my every day light and easy, hence make me believe I can do anything after all! And of course to my parents who would always be proud of me no matter what. - **Muhilan**

"For my Mother and Grandmother for their love and support throughout my life." - **Dennis**

"To my wife, Arshiya for her love, support and encouragement, my son Arfan for the sweet moments and my parents for their unconditional love - **Azgar**

Special thanks to my family and friends for their love and support. Big thanks to my colleagues, to the Cisco and Starent communities. - **Nenad**

Acknowledgments

Special thanks to Cisco's Shane Herman, Cisco Director of Technical Support and Engineering teams who supported the realization of this book. We would like to thank you for your continuous innovation and the value you provide to the industry.

Special recognition to Cisco's Technical Services leadership teams for believing in this initiative and the support provided since the inception of the idea.

In particular we want to express gratitude to the following individuals for their influence and support both prior and during the book sprint.

Anand Ram
Carl Harding
Devrim Kucuk
Joe Jette
Fred Carpenito
Joe Falcone
Katsuji Deguchi
Ken Krzyzewski
Mansoor Mohamed Omer
Marty Martinez
Rick Harris
Richard Moore
Scott Page
Shane Kirby
Ketan Kulkarni

Thanks to Book Sprints team: Laia Ros (facilitator), Raewyn Whyte (editor), Henrik van Leeuwen (illustrator), Julien Taquet (book production), Juan Gutierrez (IT support), whose hard work provided us motivation and allowed us to complete this book with joy.

Book Writing Methodology

The Book Sprint (www.booksprints.net) methodology was used for writing this book. The Book Sprint methodology is an innovative new style of cooperative and collaborative authorship. Book Sprints are strongly facilitated and leverage team-oriented inspiration and motivation to rapidly deliver large amounts of well-authored and reviewed content, and incorporate it into a complete narrative in a short amount of time. By leveraging the input of many experts, the complete book was written in a short time period of only five days, however involved hundreds of authoring man hours, and included thousands of experienced engineering hours, allowing for extremely high quality in a very short production time period.

Who Should Read This Book?

People that should read this book are customers, partners and Cisco employees who need to operate and/or troubleshoot the Cisco ASR 5000 and ASR 5500 platforms.

It is expected that the reader has prior knowledge, training and experience on these products and especially, the related technologies. The book focuses on troubleshooting and also covers theoretical concepts for a better understanding of specific features.

For additional assistance related to configuration and features, please check the Cisco ASR 5000 and ASR 5500 Configuration Guides. For assistance with protocol specific issues, consult the 3GPP or appropriate body for related specifications.

General Troubleshooting

Basic Information for Troubleshooting

Overview

Many complex problems are consequences of changes in the network. It could be a configuration change, topology change, traffic pattern change, subscriber behavior changes, signaling storms or flapping of different components. Any problem can result in some KPI degradation and show an anomaly in single or various components or counters.

Prior to troubleshooting, it is most important to get the broadest possible understanding of the problem and to try to evaluate all possible changes in the network, platform and design. The challenge here is that many production systems are maintained by multiple teams, who may not be aware of all the changes made by other teams. Complex systems also require particular levels of monitoring, and an individual troubleshooter may not have access to all monitoring tools. Even the most complex problems can be resolved by simple questions, if asked at the right time. Mastering the technology is a matter of building up experience and a repertoire of questions which bring different angles and dimensions to bear on the problems.

When troubleshooting a network device, it is best to first identify possible KPI degradations and initial events or symptoms of the problem from a macro perspective. Once a baseline is established, then zoom in on the details. Rather than leap to a conclusion, which ultimately consumes time without resulting in a solution, begin with the data and verifiable facts. Try to identify the preconditions of the issue and clearly define the symptoms.

Initial questions:

- Which product has the problem?
- What service was running in the product? What other products were affected which are not running the same service?
- What symptom was noted?
- How many nodes were affected by this problem?
- In which location did the problem occur?
- When was the problem first noticed?
- What was the expected behavior?
- Is there a location with a similar setup which did not experience this problem?

- If the problem is no longer seen, how long did the problem persist? What was done that caused the problem to be resolved?
- What activity was going on in the network during the time the problem was seen? This activity is not necessarily related to the ASR 5x00, but could be related to other activities like routing changes, switch replacement, etc.
- Was there a change in network management prior to the incident?
- Has this problem occurred before? If so, what was the history of that occurrence?
- What else was observed?

More detailed questions:

- How many subscribers are affected? Is there any specific type of subscriber affected?
- How many subscribers are not affected? Is there anything specific shared by those who are not affected?
- What specific KPI degradation was observed? Which values are expected and what are some previous trends. Is there any other KPI which follows the same trends?
- Confirm if the problem is related to:
  - Single, some or all services
  - Specific APN, group of APNs or all APNs
  - Specific card/port, group or all cards/ports
  - Specific sessmgr/aaamgr or all sessmgr/aaamgrs
  - Single or multiple services
  - Single or multiple vlans/interfaces
  - Single, multiple or all NPUs. If NPU is not the problem, check the switch fabric
  - Type of calls, and if so, what is the duration of those calls or any other factor specific to those calls?
  - A specific interface - how is the call flow affected and in which phase is it affected?
  - A specific peer group or all peers - is there anything specific about the peers affected?
- Anything specific to the affected components or objects?
- Identify any events which occurred around same times when a previous example of this issue happened. What is common to these events?
- When thinking about symptoms or conditions always confirm: Where was the problem experienced? Where was it not experienced? What was not experienced? Where? Where not? When? When not?

- What percentage of devices or users are affected? What observations can be made about these devices or users?
- Confirm whether this issue is expected behavior and if not, in what ways it is unexpected. What differences are there between the affected and unaffected? What is the key difference from non-expected behavior?
- What are the examples of working and non-working case scenarios?
- What was the duration of the issue? Is this a recurring or one-time event?
- History of the problem:
  - Issue trigger?
  - Configuration/Recent/Network changes?
  - Change management?
  - Flapping?
  - Timeline of events?
  - Logs?
  - Patterns?
  - Differences and delta?
  - Pre-conditions?
  - Micro and macro perspectives?
  - Confirmed and excluded conditions or triggers?
  - Trends?
- Relevant configuration details:
  - Working config
  - Non-working config
  - Problematic?
  - Specific details?
- Relevant counters, thresholds, limits, return codes, frequency, timeouts, delta max/avg/min/deviation?
- Any specific ranges, oscillations, deviations or differences? Trends/Graphs?

Other involved devices:

What is the difference noticed by comparison to other involved devices, both working and non-working?

- Hardware
- Software version
- Configuration changes
- Are these Cisco devices or third party devices?
- Any other unknowns: related info, logs, traces, events or history?

Topology and design details:

- Diagrams or graphs
- Design documents
- Previous stability duration
- Previous versions
- Is this a new setup?
- Is this a production, lab or FOA (First Office Application) environment?
- Are other teams involved?

Reproduction:

- Issue reproduced? If yes, can it be consistently reproduced or is it an intermittent problem?
- Method used to reproduce the issue?
- Which tools were used to reproduce the issue?
- For how long have reproduction attempts been made?

Workarounds:

- Is it possible?
- What are the disadvantages of implementing the workaround? Any subscriber impact?
- Is it confirmed, tested and validated in the lab?

Hardware Architecture

ASR 5000

Overview

The ASR 5000 is a versatile platform capable of providing multiple services in the Mobility space, including SGSN/GGSN/MME/SGW/PGW/HA/FA/PDSN/HSGW amongst others. Multiple services can be combined in a single platform, for example; MME/SGSN services in one single physical platform. The ASR 5000 uses StarOS as its operating system which is a customized version of Linux that provides a robust and flexible environment.

The Cisco ASR 5000 features a distributed architecture, high-performance capabilities, service assurance, and subscriber awareness that ultimately assures high performance. The distributed architecture incorporates a blend of high-performance processing, significant memory, and powerful switch fabric to intelligently and reliably support mobile sessions. Call control and packet forwarding paths are separated on different control and data switch fabrics, reducing the number of traffic-flow inefficiencies which diminish latency and accelerate call setup time and handoffs.

With the distributed architecture, all tasks and services can be allocated across the entire platform. This unique approach allows deployment of more efficient mobile networks that can support a greater number of concurrent calls, optimizes resource usage, and delivers enhanced services, while also providing easy scalability.

The ASR 5000 has no single point of failure: It employs full hardware and software redundancy. ECC single bit errors are also automatically corrected on DRAMs. In the unlikely event of a failure, the ASR 5000 is able to maintain user session and retail billing information, and maximize network availability. Some of the self-healing capabilities of the ASR 5000 include task migration, session recovery, fault containment, state replication, dynamic hardware removal and addition, and geographic redundancy between different chassis.

The ASR 5000 also provides in-line services, which allows for provision of stateful firewall protection, content filtering and enhanced content charging.

ASR 5000 Hardware Configuration

Each ASR 5000 chassis always requires a minimum of two 'redundant' PSC cards (1 x Standby and 1 x Demux) solely to ensure 'Carrier Grade' reliability in the chassis PLUS however many additional 'active' cards are required to handle the live traffic at the node. An ASR 5000 chassis may accommodate a maximum total of 14 PSC cards of which up to 12 will provide the capacity for handling live traffic - the specific quantity required to be determined by the dimensioning of the solution. A minimum of two 'active' PSC cards is required for a production node.

In addition to 2 x 'redundant' and 2 x 'active' PSC cards, the minimum configuration of an ASR 5000 chassis also requires the following items to be provisioned; 2 x System Management Cards (SMC), 2 x Redundancy Crossbar Cards (RCC), 2 x Switch Processor I/Os (SPIO) and two copies of whichever System Software has been selected (one per SMC).

The required StarOS image should be determined as the result of a joint effort from the Operator's Engineering Department and Cisco Advanced Services, so that the correct image can be deployed, based on the Operator needs.

The ASR 5000 capacity is defined by these three parameters: throughput, maximum simultaneous subscribers, and call model. The ASR 5000 capacity limiters are PSC or Task CPU, NPU and PSC or Task Memory. The call model describes what happens in the ASR 5000 system; it includes all events (data, activation, deactivation, handoff, accounting, etc.) that occur simultaneously. Each event consumes PSC/Task CPU processing time, NPU and memory.

Image - ASR 5000 Front View Cards:





Image - ASR 5000 Rear View Cards:



ASR 5000 Physical Components

SMC - *System Management Card*: This card is present in slots 8 (typically active) and 9 (typically standby). It hosts the high availability software that controls the system. The SMC provides system wide management control and hosts CLI sessions. It does not participate directly in call establishment, maintenance or termination.

Each SMC has a dual-core central processing unit (CPU) and 4 GB of random access memory (RAM). There is a single PC-card slot on the front panel of the SMC that supports removable ATA Type I or Type II PCMCIA cards. The SMC uses these cards to load and store configuration data, software updates, buffer accounting information, and store diagnostic or troubleshooting information.

There is also a Type II CompactFlash™ slot on the SMC that hosts configuration files, software images, and the session limiting/feature uses license keys for the system.

The SMC performs the following major functions:

- Non-blocking low latency inter-card communication
- 1:1 or 1:N redundancy for hardware and software resources
- System management control
- Persistent storage via CompactFlash and PCMCIA cards (for field serviceability), and a hard disk drive for greater storage capabilities
- Internal gigabit Ethernet switch fabrics for management and control plane communication

SPIO - Switch Process IO Card: It is the card that provides connectivity for local and remote management, CO alarming, and Building Integrated Timing Supply (BITS) timing input. SPIOs are installed in chassis slots 24 and 25, behind SMCs. During normal operation, the SPIO in slot 24 works with the active SMC in slot 8. The SPIO in slot 25 serves as a redundant component. In the event that the SMC in slot 8 fails, the redundant SMC in slot 9 becomes active and works with the SPIO in slot 24. If the SPIO in slot 24 should fail, the redundant SPIO in slot 25 takes over.

PSC - Packet Services Cards: PSC2 and PSC3. The packet-processing cards provide packet processing and forwarding capabilities within a system. Each card type supports multiple contexts, which allows an operator to overlap or assign duplicate IP address ranges in different contexts.

Specialized hardware engines support parallel distributed processing for compression, classification, traffic scheduling, forwarding, packet filtering, and statistics.


The packet-processing cards use control processors to perform packet-processing operations, and a dedicated high-speed network processing unit (NPU). The NPU does the following:

- Provides “Fast-path” processing of frames using hardware classifiers to determine each packet’s processing requirements
- Receives and transmits user data frames to and from various physical interfaces
- Performs IP forwarding decisions (both unicast and multicast)
- Provides per interface packet filtering, flow insertion, deletion, and modification
- Manages traffic and traffic engineering
- Modifies, adds, or strips datalink/network layer headers
- Recalculates checksums
- Maintains statistics

- Manages both external line card ports and the internal connections to the data and control fabrics

To take advantage of the distributed processing capabilities of the system, packet-processing cards can be added to the chassis without their supporting line cards, if desired. This results in increased packet-handling and transaction-processing capabilities. Another advantage is a decrease in CPU utilization when the system performs processor-intensive tasks such as encryption or data compression. Packet-processing cards can be installed in chassis slots 1 through 7 and 10 through 16. Each card can be either Active (available to the system for session processing) or redundant (a standby component available in the event of a failure).

Image - PSC internal structure:



Packet Services Cards

Packet Services Cards come in 2 versions: PSC2 and PSC3.

The PSC2 uses a fast network processor unit, featuring two quad-core x86 CPUs and 32 GB of RAM. These processors run a single copy of the operating system. The operating system running on the PSC2 treats the two dual-core processors as a 4-way multi-processor. The PSC2 has a dedicated security processor that provides the highest performance for cryptographic acceleration of next-generation IP Security (IPSec), Secure Sockets Layer (SSL) and wireless LAN/WAN security applications with the latest security algorithms.

PSC2s should not be mixed with PSC3s. Due to the different processor speeds and memory configurations, the PSC2 cannot be combined in a chassis with other packet-processing card types. The PSC2 can dynamically adjust the line card connection mode to support switching between XGLCs and non-XGLCs with minimal service interruption.

The PSC3 provides increased aggregate throughput and performance and a higher number of subscriber sessions than the PSC2. Specialized hardware engines support parallel distributed processing for compression, classification, traffic scheduling, forwarding, packet filtering, and statistics. The PSC3 features two 6-core CPUs and 64 GB of RAM. These processors run a single copy of the operating system. The operating system running on the PSC3 treats the two core processors as a 6-way multi-processor.

PSC3s must not be mixed with PSC2s. Active PSCs are fully redundant with spare PSCs.

Ethernet Line Cards

These provide Ethernet connections to external network elements, typically switches. They are installed in slots 17-23, 26-32, 33-39 and 42-48. They provide redundancy and all subscriber traffic is carried on these ports. Ethernet Line Cards are controlled by the PSCs, which provide most of the intelligence. Session control and data packets are forwarded via line card interfaces.

Fast Ethernet Line Card (FLC2)

The FLC2 is installed directly behind its respective packet-processing card, providing network connectivity to the packet data network. Each FLC2 (Ethernet 10/100) has eight RJ-45 interfaces. Each of these IEEE 802.3-compliant interfaces supports auto-sensing 10/100 Mbps Ethernet.

Gigabit Ethernet Line Card (GLC2)

The GLC2 is installed directly behind its respective packet-processing card, providing network connectivity to the packet data network. The GLC2 (Ethernet 1000) supports a variety of 1000 Mbps optical and copper interfaces based on the type of Small Form-factor Pluggable (SFP) modules installed on the card.

Quad Gigabit Ethernet Line Card (QGLC)

The QGLC is a 4-port Gigabit Ethernet line card that is installed directly behind its associated packet-processing card to provide network connectivity to the packet data network. There are several different versions of Small Form-factor Pluggable (SFP) modules available for the QGLC.

10 Gigabit Ethernet Line Card (XGLC)

The XGLC supports higher speed connections to packet core equipment, increases effective throughput between the ASR 5000 and the packet core network, and reduces the number of physical ports needed on the ASR 5000.

The XGLC (10G Ethernet) is a full-height line card, unlike the other line cards, which are half height.

The single-port XGLC supports the IEEE 802.3-2005 revision which defines full duplex operation of 10 Gigabit Ethernet. PSC2s or PSC3s are required to achieve maximum sustained rates with the XGLC.

The XGLC uses a Small Form-factor Pluggable Plus (SFP+) module. The modules support one of two media types: 10GBASE-SR (Short Reach) 850nm, 300m over multimode fiber (MMF), or 10GBASE-LR (Long Reach) 1310nm, 10km over single mode fiber (SMF).

The supported redundancy schemes for XGLC are L3, Equal Cost Multi Path (ECMP) and 1:1 side-by-side redundancy. Side-by-side redundancy allows two XGLC cards installed in neighboring slots to act as a redundant pair. Side-by-side pair slots are 17-18, 19-20, 21-22, 23-26, 27-28, 29-30, and 31-32.

Side-by-side redundancy only works with XGLC cards. When configured for non-XGLC cards, the cards are brought offline. If the XGLCs are not configured for side-by-side redundancy, they run independently without redundancy.

RCC - Redundant Crossbar Card: The RCC uses 5 Gbps serial links to ensure connectivity between rear-mounted line cards and every non-SMC frontloaded application card slot in the system. This creates a high availability architecture that minimizes data loss and ensures session integrity. If a packet-processing card were to experience a failure, IP traffic would be redirected to and from the LC to the redundant packet-processing card in another slot. Each RCC connects up to 14 line cards and 14 packet-processing cards for a total of 28 bidirectional links or 56 serial 2.5 Gbps bidirectional serial paths.

The RCC provides each packet-processing card with a full-duplex 5 Gbps link to 14 (of the maximum 28) line cards placed in the chassis. This means that each RCC is effectively a 70 Gbps full-duplex crossbar fabric, giving the two RCC configuration (for maximum failover protection) a 140 Gbps full-duplex redundancy capability.

Traffic Path

See below image

Image - ASR 5000 Traffic Path for PSC cards in slot 1, 2 and 3



UL traffic

1. Traffic is routed by PSC1 Network Proc. to PSC2 (Gn)
2. PSC2 handles services
3. PSC2 has been selected at PDP context set-up to load balance between the different PSC cards
4. Traffic is then routed to PSC3 Network proc. (Gi)

DL traffic

Reverse way

Notes:

- Gn & Gi routing can be on the same PSC card
- Services can be provided on the same PSC than Gn and Gi
- For illustrative purposes, these functions are split in this diagram


ASR 5500

The ASR 5500 is designed to provide subscriber management services for high-capacity wireless networks.

ASR 5500 is a multimedia core platform with maximum capacity of 20 cards with 10 slots in the front and rear. This chassis features distributed architecture allowing different services to function across the entire platform. The chassis is designed to have fabric cards in the front, and I/O and processing cards in the rear. The front cards are for persistent storage, with rear cards for I/O, session processing and management.

Slots 1 to 10 are located in the rear of the chassis with slots 5 and 6 for management as well as I/O operations. Slots 11 to 20 are in the front of the chassis with 19 and 20 reserved for future use.

Image - card layout of an ASR 5500:



In ASR 5500 there are 4 different types of cards, each providing different functionality as explained below:

Management I/O, Universal Management I/O Cards (MIO/UMIO): There are 2 Management I/O cards (MIO) or Universal Management I/O cards (UMIO) in slots 5 & 6. The UMIO card is the same hardware as MIO, but needs an additional license.

Each MIO/UMIO card has:

- 20 x 10 Gigabit interfaces for external I/O
- Two x 1 Gigabit interfaces dedicated for local context (OAM)
- One CPU subsystem with 96 GB of RAM
- Four x NPU subsystems
- Console connection for CLI Management
- 32 GB SDHC internal flash device
- USB port for flash drive connection

Universal Data Processing Card, Data Processing Card (UDPC / DPC): Data Processing Cards (DPC) and/or Universal Data Processing Cards (UDPC) can be placed in slots 1 to 4 and 7 to 10. A UDPC card is the same hardware as DPC, but needs an additional license. DPC/UPDC cards manage subscriber sessions and control traffic.

The DPC/UDPC has two identical CPU subsystems with each containing:

- 96 GB of RAM
- NPU for session data flow offload
- Crypto offload engines located on a daughter card

Fabric and Storage Cards (FSC): There may be up to 6 FSC cards installed in slots 13 to 18 which are in front of the chassis.

The FSC features:

- Fabric cross-bars providing in aggregate:
  - 120 Gbps full-duplex fabric connection to each MIO/UMIO
  - 60 Gbps full-duplex fabric connection to each DPC/UDPC

- Two 2.5" serial attached SCSI (SAS), 200GB solid state drives (SSDs) with a 6 Gbps SAS connection to each MIO/UMIO.

Every FSC adds to the available fabric bandwidth to each card. Each FSC connects to all MIO/UMIOs or DPC/UDPCs, with a varying number of links depending on the MIO/UMIO or DPC/UDPC slot. Three FSCs provide sufficient bandwidth while the fourth FSC supports redundancy.

The ASR 5500 uses an array of solid state drives (SSDs) for short-term persistent storage. The RAID 05 configuration has each pair of drives on an FSC striped into a RAID 0 array; all the arrays are then grouped into a RAID 5 array. Each FSC provides the storage for one quarter of the RAID 5 array. Data is striped across all four FSCs with each FSC providing parity data for the other three FSCs. The array is managed by the master MIO/UMIO.

System Status Cards (SSC): There are two SSC which are in dedicated slots 11 and 12.

The SSC card features:

- Three alarm relays (Form C contacts)
- Audible alarm with front panel Alarm Cutoff (ACO)
- System status LEDs


Software Architecture

ASR 5000/ASR 5500 Boot Sequence

Overview


With different cards performing different functionalities in ASR 5000/ASR 5500 chassis, it's important to understand the boot process of the chassis.

Image - ASR 5000 Boot Process Flowchart



1. When power is first applied to the chassis or a reload is performed, the SMC cards in slot 8 and 9 receive power. Once the system confirms cards are located in slots 8 and 9, power is applied to the SPIO cards in slots 24 and 25.
2. POST (Power On Self Tests) are performed on each card to ensure the hardware is operational.
3. If SMC 8 passes all POST tests, it will become the Active SMC card and the SMC card in slot 9 will become Standby. If there is an issue with SMC 8, then SMC 9 will become the Active SMC card.
4. The Active SMC will then begin loading the StarOS image designated in the boot stack file, boot.sys, located on the SMC CompactFlash. The Standby SMC will load its image from the Active SMC unless the Active SMC fails, and if so, the Standby SMC will then load its image from its own boot.sys file and will then become the Active SMC.
5. After the Active SMC finishes loading, it will determine which slots are populated with Application cards by providing power to the slots. If a card is present, power is left on for that slot. Slots without a card are not powered on.
6. PSCs and Line Cards in the system will perform POST tests as they are powered up.
7. The PSC card will enter into Standby mode after successfully completing POST tests.
8. Line cards will remain in standby mode until the associated PSC cards are made Active. If using half-height line cards, the Line Card in the upper slot will be made Active and the Line Card in lower slot will be made standby.
9. The PSC will download its code from the SMC after entering Standby mode.
10. After successfully loading the software image, the system will load the configuration file specified in the boot stack file. If no software configuration file is found, the system will enter the Quick Setup Wizard.

Image - ASR 5500 Boot Process Flowchart



1. When power is applied to the chassis or after a reload of the chassis, the MIO/UMIOs in slots 5 and 6 will receive power.
2. Power on Self Tests (POST) will be run on the MIO/UMIOs to validate the hardware is operational.

3. The MIO in slot 5 will become the Active MIO if all POSTs are successfully executed. The MIO in slot 6 will be declared the Standby card. The MIO in slot 6 will become the Active MIO if a problem is detected with the MIO in slot 5.
4. The Active MIO will then begin loading the StarOS image designated in the boot stack file, boot.sys, located in the flash memory of the MIO. The Standby MIO will load its image from the Active MIO unless the Active MIO fails, and the Standby MIO will then load its image from its own boot.sys file and will then become the Active MIO.
5. After the Active MIO finishes loading, it will determine which slots are populated with Application cards by providing power to the slots. If a card is present, power is left on for that slot. Slots without a card are not left powered on.
6. DPC Cards in the system will perform POST tests as they are powered up.
7. The DPC card will enter into Standby mode after successfully completing POST tests.
8. The DPC will download its code from the Active MIO after entering Standby mode.
9. After successfully loading the software image, the system will load the configuration file specified in the boot stack file. If no software configuration file is found, the system will enter the Quick Setup Wizard.

Boot System Priorities

When the chassis is powered on or reloaded, the system will attempt to load the StarOS image and configuration file specified in the boot.sys file. The boot system priority with the lowest numerical value will be loaded.

The boot.sys file is populated via the the following configuration commands:

```
configure
    boot system priority <number> image <StarOS Image Name> config <Configuration file name>
end
```

The system allows the user to specify a maximum of 10 boot system priorities. If 10 boot system priorities have been specified, the oldest boot system priority should be deleted. Here are the commands to delete a boot system priority:

```
configure
    no boot system priority <number>
end
```

In order to verify which boot system priority was used to load the system, the following command can be issued:

```
show boot initial-config
Friday May 08 15:20:24 CEST 2015
Initial (boot time) configuration:
    image /flash/production.52055.asr5000.bin
    config /flash/test_config.cfg
    priority 1
```

When adding new boot system priorities to the system's configuration, it is important to ensure the StarOS image name and the configuration file are valid. If the configuration file specified in the boot system priority is not valid, the system will be unable to load after a reboot.

In order to verify software is valid, the following command can be issued:

```
show version /flash/asr5000-16.1.2.bin
Friday May 08 15:22:03 CEST 2015
Reading /flash/asr5000-16.1.2.bin... done

OPERATIONAL_IMAGE Version          : 16.1 (55894)
OPERATIONAL_IMAGE Description      : ASR5000 Deployment Build <55894>
OPERATIONAL_IMAGE Date             : Monday July 21 20:15:21 GMT 2014
OPERATIONAL_IMAGE Size             : 237835776
OPERATIONAL_IMAGE Flags            : None
OPERATIONAL_IMAGE Platform         : ASR5000
```

Default boot.sys file

If the system fails to read the boot.sys file when booting, the default boot.sys file will be used. Possible reasons why this failure may occur:

- boot.sys doesn't exist
- boot.sys is corrupted
- boot.sys is zero length

Below are the contents of the default boot.sys:

Default boot.sys for ASR 5500:

```
/flash/system.bin
/flash/system.cfg
/usb1/system.bin
/usb1/system.cfg
/flash/asr5500.bin
/flash/asr5500.cfg
/usb1/asr5500.bin
/usb1/asr5500.cfg
```

Default boot.sys for ASR 5000:

```
/flash/system.bin
/flash/system.cfg
/pcmcia1/system.bin
/pcmcia1/system.cfg
/flash/st40.bin
/flash/system.cfg
/pcmcia1/st40.bin
/pcmcia1/system.cfg
```

Context

Overview

A context is a logical grouping or mapping of configuration parameters that pertains to various physical ports, logical IP interfaces, and services. Each context can be thought of as a virtual router instance. The system supports the configuration of multiple contexts. Each context is configured and operates independently of the others. Services can be configured to allow data to pass between contexts.

Local context is the default context and it is used for management of the system including CLI sessions, sys logging, ntp, etc.

Once a context has been created, administrative users can configure services, IP interfaces, add subscriber and / or APN profiles, and bind the logical interfaces to physical ports.

During troubleshooting, make sure to have the CLI in the correct context. The command "**show context**" will list what is present in the configuration. The command "**context [name]**" will allow movement between contexts.

The following command will display all the contexts in use on the system:

```
 [local]ASR5000# show context
Context Name    ContextID    State
------------    ---------    -----
local           1            Active
EPC             2            Active
SGi             3            Active
SIG             4            Active
```

What is relevant in this output is the Context ID. Each context is bound to and managed by a vpnmgr process with an instance ID that matches the Context ID:

```
[local]ASR5000# show task resources facility vpnmgr all
                    task    cputime        memory     files      sessions
 cpu facility      inst used allc   used  alloc used allc  used  allc S status
----------------------- --------- ------------- --------- ------------- ------
 1/0 vpnmgr           1 0.2%  30% 13.52M 48.10M   24 2000    --    -- -   good
 1/0 vpnmgr           2 0.2% 100% 11.19M 67.60M   35 2000    --    -- -   good
 1/0 vpnmgr           3 0.2% 100% 21.61M 71.07M   20 2000    --    -- -   good
 1/0 vpnmgr           4 0.2% 100% 10.34M 48.10M   20 2000    --    -- -   good
```

Software Managers of ASR 5000/ASR 5500

Overview

This chapter talks about different processes in ASR 5000/ASR 5500 and their functionalities.

Software Processes

Tasks within the ASR 5000/ASR 5500 chassis have a parent / child relationship that is referred to within a Controller and Manager framework. A controller task will run on an SMC or MIO depending on the hardware architecture, and is responsible for creating the manager tasks. Manager tasks will run on the PSC or DPC card depending on the hardware architecture in use.

- vpnctrl
  - VPN Controller creates a vpnmgr for each configured context
  - Controls IP routing across and within the configured contexts of the chassis
- vpnmgr
  - One vpnmgr for each configured context
  - Implements Address Resolution Protocol (ARP)
  - Installs NPU flows
  - Maintains IP pool configs and usage for appropriate context(s).
  - Part of Session Recovery along with SessMgr and AAAMgr.
- sessctrl
  - Session Controller creates
    - sessmgr and aaamgr instances
    - Signaling managers for every service configured, for example:
      - gtpcmgr
      - sgtpmgr
      - imsimgr
      - egtpinmgr

- sessmgr
  - Subscriber processing system that supports multiple subscriber types
  - Multiple Session Managers per CPU. SessMgr is distributed over multiple CPUs on all active processor cards.
  - A single Session Manager can service sessions from multiple signaling Demux managers and from multiple contexts.
  - An instance of the AAAMgr task is created and paired with each SessMgr task as part of Session Recovery.
- aaamgr
  - AAAMgr tasks are paired with SessMgr tasks
  - All AAA protocol operations and functions performed for subscribers. Performs the functions of a AAA client to AAA Servers.
  - Multiple AAA Managers per CPU
  - AAAMgr is distributed over multiple CPUs on all active processor cards
- diamproxy
  - 1 diamproxy instance per Active DPC or PSC card
  - Responsible for the processing of Diameter messaging
  - Sessmgr uses a diamproxy on a different card where aaamgrs initiate requests for S6b/STa/Rf
  - Sessmgr uses a diamproxy on the same card to initiate requests for Gx and Gy
- gtpcmgr
  - Created for the GGSN service.
  - Receives the PDP Context requests for GTP sessions from the SGSN.
    - Distributes to different sessmgr tasks for load balancing.
  - Maintains a list of current sessmgr tasks to aid in system recovery.
- imsimgr
  - Created for the SGSN RAN interface
  - Receives the attach and activate requests from UEs
  - Maintains a table of the relationship between PTMSI, IMSI and sessmgr.
- sgtpmgr
  - Created for the SGSN Gn interface
  - Receives PDP context from the SGSN service and multiplexes them onto the Gn interface

    - Manages Tunnels
    - GGSN lookups
    - Other SGSN lookups
- egtpinmgr
    - Created for the SGW and PGW S5 interface
- gtpumgr
    - Manages GTP-U flows for user sessions.
- npumgr
    - Manages the NPU subsystem
    - Executes on the SMC/MIO and DPC/PSC CPUs
    - Has local copy of NPU data
- cli
    - Task is created for each individual user logged into the chassis
    - Accepts input from the user
        - show commands
        - configuration additions or deletions

Tasks can be monitored by using the below commands:

- show task resource

```
                 task   cputime         memory      files      sessions
 cpu facility      inst used allc   used   alloc used allc  used  allc S status
---------------------- --------- ------------- --------- ------------- ------
 1/0 sitmain         10 0.2%  15%  3.12M  8.00M   14 1000    --    -- -   good
 1/0 sitparent       10 0.1%  20%  2.25M  6.00M   11  500    --    -- -   good
 1/0 evlogd           0 0.1%  95%  4.45M 25.00M   12 4000    --    -- -   good
 1/0 drvctrl          0 0.2%  15%  4.26M 10.00M   15  500    --    -- -   good
 1/0 hatsystem        0 0.1%  10%  2.51M  7.00M   10  500    --    -- -   good
 1/0 hatcpu          10 0.3%  10%  2.42M  7.00M   11  500    --    -- -   good
 1/0 rct              0 0.1% 5.0%  2.20M 17.00M   10  500    --    -- -   good
 1/0 sct              0 0.5%  50% 18.08M 25.00M   15  500    --    -- -   good
 1/0 rmmgr           10 0.9%  15%  5.29M 12.00M   27  500    --    -- -   good
 1/0 npumgr          10 0.2% 100% 117.7M 200.0M   21 1000    --    -- -   good
 1/0 sft            100 0.2%  50%  6.71M 22.00M   18  500    --    -- -   good
```

- show task table

```
cpu facility      inst    pid pri node  facility      inst    pid
---- ---------------------------------  -------------------------
 1/0 mmemgr           6   7762   0  all  sessctrl         0   4731
 1/0 mmemgr           5   7689   0  all  sessctrl         0   4731
 1/0 mmemgr           4   7616   0  all  sessctrl         0   4731
 1/0 mmemgr           3   7543   0  all  sessctrl         0   4731
 1/0 egtpegmgr        1   7470   0  all  sessctrl         0   4731
 1/0 mmemgr           2   7469   0  all  sessctrl         0   4731
 1/0 bgp             10   7252   0  all  vpnmgr          10   7209
 1/0 zebos           10   7250   0  all  vpnmgr          10   7209
```

- show task memory

```
        task    heap            physical             virtual
 cpu facility      inst    used         used  alloc         used  alloc  status
----------------------  ------  ------------------  ------------------  ------
 1/0 sitmain         10   1.54M   55%  8.83M 16.00M    9% 388.9M  4.00G  good
 1/0 sitparent       10    920K   69%  9.74M 14.00M    9% 388.0M  4.00G  good
 1/0 hatcpu          10   1.33M   67% 10.08M 15.00M    9% 388.5M  4.00G  good
 1/0 rmmgr           10   7.26M   71% 16.41M 23.00M    9% 394.8M  4.00G  good
 1/0 hwmgr           10    898K   64%  9.71M 15.00M    9% 388.0M  4.00G  good
 1/0 dhmgr           10   8.43M   46% 16.34M 35.00M    9% 395.4M  4.00G  good
 1/0 connproxy       10   2.69M   32% 11.32M 35.00M    9% 389.7M  4.00G  good
 1/0 dcardmgr        10  31.77M    6% 40.64M 600.0M   11% 465.8M  4.00G  good
 1/0 sft            100   5.50M   55% 16.51M 30.00M    9% 392.8M  4.00G  good
```

When CPU and/or Memory of tasks exceeds certain predefined limits, the status of the task will change from 'good' to 'warn' or 'over'. This will be accompanied by an SNMP trap and log to notify the system administrator.

In such cases it might be important to find out why this happens, and to take corrective action, as it could indicate a more serious issue. The Cisco TAC should be engaged in such cases. For example, a sessmgr in **over** state could start rejecting new subscriber sessions.

Software/Hardware Redundancy

Overview

This chapter covers both software and hardware redundancy options in ASR 5000/ASR 5500.

The ASR 5000/ASR 5500 is a distributed system with multiple levels of redundancy within each Processor and Management card. Full chassis-to-chassis redundancy is also available when Inter-Chassis Session Recovery (ICSR) is configured. At the software level, there are standby processes available to take over in the event of software task crashes.

Image - ASR 5000 Software Architecture:





Image - ASR 5500 Software Architecture:



The following tasks are relevant for the software/hardware redundancy:

- High Availability Task (HAT)
  - Maintains the operational state of the system
  - Monitors the software and hardware on each card type
- Recovery Control Task (RCT)
  - Recovery action is executed for any failure that occurs on the system
  - Triggers are received from HAT and CSP (Card Slot Port subsystem)
- Shared Configuration Task (SCT)
  - Sets, retrieves and is notified of system configuration changes
  - Stores configuration data for the applications that run on the system

In the event of a hardware failure, the system has been designed to contain standby hardware to take over the functions of the failed hardware. Should hardware need to be replaced, this can be done without interruption (all cards are hot swappable).

Hardware Redundancy on card level

SMC card is 1:1 redundant.

PSC cards are 1:N redundant.

Planned card migration is supported where each proclet (process) in the source card is migrated gracefully to the target card.


Unplanned card migration (when a card unexpectedly fails), will work differently. All the lost proclets on this card will have to be regenerated by querying processes on other cards. This is explained in the 'Session Recovery Architecture' section below.

When a single proclet dies, the parent proclet is notified and the parent instantiates the proclet again. Each proclet should have a recovery strategy to get back to its previous state upon recovery.

Session Recovery Architecture:

The session recovery feature provides seamless failover and reconstruction of subscriber session information in the event of a hardware or software fault within the system. Session recovery prevents a fully connected user session from being disconnected from the network and also maintains the user's state information. Session recovery is performed by mirroring key software processes (e.g. Session Manager and AAA Manager) within the system. These mirrored processes remain in an idle state (in standby-mode) wherein they perform no processing until they are needed, for example in the case of a software failure of a session manager task.

Image - Session Recovery Basics



At boot-up the system spawns new instances of "standby mode" session managers and AAA managers for each active Control Processor (CP) being used. Additionally, other key system-level software tasks, such as VPN manager, are started on physically separate Processor Cards to ensure that a double software fault (e.g. session manager and VPN manager fails at same time on the same card) cannot occur.

The Processor Card used to host the VPN manager process is in active mode and is reserved by the operating system for this use when session recovery is enabled. Other demux (signaling) tasks will be running on this Processor Card but there will be no Session manager or AAA manager instances on the card running the VPN manager instances. The additional hardware resources required for session recovery include a standby SMC in ASR 5000, MIO for ASR 5500 and a standby Processor Card (PSC in ASR 5000 or DPC in ASR 5500).

In summary:


- Calls in the ASR 5x00 are handled by work-horse proclets called sessmgrs.
- Each sessmgr is backed by a paired aaamgr. The sessmgr and aaamgr are arranged to be started on 2 different processing cards (PSC/DPC) such that card failure scenarios can be handled.
- Each call is check-pointed periodically from sessmgr to the corresponding aaamgr.

- To speed up the session recovery, a standby session manager runs in every processing card (PSC/DPC) and is quickly renamed to the lost sessmgr, after which a new standby sessmgr is created on the processing card.
- Upon unexpected loss of a sessmgr process, the standby sessmgr process retrieves the backed up information from aaamgr and re-builds its sessions.
- When aaamgr fails, the standby aaamgr queries the sessmgr to re-sync the relevant subscriber info.
- When demux-mgr fails, it queries all sessmgrs and re-builds its data-base of call-distribution information.
- Nothing is maintained by the sessctrl process. But when the sessctrl process unexpectedly fails, it should ensure that all sessmgr processes are running with the right configuration (as present in SCT process) and it should ensure this reconciliation.

Session Recovery Modes:


Task recovery mode: Wherein one or more session manager failures occur and are recovered without the need to use resources on a standby Processor Card. In this mode, recovery is performed by using the mirrored "standby-mode" session manager task(s) running on the active PSC / DPC. The "standby-mode" task is renamed, made active, and is then populated using information from AAAMgr and VPNMgr.

Image - task recovery




Full session processing cards (PSC-2/PSC-3/DPC) recovery mode: Used when a PSC / DPC hardware failure occurs, or when a card migration happens. In this mode, the standby card is made active and the "standby-mode" session manager and AAA manager tasks on the newly activated session processing card perform session recovery. Session/Call state information is pulled from the peer AAA manager task; each AAA manager and session manager task is paired. These pairs are started on a physically different PSC / DPC to ensure task recovery.

Image - Card recovery



ASR 5000 Simple Packet Flow:



These are the basic steps taken when a new call arrives in the ASR 5000:

1. When a new call arrives, it first connects to the signaling service demux-mgr (step1 above), PGW, HA, GGSN for example. The demux-mgr then chooses a sessmgr to handle the call and gives it to that session manager (in the picture above, a sessmgr in card PSC-3).
2. Traffic from the call is sent from the UE to NPU and then on to SessMgr (step 2a above). SessMgr will act on the traffic if required, and pass it back to NPU on the same PSC which then sends the traffic through the midplane and out the configured physical interface and into the network (step 2b above).
3. The response to the traffic arrives from the destination (step 3 above) and is sent back to NPU and then SessMgr. SessMgr then inspects the traffic (if configured) and then sends it back to NPU and ultimately out to the network and the UE (step 4 above).

System Verification

System Verification and Troubleshooting Overview

Overview

This chapter outlines the commands that can be executed to ensure the ASR 5000/5500 chassis is in a healthy state or identify and troubleshoot existing issues. This procedure addresses the need for a “generic” system verification process of the ASR 5000/5500 chassis.

Here a few things to keep in mind for this section:

- Any subsection in this chapter can be used individually to troubleshoot the area under investigation.
- Counters can be cleared in order to help understand which values are currently incrementing
- An administrator privilege via CLI is required.
- As a Customer running this procedure, the CLI output can be provided to Cisco in order to review the health of the system.

Prequisites

The following is needed to perform the activities in the ASR 5000/5500 System Verification Check and Troubleshooting chapter:

1. ASR 5x00 Chassis with Console or IP connectivity into the chassis.
2. Administrator level Username and Password access to the chassis.
3. Enable timestamps (the CLI command '**timestamps**' will enable this).
4. Confirm session is logged.
5. Access to Cisco ASR 5x00 Documentation:
    - http://www.cisco.com/c/en/us/support/wireless/asr-5000-series/products-installation-and-configuration-guides-list.html

Initial Data Collection

Overview

This section covers commands and outputs related to booting, syslogs, alarms, crashes and license.

Commands and Outputs

These steps will allow the User to collect information regarding the system as a reference point.

Note: Make sure CLI session logging has been enabled. (Estimated Time for completion: 15 minutes)

1. Log into the Node using ssh or console

Expected Output:

```
Now Connecting to Network Element: [ RTP-ARES ]
You are now Logged in: [local]RTP-ARES>
```

2. Enter into "Local" Context: **#> `context local`**

Expected Output:

```
[local]RTP-ARES> context local
Tuesday September 16 22:06:01 UTC 2014
[local]RTP-ARES>
```

Verify that the value "**`local`**" is present in the square brackets of the system prompt. If "**`local`**" is not present, then redo step #2.

3. Verify the time and date of the system **#> `show clock`**

Expected Output:

```
[local]RTP-ARES> show clock
Tuesday September 16 22:12:28 UTC 2014
Tuesday September 16 22:12:28 UTC 2014
[local]RTP-ARES>
```

If the clock of the system does not match the expected value, please refer to the ASR 5x00 documentation referenced in the "System Verification and Troubleshooting Overview" chapter.

4. Verify the StarOS version that is currently being run by the chassis: **#> show version**

```
[local]RTP-ARES> show version
Wednesday September 17 20:00:36 UTC 2014
Active Software:
  Image Version:                  ww.x.y.zzzzz
  Image Build Number:             zzzzz
  Image Description:              NonDeployment_Build
  Image Date:                     Thu Aug 28 20:11:02 EDT 2014
  Boot Image:                     /flash/asr5500-16.2.0.56515.bin
```

Verify the system is running the expected software image version and build number.

5. Verify the system uptime of the chassis: **#> show system uptime**

Expected Output:

```
[local]RTP-ARES> show system uptime
Wednesday September 17 20:03:29 UTC 2014
System uptime: 14D 20H 36M
```

Make note of the length of time the system has been running. An unexpected value may need to be investigated further.

6. Verify the system for configuration errors : **#> show configuration errors**

Expected Output:

```
[local]RTP-ARES> show configuration errors
 ##########################################
#                   Displaying Diameter Configuration errors
###############################################################################
Total 0 error(s) in this section !
 ###############################################################################
#                   Displaying Active-charging system errors
###############################################################################
Total 0 error(s) in this section !
 ###############################################################################
#                   Displaying IMSA-configuration errors
###############################################################################
Error   : Invalid primary host/realm configuration under endpoint : DCCA-PCRF for
imsa service : IMSA dpca. Host : minid-simulator Realm :  combination
not available in diameter configuration.
 Total 1 error(s) in this section !
```

Verify the system configuration and fix reported configuration mistakes to avoid possible problems on the system.

7. Verify the system's boot configuration: **`#> show boot`**

Expected Output:

```
[local]RTP-ARES> show boot
Wednesday September 17 20:08:24 UTC 2014

boot system priority 75 \
    image /flash/asr5500-16.2.0.56515.bin \
    config /flash/RTP-ARES-PGW_MTU-Def_20140911.cfg

boot system priority 76 \
    image /flash/asr5500-16.2.0.56515.bin \
    config /flash/RTP-ARES-PGW_E911-PCSCF-CNG_20140903.cfg

boot system priority 77 \
```

```
    image /flash/asr5500-16.2.0.56515.bin \
    config /flash/New-16.2-Sep2nd2014.cfg

boot system priority 78 \
    image /flash/asr5500-16.1.2.bin \
    config /flash/RTP-ARES-PGW_E911-PCSCF_20140819.cfg
 boot system priority 79 \
    image /flash/asr5500-16.1.2.bin \
    config /flash/RTP-ARES-PGW_20140819.cfg

boot system priority 80 \
    image /flash/asr5500-16.1.2.bin \
    config /flash/RTP-ARES-PGW_20140807.cfg

boot system priority 81 \
    image /flash/asr5500-16.1.2.bin \
    config /flash/RTP-ARES-PGW.cfg
```

The output of this command can have up to 10 entries and the specified files must be present in the "`/flash/`" drive of the ASR 5x00 chassis. The lowest priority is booted first. If the configuration file specified is not valid (misspelled or not present in the /flash directory) and the chassis is reloaded, the system will go into a continuous boot cycle.

The system will only move on to the next boot priority if the StarOS BIN file is corrupted or not found.

To determine if the files are present, issue the following command, must be logged in as an admin with this command:

```
# dir /flash/ | grep -i <Filename of image or config>
```

If the file is not present, the boot priority must be reconfigured. Contact Cisco if not familiar with this process.

8. Verify which configuration file the system booted with the last time the chassis was loaded:
`#> show boot initial-config`

Expected Output:

Verify that the system was loaded with the proper boot configuration file:

```
[local]RTP-ARES> show boot initial-config
Sunday December 14 17:16:13 UTC 2014
Initial (boot time) configuration:
  image /flash/production.56980.asr5500.bin
  config /flash/RPT-PNC-11-07-2014-16.2.cfg
  priority 86
```

Important:

- If the system configuration was recently saved, but the chassis was not reloaded, the output of "show boot initial-config" and the lowest value of "show boot" may not match.
- If after a reboot, the "show boot" and "show boot initial-config" do not match, this will need to be investigated further.

9. Display the installed Licenses: **#> `show license information`**

Expected Output:

Verify that the License Key has been installed:

```
[local]RTP-ARES> show license information
Thursday September 18 19:05:02 UTC 2014
Key Information (installed key):
  Comment       RTP-ARES (and ICSR)
  Chassis SN    SAD19971008RV
  Issued        Wednesday July 16 12:51:20 UTC 2014
  Expires       Friday January 16 12:51:20 UTC 2015
  Issued By     Cisco Systems
  Key Number    007
Enabled Features:
   Feature                                          Applicable Part Numbers
  ------------------------------------------------  ------------------------------
GGSN:                                          [ ASR5K-00-GN10SESS / ASR5K-00-GN01SESS ] +
```

```
DHCP
                                          [ ASR5K-00-CSXXDHCP ]
 IPv4 Routing Protocols                        [ none ]
   Enhanced Charging Bundle 2:                  [ ASR5K-00-CS01ECG2 ]
   + DIAMETER Closed-Loop Charging Interfac     [ ASR5K-00-CSXXDCLI ]
   + Enhanced Charging Bundle 1                 [ ASR5K-00-CS01ECG1 ]
  IPSec                                         [ ASR5K-00-CS01I-K9 / ASR5K-00-CS10I-K9 ]
  Session Recovery                              [ ASR5K-00-PN01REC / ASR5K-00-HA01REC
                                                  ASR5K-00-00000000 / ASR5K-00-GN01REC
                                                  ASR5K-00-SN01REC / ASR5K-00-AN01REC
                                                  ASR5K-00-IS10PXY / ASR5K-00-IS01PXY
                                                  ASR5K-00-HWXXSREC / ASR5K-00-PW01REC
                                                  ASR5K-05-PHXXSREC / ASR5K-00-SY01R-K9
                                                  ASR5K-00-IG01REC / ASR5K-00-PC10SR
                                                  ASR5K-00-EG01SR / ASR5K-00-FY01SR
                                                  ASR5K-00-CS01LASR / ASR5K-00-FY01USR
                                                  ASR5K-00-EW01SR / ASR5K-00-SM01SR
                                                  ASR5K-00-S301SR ]
  IPv6                                           [ N/A / N/A ]
  Lawful Intercept                               [ ASR5K-00-CSXXLI ]
  Inter-Chassis Session Recovery                 [ ASR5K-00-HA10GEOR / ASR5K-00-HA01GEOR
                                                  ASR5K-00-GN10ICSR / ASR5K-00-GN01ICSR
                                                  ASR5K-00-PW01ICSR / ASR5K-00-IGXXICSR
                                                  ASR5K-00-PC10GR / ASR5K-00-SW01ICSR
                                                  ASR5K-00-SG01ICSR ]
  RADIUS AAA Server Groups                      [ ASR5K-00-CSXXAAA ]
  Intelligent Traffic Control:                  [ ASR5K-00-CS01ITC ]
   + Dynamic Radius extensions (CoA and PoD)    [ ASR5K-00-CSXXDYNR ]
   + Per-Subscriber Traffic Policing/Shapin     [ ASR5K-00-CSXXTRPS ]
  Enhanced Lawful Intercept                     [ ASR5K-00-CS01ELI / ASR5K-00-CS10ELI ]
  Dynamic Policy Interface:                     [ ASR5K-00-CS01PIF ]
   + DIAMETER Closed-Loop Charging Interface    [ ASR5K-00-CSXXDCLI ]
  PGW                                           [ ASR5K-00-PW10GTWY / ASR5K-00-PW01LIC ]
  NAT/PAT with DPI                              [ ASR5K-00-CS01NAT ]
  NAT Bypass                                    [ ASR5K-02-CS01NATB ]
  Local Policy Decision Engine                  [ ASR5K-00-PWXXDEC ]
```

```
Session Limits:
               Sessions  Session Type
               --------  -----------------------
                  10000  GGSN
                  11000  ECS
                  10000  PGW

CARD License Counts:
 [none]
Status:
 Chassis MEC SN         Matches
 License Status         Good
```

If the output is not displayed as expected, please contact Cisco to investigate further or reference the "Licensing" section in "Platform Troubleshooting".

10. Verify the Contexts that are configured on the system: **#> show context**

Expected Output:

```
[local]RTP-ARES# show context
Wednesday September 17 20:16:52 UTC 2014
Context Name    ContextID    State     Description
--------------- --------- ----------   ----------------------
local           1            Active
PGWin           2            Active
PGWout          3            Active
SRP             4            Active
ECS             5            Active
```

Verify that all expected Contexts are present and in an "**Active**" state.

11. Verify all tasks on the chassis are in a "good" state: **#> show task resources | grep -v good**

Expected Output:

```
[local]RTP-ARES# show task resources | grep -v good
Wednesday September 17 21:38:25 UTC 2014
                    task    cputime        memory     files      sessions
 cpu facility      inst used allc   used  alloc used allc  used  allc S status
---------------------- --------- ------------- --------- ------------- ------
Total                  700 369.37%   76.87G        20308       233
```

If any process is reported in a "`Warn`" or "`Over`" state, monitor the process to see if it clears after a short period (~15 minutes). If the process continues to stay in the "`Warn`" or "`Over`" or continuously goes in and out of that state, escalate to Cisco to assist in diagnosing the cause.

The above output is an example of a chassis with no issues.

12. Review all Events present on the chassis: **`#> show logs`**

Expected Output:

```
 [local]RTP-ARES> show logs
  Friday September 19 11:17:53 UTC 2014
  2014-Sep-19+11:17:49.597 [snmp 22002 info] [5/0/4687 <cli:5004687> trap_api.c:930] [software
internal system
 syslog] Internal trap notification 52 (CLISessStart) user vendgrp privilege level Operator
ttyname /dev/pts/3
  2014-Sep-19+10:12:42.015 [snmp 22002 info] [5/0/10563 <cli:5010563> trap_api.c:930] [software
internal system
 syslog] Internal trap notification 52 (CLISessStart) user emslogin privilege level Security
Administrator
 ttyname /dev/pts/1
  2014-Sep-19+10:06:31.518 [snmp 22002 info] [5/0/5972 <sitmain:50> trap_api.c:930] [software
internal system
  syslog] Internal trap notification 53 (CLISessEnd) user emslogin privilege level Security
Administrator
 ttyname /dev/pts/1
  2014-Sep-19+09:54:52.061 [snmp 22020 error] [5/0/7431 <snmp:0> snmp_star_api.c:10218]
[software internal system
  syslog] MISC ERROR: Failed to insert data[rc=status] rc=1
```

```
  2014-Sep-19+09:51:04.670 [snmp 22020 error] [5/0/7431 <snmp:0> snmp_star_api.c:10218]
[software internal system
  syslog] MISC ERROR: Failed to insert data[rc=status] rc=1
  2014-Sep-19+08:20:52.565 [snmp 22020 error] [5/0/7431 <snmp:0> snmp_star_api.c:10218]
[software internal system
  syslog] MISC ERROR: Failed to insert data[rc=status] rc=1
```

The output of this command is listed from Newest to Oldest. The parameter "| more" can be added to the end of the command to display the output page by page.

When reviewing this output, it is important to be familiar with the system.

13. Review all recent SNMP traps present on the chassis: **#> show snmp traps history verbose**

Expected Output:

```
 [local]RTP-ARES> show snmp trap history verbose
 Friday September 19 11:21:06 UTC 2014
  There are 2241 historical trap records (5000 maximum)

 Timestamp                Trap Information
 ------------------------ ------------------------------------------------------
 Tue Sep 02 23:28:15 2014 Internal trap notification 55 (CardActive) card 14 type Fabric &
2x200GB Storage Card
 Tue Sep 02 23:28:22 2014 Internal trap notification 55 (CardActive) card 17 type Fabric &
2x200GB Storage Card
 Tue Sep 02 23:28:22 2014 Internal trap notification 55 (CardActive) card 15 type Fabric &
2x200GB Storage Card
```

The output of this command is listed from Oldest to Newest. The parameter "`| more`" can be added to the end of the command to display the output page by page.

When reviewing this output, it is important to be familiar with the system.

14. Determine if there are any active alarms on the system:**#> show alarm outstanding verbose**

Expected Output:

```
[local]RTP-ARES> show alarm outstanding verbose
Wednesday May 06 15:20:51 UTC 2015
Severity Object          Timestamp                          Alarm ID
-------- ----------      ---------------------------------- --------------------
Alarm Details
-------------------------------------------------------------------------------
Minor    Port 6/1        Friday May 01 02:55:53 UTC         3610742596960845824
Port link down
Minor    Port 6/10       Friday May 01 02:56:08 UTC         3610742596961828864
Port link down
Minor    Port 6/29       Friday May 01 02:56:12 UTC         3610742596962091008
Port link down
Minor    Port 5/29       Friday May 01 02:56:12 UTC         3610742596962091009
Port link down
```

If there are any alarms present, investigation should begin to understand why they are occurring.

15. Review crashes that have occurred on the system: **#> show crash list**
To view an individual crash: **#> show crash number <Number of crash from listing>**

Expected Output:

```
[local]RTP-ASR5K> show crash list
Tuesday October 21 11:28:12 UTC 2014
==          ====          ========  ========== ============ ================
#           Time          Process    Card/CPU/      SW          HW_SER_NUM
                                        PID       VERSION    SMC / Crash Card
==          ====          ========  ========== ============ ================
1  2012-Aug-09+01:38:13 sessmgr  14/0/04578 12.2(41915) PLB63199258/PLB327134123
2  2012-Sep-17+19:13:39 sessmgr  14/0/03962 12.2(41915) PLB63123258/PLB327103434
3  2012-Sep-14+00:08:34 sessmgr  10/0/19098 12.2(41915) PLB63162258/PLB422124432
4  2012-Sep-12+23:40:05 sessmgr  16/0/03782 12.2(41915) PLB63124558/SAD125125663
5  2014-Apr-11+18:02:52 sessmgr  05/0/23697 15.0(53417) PLB66123451/PLB328143264

Total Crashes : 37
```

The system should not have any recent software or hardware crashes. Refer to the "Software Crashes" section in the "Platform Troubleshooting" chapter for further information.

16. Verify no unplanned card switchovers or migrations have occurred on the chassis: **#> `show rct stats`**

Expected Output:

```
[local]RTP-ASR5K> show rct stats
Tuesday October 21 11:31:35 UTC 2014

RCT stats Details (Last 1 Actions)
Action             Type       From To   Start Time                 Duration
------------------ ---------- ---- ---- -------------------------  ----------
Switchover         Planned      9    8  2014-Oct-20+05:57:11.883  42.337 sec

RCT stats Summary
-----------------
Migrations  =      0
Switchovers =      1,  Average time = 42.337 sec
```

The system should not have any recent unexplained card migrations. Refer to the "Platform Troubleshooting" section for further information what can be checked.

Hardware

Overview

This section presents the commands available to check hardware health of ASR 5000 / ASR 5500

Commands and Outputs

These steps will allow the User to collect information regarding the HW health of the system.

Note: Make sure CLI session logging has been enabled.

Estimated Time for completion: 15 minutes

1. Verify the hardware inventory of the system: **#> show hardware inventory**

Expected Output:

```
[local]RTP-ARES> show hardware inventory
Thursday September 18 10:50:42 UTC 2014
Slot Type        Part Number  Product ID / Version ID   Serial Num   CLEI code
---- ----  -----------------  ----------------------  -----------  ----------
 1:  None                --                  --   --           --          --
 2:   DPC     73-15415-01 C0        ASR55-DPC-K9  V05  SAA172200LN          --
      CCK     73-15573-01 B0                  --   --  SAA172000VX          --
 3:   DPC     73-15415-01 C0        ASR55-DPC-K9  V05  SAA172300GW          --
      CCK     73-15573-01 B0                  --   --  SAA1723009S          --
 4:   DPC     73-14872-03 C0        ASR55-DPC-K9  V05  SAA1609014R          --
      CCK     73-15573-01 B0                  --   --  SAA172700NY          --
 5:   MIO     73-14853-03 B0   ASR55-MIO-10GS2K9  V06  SAA154401ZH          --
      XDC     73-14547-01 B0                  --   --  SAA1544010F          --
      XDC     73-14547-01 B0                  --   --  SAA1544010V          --
      MEC     73-14501-01 A0           ASR55-MEC  V01  SAA151000RV          --
     MIDP     73-14232-01 A0                  --   --  TBA15338867          --
     CHAS     73-14344-01 A0       ASR55-CHS-SYS  V01  FLT153800EL          --
 6:   MIO     73-14853-03 B0   ASR55-MIO-10GS2K9  V06  SAA154300D9          --
```

```
      XDC     73-14547-01 B0                  --   --  SAA15440115          --
      XDC     73-14547-01 B0                  --   --  SAA15440109          --
      MEC     73-14501-01 A0           ASR55-MEC  V01  SAA151000RV          --
     MIDP     73-14232-01 A0                  --   --  TBA15338867          --
     CHAS     73-14344-01 A0       ASR55-CHS-SYS  V01  FLA153800EL          --
 7:   DPC     73-15415-01 C0        ASR55-DPC-K9  V05  SAA173300FF          --
      CCK     73-15573-01 B0                  --   --  SAA1733005K          --
 8:   DPC     73-14872-03 C0        ASR55-DPC-K9  V05  SAA155102SS          --
      CCK     73-15573-01 B0                  --   --  KLL1735000M          --
 9:  None                 --                  --   --           --          --
10:  None                 --                  --   --           --          --
11:   SSC     73-14235-01 B0           ASR55-SSC  V01  SAA154102EX          --
12:   SSC     73-14235-01 B0           ASR55-SSC  V01  PAL154102EZ          --
13:  None                 --                  --   --           --          --
14:   FSC     73-14236-01 B0           ASR55-FSC  V01  KNL154103J8          --
15:   FSC     73-14236-01 B0           ASR55-FSC  V01  SAA154103H2          --
16:   FSC     73-14236-01 B0           ASR55-FSC  V01  SAA15400083          --
17:   FSC     73-14236-01 B0           ASR55-FSC  V01  SAA1540008B          --
..
Fan Tray           Part Number  Product ID / Version ID   Serial Num   CLEI code
-----------  -----------------  ----------------------  -----------  ----------
Lower Rear      73-14279-01 A0        ASR55-FANT-R  V01  FLM1542000D          --
Lower Front     73-14278-01 A0        ASR55-FANT-F  V01  FLM1542000M          --
Upper Rear      73-14279-01 A0        ASR55-FANT-R  V01  FLM15420002          --
Upper Front     73-14278-01 A0        ASR55-FANT-F  V01  FLM1542000R          --
```

This command is used to get a listing of all hardware types, Part Numbers and Serial Numbers of the cards populated in the chassis.

2. Verify the status of cards in the system:

- ASR 5000: **#> show card table all**
- ASR 5500:**#> show card table**

Expected Output:

ASR 5000:

```
[local]RTP-ASR5K> show card table all
Wednesday September 17 22:30:24 UTC 2014
Slot         Card Type                            Oper State     SPOF  Attach
-----------  -----------------------------------  -------------  ----  ------
 1: PSC      None                                 -              -       -  -
 2: PSC      Packet Services Card 2               Active         No     18  -
..
 8: SMC      System Management Card               Active         No     24 25
 9: SMC      System Management Card               Standby        No      -  -
..
17: LC       None                                 -              -       -
18: LC       1000 Ethernet Line Card              Active         Yes     2
19: LC       10 Gig Ethernet Line Card            Active         Yes     3
..
24: SPIO     Switch Processor I/O Card            Active         No      8
25: SPIO     Switch Processor I/O Card            Standby        -       8
26: LC       None                                 -              -       -..
40: RCC      Redundancy Crossbar Card             Active         No
41: RCC      Redundancy Crossbar Card             Active         No
..
48: LC       None                                 -              -       -
```

ASR 5500:

```
[local]RTP-ARES# show card table
Wednesday September 17 21:21:14 UTC 2014
Slot         Card Type                            Oper State     SPOF  Attach
-----------  -----------------------------------  -------------  ----  ------
 1: DPC      None                                 -              -
 2: DPC      Data Processing Card                 Active         No
 3: DPC      Data Processing Card                 Active         No
 4: DPC      Data Processing Card                 Active         No
 5: MMIO     Management & 20x10Gb I/O Card        Active         No
 6: MMIO     Management & 20x10Gb I/O Card        Standby        -
```

```
 7: DPC      Data Processing Card                  Active         No
 8: DPC      Data Processing Card                  Standby        -
 9: DPC      None                                  -              -
10: DPC      None                                  -              -
11: SSC      System Status Card                    Active         No
12: SSC      System Status Card                    Active         No
13: FSC      None                                  -              -
14: FSC      Fabric & 2x200GB Storage Card         Active         No
15: FSC      Fabric & 2x200GB Storage Card         Active         No
16: FSC      Fabric & 2x200GB Storage Card         Active         No
17: FSC      Fabric & 2x200GB Storage Card         Active         No
18: FSC      None                                  -              -
```

All cards should either be in an "`Active`" or "`Standby`" state. The SPOF column should not have any value other than "`No`" or a "`-`".

"**`Oper State`**" displays the operational state of the card. The possible operational states are:

- **`Active`:** Indicates that the card is an active component and is providing services.
- **`Standby`:** Indicates that the card is a redundant component. Redundant components will become active through manual configuration or automatically should a failure occur.
- **`Offline`:** Indicates that the card is installed but is not ready to process subscriber data sessions. This could be due to the fact that it is not completely installed (such as, the card interlock switch is not locked). Refer to the Installation Guide for additional information.

"**`SPOF`**" displays whether or not the component is a single point of failure (SPOF) in the system. If the component is a SPOF, then a "**`Yes"`** will appear in this column. If not, a "**`No"`** will be displayed.

The only exception to this rule are XGLC cards that perform Layer 3 Active/Active redudancy, which could trigger SPOF only for these type of cards because a card pair might not be in the proper slots that are predefined for default hardware redundancy (for example, for HW redundancy Active/Standby, two XGLC in slots 17 and 18 are needed, but if Layer 3 Active/Active redundancy is used, XGLC cards can exist in any slots between 17-23 to 26-32 but they will trigger SPOF in that case).

Escalate to Cisco when any card is in an unexpected state.

3. Display the output of each card with detailed information: **#> show card info** or to perform the command on one card: **#> show card info <Card Number>**

Expected Output:

ASR 5000:

```
[local]RTP-ASR5K> show card info
Thursday September 18 10:41:05 UTC 2014
Card 1:
  Slot Type                : PSC
  Operational State        : Empty
  Desired Mode             : Standby
  Last State Change        : Wednesday September 03 00:55:54 UTC 2014
  Card Standby Priority    : 14th
  Administrative State     : Enabled
Card 2:
  Slot Type                : PSC
  Card Type                : Packet Services Card 2
  Operational State        : Active
  Desired Mode             : Active
  Last State Change        : Wednesday September 03 00:59:16 UTC 2014
  Card Standby Priority    : 13th
  Administrative State     : Enabled
  Card Lock                : Locked
  Halt Issued              : No
  Reboot Pending           : No
  Upgrade In Progress      : No
  Session Busy-Out         : Disabled
  Card Usable              : Yes
  Single Point of Failure  : No
  Attachment               : 18 (1000 Ethernet Line Card)
  Attachment               : Unconnected
  Temperature              : 54 C (limit 101 C)
  Voltages                 : Good
  Card LEDs                : Run/Fail: Green | Active: Green | Standby: Off
  CPU 0                    : Diags/Kernel Running, Tasks Running
  CPU 1                    : Diags/Kernel Running, Tasks Running
```

Review the card output in the ASR 5000: all cards configured in the system should be in the expected state of Active or Standby. Escalate any unexpected output to Cisco to investigate further.

ASR 5500:

```
[local]RTP-ARES> show card info
Thursday September 18 10:30:44 UTC 2014
Card 1:
  Slot Type                : DPC
  Operational State        : Empty
  Desired Mode             : Standby
  Last State Change        : Tuesday September 02 23:27:09 UTC 2014
  Administrative State     : Enabled
..
Card 2:
  Slot Type                : DPC
  Card Type                : Data Processing Card
  Daughter Cards           : DC3
  Operational State        : Active
  Desired Mode             : Active
  Last State Change        : Tuesday September 02 23:30:52 UTC 2014
  Administrative State     : Enabled
  Card Lock                : Locked
  Halt Issued              : No
  Reboot Pending           : No
  Upgrade In Progress      : No
  Session Busy-Out         : Disabled
  Card Usable              : Yes
  Single Point of Failure  : No
  Temperature              : Normal
  Voltages                 : Good
  Card LEDs                : Run/Fail: Green | Active: Green | Redundant: Green
  CPU 0                    : Diags/Kernel Running, Tasks Running
    Error ID Log           : None
    Boot Progress Log      : None
  CPU 1                    : Diags/Kernel Running, Tasks Running
    Error ID Log           : None
    Boot Progress Log      : None
```

Review the card output in the ASR 5500. All cards configured in the system should be in the expected state of Active or Standby. Escalate any unexpected output to Cisco to investigate further.

3. Display the output of each card with detailed information: **#> show card diag** or to perform the command on one card **#> show card diag <Card Number>**

Expected Output:

ASR 5000:

```
[local]APXNC-ASR5K> show card diag
Tuesday October 21 11:19:22 UTC 2014
Card 1:
  Counters:
    Successful Warm Boots : 0
    Successful Cold Boots : 2
      (last at Friday October 10 06:18:28 UTC 2014)
    Total Boot Attempts   : 0
    In Service Date       : Mon Jul 14 06:18:54 2014 (Estimated)
  Status:
    IDEEPROM Magic Number : Good
    Boot Mode             : Normal
    Card Diagnostics      : Pass
    Current Failure       : None
    Last Failure          : None
    Card Usable           : Yes
  Current Environment:
    Temperature: Card     : 50 C (limit 101 C)
    Temperature: LM94     : 35 C (limit 101 C)
    Temperature: NPU      : 71 C (limit 115 C)
    Temperature: NPU PCB  : 56 C (limit 101 C)
    Temperature: DT       : 50 C (limit 101 C)
    Temperature: Midplane : 34 C (limit 101 C)
    Temperature: CPU-N0   : 39 C (limit 101 C)
    Temperature: CPU-N1   : 37 C (limit 101 C)
    Temperature: IOH      : 62 C (limit 110 C)
    Temperature: DDR-N0C0 : 38 C (limit 100 C)
    Temperature: DDR-N0C1 : 38 C (limit 100 C)
```

```
    Temperature: DDR-N1C0 : 31 C (limit 100 C)
    Temperature: DDR-N1C1 : 31 C (limit 100 C)
    Voltage: 12V          : 12.188 V (min 10.939 V, max 13.102 V)
    Voltage: CPU0VTT      : 1.092 V (min 0.993 V, max 1.281 V)
    Voltage: CPU1VTT      : 1.096 V (min 0.993 V, max 1.281 V)
    Voltage: 1.3V NPU     : 1.275 V (min 1.235 V, max 1.365 V)
    Voltage: 1.8V         : 1.765 V (min 1.709 V, max 1.890 V)
    Voltage: 1.5V         : 1.468 V (min 1.426 V, max 1.576 V)
    Voltage: CPU1VCC      : 0.925 V (min 0.712 V, max 1.418 V)
    Voltage: 3.3V         : 3.285 V (min 3.148 V, max 3.478 V)
    Voltage: 5V           : 4.914 V (min 4.776 V, max 5.220 V)
    Voltage: 2.5V         : 2.457 V (min 2.371 V, max 2.634 V)
    Voltage: 7.5V         : 7.351 V (min 7.125 V, max 7.875 V)
    Voltage: 1.53V DDR0   : 1.523 V (min 1.454 V, max 1.607 V)
    Voltage: 1.53V DDR1   : 1.515 V (min 1.454 V, max 1.607 V)
    Voltage: 1.1V IOH     : 1.101 V (min 1.045 V, max 1.155 V)
    Voltage: 3.3V STANDBY : 3.302 V (min 3.130 V, max 3.458 V)
```

Review the card output in the ASR 5000. Any unexpected outputs should be investigated.

ASR 5500:

```
[local]RTP-ARES> show card diag
Tuesday October 21 11:14:54 UTC 2014
Card 1:
  Counters:
    Successful Warm Boots : 1
      (last at Friday February 21 08:40:04 UTC 2014)
    Successful Cold Boots : 8
      (last at Friday August 29 04:14:48 UTC 2014)
    Total Boot Attempts   : 15
    In Service Date       : Thu Sep 05 05:42:35 2013 (Estimated)
  Status:
    IDEEPROM Magic Number : Good
    Boot Mode             : Normal
    Card Diagnostics      : Pass
    Current Failure       : None
    Last Failure          : None
    Card Usable           : Yes
```

```
  Last Reset Cause CPU 0: PRT Reset, ICH PLT Reset, ITP Reset
  Last Reset Cause CPU 1: PRT Reset, ICH PLT Reset, ITP Reset
Current Environment:
  Temp: CPU0 DDR-N0C0D0 : 35.00 C (limit 95.00 C)
  Temp: CPU0 DDR-N0C1D0 : 35.00 C (limit 95.00 C)
  Temp: CPU0 DDR-N0C2D0 : 35.00 C (limit 95.00 C)
  Temp: CPU0 DDR-N1C0D0 : 33.00 C (limit 95.00 C)
  Temp: CPU0 DDR-N1C1D0 : 33.00 C (limit 95.00 C)
  Temp: CPU0 DDR-N1C2D0 : 33.00 C (limit 95.00 C)
  Temp: CPU0 CPU-N0C0   : 32.00 C (limit 95.00 C)
  Temp: CPU0 CPU-N0C1   : 27.00 C (limit 95.00 C)
  Temp: CPU0 CPU-N0C2   : 24.00 C (limit 95.00 C)
  Temp: CPU0 CPU-N0C3   : 29.00 C (limit 95.00 C)
  Temp: CPU0 CPU-N0C4   : 34.00 C (limit 95.00 C)
  Temp: CPU0 CPU-N0C5   : 29.00 C (limit 95.00 C)
  Temp: CPU0 CPU-N1C0   : 35.00 C (limit 95.00 C)
  Temp: CPU0 CPU-N1C1   : 29.00 C (limit 95.00 C)
  Temp: CPU0 CPU-N1C2   : 29.00 C (limit 95.00 C)
  Temp: CPU0 CPU-N1C3   : 28.00 C (limit 95.00 C)
  Temp: CPU0 CPU-N1C4   : 35.00 C (limit 95.00 C)
  Temp: CPU0 CPU-N1C5   : 31.00 C (limit 95.00 C)
  Temp: CPU0 IOH        : 55.50 C (limit 110.00 C)
  Temp: NP4 #0          : 62.00 C (limit 115.00 C)
  Temp: CPU1 DDR-N0C0D0 : 33.00 C (limit 95.00 C)
  Temp: CPU1 DDR-N0C1D0 : 32.00 C (limit 95.00 C)
  Temp: CPU1 DDR-N0C2D0 : 31.00 C (limit 95.00 C)
  Temp: CPU1 DDR-N1C0D0 : 34.00 C (limit 95.00 C)
  Temp: CPU1 DDR-N1C1D0 : 34.00 C (limit 95.00 C)
  Temp: CPU1 DDR-N1C2D0 : 34.00 C (limit 95.00 C)
  Temp: CPU1 CPU-N0C0   : 36.00 C (limit 95.00 C)
  Temp: CPU1 CPU-N0C1   : 33.00 C (limit 95.00 C)
  Temp: CPU1 CPU-N0C2   : 29.00 C (limit 95.00 C)
  Temp: CPU1 CPU-N0C3   : 30.00 C (limit 95.00 C)
  Temp: CPU1 CPU-N0C4   : 31.00 C (limit 95.00 C)
  Temp: CPU1 CPU-N0C5   : 33.00 C (limit 95.00 C)
  Temp: CPU1 CPU-N1C0   : 32.00 C (limit 95.00 C)
  Temp: CPU1 CPU-N1C1   : 28.00 C (limit 95.00 C)
  Temp: CPU1 CPU-N1C2   : 28.00 C (limit 95.00 C)
  Temp: CPU1 CPU-N1C3   : 33.00 C (limit 95.00 C)
```

```
Temp: CPU1 CPU-N1C4   : 31.00 C (limit 95.00 C)
Temp: CPU1 CPU-N1C5   : 32.00 C (limit 95.00 C)
Temp: CPU1 IOH        : 59.00 C (limit 110.00 C)
Temp: NP4 #1          : 57.00 C (limit 115.00 C)
Temp: LM94 D0         : 35.50 C
Temp: LM94 D1         : 34.50 C
Temp: Petra0          : 56.00 C (limit 100.00 C)
Temp: Petra1          : 53.00 C (limit 100.00 C)
Temp: Upper-right     : 45.00 C (limit 95.00 C)
Temp: DDF1            : 60.00 C (limit 85.00 C)
Temp: DDF2            : 55.00 C (limit 85.00 C)
Temp: Mid-left        : 41.00 C (limit 95.00 C)
Temp: Center          : 46.00 C (limit 85.00 C)
Temp: Top Center      : 54.00 C (limit 95.00 C)
Temp: F600 #1         : 39.86 C
Temp: F600 #2         : 29.45 C
Voltage: 12V-A        : 12.035 V
Voltage: 1.0V NPU1    : 1.052 V (min 0.950 V, max 1.102 V)
Voltage: 0.9V DDF1    : 0.893 V (min 0.855 V, max 0.945 V)
Voltage: 1.8V         : 1.790 V (min 1.700 V, max 1.900 V)
Voltage: CPU0/0 1.53V : 1.366 V (min 1.282 V, max 1.606 V)
Voltage: CPU0/1 1.53V : 1.366 V (min 1.282 V, max 1.606 V)
Voltage: CPU0/0 VCC   : 0.906 V (min 0.712 V, max 1.417 V)
Voltage: CPU0/1 VCC   : 0.943 V (min 0.712 V, max 1.417 V)
Voltage: 3.3V         : 3.283 V (min 3.140 V, max 3.470 V)
Voltage: 5V           : 4.999 V (min 4.750 V, max 5.250 V)
Voltage: 2.5V         : 2.473 V (min 2.380 V, max 2.630 V)
Voltage: 1.5V         : 1.476 V (min 1.430 V, max 1.580 V)
Voltage: CPU0/0 VTT   : 1.085 V (min 0.992 V, max 1.281 V)
Voltage: CPU0/1 VTT   : 1.085 V (min 0.992 V, max 1.281 V)
Voltage: CPU0 1.1V IO : 1.101 V (min 1.045 V, max 1.155 V)
Voltage: 3.3V Stdby   : 3.319 V (min 2.970 V, max 3.630 V)
Voltage: 12V-B        : 12.097 V
Voltage: 1.05V Petra  : 1.048 V (min 0.997 V, max 1.102 V)
Voltage: 1.0V CC      : 1.009 V (min 0.950 V, max 1.050 V)
Voltage: 1.2V         : 1.193 V (min 1.140 V, max 1.260 V)
Voltage: CPU1/0 1.53V : 1.366 V (min 1.282 V, max 1.606 V)
Voltage: CPU1/0 1.53V : 1.366 V (min 1.282 V, max 1.606 V)
Voltage: CPU1/0 VCC   : 0.918 V (min 0.712 V, max 1.417 V)
```

```
    Voltage: CPU1/1 VCC   : 0.993 V (min 0.712 V, max 1.417 V)
    Voltage: 7.5V         : 7.579 V (min 7.130 V, max 7.880 V)
    Voltage: 5V           : 4.921 V (min 4.750 V, max 5.250 V)
    Voltage: 12V-C        : 11.812 V
    Voltage: 1.5V Petra   : 1.476 V (min 1.430 V, max 1.580 V)
    Voltage: CPU1/0 VTT   : 1.085 V (min 0.992 V, max 1.281 V)
    Voltage: CPU1/1 VTT   : 1.085 V (min 0.992 V, max 1.281 V)
    Voltage: CPU1 1.1V IO : 1.096 V (min 1.045 V, max 1.155 V)
    Voltage: 3.3V Stdby   : 3.336 V (min 2.970 V, max 3.630 V)
    Voltage: 48V-A        : 50.150 V
    Voltage: 48V-B        : 51.150 V
    Current: 48V-A        : 3.82 A
    Current: 48V-B        : 5.26 A
    Airflow: Middle Right : 293 FPM
    Airflow: Middle Left  : 254 FPM
```

Review the card output in the ASR 5500. Any unexpected outputs should be investigated.

4. Verify the status of all card programmables: **`#> show card hardware`**

Expected Output:

ASR 5000:

```
[local]RTP-ASR5K> show card hardware
Thursday May 07 18:34:38 UTC 2015
Card 2:
  Card Type               : Packet Services Card 2 (R02)
  Description             : PSC2
  Starent Part Number     : 530-60-1055 04
  Starent Serial Num      : PLB40101
  Starent CLEI Code       : CRCCACUDAA  Switch Fabric Modes     : control plane, switch fabric
  Card Programmables      : up to date
  NPU Microcode           : running 1.0
  Slave SCB               : on-card 1.6
  PSR2                    : on-card 0
  BIOS                    : on-card-a 1.1.10, on-card-b 0.2.0
  DT2 FPGA                : running 3.27
```

```
  CPU 0 Type/Memory       : Socket 0: Xeon L5518 D0, 2130 MHz
                          : Socket 1: Xeon L5518 D0, 2130 MHz
                          : Chipset: 5520-IOH B3, ICH10R A0, 32 GB
  CPU 0 DIMM-N0D0 P/N     : 36JCZS1G72PY-1G1A
  CPU 0 DIMM-N0D1 P/N     : 36JCZS1G72PY-1G1A
  CPU 0 DIMM-N1D0 P/N     : 36JCZS1G72PY-1G1A
  CPU 0 DIMM-N1D1 P/N     : 36JCZS1G72PY-1G1A
  CPU 1 Type/Memory       : IXP2855 A0, 1500 Mhz, 1536 MB
  CPU 0 CFE/Diags         : on-card 2.2.3, running 130.2.9
```

ASR 5500:

```
[local]SLK-ARES> show card hardware
Thursday May 07 18:37:30 UTC 2015
Card 2:
  Card Type               : Data Processing Card (R02)
  Description             : DPC
  Cisco Part Number       : 73-15415-01 C0
  UDI Serial Number       : SAD100897LN
  UDI Product ID          : ASR55-DPC-K9
  UDI Version ID          : V05
  UDI Top Assem Num       : 68-4945-01 C0
  Daughter Card #3:
   Card Type             : DPC CCK Daughter Card (R02)
    Description           : DPC_CRYPTO_DC
    Cisco Part Number     : 73-15573-01 B0
    UDI Serial Number     : SAD100897LN
  Card Programmables      : up to date
  BCF                     : on-card 0.2.7
  CAF                     : on-card 0.0.56
  CPU 0 Type/Memory       : Socket 0: Xeon L5638 B1, 2000 MHz
                          : Socket 1: Xeon L5638 B1, 2000 MHz
                          : Chipset: 5520-IOH C2, ICH10R A0, 96 GB
  CPU 0 DIMM-N0C0D0 P/N   : M392B2G70BM0-YH9
  CPU 0 DIMM-N0C1D0 P/N   : M392B2G70BM0-YH9
  CPU 0 DIMM-N0C2D0 P/N   : M392B2G70BM0-YH9
  CPU 0 DIMM-N1C0D0 P/N   : M392B2G70BM0-YH9
  CPU 0 DIMM-N1C1D0 P/N   : M392B2G70BM0-YH9
  CPU 0 DIMM-N1C2D0 P/N   : M392B2G70BM0-YH9
```

```
CPU 0 BIOS              : on-card-a 1.1.10, on-card-b 1.1.10
CPU 0 i82599            : eeprom-a 0.1.4
CPU 0 i82574            : eeprom-a 0.1.4
CPU 0 CFE               : on-card 3.2.4
CPU 0 DH89XXCC          : on-card 0.3.1
CPU 1 Type/Memory       : Socket 0: Xeon L5638 B1, 2000 MHz
                        : Socket 1: Xeon L5638 B1, 2000 MHz
                        : Chipset: 5520-IOH C2, ICH10R A0, 96 GB
CPU 1 DIMM-N0C0D0 P/N   : M392B2G70BM0-YH9
CPU 1 DIMM-N0C1D0 P/N   : M392B2G70BM0-YH9
CPU 1 DIMM-N0C2D0 P/N   : M392B2G70BM0-YH9
CPU 1 DIMM-N1C0D0 P/N   : M392B2G70BM0-YH9
CPU 1 DIMM-N1C1D0 P/N   : M392B2G70BM0-YH9
CPU 1 DIMM-N1C2D0 P/N   : M392B2G70BM0-YH9
CPU 1 BIOS              : on-card-a 1.1.10, on-card-b 1.1.10
CPU 1 i82599            : eeprom-a 0.1.4
CPU 1 i82574            : eeprom-a 0.1.4
CPU 1 CFE               : on-card 3.2.4
CPU 1 DH89XXCC          : on-card 0.3.1
```

Verify that all cards have "**`up to date`**" in the "**`Card Programmables :`** " field. Escalate the issue to Cisco if any other data is present.

5. Verify the status of all fans: **`#> show fans`**

Expected Output:

ASR 5000:

```
[local]RTP-ASR5K> show fans
Thursday September 18 19:16:57 UTC 2014
Retrieving fan information...
Upper Fan Tray:  State=Normal                    Speed=100 %  Temp=38 C
Lower Fan Tray:  State=Normal                    Speed= 90 %  Temp=29 C
```

ASR 5500:

```
[local]RTP-ARES> show fans
Thursday September 18 19:16:27 UTC 2014
Lower Rear Fan Tray:
  State:       Normal
  Speed:       50%
  Temperature: 29C

Upper Rear Fan Tray:
  State:       Normal
  Speed:       50%
  Temperature: 37C

Lower Front Fan Tray:
  State:       Normal
  Speed:       75%
  Temperature: 27C

Upper Front Fan Tray:
 State:       Normal
  Speed:       75%
  Temperature: 35C
```

Verify the state of the fans are normal and the temperature is within normal operating range. The "`verbose`" parameter can be added to the command for additional details.

6. Verify the temperature of the chassis: **`#> show temperature`**

Expected Output:

ASR 5000:

```
[local]RTP-ASR5K> show temperature
Thursday September 18 19:25:14 UTC 2014
Card  2:   54 C (limit 101 C)
Card  3:   53 C (limit 101 C)
Card  4:   50 C (limit 101 C)
```

```
Card  8:   36 C (limit 101 C)
Card  9:   33 C (limit 101 C)
Card 11:   48 C (limit 101 C)
Card 12:   51 C (limit 101 C)
Card 16:   71 C (limit 101 C)
Card 18:   36 C (limit 85 C)
Card 19:   40 C (limit 90 C)
Card 20:   42 C (limit 90 C)
Card 21:   36 C (limit 85 C)
Card 24:   37 C (limit 85 C)
Card 25:   39 C (limit 85 C)
Card 27:   42 C (limit 90 C)
Card 28:   41 C (limit 90 C)
Card 32:   38 C (limit 85 C)
Card 40:   39 C (limit 85 C)
Card 41:   37 C (limit 85 C)
Fan Upper: 37 C
Fan Lower: 29 C
```

Ensure that all of the temperatures are within normal operating range. Cards that are in the left- or right-most slots will have a higher temperature reading than cards more centrally located in the chassis. The keyword "`verbose`" can be added to the command for more detailed information.

ASR 5500:

```
[local]RTP-ARES> show temperature
Thursday September 18 19:22:47 UTC 2014
Card  1:   Normal
Card  2:   Normal
Card  3:   Normal
Card  4:   Normal
Card  5:   Normal
Card  6:   Normal
Card  7:   Normal
Card  8:   Normal
Card  9:   Normal
Card 10:   Normal
Card 11:   Normal
```

```
Card 12:   Normal
Card 14:   Normal
Card 15:   Normal
Card 16:   Normal
Card 17:   Normal
Fan Lower Rear: 29 C
Fan Upper Rear: 37 C
Fan Lower Front: 27 C
Fan Upper Front: 35
```

Ensure that all cards show a value of "`Normal`". The keyword "verbose" can be added to the command for more detailed information.

7. Verify the HD-RAID status of the chassis: **`#> show hd raid`**

The keyword "verbose" can be added to the command for more detailed information.

Expected Output:

ASR 5000:

```
[local]RTP-ASR5K> show hd raid
Sunday October 19 20:24:27 UTC 2014
HD RAID:
  State                     : Available
  Degraded                  : No
  UUID                      : 384563c9:e1ffcc33:60e3195b:ae25a34a
  Size                      : 146GB
  Action                    : Idle
  Disk                      : hd-local1
    State                   : In-sync component
  Disk                      : hd-remote1
    State                   : In-sync component
```

ASR 5500:

```
[local]RTP-ARES> show hd raid
Sunday October 19 20:24:20 UTC 2014
```

```
HD RAID:
  State                     : Available
  Degraded                  : No
  UUID                      : 2010dbd9:fbad6ab5:d1dae3e0:2b96a066
  Size                      : 1.2TB
  Action                    : Idle
  Card 14
    State                   : In-sync card
    Disk hd14a
      State                 : In-sync component
    Disk hd14b
      State                 : In-sync component
..
  Card 17
    State                   : In-sync card
    Disk hd17a
      State                 : In-sync component
    Disk hd17b
      State                 : In-sync component
```

If the HD-RAID status is in a degraded state, immediately escalate the issue to Cisco to investigate further. Failure to act immediately could result in a loss of billing data if HD-RAID is being used for billing record storage.

Local Ethernet and IP Network

Overview

This section covers Layer 2 and Layer 3 health check commands in ASR 5000/ASR 5500.

Commands and Outputs

These steps will allow the User to verify that the chassis' network interfaces, Layer 2, and Layer 3 network connectivity are operating properly.

Note: Make sure CLI session logging has been enabled. (Estimated Time for completion: 15 minutes)

1. Verify the status of the local Ethernet interfaces: **`#> show port table`**

Expected Output:

```
[local]RTP-ARES> show port table
Friday September 19 11:33:28 UTC 2014
Port  Role Type                      Admin    Oper Link State    Pair  Redundant
----- ---- ------------------------  -------- ---- ---- -------  ----- ---------
18/1  Srvc 1000 Ethernet             Enabled  -    Up   -        None  No L2
19/1  Srvc 10G Ethernet              Enabled  -    Up   -        None  LA+ 19/1
20/1  Srvc 10G Ethernet              Enabled  Up   Up   Active   None  LA~ 19/1
24/1  Mgmt 1000 Ethernet Dual Media  Enabled  Up   Up   Active   25/1  L2 Link
24/2  Mgmt 1000 Ethernet Dual Media  Disabled Down Down Active   25/2  L2 Link
24/3  Mgmt RS232 Serial Console      Enabled  Down Down Active   25/3  L2 Link
24/4  Mgmt BITS T1/E1 Timing         Disabled Down Down Active   25/4  L2 Link
25/1  Mgmt 1000 Ethernet Dual Media  Enabled  Down Up   Standby  24/1  L2 Link
25/2  Mgmt 1000 Ethernet Dual Media  Disabled Down Down Standby  24/2  L2 Link
25/3  Mgmt RS232 Serial Console      Enabled  Down Down Standby  24/3  L2 Link
25/4  Mgmt BITS T1/E1 Timing         Disabled Down Down Standby  24/4  L2 Link
27/1  Srvc 10G Ethernet              Enabled  Up   Up   Active   None  LA+ 19/1
28/1  Srvc 10G Ethernet              Enabled  Up   Up   Active   None  LA~ 19/1
```

If the implementation is using LACP (Link Aggregation Control Protocol), the LAG Ports will have the following possible status:

```
+ means LAG distributing state, LAG is Active <Good>
~ means LAG agreed state, LAG is Standby <Good>
- means LAG not distributing state <Needs to be investigated>
* means LAG negotiated state <Needs to be investigated>
! means timeout <Needs to be investigated>
```

In the above output, verify the "`Admin`", "`Oper`", "`Link`" and "`State`" column. Ensure that all ports are in their expected state. If not, follow local procedures to troubleshoot the local network.

Refer to the "LAG Troubleshooting" section under "Platform Troubleshooting" for further instructions on how to resolve.

If assistance is needed from Cisco, please open an SR.

2. This command reviews detailed information on individual ports: **`#> show port info <card/slot>`**

Expected Output:

```
[local]RTP-ARES> show port info 5/10
Sunday October 19 16:09:22 UTC 2014
Port: 5/10
  Port Type                : 10G Ethernet
  Role                     : Service Port
  Description              : Ingress Line Card
  Redundancy Mode          : Port Mode
  Framing Mode             : Unspecified
  Redundant With           : 6/10
  Preferred Port           : Non-Revertive
  Physical ifIndex         : 84541440
  Administrative State     : Enabled
  Configured Duplex        : Auto
  Configured Speed         : Auto
  Fault Unidirection Mode : 802_3ae clause 66
  Local Fault              : No
```

```
Remote Fault            : No
Laser Transmit Enabled  : Yes
Configured Flow Control : Enabled
Interface MAC Address   : 70-81-05-96-3F-E9
SRP Virtual MAC Address : None
Fixed MAC Address       : 70-81-05-96-3F-C9
Link State              : Up
Link Duplex             : Full
Link Speed              : 10 Gb
Flow Control            : Enabled
Link Aggregation Group  : 50 (global, master)
Link Aggregation LACP   : Active, Short, Auto
LAG Toggle Link         : No
LAG Redundancy Mode     : Standard
LAG Hold Time           : 10
Link Aggregation Master : 5/10
Link Aggregation State  : Port distributing
Link Aggregation Actor  : (8000,70-81-05-96-3F-00,001A,8000,050A)
Link Aggregation Peer   : (007F,80-71-1F-4C-77-F0,002F,007F,0008)
Untagged:
  Logical ifIndex       : 84541441
  Operational State     : Up, Active
Tagged VLAN: VID 2011
  Logical ifIndex       : 84541442
  VLAN Type             : Standard
  VLAN Priority         : 0
  Administrative State  : Enabled
  Operational State     : Up, Active
Number of VLANs         : 2
SFP Module              : Present (10G Base SR)
```

With this command, it is important to make sure the port is in the expected state. The Link's Duplex and Speed setting can also be verified. Most installations should be in a Full/Duplex setting. Different settings of interest have been highlighted in the output above.

Verify the duplex and speed settings match on both sides of the link.

3. Verify the utilization of the ports: #> **show port utilization table**

Expected Output:

```
 [local]RTP-ARES> show port utilization table
Sunday October 19 16:17:38 UTC 2014
                                ------ Average Port Utilization (in mbps) ------
 Port   Type                      Current           5min             15min
                                  Rx       Tx       Rx       Tx       Rx      Tx
 ----- ------------------------  -------  -------  -------  -------  -------  -------
  5/1  1000 Ethernet             0        0        0        0        0        0
  5/10 10G Ethernet              4309     4196     4240     4220     4182     4235
  5/11 10G Ethernet              4012     4036     4088     4123     4116     4100
  5/15 10G Ethernet              4163     4169     4179     4149     4154     4143
  5/16 10G Ethernet              3945     4076     4123     4207     4126     4156
  5/28 10G Ethernet              0        0        0        0        0        0
  5/29 10G Ethernet              0        0        1        25       0        25
  6/1  1000 Ethernet             0        0        0        0        0        0
  6/10 10G Ethernet              0        0        0        0        0        0
  6/11 10G Ethernet              0        0        0        0        0        0
  6/15 10G Ethernet              0        0        0        0        0        0
  6/16 10G Ethernet              0        0        0        0        0        0
  6/28 10G Ethernet              8        63       8        63       8        64
  6/29 10G Ethernet              0        0        0        0        0        0
```

If there is:

- A significant imbalance
- Lower than normal utilization
- Traffic on ports that are not normally active

All of the above should be investigated to understand what is occurring in the network.

If the implementation is using LACP, the Tx and Rx values should be very close in utilization. If they are not, this should be investigated further. Refer to the "LAG" section in the "Platform Troubleshooting" chapter.

4. Verify Layer 2 of the local Ethernet ports: **#> show port datalink counters <card/slot>**

Expected Output:

ASR 5500:

```
[local]RTP-ARES> show port datalink counters 5/10
Sunday October 19 16:23:48 UTC 2014
Counters for port 5/10:
Line Card 10 Gigabit Ethernet Port
Rx Counter                          Data  |  Tx Counter                          Data
----------------------  -------------- + ----------------------  -------------
RX Bytes                319226677986554 | TX Bytes                317202258541038
RX Unicast frames          480327895602 | TX Unicast frames         463571244297
RX Multicast frames             4915372 | TX Multicast frames             815383
RX Broadcast frames               60474 | TX Broadcast frames                18
RX Size 64 frames             195196103 | TX Size 64 frames           2522213910
RX Size   65 ..  127 fr      2897540401 | TX Size   65 ..  127 fr      464790369
RX Size  128 ..  255 fr      4038148867 | TX Size  128 ..  255 fr     1935712192
RX Size  256 ..  511 fr      4112043921 | TX Size  256 ..  511 fr     4174801578
RX Size  512 .. 1023 fr       908298829 | TX Size  512 .. 1023 fr      610204833
RX Size 1024 .. 1518 fr      1521075953 | TX Size 1024 .. 1518 fr     2480901810
RX Size 1519 .. 1522 fr      2804099391 | TX Size 1519 .. 1522 fr      411868919
RX OverSize frames                    0 | TX OverSize frames                   0
RX UnderSize frames                   0 | TX UnderSize frames                  0
RX ExceedMaxSize frames               0
RX Fragment frames                    0 | TX Fragment frames                  0
RX Jabber frames                      0 | TX Jabber frames                    0
RX Control frames                     0 | TX Control frames                   0
RX Pause frames                       0 | TX Pause frames                     0
RX FCS Error frames                   0 | TX FCS Error frames                 0
RX Length Error frames                0 | TX Length Error frames              0
RX Code Error frames                  0
RX ExMaxSize Err frames               0
----------------------  -------------- + ----------------------  -------------
```

ASR 5000:

```
[local]RTP-ASR5K> show port datalink counters 20/1
Sunday October 19 16:49:26 UTC 2014
Counters for port 20/1:
Line Card 10 Gigabit Ethernet Port
Rx Counter                          Data  |  Tx Counter                          Data
-----------------------  -------------- + -----------------------  -------------
RX Unicast frames          138517244912 | TX Unicast frames          135320058254
RX Multicast frames            71381895 | TX Multicast frames                   0
RX Broadcast frames              119098 | TX Broadcast frames                   0
RX Size   64 frames          1396965770 | TX Size   64 frames          6556276541
RX Size   65 ..  127 fr     50466895763 | TX Size   65 ..  127 fr     55277659054
RX Size  128 ..  255 fr     29589636065 | TX Size  128 ..  255 fr     23164268053
RX Size  256 ..  511 fr     13100922011 | TX Size  256 ..  511 fr      5759701205
RX Size  512 .. 1023 fr      4682854867 | TX Size  512 .. 1023 fr      4291772750
RX Size 1024 .. 1518 fr     38146235838 | TX Size 1024 .. 1518 fr     40270381306
RX Size > 1518 frames        1133732698 | TX Size > 1518 frames                 0
RX Bytes OK              74557273143465 | TX Bytes OK              73960762870239
RX Bytes BAD                         0 | TX Bytes BAD                          0
RX SHORT OK                          0 | TX PAUSE                              0
RX SHORT CRC                         0 | TX ERR                                0
RX OVF                               0 |
RX NORM CRC                          0 |
RX LONG OK                           0 |
RX LONG CRC                          0 |
RX PAUSE                             0 |
RX FALS CRS                          0 |
RX SYM ERR                           0 |
RX SPI FRAME COUNT         138488855278 | TX SPI FRAME COUNT         135291491891
RX SPI LEN ERR                       0 | TX SPI LEN ERR                        0
RX SPI DIP 2 ERR                     0 | TX SPI DIP 4 ERR                      0
RX SPI STATUS OOF ERR                0 | TX SPI DATA OOF ERR                   0
RX FIFO OVERFLOW                     0 | TX FIFO FULL DROP                     0
RX PAUSE COUNT                       0 | TX DIP 4 PACKET DROP                  0
SPI EOP/ABORT                        0 |
RX FRAGMENTS COUNT                   0 |
```

```
RX MAC ERR                          0 |
RX JABBER COUNT                     0 |
----------------------  -------------- + ----------------------  -------------
```

With this command, verify the Layer 2 counters for the individual Ethernet port connectivity of the ASR 5x00. All "**bolded**" counters should typically be "**0**" or very low. If these values are actively incrementing they should be investigated. Usually, if the counter is an "**Rx**" (Receive) then the issue is external to the chassis. If it is "**Tx**" (Transmit), then the problem may be on the chassis.

Attempt the following to resolve:

- Bounce the port on the adjacent node (Layer 2 switch)
- Switchover to redundant port
- Clean the fibers if fiber-based
- Swap cables
- Replace cable/fiber
- ASR 5000: PSC migration
- ASR 5500: MIO migration
- SFP replacement on either or both sides of the fiber link
- Hardware replacement on the adjacent Layer 2 switch
- Hardware replacement on the ASR 5x00

Refer to the "Card and Ports" section in the "Platform Troubleshooting" chapter for further information.

5. ASR 5500 ONLY: Verify the SFP Module installed in the MIO card:**#> show port transceiver <card/slot>**

Expected Output:

```
[local]RTP-ARES> show port transceiver 5/10
Sunday October 19 17:56:43 UTC 2014
Port 5/10 SFP+ Optical Module Detailed Information:
  SFP Transceiver info : 10G Base SR
  SFP Vendor info      : Vendor Name: JDSU  Vendor IEEE ID: 412
  SFP Vendor Rev info  : 2
```

```
SFP Parts info       : P/N: PLRXPLSCS4322N S/N: CB33UF0P7 Date: 08/09/2011
Nominal Bitrate      : 10300 MBits/sec
Length 50/125um      : 80 m
Length 62.5/125um    : 30 m
Wavelength           : 850 nm
Diagnostic Monitor   : Yes
Internally Calibrated: Yes
Externally Calibrated: No
SFF-8472 Compliance  : Rev 10.2
                     : Low Alarm  Low Warn    Actual   High Warn High Alarm
                     : Threshold Threshold     Value   Threshold  Threshold
Temp(C)              :  -10.0000   -5.0000   44.1211     75.0000    80.0000
Voltage(V)           :    2.8500    2.9700    3.2978      3.6300     3.7000
Bias(mA)             :    2.6000    3.0000    7.6400      8.5000    10.0000
TxPower(dBm)         :   -8.0024   -7.5007   -2.5376     -1.3001    -1.0002
RxPower(dBm)         :  -14.0012  -11.9997   -4.5544      0.9851     1.4999
                     :(--)low_alarm (-)low_warn (+)high_warn (++)high_alarm
```

This command can be helpful when troubleshooting fiber links. This will provide readouts regarding the Transmit and Receive power levels detected on the fiber link.

If the readings are not of the expected values, attempt the following:

- Clean fiber pairs
- Replace SFPs
- Replace fiber cable

6. Verify:

- ARP/Neighbor tables are populated for each of the configured Contexts: **#> context <Each Context configured in the system>**
- For configured IPv4 interfaces: **#> show ip arp**
- For configured IPv6 interfaces:**#> show ipv6 neighbors**

Expected Output:

```
[local]RTP-ASR5K> context Egress
Tuesday October 21 11:02:13 UTC 2014
```

```
[Egress]RTP-ASR5K> show ip arp
Tuesday October 21 11:02:13 UTC 2014
Flags codes:
I - Incomplete, R - Reachable, M - Permanent, S - Stale,
D - Delay,      P - Probe,     F - Failed

Address          Link Type Link Address      Flags  Mask            Interface
69.22.33.50      ether     00:1F:DB:FF:20:00 R                      5/10-V4
69.22.33.49      ether     00:1F:DB:FF:10:00 R                      5/10-V4
Total number of arps: 2
```

```
[Egress]RTP-ASR5K> show ipv6 neighbors
Tuesday October 21 11:02:16 UTC 2014
2001:4888:24:2010:223:25::              ether  00:10:DB:FF:10:00  R     5/10-V6
```

If the expected MAC Addresses are not populated in the ARP table or IPv6 Neighbors table, refer to the "ARP" section in the "Platform Troubleshooting" chapter.

7. Verify Layer 3 interfaces are in an expected state for each of the configured Contexts:**#> context <Each Context configured in the system>**

- For configured IPv4 interfaces: **#> show ip interface summary**
- For configured IPv6 interfaces: **#> show ipv6 interface summary**

Expected Output:

```
[local]RTP-ARES> context Egress
Tuesday October 21 11:02:13 UTC 2014
```

```
[Egress]RTP-ARES> show ip interface summary
Sunday October 19 17:05:49 UTC 2014
Interface Name                 Address/Mask        Port                Status
============================== ================== ================== ======
5/10-V4                        62.11.22.51/28      5/10 vlan 2007     UP
BGPV4-OUT-LOOP                 61.11.122.222/32    Loopback           UP
Total interface count: 2
```

```
[Egress]RTP-ARES> show ipv6 interface summary
Sunday October 19 17:05:57 UTC 2014
Interface Name                  Address/Mask        Port                Status
============================== ================== ================== ======
5/10-V6                         2001:beef:20:2010:201:200::/64 5/10 vlan 2427     UP
BGPV6-OUT-LOOP                  2001:beef:0:1000:201:200::/128 Loopback           UP

Total interface count: 2
```

All configured interfaces should be in their expected state. If an interface is not in the correct state, refer to the section above containing the "show port info" command. Refer to the "ARP" or "Cards or Ports" section in the "Platform Troubleshooting" chapter for further information.

Loopback interfaces will show a state of "**INACTIVE**" if the chassis is in the SRP Standby state.

8. Verify Layer 3 interface counters: **#> show port npu counters <card/slot>**

Expected Output:

```
[Egress]RTP-ARES> show port npu counters 5/10
Sunday October 19 17:15:01 UTC 2014
Counters for port 5/10
Counter                   Rx Frames       Rx Bytes      Tx Frames        Tx Bytes
-------------------- ------------- --------------- ------------- ---------------
Unicast              18779411596791267353810600788 186489456549512707180079531 25
Multicast                  8229798       701002284       6547597       811901048
Broadcast                   121410         7284744            36            1656
IPv4 unicast         1579560569069 980548339107180 16484692962251186193652538372
IPv4 non-unicast           1869126       119624064             0               0
IPv6 unicast          298373893695 286804649948691  216424908839  67703541283852
IPv6 non-unicast           6360672       581378220        199773        53246531
Fragments received      2579634775   2040987368899           n/a             n/a
Packets reassembled     1289756423   1988678514802           n/a             n/a
Fragments to kernel              0               0           n/a             n/a
HW error                         0               0           n/a             n/a
Port non-operational             0               0             0               0
SRC MAC is multicast             0               0           n/a             n/a
Unknown VLAN tag                 0               0           n/a             n/a
```

```
Other protocols              471638        28725024           n/a             n/a
Not IPv4              298377074128 286804940769757           n/a             n/a
Bad IPv4 header                  0               0           n/a             n/a
IPv4 MRU exceeded                0               0           n/a             n/a
TCP tiny fragment                0               0             0               0
No ACL match                     0               0             0               0
Filtered by ACL                  0               0             0               0
TTL expired                      0               0           n/a             n/a
Flow lookup twice                0               0           n/a             n/a
Unknown IPv4 class               0               0           n/a             n/a
Too short: IP                    0               0           n/a             n/a
Too short: ICMP                  0               0             0               0
Too short: IGMP                  0               0             0               0
Too short: TCP                   0               0             0               0
Too short: UDP                   0               0             0               0
Too short: IPIP                  0               0           n/a             n/a
Too short: GRE                   0               0           n/a             n/a
Too short: GRE key               0               0           n/a             n/a
Don't frag discards            n/a             n/a             0               0
Fragment packets               n/a             n/a   13124029886  20199200521626
Fragment fragments             n/a             n/a   26248059772 768398910185208
IPv4VlanMap dropped              0               0           n/a             n/a
IPSec NATT keep alive            0               0           n/a             n/a
MPLS Flow not found              0               0           n/a             n/a
MPLS unicast                     0               0             0               0
Size    0 ..   63       1007423352     60570440084  285852562031  16578104126990
Size   64 ..  127     821450909293   77484909314985  543905420671  48114421574111
Size  128 ..  255     143797753015   23968035265887  123416733852  22355615192367
Size  256 ..  511      65638054314   23520371737752   66883470267  23600696739172
Size  512 .. 1023      53512926638   39040090950903   53907682184  39277239295411
Size 1024 .. 2047     792542548125110328061715715 790935338795112079279329273 9
Size 2048 .. 4095                0               0             0               0
Size 4096 .. 8191                0               0             0               0
Size >= 8192                     0               0             0               0
```

With this command, verify the Layer 3 counters for the individual Ethernet port of the ASR 5x00. All "**bolded**" counters should typically be "**0**". If they are actively incrementing they should be investigated. Usually, if the counter is an "**Rx**" (Receive) then the issue is external to the chassis, if it is "**Tx**"(Transmit), then the problem may be on the chassis.

Refer to the "Switch Fabric and NPU" section in the "Platform Troubleshooting" chapter for further information. If the "**bolded**" counters are increasing, contact Cisco in order to perform analysis and troubleshooting.

9. Verify IP Routing tables are present for each of the configured Contexts: **#> context <Each Context configured in the system>**

- For configured IPv4 interfaces: **#> show ip route**
- For configured IPv6 interfaces: **#> show ipv6 route**

Expected Output:

```
[Egress]RTP-ARES> show ip route
Tuesday October 21 11:06:41 UTC 2014
"*" indicates the Best or Used route.  S indicates Stale.
  Destination         Nexthop          Protocol    Prec Cost Interface
*0.0.0.0/0           69.33.39.49      bgp         20   0    5/10-V4
 0.0.0.0/0           69.33.39.49      static      40   0    5/10-V4
*10.128.0.0/13       0.0.0.0          connected   0    0    pool admin41
*10.144.0.0/13       0.0.0.0          connected   0    0    pool appl41
*10.160.0.0/13       0.0.0.0          connected   0    0    pool inter41
*10.168.0.0/13       0.0.0.0          connected   0    0    pool inter41
*10.176.0.0/13       0.0.0.0          connected   0    0    pool inter41
*10.184.0.0/13       0.0.0.0          connected   0    0    pool inter41
*66.74.68.77/32      0.0.0.0          connected   0    0    BGPV4-OUT-LOOP
*69.83.39.48/28      0.0.0.0          connected   0    0    5/10-V4
*69.83.39.52/32      0.0.0.0          connected   0    0    5/10-V4
*69.83.228.33/32     69.83.39.49      static      1    0    5/10-V4
*69.83.228.34/32     69.83.39.49      static      1    0    5/10-V4
*70.209.0.0/20       0.0.0.0          connected   0    0    pool natl_inter
*70.209.16.0/20      0.0.0.0          connected   0    0    pool natl_inter
*72.96.136.0/23      0.0.0.0          connected   0    0    pool natl_admin
*72.96.138.0/23      0.0.0.0          connected   0    0    pool natl_admin
*72.104.104.0/21     0.0.0.0          connected   0    0    pool intr42
*72.120.72.0/23      0.0.0.0          connected   0    0    pool natl_appl
*72.120.74.0/23      0.0.0.0          connected   0    0    pool natl_appl
*167.163.60.0/24     0.0.0.0          connected   0    0    pool natl
*167.163.61.0/24     0.0.0.0          connected   0    0    pool natl_
```

```
Total route count : 22
Unique route count: 21
Connected: 18 Static: 3 BGP: 1
```

```
[Egress]RTP-ARES> show ipv6 route
Tuesday October 21 11:06:53 UTC 2014
"*" indicates the Best or Used route.  S indicates Stale.

 Destination                        Nexthop
                              Protocol    Prec Cost Interface
*::/0                                2001:4888:24:2010:223:25::   static     40   0    5/10-V6
*2001:f888:0:7:223:2a1::/128         2001:4888:24:2010:223:25::   static     1    0    5/10-V6
*2001:f888:0:7:223:2a1:0:1/128       2001:4888:24:2010:223:25::   static     1    0    5/10-V6
*2001:f888:0:1000::/128              ::                           connected  0    0    BGPV6
*2001:f888:24:2a10::/64              ::                           connected  0    0    5/10-V6
*2001:4f88:24:2a10:223:200::/128     ::                           connected  0    0    5/10-V6
*2600:1f06:21a0::/44                 ::                           connected  0    0    chg961
*2600:1f06:21a0::/44                 ::                           connected  0    0    chg961
*2600:1f06:81a0::/44                 ::                           connected  0    0    ims961
*2600:1ff06:8a10::/44                 ::                           connected  0    0    ims961
*2600:1f06:81a0::/44                 ::                           connected  0    0    ims961
*2600:1f06:91a0::/44                 ::                           connected  0    0    appl961
*2600:1f06:b1a0::/44                 ::                           connected  0    0    intl961
*2600:1f06:b1a0::/44                 ::                           connected  0    0    intl961
*2600:1f06:b1a0::/44                 ::                           connected  0    0    intl961
*2600:1f06:f1a0::/44                 ::                           connected  0    0    admin961

Total route count : 16
Unique route count: 16
Connected: 13 Static: 3
```

The “**ping**”, “**ping6**”, “**traceroute**”, or “**traceroute6**” command can be used to test IP Layer connectivity to the far end IPv4 or IPv6 address.

Refer to the "Routing Protocol" chapter for more information on this subject.

Call Processing

Overview

With many subscribers connecting to ASR 5000/ASR 5500, this section covers how to verify session connections and setup times.

Commands and Outputs

These steps will allow the User to verify that the chassis is processing incoming calls with no issues.

Note: Make sure the CLI session logging has been enabled. (Estimated Time for completion: 15 minutes)

1. Verify the total number of subscribers currently attached to the chassis:**#> show subscribers summary**

Expected Output:

```
[local]RTP-ARES> show subscribers summary
Sunday October 19 18:17:45 UTC 2014
 Total Subscribers:             2924438
Active:                         2924438       Dormant:                        0
pdsn-simple-ipv4:               0             pdsn-simple-ipv6:               0
pdsn-mobile-ip:                 0             ha-mobile-ipv6:                 0
hsgw-ipv6:                      0             hsgw-ipv4:                      0
hsgw-ipv4-ipv6:                 0             pgw-pmip-ipv6:                  138139
pgw-pmip-ipv4:                  59            pgw-pmip-ipv4-ipv6:             94226
pgw-gtp-ipv6:                   927412        pgw-gtp-ipv4:                   3036
pgw-gtp-ipv4-ipv6:              764397        sgw-gtp-ipv6:                   0
sgw-gtp-ipv4:                   0             sgw-gtp-ipv4-ipv6:              0
sgw-pmip-ipv6:                  0             sgw-pmip-ipv4:                  0
sgw-pmip-ipv4-ipv6:             0             pgw-gtps2b-ipv4:                0
pgw-gtps2b-ipv6:                0             pgw-gtps2b-ipv4-ipv6:           0
pgw-gtps2a-ipv4:                0             pgw-gtps2a-ipv6:                0
```

```
pgw-gtps2a-ipv4-ipv6:          0
mme:                           0
henbgw-ue:                     0             henbgw-henb:                      0
ipsg-rad-snoop:                0             ipsg-rad-server:                  0
ha-mobile-ip:                  997252        ggsn-pdp-type-ppp:                0
ggsn-pdp-type-ipv4:            0             lns-l2tp:                         0
ggsn-pdp-type-ipv6:            0             ggsn-pdp-type-ipv4v6:             0
ggsn-mbms-ue-type-ipv4:        0pdif-simple-ipv4:              0
pdif-simple-ipv6:              0             pdif-mobile-ip:                   0
wsg-simple-ipv4:               0             wsg-simple-ipv6:                  0
pdg-simple-ipv4:               0             ttg-ipv4:                         0
pdg-simple-ipv6:               0             ttg-ipv6:                         0
femto-ip:                      0
epdg-pmip-ipv6:                0             epdg-pmip-ipv4:                   0
epdg-pmip-ipv4-ipv6:           0
epdg-gtp-ipv6:                 0             epdg-gtp-ipv4:                    0
epdg-gtp-ipv4-ipv6:            0
sgsn:                          0             sgsn-pdp-type-ppp:                0
sgsn-pdp-type-ipv4:            0             sgsn-pdp-type-ipv6:               0
sgsn-pdp-type-ipv4-ipv6:       0             type not determined:              0
sgsn-subs-type-gn:             0             sgsn-subs-type-s4:                0
sgsn-pdp-type-gn:              0             sgsn-pdp-type-s4:                 0
asngw-simple-ipv4:             0             asngw-simple-ipv6:                0
asngw-mobile-ip:               0
asngw-non-anchor:              0             asngw-auth-only:                  0
phsgw-simple-ipv4:             0             phsgw-simple-ipv6:                0
phsgw-mobile-ip:               0
phsgw-non-anchor:              0
cdma 1x rtt sessions:          0             cdma evdo sessions:               0
cdma evdo rev-a sessions:      0             cdma 1x rtt active:               0
cdma evdo active:              0             cdma evdo rev-a active:           0
asnpc-idle-mode:               0             phspc-sleep-mode:                 0
hnbgw:                         0             hnbgw-iu:                         0
bng-simple-ipv4:               0pcc:                           0
in bytes dropped:              14698706480    out bytes dropped:               70438975999
in packet dropped:             98732774      out packet dropped:               64916512
in packet dropped zero mbr:    0             out packet dropped zero mbr:      0
in bytes dropped ovrchrgPtn:   0             out bytes dropped ovrchrgPtn:     0
in packet dropped ovrchrgPtn:  0             out packet dropped ovrchrgPtn:    0
```

```
ipv4 ttl exceeded:              221852        ipv4 bad hdr:                  57641
ipv4 bad length trim:           7051495
ipv4 frag failure:              0             ipv4 frag sent:                0
ipv4 in-acl dropped:            32698001      ipv4 out-acl dropped:          9832
ipv6 bad hdr:                   5376          ipv6 bad length trim:          27005
ipv6 in-acl dropped:            355           ipv6 out-acl dropped:          306
ipv4 in-css-down dropped:       0             ipv4 out-css-down dropped:     0
ipv4 out xoff pkt dropped:      0             ipv6 out xoff pkt dropped:     0
ipv4 xoff bytes dropped:        0             ipv6 xoff bytes dropped:       0
ipv4 out no-flow dropped:       0
ipv4 early pdu rcvd:            0             ipv4 icmp packets dropped:     0
ipv6 input ehrpd-access drop:   684           ipv6 output ehrpd-access drop: 51
dormancy count:                 0             handoff count:                 13241292
pdsn fwd dynamic flows:         0             pdsn rev dynamic flows:        0
fwd static access-flows:        2976          rev static access-flows:       2976
pdsn fwd packet filters:        0             pdsn rev packet filters:       0
traffic flow templates:         0
```

If the total number of subscribers is not the expected or normal value, refer to the "Session Troubleshooting" chapter or specific call control protocol chapters for further information.

2. Verify the sessions in progress that are currently observed in the system: **#> `show session progress`**

Expected Output:

```
 [local]RTP-ARES> show session progress
Thursday May 01 15:26:43 UTC 2015
       66 In-progress calls
       66 In-progress active calls
        0 In-progress dormant calls
        0 In-progress always-on calls
        0 In-progress calls @ ARRIVED state
        0 In-progress calls @ CSCF-CALL-ARRIVED state
        0 In-progress calls @ CSCF-REGISTERING state
        0 In-progress calls @ CSCF-REGISTERED state
        0 In-progress calls @ LCP-NEG state
        0 In-progress calls @ LCP-UP state
```

```
  0 In-progress calls @ AUTHENTICATING state
  0 In-progress calls @ BCMCS SERVICE AUTHENTICATING state
  0 In-progress calls @ AUTHENTICATED state
  0 In-progress calls @ PDG AUTHORIZING state
  0 In-progress calls @ PDG AUTHORIZED state
  0 In-progress calls @ IMS AUTHORIZING state
  0 In-progress calls @ IMS AUTHORIZED state
  0 In-progress calls @ MBMS UE AUTHORIZING state
  0 In-progress calls @ MBMS BEARER AUTHORIZING state
  0 In-progress calls @ DHCP PENDING state
  0 In-progress calls @ L2TP-LAC CONNECTING state
  0 In-progress calls @ MBMS BEARER CONNECTING state
  0 In-progress calls @ CSCF-CALL-CONNECTING state
  0 In-progress calls @ IPCP-UP state
  0 In-progress calls @ NON-ANCHOR CONNECTED state
  0 In-progress calls @ AUTH-ONLY CONNECTED state
  0 In-progress calls @ SIMPLE-IPv4 CONNECTED state
  0 In-progress calls @ SIMPLE-IPv6 CONNECTED state
  0 In-progress calls @ SIMPLE-IPv4+IPv6 CONNECTED state
  0 In-progress calls @ MOBILE-IPv4 CONNECTED state
  0 In-progress calls @ MOBILE-IPv6 CONNECTED state
  0 In-progress calls @ GTP CONNECTING state
  0 In-progress calls @ GTP CONNECTED state
  0 In-progress calls @ PROXY-MOBILE-IP CONNECTING state
  0 In-progress calls @ PROXY-MOBILE-IP CONNECTED state
  0 In-progress calls @ EPDG RE-AUTHORIZING state
  0 In-progress calls @ HA-IPSEC CONNECTED state
  0 In-progress calls @ L2TP-LAC CONNECTED state
  0 In-progress calls @ HNBGW CONNECTED state
  0 In-progress calls @ PDP-TYPE-PPP CONNECTED state
  0 In-progress calls @ IPSG CONNECTED state
  0 In-progress calls @ BCMCS CONNECTED state
  0 In-progress calls @ PCC CONNECTED state
  0 In-progress calls @ MBMS UE CONNECTED state
  0 In-progress calls @ MBMS BEARER CONNECTED state
  0 In-progress calls @ PAGING CONNECTED state
  0 In-progress calls @ PDN-TYPE-IPv4 CONNECTED state
 35 In-progress calls @ PDN-TYPE-IPv6 CONNECTED state
 31 In-progress calls @ PDN-TYPE-IPv4+IPv6 CONNECTED state
```

```
0 In-progress calls @ CSCF-CALL-CONNECTED  state
0 In-progress calls @ MME ATTACHED state
0 In-progress calls @ HENBGW CONNECTED state
0 In-progress calls @ CSCF-CALL-DISCONNECTING state
0 In-progress calls @ DISCONNECTING state
```

Make note of values that are not in the "connected" state and any values that are higher or lower than expected.

If the values under "`show session progress`" are not the expected or normal values, refer to the "Session Troubleshooting" chapter or specific call control protocol chapters for further information.

3. Verify the disconnect reasons that are currently observed in the system: **`#> show session disconnect-reasons`**

Expected Output:

```
[local]RTP-ARES> show session disconnect-reasons
Sunday October 19 18:23:42 UTC 2014
Session Disconnect Statistics
 Total Disconnects: 6581461
Disconnect Reason                                    Num Disc  Percentage
-----------------------------------------------------  ----------  ----------
Remote-disconnect                                     3018545    45.86436
Invalid-AAA-attr-in-auth-response                       12393     0.18830
Inactivity-timeout                                     358317     5.44434
Absolute-timeout                                        86530     1.31475
Invalid-source-IP-address                               53489     0.81272
MIP-remote-dereg                                      1340660    20.37025
MIP-lifetime-expiry                                    313174     4.75843
MIP-proto-error                                         90442     1.37419
MIP-auth-failure                                       431641     6.55844
MIP-Reg-Revocation                                     604360     9.18276
Admin-AAA-disconnect                                   139528     2.12002
failed-auth-with-charging-svc                           96210     1.46183
```

```
volume-quota-reached                                  233     0.00354
gtp-user-auth-failed                                   16     0.00024
mipha-prepaid-reset-dynamic-newcall                     3     0.00005
ims-authorization-failed                            27468     0.41735
Gtp-context-replacement                               374     0.00568
ims-authorization-revoked                            1031     0.01567
disconnect-from-policy-server                        5811     0.08829
s6b-auth-failed                                       912     0.01386
gtpu-err-ind                                           75     0.00114
```

Review the percentage column of the "`disconnect-reasons`". Ensure that the percentages are near their normal values. Typically, if an issue is occurring within the network, a "`disconnect-reason`" counter may be higher or lower than normal.

To get a current readout of the disconnect reasons, clearing the counters can be done prior to displaying the values. Then display the values over a 5 to 10 minute period to understand the current disconnect reasons in the system.

#> **clear session disconnect-reasons**
#> `show session disconnect-reasons`

If the values under "`show session disconnect-reasons`" are not expected, refer to the "Session Troubleshooting" chapter or specific call control protocol chapters for further information.

4. Verify the setup time taken by the system to attach a subscriber to the chassis: **`#> show session setuptime`**

Expected Output:

```
[local]RTP-ARES> show session setuptime
Sunday October 19 18:43:10 UTC 2014
      Setup Time          Count    Setup Time          Count
     ----------          -----    ----------          -----
         <100ms        6479964       1..2sec         239314
     100..200ms       29370656       2..3sec           4976
     200..300ms       34093512       3..4sec           4258
     300..400ms       18692819       4..6sec             76
```

```
    400..500ms      36872022      6..8sec            3
    500..600ms      29481901     8..10sec            0
    600..700ms      20918216    10..12sec           16
    700..800ms       8672949    12..14sec            0
    800..900ms       1817528    14..16sec            0
   900..1000ms        409005    16..18sec            0
                                   >18sec            0
```

To get a current readout of the session setup time, clearing the counters can be done prior to displaying the values. Then display the values over a 5 to 10 minute period to understand the current session setup time in the system.

```
#> clear session setuptime
#> show session setuptime
```

If the values under "`show session setuptime`" are not expected, refer to the "Session Troubleshooting" chapter or specific call control protocol chapters for further information.

5. Verify the historical session counters of calls being attached to the system: **`#> show session counters historical all`**

Expected Output:

```
[local]RTP-ARES> show session counters historical all
Sunday October 19 19:29:28 UTC 2014
                        ------------------- Number of Calls ------------------
                                                                    (A+R+D+F+H+R)
Intv  Timestamp           Arrived  Rejected  Connected   Disconn  Failed   Handoffs  Renewals  CallOps
----  ------------------- -------- --------  ---------   -------- -------  --------  --------  -------
   1  2014:10:19:19:15:00   471139    22995    299716    267934    6377    409878    206282   1384605
   2  2014:10:19:19:00:00   427698    22267    270171    257073    5909    390215    186181   1289343
   3  2014:10:19:18:45:00   392151    21869    246758    252120    5712    373437    165098   1210387
   4  2014:10:19:18:30:00   388653    22086    235112    252925    5467    386556    151795   1207482
   5  2014:10:19:18:15:00   420167    21573    250441    253493    5637    414015    178711   1293596
   6  2014:10:19:18:00:00   430109    22272    255530    252964    5407    419297    186714   1316763
   7  2014:10:19:17:45:00   453561    22153    269089    258437    5499    432931    200689   1373270
   8  2014:10:19:17:30:00   483870    22360    298484    259402    5968    428761    223685   1424046
   9  2014:10:19:17:15:00   470265    22083    303149    267306    5881    400637    200586   1366758
```

```
 10  2014:10:19:17:00:00   428951    21384    275798    258064    5456    376979     176975    1267809
 11  2014:10:19:16:45:00   380787    21031    241877    237038    5426    357499     159090    1160871
 12  2014:10:19:16:30:00   368436    20792    225820    230429    5391    361535     147621    1134204
```

With the output of "**show session counters historical all**", it is important to take notice of any sudden spikes in any of the columns. Such a spike will usually indicate an issue has taken place in the network. If there is a large increase or decrease, follow local procedures to troubleshoot the issue.

If the values under "**show session counters historical all**" are not expected, refer to the "Session Troubleshooting" chapter or specific call control protocol chapters for further information.

6. Verify that all Session Managers on the system are evenly distributed: **#> show task resources facility sessmgr all**

Expected Output:

```
[local]RTP-ARES> show task resources facility sessmgr all
Sunday October 19 19:49:21 UTC 2014
                   task   cputime        memory     files      sessions
 cpu facility      inst used allc   used  alloc used allc  used  allc S status
----------------------- --------- ------------- --------- ------------- ------
 2/0 sessmgr       5012 0.2%  50% 121.4M 230.0M  109  500    --    -- S   good
 2/0 sessmgr          9  32% 100% 847.7M  2.49G  127  500 10254 35200 I   good
 2/0 sessmgr         21  29% 100% 840.0M  2.49G  127  500 10250 35200 I   good
..
 2/1 sessmgr       5006 0.2%  50% 120.9M 230.0M  110  500    --    -- S   good
 2/1 sessmgr          3  30% 100% 850.4M  2.49G  129  500 10206 35200 I   good
 2/1 sessmgr         15  31% 100% 841.4M  2.49G  127  500 10211 35200 I   good
..
 3/0 sessmgr       5014 0.2%  50% 121.0M 230.0M  111  500    --    -- S   good
 3/0 sessmgr        100  29% 100% 852.8M  2.49G  131  500 10263 35200 I   good
 3/0 sessmgr        113  33% 100% 848.1M  2.49G  132  500 10262 35200 I   good
..
 3/1 sessmgr       5008 0.2%  50% 121.3M 230.0M  108  500    --    -- S   good
 3/1 sessmgr        105  26% 100% 848.4M  2.49G  130  500 10271 35200 I   good
 3/1 sessmgr        125  32% 100% 846.2M  2.49G  130  500 10266 35200 I   good
```

```
..
Total               348 8750.83%  244.7G        44081      3.0m
```

All Session Managers on the system should show a value in the “**used**” column that is fairly equal. If the system shows a Session Manager that has a value that is much higher or lower than other Session Managers on the system, this should be investigated immediately. Try to determine if the affected Session Managers are all on the same card, or if it is affecting multiple cards.

If the sessions are not evenly distributed, refer to the "Session Managers Imbalanced" section in the "Platform Troubleshooting" chapter for further information.

Chassis Fabric

Overview

This section covers a health check of Swtich Fabric on ASR 5000/ASR 5500.

Commands and Outputs

These steps allow the User to verify the internal Fabric of the ASR 5000/ASR 5500 chassis. Some commands are specific to the ASR 5000 or ASR 5500 chassis and are marked accordingly. These commands require Administrative access rights to the chassis.

Note: Make sure CLI session logging has been enabled.

Estimated Time for completion: 15 minutes

> The below CLI command requires CLI test-commands password configured in the chassis. Please use the command with caution!
> Many **TEST** commands are processor-intensive and can cause serious system problems if used too frequently.

1. Access hidden/test mode of the chassis CLI:

#> hidden p <password>

Or

#> cli test-commands password <password>

Expected Output:

```
[local]RTP-ARES> hidden p xxxxxx
Thursday September 18 11:25:15 UTC 2014
Warning: HIDDEN access enables internal testing and debugging commands
         USE OF THIS MODE MAY CAUSE SIGNIFICANT SERVICE INTERRUPTION
```

Or

```
[local]RTP-ARES> cli test-commands password XXXXXX
Wednesday May 06 15:59:46 UTC 2015
Warning: Test commands enables internal testing and debugging commands
        USE OF THIS MODE MAY CAUSE SIGNIFICANT SERVICE INTERRUPTION
```

Skip to Step 6 if for ASR 5000 chassis.

2. ASR 5500 Only, verify the SERDES Links on the chassis:

`#> show fabric status`

Expected Output:

```
[local]RTP-ARES> show fabric status
Sunday October 19 20:40:47 UTC 2014
Total number of FAPs: 24
Total number of FEs : 8
Total number of SERDES links:        1600
Total number of active SERDES links: 1600
```

The total number of SERDES links should be equal to the number of active SERDES links.

3. ASR 5500 Only, run twice 1 minute apart:

`#> show fabric health | grep -i -E  "^Petra|EGQ"`

Expected Output:

```
[local]RTP-ARES> show fabric health | grep -i -E "^Petra|EGQ"
Sunday October 19 20:46:41 UTC 2014
Petra-B 1=1/1
Petra-B 2=1/2
Petra-B 3=2/1
EGQ.RqpDiscardPacketCounter                              5
EGQ.EhpDiscardPacketCounter                              5
```

```
EGQ.PqpDiscardUnicastPacketCounter                    5
Petra-B 4=2/2
EGQ.RqpDiscardPacketCounter                           2
EGQ.EhpDiscardPacketCounter                           2
EGQ.PqpDiscardUnicastPacketCounter                    2
Petra-B 5=3/1
Petra-B 6=3/2
Petra-B 11=4/1
Petra-B 12=4/2
Petra-B 17=5/1
Petra-B 18=5/2
Petra-B 19=5/3
Petra-B 20=5/4
Petra-B 21=6/1
Petra-B 22=6/2
Petra-B 23=6/3
Petra-B 24=6/4
Petra-B 25=7/1
```

This command will show whether or not Egress Queue Discards are currently occurring in the chassis. In order to see if the values are incrementing, the command must be run at least every minute. If values are incrementing, refer to the "Switch Fabric and NPU" section in the "Platform Troubleshooting" chapter.

4. ASR 5500 Only, verify the Fabric capacity:

`#> show fabric capacity`

Expected Output:

```
[local]RTP-ARES> show fabric capacity
Sunday October 19 20:56:03 UTC 2014
          FSC 14   |  FSC 15   |  FSC 16   |  FSC 17   |
------------------+-----------+-----------+-----------+
Slot  1:   75.000 |   75.000 |   75.000 |   75.000 |
Slot  2:   75.000 |   75.000 |   75.000 |   75.000 |
Slot  3:   75.000 |   75.000 |   75.000 |   75.000 |
Slot  4:   75.000 |   75.000 |   75.000 |   75.000 |
```

```
Slot  5:  150.000 |  150.000 |  150.000 |  150.000 |
Slot  6:  150.000 |  150.000 |  150.000 |  150.000 |
Slot  7:   75.000 |   75.000 |   75.000 |   75.000 |
Slot  8:   75.000 |   75.000 |   75.000 |   75.000 |
Slot  9:   75.000 |   75.000 |   75.000 |   75.000 |
Slot 10:   75.000 |   75.000 |   75.000 |   75.000 |
units = gbps
```

Ensure the following values are observed:

- DPC1 slots show 75.000
- DPC2 slots show 37.500
- MIO slots show 150.000

Any other values should be escalated to Cisco via an SR.

5. ASR 5500 Only, verify the utilization of the Fabric paths:

```
#> show fabric utilization
```

Expected Output:

```
[local]RTP-ARES> show fabric utilization
Sunday October 19 20:59:23 UTC 2014
                         Rx          Tx
----------------------------------------
FAP  1/1   Fabric      0.0159%    0.0152%
FAP  1/2   Fabric      0.0380%    0.3894%
FAP  2/1   Fabric      1.1288%    1.1881%
FAP  2/2   Fabric      1.2889%    1.2351%
FAP  3/1   Fabric      1.2465%    1.1678%
FAP  3/2   Fabric      1.3266%    1.2206%
FAP  4/1   Fabric      1.2877%    1.2312%
FAP  4/2   Fabric      1.3176%    1.2255%
FAP  5/1   Fabric      6.9960%    7.0268%
FAP  5/2   Fabric      6.7397%    6.7562%
FAP  5/3   Fabric      0.0037%    0.0009%
FAP  5/4   Fabric      0.0118%    0.1179%
FAP  6/1   Fabric      0.0000%    0.0008%
FAP  6/2   Fabric      0.0000%    0.0008%
FAP  6/3   Fabric      0.0032%    0.0008%
FAP  6/4   Fabric      0.0012%    0.0549%
FAP  7/1   Fabric      1.2019%    1.1031%
FAP  7/2   Fabric      1.4261%    1.3851%
FAP  8/1   Fabric      1.2024%    1.1407%
FAP  8/2   Fabric      1.4109%    1.3286%
FAP  9/1   Fabric      1.1198%    1.0661%
FAP  9/2   Fabric      1.3062%    1.2103%
FAP 10/1   Fabric      0.0001%    0.0002%
FAP 10/2   Fabric      0.0001%    0.0002%
```

Ensure that none of the listed cards have excessive utilization compared to other cards in the system.

6. ASR 5000 Only, verify the Switch Fabric of the ASR 5000 chassis:

```
#> show sf stats sft
```

Expected Output

```
[local]RTP-ASR5K# show sf stats sft
Sunday October 19 21:09:54 UTC 2014

lost_fails ------------------------------------------------------------------------------+
bonus_fails -----------------------------------------------------------------------+     |
length_fails ----------------------------------------------------------------+     |     |
data_fails ------------------------------------------------------------+     |     |     |
last_valid_packet_number ----------------------------------+        |     |     |     |
valid_rcvd_pkts -------------------------------+        |        |     |     |     |
received_pkts --------------------------+        |        |        |     |     |     |
sent_pkts ----------------------+        |        |        |        |     |     |     |
gen_pkts -------------+        |        |        |        |        |     |     |     |
cpu/inst +            |        |        |        |        |        |     |     |     |
sl       |            |        |        |        |        |        |     |     |     |
 1      0/0 -> 26757021 26757021 26757021 26757021 26757021 ->     0     0     0     0
 2      0/0 -> 26345617 26345617 26345617 26345617 26345617 ->     0     0     0     0
 3      0/0 -> 26705123 26705123 26705123 26705123 26705123 ->     0     0     0     0
 4      0/0 -> 26707048 26707048 26707048 26707048 26707048 ->     0     0     0     0
 5      0/0 -> 26702253 26702253 26702253 26702253 26702253 ->     0     0     0     0
 6      0/0 -> 26703086 26703086 26703086 26703086 26703086 ->     0     0     0     0
 7      0/0 -> 26706768 26706768 26706768 26706768 26706768 ->     0     0     0     0
10      0/0 -> 26705221 26705221 26705221 26705221 26705221 ->     0     0     0     0
11      0/0 -> 26703240 26703240 26703240 26703240 26703240 ->     0     0     0     0
12      0/0 -> 26701973 26701973 26701973 26701973 26701973 ->     0     0     0     0
13      0/0 -> 26708119 26708119 26708119 26708119 26708119 ->     0     0     0     0
14      0/0 -> 5330377 5330377 5330377 5330377 5330377 ->          0     0     0     0
15      0/0 -> 26711346 26711346 26711346 26711346 26711346 ->     0     0     0     0
16      0/0 -> 26706719 26706719 26706719 26706719 26706719 ->     0     0     0     0
```

The right most column "**`lost fails`**" should be "**`0`**" or not incrementing. If the values are incrementing, please escalate to Cisco to immediately begin investigation.

Collecting a Show Support Details

Overview

This section covers how to collect Tech Support information for troubleshooting.

Commands and Outputs

These steps allow the User to collect a “show support details” from the ASR 5000/ASR 5500 chassis.

Note: Make sure CLI session logging has been enabled.

Estimated Time for completion: 5-25 minutes, depends on the configuration of the chassis

1. This command will provide a snapshot of the system:

This version of the command will send the output to the User’s screen:

#> show support details

This version of the command will create a compressed file and save it to the “/flash/” file system on the chassis:

#> show support details to file /flash/<filename> compress

Expected Output:

Sending to the screen:

```
[local]RTP-ASR5K> show support details
Sunday October 19 21:20:07 UTC 2014

******** show version verbose *******
Active Software:
  Image Version:                  15.0 (54944)
```

```
  Image Branch Version:           015.000(019)
  Image Description:              Production_Build
  Image Date:                     Mon May 12 12:12:24 EDT 2014
  Boot Image:                     /flash/production.54944.asr5000.bin
..
```

Sending the SSD to the "/flash" file system of the chassis:

```
[local]RTP-ASR5K> show support details to file /flash/ssd-1019 compress
Sunday October 19 21:24:28 UTC 2014
Are you sure? [Yes|No]: yes
Sunday October 19 21:24:35 UTC 2014
Warning: Changed output URL to file: /flash/ssd-1019.tar.gz
```

This output is helpful when escalating issues to Cisco, and should be taken before any maintenance occurs on the system, after the maintenance is completed, and a few times during any event that may need to be investigated by Cisco.

Platform Troubleshooting

CPU/Memory issues

Overview

This section discusses different types of resources that can be monitored on ASR 5000/ASR 5500.

Description

In the ASR 5000/ASR 5500 chassis, different types of resources are monitored.

- CPU
- Memory
- Files
- Sessions

CPU/Memory

CPU and memory usage are monitored by the system in multiple ways:

- CPU/Memory per card - This is the usage of physical cpu and memory on each card.
- CPU/Memory per process - This is the usage of each process.
- CPU/Memory per system/kernel - This is similar to the first, but from the Linux kernel perspective.

Files

This is a file descriptor opened by a process. The number of file descriptors is monitored by the system. There are also multiple ways the system monitors for files; process level and Linux level.

Sessions

Session counts are applicable to sessmgrs, aaamgrs, and some demux tasks. A new session would be rejected once the max-limit, defined by either the individual task limit or the system license limit, is reached.

CPU/Memory per card

To check cpu/memory usage per card, the following CLI can be used.

- show cpu table - Display cpu/memory usage table.

Below is sample output from an ASR 5500 chassis.

```
# show cpu table
              --------Load--------  ------CPU-Usage-----  ---------Memory--------
cpu   state     now    5min   15min     now    5min   15min    now   5min 15min total
----  -----   ------ ------ ------   ------ ------ ------  ----- ----- ----- -----
3/0   Actve    0.04   0.08   0.19     0.7%   0.7%   0.7%  3181M 3181M 3181M 96.0G
3/1   Actve    0.12   0.22   0.23     0.7%   0.7%   0.7%  3183M 3183M 3184M 96.0G
5/0   Actve    0.61   0.92   0.82     3.0%   3.4%   3.5%  3922M 3923M 3923M 96.0G
6/0   Sndby    1.03   0.49   0.50     2.2%   2.2%   2.2%  3237M 3238M 3238M 96.0G
8/0   Actve    0.70   0.49   0.52     1.1%   1.1%   1.1%  8380M 8381M 8380M 96.0G
8/1   Actve    0.82   0.57   0.58     1.1%   1.1%   1.1%  8328M 8330M 8329M 96.0G
9/0   Actve    0.64   0.51   0.53     1.1%   1.1%   1.1%  7921M 7922M 7922M 96.0G
9/1   Actve    0.68   0.58   0.57     1.1%   1.1%   1.1%  8342M 8343M 8343M 96.0G
```

Load	Number of processes waiting to be processed
CPU-Usage	CPU usage of each CPU sub-system
Memory	Memory usage of each CPU sub-system

CPU/Memory per process

To check cpu / memory usage per process, the following CLI commands can be used:

- show task resources - All processes in the system will be listed.
- show task resources max - Displays the maximums for tasks rather than current usage.
- show task resources facility [facility name] - Limits to a specific facility.
- show task resources card [card num] - Specific card number.
- show task memory - Dedicated for memory usage.

Below is a sample output from ASR 5500 chassis.

```
# show task resources
                    task    cputime        memory     files      sessions
cpu facility      inst used allc   used  alloc used allc  used  allc S status
----------------------- --------- ------------- --------- ------------- ------
3/0 sitmain         30 0.1%  15%  8.52M 24.00M   13 1000    --    -- -   good
3/0 sitparent       30 0.1%  20%  9.34M 14.00M   10  500    --    -- -   good
3/0 hatcpu          30 0.2%  10%  8.21M 24.00M   11  500    --    -- -   good
3/0 afmgr           30 0.1%  10% 11.76M 20.00M   13  500    --    -- -   good
3/0 rmmgr           30 0.7%  15% 13.61M 23.00M  209  500    --    -- -   good
3/0 hwmgr           30 0.2%  15%  8.38M 15.00M   12  500    --    -- -   good
3/0 dhmgr           30 0.1%  15% 15.97M 35.00M   20 6000    --    -- -   good
3/0 connproxy       30 0.1%  90% 10.51M 35.00M   11 1000    --    -- -   good
3/0 dcardmgr        30 0.2%  60% 41.44M 600.0M   12  500    --    -- -   good
3/0 npumgr          30 0.4% 100% 479.0M  2.27G   22 1000    --    -- -   good
3/0 npusim         301 0.1%  33% 13.90M 60.00M   12  500    --    -- -   good
3/0 sft            300 0.1%  50% 12.42M 30.00M   10  500    --    -- -   good
3/0 vpnmgr           2 0.1% 100% 25.11M 57.20M   30 2000    --    -- -   good
3/0 zebos            2 0.0%  50% 11.95M 25.00M   15 1000    --    -- -   good
```

In the output above CPU / Memory usage per process can be seen. Note that each process has an allocated value and a currently used value. Inside StarOS there is a resource management subsystem (resctrl/resmgr) that assigns a set of resource limits for each process in the system. These limits can't be changed by the user.

If a process exceeds the limit on CPU, Memory, or Files, the status will be changed from "good" to "warn" or "over" depending on how much the process exceeds the limit. Please note, seeing a task in "warn" or "over" does not necessarily mean there is a problem. The limits are just for monitoring, and the process will continue to work even after violating the limit. If a process stays at or near 100% CPU usage, or the memory usage keeps growing, the task(s) should be investigated to see if there is an issue.

CPU/Memory per system/kernel

- show cpu info - Display detailed info of CPU.
- show cpu info verbose - More detailed version of the above.

Below is a sample output from an ASR 5500 chassis.

```
# show cpu info verbose
Card 3, CPU 0:
  Status                : Active, Kernel Running, Tasks Running
  Load Average          : 0.20, 0.22, 0.22 (1.51 max)
  Total Memory          : 98304M (49152M node-0, 49152M node-1)
  Kernel Uptime         : 12D 1H 20M
  Last Reading:
   CPU Usage All       : 0.6% user, 0.1% sys, 0.0% io, 0.0% irq, 99.3% idle
      Node 0            : 0.5% user, 0.1% sys, 0.0% io, 0.0% irq, 99.4% idle
        Core 0          : 0.1% user, 0.3% sys, 0.0% io, 0.0% irq, 99.6% idle
        Core 12         : 0.1% user, 0.2% sys, 0.0% io, 0.0% irq, 99.7% idle
        Core 1          : 0.0% user, 0.1% sys, 0.0% io, 0.0% irq, 99.9% idle
        Core 13         : 0.2% user, 0.4% sys, 0.0% io, 0.0% irq, 99.4% idle
        Core 2          : 0.1% user, 0.0% sys, 0.0% io, 0.0% irq, 99.9% idle
        Core 14         : 0.0% user, 0.0% sys, 0.0% io, 0.0% irq, 100.0% idle
        Core 3          : 0.0% user, 0.0% sys, 0.0% io, 0.0% irq, 100.0% idle
        Core 15         : 0.0% user, 0.0% sys, 0.0% io, 0.0% irq, 100.0% idle
        Core 4          : 4.7% user, 0.1% sys, 0.0% io, 0.1% irq, 95.1% idle
        Core 16         : 0.2% user, 0.1% sys, 0.0% io, 0.0% irq, 99.7% idle
        Core 5          : 0.1% user, 0.1% sys, 0.0% io, 0.0% irq, 99.8% idle
        Core 17         : 0.1% user, 0.1% sys, 0.0% io, 0.0% irq, 99.8% idle
      Node 1            : 0.6% user, 0.1% sys, 0.0% io, 0.0% irq, 99.2% idle
        Core 6          : 5.7% user, 0.2% sys, 0.0% io, 0.1% irq, 94.0% idle
        Core 18         : 0.3% user, 0.0% sys, 0.0% io, 0.0% irq, 99.7% idle
        Core 7          : 0.0% user, 0.2% sys, 0.0% io, 0.0% irq, 99.8% idle
        Core 19         : 0.0% user, 0.1% sys, 0.0% io, 0.0% irq, 99.9% idle
        Core 8          : 0.0% user, 0.0% sys, 0.0% io, 0.0% irq, 100.0% idle
        Core 20         : 0.0% user, 0.1% sys, 0.0% io, 0.0% irq, 99.9% idle
        Core 9          : 1.4% user, 0.1% sys, 0.0% io, 0.0% irq, 98.5% idle
        Core 21         : 0.0% user, 0.2% sys, 0.0% io, 0.0% irq, 99.8% idle
        Core 10         : 0.0% user, 0.0% sys, 0.0% io, 0.0% irq, 100.0% idle
        Core 22         : 0.1% user, 0.1% sys, 0.0% io, 0.0% irq, 99.8% idle
        Core 11         : 0.2% user, 0.1% sys, 0.0% io, 0.1% irq, 99.6% idle
        Core 23         : 0.0% user, 0.1% sys, 0.0% io, 0.0% irq, 99.9% idle
    Processes / Tasks   : 213 processes / 19 tasks
    Network cpeth0      : 0.090 kpps rx, 0.102 mbps rx, 0.064 kpps tx, 0.442 mbps tx
      [ High res sample : 0.097 kpps rx, 0.105 mbps rx, 0.064 kpps tx, 0.067 mbps tx ]
```

```
    Network cpeth1       : 0.075 kpps rx, 0.093 mbps rx, 0.043 kpps tx, 0.037 mbps tx
      [ High res sample : 0.081 kpps rx, 0.096 mbps rx, 0.051 kpps tx, 0.044 mbps tx ]
    Network mcdma0       : 0.000 kpps rx, 0.000 mbps rx, 0.000 kpps tx, 0.000 mbps tx
    Network mcdma1       : 0.000 kpps rx, 0.000 mbps rx, 0.000 kpps tx, 0.000 mbps tx
    Network mcdma2       : 0.000 kpps rx, 0.000 mbps rx, 0.000 kpps tx, 0.000 mbps tx
    Network mcdma3       : 0.000 kpps rx, 0.000 mbps rx, 0.000 kpps tx, 0.000 mbps tx
    Network mcdmaN       : 0.000 kpps rx, 0.000 mbps rx, 0.000 kpps tx, 0.000 mbps tx
    Network Total        : 0.166 kpps rx, 0.195 mbps rx, 0.108 kpps tx, 0.480 mbps tx
    File Usage           : 1056 open files, 9899609 available
    Memory Usage         : 3180M 3.2% used (1549M 3.2% node-0, 1630M 3.3% node-1)
    Memory Details:
      Static             : 1438M kernel, 177M image
      System             : 8M tmp, 0M buffers, 185M kcache, 70M cache
      Process/Task       : 1260M (126M small, 688M huge, 446M other)
      Other              : 38M shared data
```

In the output, as highlighted, is the cpu / memory usage at the Linux kernel level. For cpu, the following can be checked:

user	User process
sys	Kernel process
io	Waiting for I/O completion
irq	Interrupts
idle	Idle time

If there is high cpu usage, check the following. For example, the high CPU in the output below is being caused by IO.

```
Card 5, CPU 0:
  Status               : Active, Kernel Running, Tasks Running
  Load Average         : 531.06, 529.32, 524.18 (531.06 max)
  Total Memory         : 98304M
  Kernel Uptime        : 23D 8H 23M
  Last Reading:
    CPU Usage All      : 6.1% user, 3.8% sys, 80.6% io, 1.8% irq, 7.7% idle
```

```
Core 0          : 7.0% user, 6.9% sys, 83.5% io, 2.6% irq, 0.0% idle
Core 6          : 6.4% user, 5.4% sys, 84.7% io, 3.5% irq, 0.0% idle
Core 1          : 4.1% user, 3.3% sys, 91.4% io, 1.2% irq, 0.0% idle
Core 7          : 4.2% user, 4.3% sys, 90.6% io, 0.9% irq, 0.0% idle
Core 2          : 4.9% user, 2.8% sys, 90.8% io, 1.5% irq, 0.0% idle
Core 8          : 6.0% user, 1.9% sys, 91.1% io, 1.0% irq, 0.0% idle
Core 3          : 3.3% user, 3.7% sys, 91.3% io, 1.7% irq, 0.0% idle
Core 9          : 3.0% user, 1.8% sys, 94.4% io, 0.8% irq, 0.0% idle
Core 4          : 4.2% user, 2.1% sys, 0.0% io, 1.0% irq, 92.7% idle
Core 10         : 4.7% user, 2.8% sys, 90.1% io, 2.4% irq, 0.0% idle
Core 5          : 8.8% user, 5.8% sys, 83.3% io, 2.1% irq, 0.0% idle
Core 11         : 16.6% user, 5.0% sys, 75.8% io, 2.6% irq, 0.0% idle
```

An important command for live troubleshooting provides graphs per values reported in the command:

```
show cpu performance verbose graphs
```

> The above CLI command requires CLI test-commands password configured in the chassis.
> Please use the command with caution! Many **TEST** commands are processor-intensive and can cause serious system problems if used too frequently.

Troubleshooting for CPU/Memory issues

CPU

For high CPU issues, refer to the following commands:

- show task resources - Check if any proclet goes warn/over state.
- show task resource max - Check max usage rather than current usage.
- show snmp trap history - Check if there is any CPUWarn/Over event.

- show profile - This is the background cpu profiler. This command allows checking which functions consume the most CPU time. This command will require cli test-command password.

Below is a sample output of show profile. The facility, instance, card, or more can be specified with this command. For depth option, 4 is the recommended value.

```
# show profile facility sessmgr instance 1 depth 4
 100.0%          1  libc.so.6/poll()
                   [0aa82edb/X] sn_loop_run()
                   [0a86d7c4/X] main()
Total samples collected: 1# irq, 0.0% idle
```

Below are examples of snmp traps related to memory usage.

```
 Internal trap notification 1220 (CPUOverClear) facility cli instance 5010294 card 5 cpu 0
allocated 600 used 272
 Internal trap notification 1216 (CPUWarnClear) facility cli instance 5010294 card 5 cpu 0
allocated 600 used 272
 Internal trap notification 1215 (CPUWarn) facility cli instance 5010317 card 5 cpu 0 allocated
600 used 595
 Internal trap notification 1216 (CPUWarnClear) facility cli instance 5010317 card 5 cpu 0
allocated 600 used 220
```

Memory

For high memory issues, please see the following CLI commands. For the last 2 commands in the list, please capture multiple iterations over a consistent time interval, every 15 minutes for 4 iterations for example.

- show task resources - Check if any process goes warn/over state
- show task resource max - Check max usage rather than current usage
- show snmp trap history - Check if there is any MemoryWarn/Over event
- show logs - Check if there is any warning/error reported by resmgr
- show messenger proclet facility <name> instance <x> heap - Check heap usage of the process

- show messenger proclet facility <name> instance <x> system heap - Check system heap information for containing process

For example, if sessmgr 2 and mmemgr 3 are in warn or over state, the following would be required:

- show messenger proclet facility sessmgr instance 2 heap
- show messenger proclet facility sessmgr instance 2 system heap
- show messenger proclet facility mmemgr instance 3 heap
- show messenger proclet facility mmemgr instance 3 system heap
- show messenger commands requires CLI test-commands password

Below are examples of snmp traps related to memory usage.

```
 Internal trap notification 1221 (MemoryOver) facility sessmgr instance 16 card 1 cpu 0
allocated 204800 used 220392
 Internal trap notification 1222 (MemoryOverClear) facility sessmgr instance 16 card 1 cpu 0
allocated 1249280 used 219608
 Internal trap notification 1217 (MemoryWarn) facility npudrv instance 401 card 5 cpu 0
allocated 112640 used 119588
 Internal trap notification 1218 (MemoryWarnClear) facility cli instance 5011763 card 5 cpu 0
allocated 56320 used 46856
```

Message Bounces

Bounces occur when the system is busy or tasks are not available (not started or recovering), and messages between subsystems do not reach the intended recipient. These bounces can be used to help determine where messages got lost (one subsystem or the other). Message code will indicate whether the recipient was not present or whether the recipient was busy (timeout).

Bounces typically happen due to software issues on tasks, but they are also indicators which can be used to isolate a problem to a single card. It is good to check if bounces frequently occur for specific card-destinations or task instances which could indicate a problem for a specific card or instance.

"show messenger bounces" requires CLI test-commands password

Memory leak / fragmentation

It's important to understand that there are 2 different reasons why the process memory consumption exceeds its assigned limit: memory leak and memory fragmentation.

Memory leak

If a process continues to allocate memory, but doesn't release it to the task, it will continue to consume more and more memory resources. This is classified as a memory leak. In this situation, the memory consumption will keep increasing, and sooner or later the process will outgrow not just its allocated limit, but also the actual available memory on the card. To troubleshoot memory leak issues, following CLI outputs are required.

- show messenger proclet facility <name> instance <x> heap
- show messenger proclet facility <name> instance <x> system heap

Above CLI commands requires CLI test-commands password.

Fragmentation

If a task does not appear to be leaking memory, but is over its specified system limits, as seen in "show task resources" output, it could be that the task has fragmented memory allocation. Memory fragmentation is usually a result of repetitive allocation/freeing of small memory blocks. This creates many free chunks without any of them big enough to be re-used. To troubleshoot memory fragmentation issues, following CLI outputs are required.

- show messenger proclet facility <name> instance <x> heap
- show messenger proclet facility <name> instance <x> system heap



The above CLI commands requires CLI test-commands password configured in the chassis.
Please use the command with caution! Many **TEST** commands are processor-intensive and can cause serious system problems if used too frequently.

Generating a core file

In some cases, generating a core file for a process is useful in troubleshooting high cpu / memory issues. For example, to generate a core file for sessmgr instance 1, use the command below:

- task core facility sessmgr instance 1

Above CLI command requires CLI test-commands password

Make sure "crash enable" is properly configured when issuing the above CLI.

Console Logs

If SSD is collected, please inspect the **debug console card <> cpu <> tail 10000 only** command output for the relevant card(s) and observe if there are any recent kernel messages. If present, these may provide an indication of resource issues. Please note that in older versions of StarOS, the beginning of the lines in the console logs are Unix timestamps.

Above CLI command requires CLI test-commands password

Following is an example of how to translate unixtime into UTC with date command on any Linux server:

```
date -d @1376209406.298 -u Sun Aug 11 08:23:26 UTC 2013
```

Use http://www.epochconverter.com/ to convert unix time to human readable text or use below shell script in Linux M/c.

Action Plan for high CPU issues:

The following is standard information required to troubleshoot any task with high CPU. The following commands are not intrusive to the system, but it is highly recommended to run them during a Maintenance Window (MW) only.

CLI commands below require the CLI test-commands password:

- show task resources table - Check which task is utilizing high CPU
- Collect the output of the following commands in hidden mode: "show profile facility <task-facility> active instance <instance> depth 1" where depth could be 1,4 and/or 8
- Collect the core dump for any of the affected tasks with high CPU using "task core facility <task-facility> instance <instance-value>"
- Collect SSD when some process/facility is facing high CPU state.

Action Plan for memory leak issues:

The following is standard information required to troubleshoot SessMgr memory leak issues. The same commands would be applicable for other software tasks as well. The commands are not intrusive to the system, but it is highly recommended to run them during Maintenance Window (MW) only.

> The below CLI commands requires CLI test-commands password configured in the chassis.
> Please use the command with caution! Many **TEST** commands are processor-intensive and can cause serious system problems if used too frequently.

- Collect SSD when SESSMGR instance is in warn/over state
- Collect the core dump for any of the affected sessmgr using "task core facility sessmgr instance <instance-value>"
- Collect the output of the following commands in test mode:
  - show messenger proclet facility sessmgr instance <instance-value> heap depth 9
  - show messenger proclet facility sessmgr instance <instance-value> system heap depth 9
  - show messenger proclet facility sessmgr instance <instance-value> heap
  - show messenger proclet facility sessmgr instance <instance-value> system
  - show snx sessmgr instance <instance-value> memory ldbuf
  - show snx sessmgr instance <instance-value> memory mblk
  - show session subsystem facility sessmgr instance <instance-value> debug-info verbose
  - show task resources facility sessmgr instance <instance-value>
  - show messenger proclet facility sessmgr instance <instance-value> graphs heap
- Collect output of following CLIs:
  - show ssi mem facility sessmgr instance <>
  - show ssi mem facility sessmgr instance <> verbose

In some cases it is necessary to collect several iterations of the same commands periodically in order to observe which region of memory is increasing. It is highly recommended to monitor the "show task memory" commands and observe any increase on a daily basis.

If a task crashes due to exhausting the physical memory of a card, or from being way over its defined limits, it is possible that the core files generated from the crash will be too big. Please refer to the section related to crashes and how to increase maximum crash size. In extreme cases, it may be required to capture the core prior to hitting memory maximum.

Licensing

Overview

StarOS requires a proper license to be installed for operation. License keys define capacity limits (number of allowed subscriber sessions) and available features on the system. Universal type cards, such as UDPC / UMIO on ASR 5500 require a card license as well.

To check the license on a system, use the CLI command "**show license info**".

Features

```
Enabled Features:
  Feature                                          Applicable Part Numbers
  -----------------------------------------------  ---------------------------
  IPv4 Routing Protocols                           [ none ]
  Enhanced Charging Bundle 2:                      [ 600-00-7574 ]
   + DIAMETER Closed-Loop Charging Interface       [ None ]
   + Enhanced Charging Bundle 1                    [ 600-00-7526 ]
  Session Recovery                                 [ 600-00-7513 / 600-00-7546
                                                     600-00-7552 / 600-00-7554
                                                     600-00-7566 / 600-00-7594
                                                     600-00-9100 / 600-00-9101
                                                     600-00-7638 / 600-00-7640
                                                     600-00-7634 / 600-00-7595
                                                     600-00-7669 / None
                                                     600-00-7897 / None
                                                     600-20-0145 / None
                                                     None / None
                                                     None ]
```

Sessions

```
Session Limits:
               Sessions  Session Type
               --------  ----------------------
                  50000  ECS
                  50000  PGW
```

Cards

```
CARD License Counts:
                Cards    License Type
                -------  ----------------------
                      4  ASR5500 Initial System SW, Per UDPC
                      2  ASR5500 Initial System SW, Per UMIO
```

How to install a new license

Several features of the ASR 5000/ASR 5500 can be used only when a license is installed. The license can be obtained only from Cisco.

When the license is received, cut the text portion where indicated and paste it in configuration mode as below:

```
[local]ASR5000(config)# license key   <A string> of size 100 to 2000
```

Verify that the license is properly installed with "show license info". Save the configuration as appropriate. Then synchronize the file system so the configuration file will be copied to the flash card in the standby management module.

```
[local]ASR5000# filesystem synchronize all
```

Log Collection

- show license info - To check what license is installed.

- show license key - To check license key itself.
- show resources session - To check session count is under the limit.
- syslog - To check if there is any license-related log.
- snmp traps - To check if there is any license-related trap.
- show card hardware - To check serial numbers required for license.

Example Scenarios

Session count limits

Problem:

If the following license is installed, then new calls still can be established.

Always On Licensing [600-20-0111]

Logs and snmp traps similar to those shown below will be written if a license limit is exceeded:

```
 Sat Feb 21 23:13:32 2015 Internal trap notification 65 (LicenseExceeded) license exceeded for Enhanced Charging Service service; current sessions 1010 exceeds license 1000
 Sat Feb 21 23:13:32 2015 Internal trap notification 65 (LicenseExceeded) license exceeded for PGW service; current sessions 1010 exceeds license 1000
```

```
 2015-Feb-21+23:13:32.251 [resmgr 14566 info] [5/0/27652 <rmctrl:0> ource_session.c:5136] [software internal system critical-info syslog] The license limit for the PGW service has been reached. In Use 1010, Limit 1000. License suppression tuned on, still accepting new PGW calls
2015-Feb-21+23:13:32.251 [resmgr 14566 info] [5/0/27652 <rmctrl:0> ource_session.c:5136] [software internal system critical-info syslog] The license limit for the ECSv2 service has been reached. In Use 1010, Limit 1000. License suppression tuned on, still accepting new ECSv2 calls
```

If the "Always on" license is not installed, new calls would be rejected, and the logs and snmp traps below will be seen:

```
 Sat Feb 21 23:21:52 2015 Internal trap notification 65 (LicenseExceeded) license exceeded for
```

```
Enhanced Charging Service service; current sessions 1010 exceeds license 1000
 Sat Feb 21 23:21:52 2015 Internal trap notification 65 (LicenseExceeded) license exceeded for
PGW service; current sessions 1010 exceeds license 1000
```

```
 2015-Feb-21+23:21:52.251 [resmgr 14530 warning] [5/0/27652 <rmctrl:0> ource_session.c:5138]
[software internal system critical-info syslog] The license limit for the PGW service has been
reached. In Use 1010, Limit 1000.  No new PGW calls can be accepted until usage drops or
license is increased.
 2015-Feb-21+23:21:52.251 [resmgr 14530 warning] [5/0/27652 <rmctrl:0> ource_session.c:5138]
[software internal system critical-info syslog] The license limit for the ECSv2 service has
been reached. In Use 1010, Limit 1000.  No new ECSv2 calls can be accepted until usage drops or
license is increased.
```

The "**show resources session**" command indicates where current session levels are relative to license limits..

```
# show resources session
Session Information:
  In-Use Session Managers:
    Number of Managers  : 6
    Capacity            : 52800 min / 105600 typical / 211200 max
    Usage               : 1010
  Busy-Out Session Managers:
    Number of Managers  : 0
    Capacity            : 0 min / 0 typical / 0 max
    Usage               : 0
  Standby Session Managers:
    Number of Managers  : 7
  Per-Service "Max Used" values last cleared : Never
  PGW Service:
    In Use              : 1010
    Max Used            : 1010 ( Saturday February 21 23:13:32 EST 2015 )
    Limit               : 1000
    License Status      : Over License Capacity (Rejecting Excess Calls)
ECS Information:
  Enhanced Charging Service Service:
    In Use              : 1010
```

```
Max Used            : 1010 ( Saturday February 21 23:13:32 EST 2015 )
Limit               : 1000
License Status      : Over License Capacity (Rejecting Excess Calls)
```

License issue

Problem Description:

The license key needs to match a stored value in hardware.

For ASR 5500: The Midplane serial number is stored in the MEC which resides in the chassis. For ASR 5500, there is no need to regenerate a new license unless the chassis will be replaced.

For ASR 5000: The serial number of the CompactFlash on each SMC is checked against the license key.

For ASR 5000, in the event that an individual SMC is replaced, the CompactFlash card on the new SMC must be exchanged with the
CompactFlash from the original SMC. This will preserve the validity of the license key as it is tied to the serial number of the CompactFlash card associated with the original SMC.

If the licenses do not match, then the following message will be seen with the "show license info" output:

ASR 5000

```
Device 1              Matches card 8 flash
Device 2              Does not match
License Status        Good (Not Redundant)
```

ASR 5500

```
Chassis MEC SN        Does not match
License Status        Not Valid [In Grace Period]
Grace Period Ends     Tuesday March 24 00:43:14 EDT 2015
```

Logging

```
 2015-Feb-21+23:43:22.251 [resmgr 14571 warning] [5/0/27652 <rmctrl:0> ource_license.c:1537]
[software internal system critical-info syslog] License status changed to: invalid [grace
period]. It does not match either card.
```

Specific feature(s) not configurable

Problem Description

If the CLI commands for a particular feature are either not present, or the CLI is reporting errors upon entering them, it could be the required feature license is missing. In most cases, if the license for the feature is missing, the CLI associated with the feature will not be viewable in the CLI:

```
Without ICSR license:
# se?
  server               - Configures remote server protocols and parameters
  session-event-module - Creates the Session Event Records
With ICSR license:
# se?
  server               - Configures remote server protocols and parameters
  service-redundancy-protocol - Configure the Service Redundancy Protocol (SRP)
  session-event-module - Creates the Session Event Records
```

If the chassis license is overwritten with a new version that does not include features which were present in the old license, those configurations will be lost. If loading a new license on to an existing Production system, please compare the feature sets documented in the material that comes from Cisco with the new license to the "show license info" from the chassis which the new license is going to be loaded onto. Check to make sure the new license includes all features of the old one. There may be some cases, for example if a feature is being turned off, where the new license may not have everything of the old one.

HD RAID

Overview

ASR 5000/ASR 5500 has hard drives in certain cards which are used to store different information. In this chapter, hard disk architecture in both platforms, and how to troubleshoot raid issues are covered.

Description of HD-Raid for ASR 5000


A RAID (Redundant Array of Independent Disks) is a storage technology that combines multiple disks into a single logical unit.

In the ASR 5000 the RAID HD (Hard Disk) is used to store data, specially CDR records.

The HD Raid is hosted on the SMC cards. Each SMC has two disks of 147 GB each.

The ASR 5000 RAID disks are called hd-local1 (active SMC) and hd-remote-1 (standby SMC). The disk partition has a total size of 146 GB using RAID1 (1+1) disks.

Image - ASR 5000 RAID Interconnection




Description of HD-Raid for ASR 5500

In the ASR 5500, the storage is located in the FSC (Fabric and Storage Cards) cards. A minimum of three FSCs is required, and a maximum of six FSCs are supported. Although four FSCs are required for redundancy, the system can operate with three FSCs in the presence of a fourth failed FSC. Four FSCs must be installed for normal operation. The drive size is 200 GB and there are 2 dual port SSD drives.

In the ASR 5500 the disks are called hd13, hd14, hd15 etc. The total capacity of the RAID depends on the number of FSC cards.

Image - ASR 5500 RAID Interconnection



HDCTRL task. The hard disk controller task is called HDCTRL. It is responsible for disk management, RAID setup, file system management and Network File System (NFS) support. It also provides disk monitoring, file synchronization, basic free space management and simple cleanup support.

Troubleshooting HD RAID

The following are general troubleshooting commands that are useful for troubleshooting of HD RAID issues:

- show hd raid verbose - Check HD RAID status
- show card table - Check card's status
- show card hardware - Check a card's hardware
- show active-charging edr-udr-file statistics / show cdr statistics
- dir /hd-raid/records/ - Check billing records
- show snmp trap history verbose - Monitor recent traps related to RAID
  e.g. RaidDegraded

> The below CLI commands requires CLI test-commands password configured in the chassis.
> Please use the command with caution! Many **TEST** commands are processor-intensive and can cause serious system problems if used too frequently.

- debug hdctrl lssas - Check physical links
- show hd smart - Check Self-Monitoring, Analysis and Reporting Technology (SMART) statistics for hard drives

Please refer to the Console Logs in the CPU/Memory Issues chapter for additional troubleshooting steps.

Example Sceanrios

Uncorrected errors incrementing in HD Raid

Problem Description:

Total uncorrected errors incrementing continuously with the command "show hd smart ...":

Logs collected:

```
Error counter log:
           Errors Corrected by           Total   Correction     Gigabytes    Total
               ECC          rereads/    errors   algorithm      processed    uncorrected
           fast | delayed   rewrites  corrected  invocations   [10^9 bytes]  errors
```

```
read:          0         0         0         0         0     135681.146          31554
write:         0         0         0         0         0       5250.918          4564
```

Resolution:

If the errors are incrementing continuously, the hardware must be replaced; contact Cisco for assistance.

Problem Description:

In ASR 5000, HD RAID is in 'degraded' state.

When chassis detects RAID is degraded, it will trigger the following snmp trap:

```
Internal trap notification 1079 (RaidDegraded) Raid array hd-raid degraded
```

CLI command '**show hd raid verbose**' shows if RAID is degraded or not:

```
[local] HA# show hd raid verbose
HD RAID:
  State                     : Available (clean)
  Degraded                  : Yes
  UUID                      : 954baf46:1198a1bb:c085fdd9:0a56c169
  Size                      : 146000000000 bytes
  Action                    : Idle
  Disk                      : hd-local1
    Created                 : Tue Apr 27 05:56:53 2010
    Updated                 : Sat Sep 24 13:54:45 2011
    Events                  : 1213068
    Model                   : SEAGATE-ST9146802SS
    Serial Number           : 3NM1DKT8000000000SYS
    Location                : SMC8 PLB00000000
    Size                    : 146815737856 bytes
    Partitions              : 1
      Partition 1           : 146006913024 bytes or 285169752 sectors
  Disk                      : hd-remote1
    State                   : In-sync component
```

```
Created                 : Tue Apr 27 05:56:53 2010
Updated                 : Sat Sep 24 14:02:42 2011
Events                  : 1213324
Model                   : SEAGATE-ST0000000SS
Serial Number           : 3NM1SZKN000000000HL
Location                : SMC9 PLB00000000
Size                    : 146815737856 bytes
Partitions              : 1
Partition 1           : 146006913024 bytes or 285169752 sectors
```

Analysis:

The HD RAID should be re-synched to clear degradation state during a maintenance window.

Resolution:

In ASR 5000, the hard drive being formatted/overwritten must be on an SMC in Standby mode on a production chassis. Change SMC mode from active if necessary before beginning the format / overwrite operations.

- Confirm the card that's faulty is in standby mode. In the above example, it is card 8. Make card 9 active and card 8 as standby using the command 'card switch from 8 to 9'. Make sure that "hd-remote1" is showing "Valid image".
- Open a second connection to the chassis and active logging for hdctrl to monitor formatting/overwriting progress using the following commands

```
# logging filter active facility hdctrl level info
 # logging active
```



Be aware that the operations below may have an impact

- Below CLI command requires CLI test-commands password configured in the chassis.
- Overwrite standby SMC's hard drive (remote1) using:

```
# hd raid overwrite remote1
```

- If command fails then try to reset the remote1 using the command:

```
# hd raid reset-phy remote1
```

- Repeat overwrite command with:

```
# hd raid overwrite remote1
```

- Verify the sync process using:

```
# show hd raid verbose
```

The logging in the second connection will show the progress as well.

- In the second connection disable logging with:

```
# no logging active
```

FSC card out of sync

Problem Description:

In ASR 5500 a FSC card is out of sync.

Analysis:

Overwrite hard drive and re-synch RAID during a maintenance window.

Resolution:

- Check HD RAID

```
# show hd raid verbose.
```

- Open second connection to the chassis and active logging for hdctrl to monitor overwrite progress:

```
# logging filter active facility hdctrl level info
 # logging active
```

- Below CLI command requires CLI test-commands password configured in the chassis.
- Overwrite hard drive with the issue (e.g. hd14, hd15, hd16, hd17)

Be aware that the operations below may have an impact

```
# hd raid overwrite < hd14, hd15, hd16, hd17>
```

- Check overwrite progress with "show hd raid verbose". The logging will show overwrite progress as well.
- Disable logging in second connection:

```
# no logging active
```

Firmware upgrade Warning Logs for HD

Problem Description:

Following logs observed in the syslogs for FSC cards.

```
 2014-Dec-10+00:19:17.899 [hdctrl 132018 warning] [6/0/18682 <hdctrl:0> ctrl_fsm_disk.c:2435]
[software internal system critical-info syslog] Disk hd16a (STEC Z0000000-200UCU E46E) needs
firmware upgrade!
```

Analysis:

In the output above the hard drive firmware on the disk, hd16a should be upgraded during the maintenance window (MW).

Disk firmware upgrade. When HDCTRL issues the following warnings, the firmware of hard drive (HD) on a FSC card may be upgraded but most likely the data on disk would be wiped out, so the effect looks like formatting, and the procedures are similar.

HD firmware upgrade must be done one card at a time - do NOT start upgrade on another card utill it finished previous one.

Resolution:

- Check HD RAID, it has to be in non-degraded state. Do not start the following procedures with degraded HD RAID.

```
show hd raid verbose
```

The below CLI commands requires CLI test-commands password configured in the chassis.
Please use the command with caution! Many **TEST** commands are processor-intensive and can cause serious system problems if used too frequently.

- Remove FSC from RAID. This is needed before a firmware upgrade. To preserve RAID data, make sure RAID is not degraded before issuing this command:

```
# hd raid remove hd16 -force
```

Note that "-force" is needed to disable RAID0 on the two disks for further steps, and the command should be executed even if a previous "hd raid remove hd16" had been executed (without "-force").

- Upgrade firmware of both disks:

```
# debug hdctrl upgrade-firmware hd16a
 # debug hdctrl upgrade-firmware hd16b
```

Note that disks will be power cycled. Insert FSC back to RAID if needed:

```
# hd raid insert hd16
```

Note that this is needed only when trying to preseve RAID data. Do not reload the chassis while RAID is being rebuilt.

- Check status with the command below:

```
# show hd raid verbose
```

Software Crashes

Overview

As with any software, there are times when situations arise in processing where the underlying logic fails and the software task must restart itself to get back to proper working order. This section details how to check for such crash events in the system, and the information to collect so issues resulting in crashes can be addressed by Cisco.

Troubleshooting Commands

Use the commands below to get more information about crashes on the system:

- show crash list
- show crash number [number].

When reporting this crash to Cisco TAC support, the following info needs to be collected:

- show support details to file /flash/[name].tar.gz compress
  - this archive will contain SSD support file and minicore files
- core dump of the crash

A **minicore** file contains information about the failing task like current stack-trace, past profiler samples, past memory-activity samples, and a few other things bundled into a proprietary file-format.

A **Core dump** (or full core) provides a full memory dump of the process immediately after the crash condition was encountered. This memory dump is often crucial to find the root cause of the software crash.

Interpretations and collection of show crash list

The indication that some process has crashed is the TaskFailed SNMP trap. Example of SNMP traps in the **show snmp trap history verbose** command:

```
 Fri Dec 26 08:32:20 2014 Internal trap notification 73 (ManagerFailure) facility sessmgr
instance 188 card 7 cpu 0
 Fri Dec 26 08:32:20 2014 Internal trap notification 150 (TaskFailed) facility sessmgr instance
188 on card 7 cpu 0
 Fri Dec 26 08:32:23 2014 Internal trap notification 1099 (ManagerRestart) facility sessmgr
instance 139 card 4 cpu 1
 Fri Dec 26 08:32:23 2014 Internal trap notification 151 (TaskRestart) facility sessmgr
instance 139 on card 4 cpu 1
```

Please monitor logs for the following message after a crash [show logs]:

```
 2015-Apr-14+15:11:39.497 [sitmain 4090 warning] [5/0/7167 <sitparent:50> crashd.c:889]
[software internal system critical-info syslog] No full core destination configured; not
collecting core
```

If the above log is seen, it indicates that a location for full cores is not configured. Full cores are often essential for a quick and complete analysis of software crash issues. Please be sure to configure a destination where the system can send full cores. This can be done via the following config level CLI:

```
[local]asr5k(config)# crash enable url
  One of: [file:]{/flash | /usb1 | /hd-raid}[/directory]/<filename>
   tftp://<host>[:<port>][/<directory>]/<filename
   ftp://[<username>[:<password>]@]<host>[:<port>][/<directory>]/<filename
   sftp://[<username>[:<password>]@]<host>[:<port>][/<directory>]/<filename
```

Make sure there is space available for storing core files. To double check current crash config use the following command (requires CLI test command password):

```
[local]asr5000# show crash config
```

The following is the output of the **show crash list** command:

```
 ******** show crash list  *******
Friday April 17 08:47:01 CEST 2015
=== ==================== ======== ========== =============== ======================
#            Time          Process  Card/CPU/         SW           HW_SER_NUM
                                        PID          VERSION       SMC / Crash Card
=== ==================== ======== ========== =============== ======================

1   2015-Mar-13+12:48:09 cli      08/0/31785 17.1.1          PLB44074916/PLB24084505
2   2015-Apr-13+20:30:32 sessmgr  05/0/10215 17.1.1          PLB44074916/PLB16105979
3   2015-Apr-15+15:00:50 sessmgr  06/0/06238 17.1.1          PLB44074916/PLB26096444
4   2015-Apr-17+04:28:56 sessctrl 08/0/23156 17.1.1          PLB44074916/PLB24084505

Total Crashes : 25&#10
```

The name of the core-file itself is: crash-<card>-<cpu>-<unixtime>-core

similar for mini core: mc-crash-<card>-<cpu>-<unixtime>-core

The unixtime is the unix-epoch in hex. This timestamp can be compared, along with the card number and time from the show-crash listing, to identify which full core maps to which crash. If 2 crashes happen on the same card/cpu around the same timeframe, only the first crash will generate a core. The system cannot generate more than one core file at a time.

For example in the core file 'crash-07-00-**5343ad73**-core', when the core is generated can be identified by using the following simple Linux shell script.

http://www.epochconverter.com/ also can be used to convert unix time to GMT.

```
export TZ=UTC;
date -d @`printf %d 0x5343ad73`;
 Tue Apr  8 08:04:03 UTC 2014;
```

Perl example:

```
perl –e 'print scalar(localtime(0x5343ad73))';
```

Other behaviors within "show crash list" to be aware of:

- Similar crashes will be consolidated into one record. The record does display the number of times this crash type has occurred.

```
******************** CRASH #02 ***********************
SW Version          : 15.0(55812)
Similar Crash Count : 2
Time of First Crash : 2015-Jan-26+10:37:08
```

- Sometimes only a core file is generated while there is no record in show crash list. This could be a crash of non-StarOS processes such as telnet, or stack overflow.

Check crash related to one or more sessmgrs

With continuous or multiple task crashes, the first step is to determine if the crashes are related to a specific task instance, specific card, or if they are equally distributed across all cards / manager instances. To determine this, on any Unix/Linux server, parse output of the SSD (support_summary) or output the command "show snmp trap history verbose".

The following Linux command shows the distribution of the crashes per cards:

```
 grep TaskFailed show_snmp_trap_history_verbose.txt | awk '{print $17}' | sort | uniq -c | sort
-n -r
      21 15
      19 6
      11 13
      10 4
```

In this example there are 21 crashes on card 15, 19 crashes on card 6 and 11 crashes on card 13. In cases where multiple active cards are on the chassis, and crashes are related only to specific cards, troubleshooting would require more detailed analysis of the info related to

the card(s). As a next step, inspect related **debug console card <> cpu <> tail_10000 only** outputs inside SSD's.

Similarly, the following will provide distribution information of crashes per instance(s) of the process:

```
 grep TaskFailed show_snmp_trap_history_verbose.txt  | awk '{print $14}' | sort | uniq -c |
sort -n -r
```

Provide mini-core and SSD (show support details)

Any task crash analysis requires an SSD (support_details) file. If collected in the below manner, an archive will be generated which also contains the minicore files.

```
[local]asr5000# show support details to file
  One of: [file:]{/flash | /usb1 | /hd-raid}[/directory]/<filename>
   tftp://<host>[:<port>][/<directory>]/<filename
   ftp://[<username>[:<password>]@]<host>[:<port>][/<directory>]/<filename
   sftp://[<username>[:<password>]@]<host>[:<port>][/<directory>]/<filename
 [local]asr5000# show support details to file file:/flash/SSD compress
Are you sure? [Yes|No]: Yes
Warning: Changed output URL to file: file:/flash/SSD.tar.gz
```

Verify if core is created and truncated (config change if truncated)

Examples of successful core-transfer [show logs]:

```
 2015-Apr-18+15:05:51.796 [sitmain 4080 info] [8/0/4363 <sitparent:80> crashd.c:814] [software
internal system critical-info syslog] Core file transfer to SPC complete, received 217939968/0
bytes
 2015-Apr-18+15:05:51.806 [sitmain 4074 trace] [8/0/4363 <sitparent:80> crashd.c:853] [software
internal system critical-info syslog] Crash handler file transfer starting (type=2 size=0
child_ct=1 core_ct=1 pid=21685)
 2015-Apr-18+15:05:51.808 [system 1001 error] [8/0/4365 <evlogd:0> evlgd_syslogd.c:155]
[software internal system syslog] CPU[1/0]: xmitcore[15819]: Core file transmitted to card 8;
sz=217939968 elapsed=6s.
 2015-Apr-18+15:06:04.532 [sitmain 4075 trace] [8/0/4363 <sitparent:80> crashd.c:581] [software
```

```
internal system critical-info syslog] Crash handler file transfer ended (type=2 size=0
child_ct=0 core_ct=0 pid=21685 status=1 elapsed=13s)
```

Examples failed core-transfer [show logs]:

```
 2015-Apr-18+15:02:14.877 [sitmain 4080 info] [8/0/4363 <sitparent:80> crashd.c:814] [software
internal system critical-info syslog] Core file transfer to SPC complete, received 196546560/0
bytes
 2015-Apr-18+15:02:14.883 [sitmain 4074 trace] [8/0/4363 <sitparent:80> crashd.c:853] [software
internal system critical-info syslog] Crash handler file transfer starting (type=2 size=0
child_ct=1 core_ct=1 pid=21128)
 2015-Apr-18+15:02:14.886 [system 1001 error] [8/0/4365 <evlogd:0> evlgd_syslogd.c:155]
[software internal system syslog] CPU[2/1]: xmitcore[18952]: Out of time after 20s while
writing core type 2 to master
```

If core files are already transferred, the following is a quick check to validate if the transfer was successful:

```
$ mv crash-07-00-5343ad73-core crash-07-00-5343ad73-core.gz
$ gunzip crash-07-00-5343ad73-core
$  echo $?
0
```

If gunzip doesn't report any error, and output of the echo $? is 0, then the core transfer was successful:

```
$ mv crash-16-00-51e7259a-core crash-16-00-51e7259a-core.gz
$ gunzip crash-16-00-51e7259a-core.gz
gunzip: crash-16-00-51e7259a-core.gz: unexpected end of file
$  echo $?
1
```

If gunzip reports an error such as "unexpected end of file", and output of the echo $? is 1, then core transfer was not successful and the core file is truncated. If "failed core transfer" syslog

messages are observed, or core file is truncated, then please increase temporary crash maximum size with configuration command:

```
[local]asr5000(config)# crash max-size <value>
```

The default and max values are different on different platforms. For ASR 5000 the minimum is 128, default 1024, and maximum 2048 megabytes. For ASR 5500 default is 2048 and maximum is 4096.

NOTE: It is advised to keep this value default, and if changed, to change it only temporarily if the "failed core transfer" syslog message is seen, in order to capture the required core file during the next occurrence. Once the core file is provided to Cisco Support, and it is confirmed to be good, please return the size value back to default.

Session Recovery

This topic is also handled in the SW architecture chapter where it's approached from an architectural point of view.

Overview: Session Recovery is a licensed feature. It allows for the preservation of sessions during task and card level failure events.

```
[local]5500# show license info | grep "Session Recovery"
Tuesday May 05 14:00:14 EDT 2015
   + Session Recovery                        [ASR5K-00-PN01REC / ASR5K-00-HA01REC]
```

If enabled, to check the status of session recovery:

```
[local]5500# show session recovery status verbose
Tuesday May 05 14:06:31 EDT 2015
Session Recovery Status:
  Overall Status        : Ready For Recovery
  Last Status Update    : 3 seconds ago
~~~other output deleted~~~
```

Session Recovery is based around three managers within the chassis; SessMgr, AAAMgr, and VPNMgr. The SessMgr and AAAMgr back each other up by instance number. For example, SessMgr instance 100 is paired with AAAMgr instance 100. If one were to crash, the other could rebuild the session info. VPNMgr comes into play with IP allocations and reservations for the sessions. The VPNMgr instance ID is equal to the context ID where the IP pools are configured for the chassis. If there are multiple contexts with IP pools, there could be multiple VPNMgrs involved in a recovery event. As part of the requirements for Session Recovery, all three managers must live on different cards in the chassis. SessMgr and AAAMgr will live on active processing cards whereas VPNMgr will live on the demux card.

```
[local]5500# show task resources facility sessmgr instance 100
Tuesday May 05 14:17:59 EDT 2015
                    task    cputime         memory      files       sessions
 cpu facility       inst used allc   used   alloc used allc  used   allc S status
----------------------- --------- ------------- --------- ------------- ------
 3/1 sessmgr         100   12% 100% 414.9M 900.0M   35  500   4225 12000 I   good
Total                  1 12.67%     414.9M         35          4225
   [local]5500# show task resources facility aaamgr instance 100
Tuesday May 05 14:18:10 EDT 2015
                    task    cputime         memory      files       sessions
 cpu facility       inst used allc   used   alloc used allc  used   allc S status
----------------------- --------- ------------- --------- ------------- ------
 1/0 aaamgr          100 0.9%  95% 116.0M 250.0M   18  500     --     -- -   good
Total                  1 0.96%      116.0M         18             0
   [local]5500# show task resources facility vpnmgr instance 3
Tuesday May 05 14:18:27 EDT 2015
                    task    cputime         memory      files       sessions
 cpu facility       inst used allc   used   alloc used allc  used   allc S status
----------------------- --------- ------------- --------- ------------- ------
 5/0 vpnmgr             3 1.3% 100% 42.38M 147.9M 1948 2000     --     -- -   good
Total                  1 1.35%      42.38M         1948           0
```

Session Recovery requires a minimum of one Standby processor card (recommendation is two processor cards to cover double failure scenarios) as well as a dedicated Demux card. In 5500 the Demux can be either on MIO or DPC. In 5000, Demux must be on a PSC. Given the hardware requirements, for there to be a true hardware-related resource issue which would cause problems with session recovery, there would need to be two processor card failures.

System could go into a state where it's "**`Not ready`**" to perform session recovery. Single crash events are typically handled by the system and do not result in any major loss of subscribers, data, or billing info. In rare cases where there are cascading (one right after another) crashes of one of the managers, it is possible that the recovery of sessions may not happen correctly. For example, 2 sessmgr crashes on the same card and same CPU at the same time. Additionally, multiple failures across multiple managers could also cause issues with Session Recovery. In any of these crash cases, Cisco technical support should be contacted.

In order to analyze how many sessions are recovered, and the impact of the sessmgr crash, analyze the following traps from the command **show snmp trap history verbose** output:

```
 Tue Apr 07 15:02:49 2015 Internal trap notification 183 (SessMgrRecoveryComplete) Slot Number
3 Cpu Number 0 fetched from aaa mgr 1849 prior to audit 1849 passed audit 1830 calls recovered
1830 all call lines 1830 time elapsed ms 3280.
 Tue Apr 07 15:02:49 2015 Internal trap notification 183 (SessMgrRecoveryComplete) Slot Number
3 Cpu Number 0 fetched from aaa mgr 1848 prior to audit 1848 passed audit 1836 calls recovered
1837 all call lines 1837 time elapsed ms 3277.
 Tue Apr 07 15:02:49 2015 Internal trap notification 183 (SessMgrRecoveryComplete) Slot Number
3 Cpu Number 0 fetched from aaa mgr 1858 prior to audit 1858 passed audit 1851 calls recovered
1851 all call lines 1851 time elapsed ms 3345.
 Tue Apr 07 15:02:49 2015 Internal trap notification 183 (SessMgrRecoveryComplete) Slot Number
3 Cpu Number 0 fetched from aaa mgr 1844 prior to audit 1844 passed audit 1836 calls recovered
1837 all call lines 1837 time elapsed ms 3315.
```

The following simple Linux script will help with analysis/troubleshooting. It will provide the difference between total calls and recovered calls so it is possible to evaluate the real impact of the sessmgr crash.

```
 cat show_snmp_trap_history_verbose.txt | grep SessMgrRecoveryComplete | awk -F
SessMgrRecoveryComplete '{print $2}' | awk '{print $12 " " $22;tot+=$12;rec+=$22} END{print
"==== total:" tot " recovered:" rec}'
```

For more information about audit statistics per sessmgr instance, please check the audit and recovery counters for each session manager instance under the "show session subsystem facility sessmgr all debug info" commands (requires CLI test-command password).

```
Last Sessmgr Audit Report:
 Sessmgr Recovery Start Time          :2014-12-17 20:30:39
 Sessmgr Recovery Audit Complete Time :2014-12-17 20:30:44
 Total Duration                       :3934(ms)
 State Recovery Phase Timing:
      FSM State      Start Time(ms)/Duration(ms)
      ----------------------------------------
      Wait-Fetch        : 8/325
      Validate          : 333/41
      Wait-validate     : 374/271
      Wait-sess-recovery: 646/2731
      Purge             : 3377/88
      Wait-purge        : 3466/467
      Complete          : 3933/0
 fetched_from_aaamgr           : 4771            pror_to_audit           : 4771
 passed_audit                  : 4769            calls_recovered         : 4769
 calls_recovered_by_tmr        : 4760            calls_recovered_by_med  : 9
 calls_recovered_by_without_flowentry  : 0
 med_pkt_to_crr_fail_count     : 0               avg_crr_fetch_delay     : 0
 data_pkt_queue_overflow       : 0               ctrl_pkt_queue_overflow : 0
 dpkt_drop_on_recovery_progress: 0               crr_rcvry_fail_total    : 2
```

ARP Troubleshooting

Overview

The following chapter covers the basic Address Resolution Protocol (ARP) troubleshooting.

The following commands are helpful in identifying ARP entries and clearing them. As every context is a virtual router, arp entries are for that particular context:

- show ip arp
- clear ip arp

Sample Output:

```
[local]SPGW-1#
[local]SPGW-1# context spgw
[spgw]SPGW-1#
[spgw]SPGW-1#
[spgw]SPGW-1# show ip arp
Flags codes:
I - Incomplete, R - Reachable, M - Permanent, S - Stale,
D - Delay,      P - Probe,     F - Failed

Address         Link Type Link Address      Flags  Mask            Interface
10.201.251.7    ether     00:50:56:9C:5D:2D R                      spgw
192.168.10.30   ether     00:50:56:9C:16:23 R                      spgw
10.201.251.23   ether     00:0C:29:D4:18:0A R                      spgw
10.201.251.25   ether     00:50:56:9C:0E:14 R                      spgw
10.201.251.1    ether     00:24:97:2F:4B:00 R                      spgw
10.201.251.9    ether     00:50:56:9C:36:77 R                      spgw
10.201.251.5    ether     00:50:56:9C:61:B8 R                      spgw
192.168.5.130   ether     00:50:56:9C:61:B8 R                      spgw
Total number of arps: 8
[spgw]SPGW-1#
[spgw]SPGW-1#
```

1. Logging can be enabled to identify low level information about ARP. This should only be done upon recommendation from Cisco Support as increasing the logging too high may risk stress on the system and impact subscribers:

- logging filter active facility ip-arp level unusual
- logging filter active facility vpn level unusual
- logging filter active facility npumgr level unusual
- logging active

Once required logging output is collected, it is required to do '**no logging active**'.

Card and Port Troubleshooting

Overview

Major commands and multiple troubleshooting scenarios related to cards and ports in the ASR 5000/ASR 5000 are covered in this chapter.

Troubleshooting commands

For troubleshooting ASR 5000 / ASR 5500 hardware problems, following commands/logs are used

- show system uptime - Check if the system recently reloaded
- show card table all - Shows cards operational states
- show card diag <slot> - Verify "Current Failure", Last Failure reason, environmental variables
- show cpu table - Monitor CPU utilization, see if it exceeds 70% on any of the cards
- show cpu info - Monitor CPU usage, file usage, memory usage
- show card memory - Monitor memory errors
- show cpu errors - Monitor CPU errors
- show rct stat - Found in 'show support details' prior to 16.0. Monitor if any card migration, switchovers and shutdowns happened recently
- show port table all - Monitor status of the interfaces
- show port transceiver <slot/port> - applicable to ASR 5500 only. Monitor RxPower / TxPower
- show port utilization table - Monitor port utilization, observe anomalies
- show port utilization graph - Monitor port utilization, observe anomalies
- show port datalink counters <slot/port> - Monitor datalink counters, look for errors
- show port npu counters <slot/port> - Monitor for errors
- show logs - Monitor recent logs, search for anomalies
- show snmp trap history verbose - Identifies recent SNMP traps
- show alarm outstanding - Monitor if any alarms are still outstanding

All above commands are part of "show support details" (SSD). It is recommended to collect SSDs to analyze the output of these commands. Please note the output of 'show logs' starts with the most recent entries.

For example, the following command is available via CLI in 16.0 and newer, or in SSD for releases prior to 16.0. It shows the actions that happened with cards in the chassis indicating planned or unplanned migrations and switchovers.

```
[local]ASR5500# show rct stats
RCT stats Details (Last 9 Actions)
Action             Type      From To   Start Time                 Duration
------------------ --------- ---- ---- -------------------------  ----------
Migration          Planned      2    8  2015-Apr-25+15:21:33.790   1.694 sec
Shutdown           N/A          2    0  2015-Apr-25+15:22:40.143   0.020 sec
Switchover         Planned      5    6  2015-Apr-28+07:31:54.046  16.442 sec
Switchover         Planned      6    5  2015-Apr-28+21:53:01.950  16.675 sec
Shutdown           N/A          6    0  2015-Apr-28+22:21:26.843   0.012 sec
Switchover         Planned      5    6  2015-Apr-28+22:26:19.350  17.096 sec
Shutdown           N/A          5    0  2015-Apr-28+22:28:15.823   0.011 sec
Shutdown           N/A          2    0  2015-Apr-29+12:37:52.364   0.021 sec
Switchover         Planned      6    5  2015-May-05+16:43:25.470  15.630 sec
RCT stats Summary
-----------------
Migrations  =      1,  Average time = 1.695 sec
Switchovers =      4,  Average time = 16.461 sec
```

Port Status

When BAD, ERR, OVF, or Disc counters in "show port datalink counters" are excessively increasing in a short period of time, then the fiber-optic cable should be investigated as a potential layer 1 issue. For example, replacing the fiber cable, cleaning connectors and checking local/remote ports.

When troubleshooting NPU/port-related issues execute the "show port npu counters". If any of the following counters is non-zero and excessively increasing , then there might be a configuration issue or the port is receiving bad frames/packets.

- SRC MAC is multicast

- Unknown VLAN tag
- Bad IPv4 header
- IPv4 MRU exceeded
- TCP tiny fragment
- Filtered by ACL
- TTL expired
- Too short
- Don't frag discards
- IPv4VlanMap dropped
- MPLS Flow not found

Example Scenarios

Problem description:

Card in slot 1 failure on boot. Card failed and standby card took over sessions.

Analysis:

Collect 'show support details'. In the SSD output 'show card diag ' shows the last reason for failure.

```
 ******** show card diag *******
Card 1:
  Counters:
    Successful Warm Boots : 2
      (last at Tuesday May 05 05:22:14 UTC 2015)
    Successful Cold Boots : 18
      (last at Wednesday April 29 06:51:32 UTC 2015)
    Total Boot Attempts   : 0
    In Service Date       : Wed Feb 01 18:49:30 2012 (Estimated)
  Status:
    IDEEPROM Magic Number : Good
    Boot Mode             : Normal
    Card Diagnostics      : Pass
    Current Failure       : None
    Last Failure          : Failure: Device=CPU_0, Reason=CARD_BOOT_TIMEOUT_EXPIRED,
(0x03001000)
      (last at Tuesday May 05 05:20:08 UTC 2015)
```

Analyze 'show logs' of SSD for card 1 boot process

```
 2015-Apr-29+05:26:52.797 [system 1000 critical] [8/0/4426 <evlogd:0> evlgd_syslogd.c:151]
[software internal system syslog] CPU[1/0]: CRITICAL: BIOS Failed to properly Size System
Memory aborting boot
 2015-Apr-29+05:26:52.797 [system 1000 critical] [8/0/4426 <evlogd:0> evlgd_syslogd.c:151]
[software internal system syslog] CPU[1/0]: ERROR: Bus 254 CPU 1 Chan 0 DIMM 0 NotPresent
 2015-Apr-29+05:26:52.797 [system 1000 critical] [8/0/4426 <evlogd:0> evlgd_syslogd.c:151]
[software internal system syslog] CPU[1/0]: ERROR: Memory size 24576 MB for cpu0 not matching
with value 32768 MB in IDEEPROM
 2015-Apr-29+05:26:52.797 [system 1000 critical] [8/0/4426 <evlogd:0> evlgd_syslogd.c:151]
[software internal system syslog] CPU[1/0]: WARNING: Memory size 24576 MB for cpu0 not matching
with value 32768 MB in IDEEPROM

 2015-Apr-29+05:29:22.286 [csp 7005 critical] [8/0/4469 <cspctrl:0> spctrl_events.c:2837]
[hardware internal system syslog] The Packet Services Card 2 in slot 1 did not boot in the
allowed time. CPU 0 did not boot. CPU 1 did not boot.
 2015-Apr-29+05:29:22.353 [csp 7019 critical] [8/0/4469 <cspctrl:0> spctrl_events.c:3691]
[hardware internal system diagnostic] The Packet Services Card 2 with serial number PLB00000000
in slot 1 has failed and will be brought down and kept down. (Device=CPU_0,
Reason=CARD_BOOT_TIMEOUT_EXPIRED, Status=[CPU0 MB: CFE_FAILURE HB_cpu: 00:00] [CPU1 HB_cpu:
00:00] [CPU2 HB_cpu: 00:00] [CPU3 HB_cpu: 00:00] [GPIO_IN: 00,ff,ff,ff] [GPIO_OUT:
01,ff,00,ff])
```

The above logs show that the card failed to boot due to a memory problem. After trying to boot the card several times, due to multiple failures, the card is shut down by the system.

Every card has console logs. When a card boots, all the kernel log information will be in 'debug console card <card no> cpu <0/1> tail 4000' within the SSD. As the logs above are related to card 1, 'debug console card 1 cpu 0' has the following information confirming the memory problem.

```
 1430285212.787 card 1-cpu0: Ophir 82571 Ethernet controller 0x10608086 (Serdes) on 2/0/0
 1430285212.787 card 1-cpu0: WARNING: Memory size 24576 MB for cpu0 not matching with value
32768 MB in IDEEPROM
```

The number **1430285212.787** in the above log is date and time in epoch format. Converting that results in Wed, 29 Apr 2015 05:26:52 GMT. From version 17.0, epoch format in the line is replaced with date and time format.

Resolution:

The card in slot 1 needs to be replaced.

Problem Description:

The ioerr_cnt for a hd is increasing in the logs

```
 'show logs | grep 'ioerr_cnt'
 2012-Aug-14+12:33:20.601 [hdctrl 132016 error] [6/0/7345 <hdctrl:0 rl_fsm_mirror.c:3153]
[software internal system critical-info syslog] Error detected on hd17a (STEC-Z16IZF2D-200UCT
STM000000000), FSC17 SAD15290110: ioerr_cnt increased from 1420 to 1421
```

Analysis

Check the health of the Hard Drive using the following command

- Enter the CLI test-commands password..
- Check 'show hd smart <hd number>'

```
 [local]ASR5500# show hd smart hd17a Device: STEC     Z16IZF2D-200UCT  Version: E125 Serial
number: STM00000000 Device type: disk Transport protocol: SAS Local Time is: Fri Aug 10
16:30:18 2012 UTC Device supports SMART and is Enabled Temperature Warning Enabled SMART Health
Status: FAILURE PREDICTION THRESHOLD EXCEEDED: ascq=0xb [asc=5d, ascq=b] Current Drive
Temperature:     46 C Drive Trip Temperature:        75 C
```

Above indicates there is a problem in the hd 17. One reason for this is due to high temperature and clearing temperature history will help. Following commands can be used to verify if the hd is faulty. Below CLI command requires CLI test-commands password be configured in the chassis.

```
[local]ASR5500# show hd iocnt hd17a
  iorequest_cnt=0x1f576
     iodone_cnt=0x1f576
      ioerr_cnt=0x229  (this in itself doesn't necessarily indicate disk failure but is a
measure of the number of failures. These can also be seen in the logs)

debug console card <active MIO> cpu 0 tail 5000
1413433763.676 card 5-cpu0: [  258.690395] md: super_written gets error=-5, uptodate=0
1413433763.676 card 5-cpu0: [  258.695595] md/raid:md0: Disk failure on md17, disabling
device.
1413433763.676 card 5-cpu0: [  258.695596] md/raid:md0: Operation continuing on 3 devices.
```

Resolution

Card in slot 17 needs to be replaced due to disk failure.

Problem Description

Firmware needs to be upgraded. When ASR 5000 / ASR 5500 chassis is upgraded to a newer StarOS version, all cards in the chassis should upgrade to the firmware version in that StarOS version. Sometimes, a few cards may not get upgraded to the correct firmware version. In that scenario, a manual upgrade of firmware is needed for those cards.

The outpout below shows that firmware is out of date by using the command 'show card hardware'.

```
[local]ASR5500# show card hardware 9
Card 9:
  Card Type                : Data Processing Card (R01)
  Description              : DPC
  Cisco Part Number        : 73-14872-02 A0
  UDI Serial Number        : SAD0000000
  UDI Product ID           : ASR55-DPC-K9
  UDI Version ID           : V02
  UDI Top Assem Num        : 68-4669-02 A0
  Daughter Card #3:
    Card Type              : DPC CCK Daughter Card (R01)
```

```
    Description           : DPC_CRYPTO_DC
    Cisco Part Number     : 73-14558-01 B0
    UDI Serial Number     : SAD00000000
  Card Programmables      : DPC-CFE is out of date
                          : DPC-CFE is out of date
  CPU 0 CFE               : on-card 3.0.19
```

Analysis:

The firmware needs to be upgraded manually during the maintenance window.

Resolution:

- Put the card in standby mode using the command 'card migrate from <slot no.> to <slot no.>
- Use the command 'card upgrade <card no.>' to upgrade the firmware. Card upgrade takes few minutes and after upgrade the card will reboot.

```
[local]ASR5500# card upgrade 9
                                -- WARNING --
A card upgrade will update the programmables stored on the card to the versions
included with this software build. This command should only be used
when instructed by or working with Cisco Support.
If a failure occurs or a card is removed from the chassis during this update the
card being updated may become unusable. If this occurs the card may require
manual reprogramming outside of the chassis.
Performing unrelated operations while this upgrade is in progress is not
recommended.
The status of this card upgrade is shown in the 'Upgrade In Progress' line of
'show card info 9'
                                -- WARNING --
[local]ASR5500#
```

The upgrade process can be observed in 'show logs'

```
[local]ASR5500# show logs | grep -i "slot 9"
2015-May-06+09:14:31.167 [csp 7716 info] [5/0/18288 <cspctrl:0> pctrl_helpers.c:14294]
[software internal system critical-info syslog] upgrade of DPC_BCF_FPGA in slot 9 finished with
```

```
success
 2015-May-06+09:14:30.188 [csp 7715 info] [5/0/18288 <cspctrl:0> pctrl_helpers.c:14470]
[software internal system critical-info syslog] upgrade of DPC_BCF_FPGA in slot 9 started
 2015-May-06+09:14:30.186 [csp 7715 info] [5/0/18288 <cspctrl:0> pctrl_helpers.c:14387]
[software internal system critical-info syslog] upgrade of DPC_CAF_FPGA in slot 9 started
 2015-May-06+09:14:28.751 [csp 7043 info] [5/0/18288 <cspctrl:0> spctrl_events.c:14169]
[hardware internal system critical-info syslog] Upgrade issued for the Data Processing Card
with serial number SAD00000000 in slot 9. Will upgrade 0x4180800000000000000000.  Please
wait...
 2015-May-06+09:13:48.385 [csp 7314 warning] [5/0/18288 <cspctrl:0> spctrl_events.c:2545]
[software internal system critical-info syslog] The DPC-CFE programmable on the Data Processing
Card in slot 9 is an out of date version
 2015-May-06+09:13:48.385 [csp 7314 warning] [5/0/18288 <cspctrl:0> spctrl_events.c:2545]
[software internal system critical-info syslog] The DPC-CFE programmable on the Data Processing
Card in slot 9 is an out of date version
 2015-May-06+09:13:42.908 [csp 7009 info] [5/0/18288 <cspctrl:0> pctrl_helpers.c:3078]
[hardware internal system critical-info syslog] Migrating all tasks on the Data Processing Card
in slot 9 to the one in slot 2.
```

Once the card is booted, verify the card has the latest firmware version using the command 'show card hardware <card no.>'

```
[local]ASR5500# show card hardware 9
Card 9:
  Card Type                : Data Processing Card (R01)
  Description              : DPC
  Cisco Part Number        : 73-14872-02 A0
  UDI Serial Number        : SAD000000000
  UDI Product ID           : ASR55-DPC-K9
  UDI Version ID           : V02
  UDI Top Assem Num        : 68-4669-02 A0
  Daughter Card #3:
    Card Type              : DPC CCK Daughter Card (R01)
    Description            : DPC_CRYPTO_DC
    Cisco Part Number      : 73-14558-01 B0
    UDI Serial Number      : SAD0000000
  Card Programmables       : up to date
  CPU 0 CFE                : on-card 3.1.4
```

LAG Troubleshooting

Overview

This section covers LAG implementation and troubleshooting, along with some example issue scenarios.

LAG Description

Two or more physical ports can be logically combined in order to increase the bandwidth capability and to create more resilient connections. A Link Aggregation Group (LAG) works by exchanging control packets via Link Aggregation Control Protocol (LACP) over configured physical ports with peers to reach agreement on an aggregation of links as defined in IEEE 802.3ad. The LAG sends and receives the control packets directly on physical ports. Link aggregation (also called trunking or bonding) provides higher total bandwidth, auto-negotiation, and recovery, by combining parallel network links between devices as a single link.

In the standard LAG configuration, the first port configured is selected as Master Port.

LAG on ASR 5000 vs ASR 5500:

On ASR 5000 LAG, there is a single master port and interfaces are always bound to it.

While on ASR 5500, LACP distributing status (LA+/LA~) is independent of master port selection. That is, the master port may be in the distributing (LA+) or agreed (LA~) set of ports.

LACP distributing status changes do not affect LAG interface bindings - they're always bound to the master port, which may be LA+ or LA-. If the master port LC is removed, the system will automatically select a new master port and move the LAG configuration to that port. This changes all LAG interface bindings. The LAG master port can also move if an LC does not recover or takes "too long" to recover, following a redundancy event (e.g., reboot or migration/re-attachment). The "too long" period cannot be pinned down to a specific number as there are events (such as boot time) which will cause variability. Generally speaking, the system tries to avoid moving the master port configuration, as this requires changing the LAG system ID which is derived from the master port MAC and will bounce the LAG.

In ASR 5000, ports are not paired (unless SSR is used, but that's mutually exclusive with LAG). There is only one master port and it has no fixed backup. Because there is only one master port, the interface binding will always match the master port as displayed in "show port table".

In ASR 5500 the LAG system ID is generated from the chassis MAC. ASR 5000 LAG system ID is generated from master port MAC. This means that if master port on ASR 5000 goes away for some reason, the system needs to dynamically choose a new master port and reconfigure the LAG with a system ID derived from that port's MAC. Both master LAG ports operate in ACTIVE mode.

LAG Troubleshooting

The following are useful commands for troubleshooting and health check of the LAG on ASR 5x00 chassis.

- show port table all

Symbol	LAG State
+	LAG distributing
~	LAG agreed
-	LAG not distributing
*	LAG negotiated
!	Timeout

- show port utilization table
- show port info
- show logs
- show port datalink counters
- show snmp trap history verbose - Monitor for LAG events. When a LAG group goes up or down, the following messages are generated for SNMP traps as well as in 'show logs':

```
 Fri Nov 23 01:48:37 2012 Internal trap notification 1204 (LAGGroupDown) card:19, port:1,
partner:(007F,B0-C6-9A-C4-79-F0,0016)
 Fri Nov 23 01:48:37 2012 Internal trap notification 1205 (LAGGroupUp) card:19, port:1,
partner:(007F,B0-C6-9A-C4-5F-F0,0016)
 2012-Nov-23+01:48:37.321 [lagmgr 179050 warning] [1/0/4059 <lagmgr:0> lagmgr_state.c:1268]
```

```
[software internal system critical-infosyslog] LAG group 50 (global) with master port 19/1 has changed partner from (007F,B0-C6-9A-C4-79-F0,0016) on 20/1, 26/1, 28/1 to (007F,B0-C6-9A-C4-5F-F0,0016) on 19/1, 23/1, 27/1
```

Below is the command to switchover LAG groups (if applicable).

- link-aggregation port switch to <any-port-number-in-lag-agreed-state>

Below CLI commands require CLI test-commands password be configured in the chassis

- show lagmgr lacp-port
- show lagmgr counters
- show lagmgr events

* For show lagmgr events, note that the timestamp would be UTC. This may be different than the timestamps in snmp/logging.

Following is an example of normal operation for a LAG with redundant configuration. In the output below port 19/1 is master port. Ports 19/1, 23/1, 27/1 and 29/1 are in LAG distributing state (carry traffic). Ports 20/1, 26/1, 28/1 and 30/1 are in agreed state.

```
******** show port table all ********
Port  Role Type                     Admin    Oper Link State    Pair  Redundant
----- ---- ------------------------ -------- ---- ---- -------  ----- ---------
19/1  Srvc 10G Ethernet             Enabled  -    Up   -        None  LA+ 19/1
           Untagged                 Enabled  Up   -    Active   -     -
           Tagged VLAN  1         Enabled  Up   -    Active   -     -
           Tagged VLAN  2         Enabled  Up   -    Active   -     -
           Tagged VLAN  3         Enabled  Up   -    Active   -     -
           Tagged VLAN  4         Enabled  Up   -    Active   -     -
           Tagged VLAN  5         Enabled  Up   -    Active   -     -
20/1  Srvc 10G Ethernet             Enabled  Up   Up   Active   None  LA~ 19/1
21/1  Srvc 1000 Ethernet            Enabled  -    Up   -        37/1  L2 Link
           Untagged                 Enabled  Down -    Active   -     -
           Tagged VLAN     6        Enabled  Up   -    Active   -     -
22/1  Srvc 1000 Ethernet            Enabled  -    Up   -        38/1  L2 Link
           Untagged                 Enabled  Down -    Active   -     -
```

```
           Tagged VLAN     7         Enabled  Up   -    Active   -     -
23/1  Srvc 10G Ethernet              Enabled  Up   Up   Active   None  LA+ 19/1
24/1  Mgmt 1000 Ethernet Dual Media  Enabled  Up   Up   Active   25/1  L2 Link
24/2  Mgmt 1000 Ethernet Dual Media  Disabled Down Down Active   25/2  L2 Link
24/3  Mgmt RS232 Serial Console      Enabled  Down Down Active   25/3  L2 Link
24/4  Mgmt BITS T1/E1 Timing         Disabled Down Down Active   25/4  L2 Link
25/1  Mgmt 1000 Ethernet Dual Media  Enabled  Down Up   Standby  24/1  L2 Link
25/2  Mgmt 1000 Ethernet Dual Media  Disabled Down Down Standby  24/2  L2 Link
25/3  Mgmt RS232 Serial Console      Enabled  Down Down Standby  24/3  L2 Link
25/4  Mgmt BITS T1/E1 Timing         Disabled Down Down Standby  24/4  L2 Link
26/1  Srvc 10G Ethernet              Enabled  Up   Up   Active   None  LA~ 19/1
27/1  Srvc 10G Ethernet              Enabled  Up   Up   Active   None  LA+ 19/1
28/1  Srvc 10G Ethernet              Enabled  Up   Up   Active   None  LA~ 19/1
29/1  Srvc 10G Ethernet              Enabled  Up   Up   Active   None  LA+ 19/1
30/1  Srvc 10G Ethernet              Enabled  Up   Up   Active   None  LA~ 19/1
37/1  Srvc 1000 Ethernet             Enabled  -    Up   -        21/1  L2 Link
           Untagged                  Enabled  Down -    Standby  -     -
           Tagged VLAN     6         Enabled  Down -    Standby  -     -
38/1  Srvc 1000 Ethernet             Enabled  -    Up   -        22/1  L2 Link
           Untagged                  Enabled  Down -    Standby  -     -
           Tagged VLAN     7         Enabled  Down -    Standby  -     -

******** show port utilization table ********
                                ------ Average Port Utilization (in mbps) ------
Port   Type                       Current            5min              15min
                                  Rx       Tx       Rx       Tx       Rx      Tx
----- ------------------------  ------- -------  ------- -------  ------- ------
19/1  10G Ethernet              2505    2492     2493    2534     2460    2520
20/1  10G Ethernet              0       0        0       0        0       0
21/1  1000 Ethernet             0       19       0       14       0       14
22/1  1000 Ethernet             7       46       7       45       7       46
23/1  10G Ethernet              2384    2685     2459    2595     2475    2548
26/1  10G Ethernet              0       0        0       0        0       0
27/1  10G Ethernet              2828    2500     2711    2587     2668    2580
28/1  10G Ethernet              0       0        0       0        0       0
29/1  10G Ethernet              2598    2661     2646    2620     2618    2586
30/1  10G Ethernet              0       0        0       0        0       0

[local]ASR5000> show port info | grep -i "Link Aggregation State"
```

```
  Link Aggregation State  : Port distributing
  Link Aggregation State  : Agreed with LACP peer
  Link Aggregation State  : Port distributing
  Link Aggregation State  : Agreed with LACP peer
  Link Aggregation State  : Port distributing
  Link Aggregation State  : Agreed with LACP peer
  Link Aggregation State  : Port distributing
  Link Aggregation State  : Agreed with LACP peer
```

Following is an example of a system being unable to establish LAG over port 17/1. In the output below Port 17/1 is master port for the LAG group but it is NOT in distributing state (overall that means that LACP messages are timing out and chassis cannot establish LACP over port 17/1). Ports 18/1 and 20/1 are in distributing state and carry traffic. Port 19/1 is in agreed state. In this case the issue with port 17/1 being unable to establish LAG should be investigated. Further investigation would include checking the LAG setup in the device that this port is connected to as well as sniffer traces. The command "show lagmgr events" command is also useful to trace LACP events.

```
******** show port table all ********
Port  Role Type                      Admin    Oper Link State    Pair  Redundant
----- ---- ------------------------  -------- ---- ---- -------  ----- ---------
19/1  Srvc 10G Ethernet              Enabled  -    Up   -        None  LA+ 19/1
           Untagged                  Enabled  Up   -    Active   -     -
           Tagged VLAN  1         Enabled  Up   -    Active   -     -
           Tagged VLAN  2         Enabled  Up   -    Active   -     -
           Tagged VLAN  3         Enabled  Up   -    Active   -     -
           Tagged VLAN  4         Enabled  Up   -    Active   -     -
           Tagged VLAN  5         Enabled  Up   -    Active   -     -
20/1  Srvc 10G Ethernet              Enabled  Up   Up   Active   None  LA~ 19/1
21/1  Srvc 1000 Ethernet             Enabled  -    Up   -        37/1  L2 Link
           Untagged                  Enabled  Down -    Active   -     -
           Tagged VLAN     6         Enabled  Up   -    Active   -     -
22/1  Srvc 1000 Ethernet             Enabled  -    Up   -        38/1  L2 Link
           Untagged                  Enabled  Down -    Active   -     -
           Tagged VLAN     7         Enabled  Up   -    Active   -     -
23/1  Srvc 10G Ethernet              Enabled  Up   Up   Active   None  LA+ 19/1
24/1  Mgmt 1000 Ethernet Dual Media  Enabled  Up   Up   Active   25/1  L2 Link
24/2  Mgmt 1000 Ethernet Dual Media  Disabled Down Down Active   25/2  L2 Link
```

```
24/3  Mgmt RS232 Serial Console      Enabled  Down Down Active   25/3  L2 Link
24/4  Mgmt BITS T1/E1 Timing         Disabled Down Down Active   25/4  L2 Link
25/1  Mgmt 1000 Ethernet Dual Media  Enabled  Down Up   Standby  24/1  L2 Link
25/2  Mgmt 1000 Ethernet Dual Media  Disabled Down Down Standby  24/2  L2 Link
25/3  Mgmt RS232 Serial Console      Enabled  Down Down Standby  24/3  L2 Link
25/4  Mgmt BITS T1/E1 Timing         Disabled Down Down Standby  24/4  L2 Link
26/1  Srvc 10G Ethernet              Enabled  Up   Up   Active   None  LA~ 19/1
27/1  Srvc 10G Ethernet              Enabled  Up   Up   Active   None  LA+ 19/1
28/1  Srvc 10G Ethernet              Enabled  Up   Up   Active   None  LA~ 19/1
29/1  Srvc 10G Ethernet              Enabled  Up   Up   Active   None  LA+ 19/1
30/1  Srvc 10G Ethernet              Enabled  Up   Up   Active   None  LA~ 19/1
37/1  Srvc 1000 Ethernet             Enabled  -    Up   -        21/1  L2 Link
          Untagged                   Enabled  Down -    Standby  -     -
          Tagged VLAN     6          Enabled  Down -    Standby  -     -
38/1  Srvc 1000 Ethernet             Enabled  -    Up   -        22/1  L2 Link
          Untagged                   Enabled  Down -    Standby  -     -
          Tagged VLAN     7          Enabled  Down -    Standby  -     -

******** show port utilization table ********
                                ------ Average Port Utilization (in mbps) ------
Port   Type                       Current           5min             15min
                                  Rx      Tx      Rx       Tx       Rx     Tx
----- ------------------------  ------- -------  ------- -------  ------- ------
19/1  10G Ethernet              2505    2492     2493    2534     2460    2520
20/1  10G Ethernet              0       0        0       0        0       0
21/1  1000 Ethernet            0       19       0       14       0       14
22/1  1000 Ethernet            7       46       7       45       7       46
23/1  10G Ethernet              2384    2685     2459    2595     2475    2548
26/1  10G Ethernet              0       0        0       0        0       0
27/1  10G Ethernet              2828    2500     2711    2587     2668    2580
28/1  10G Ethernet              0       0        0       0        0       0
29/1  10G Ethernet              2598    2661     2646    2620     2618    2586
30/1  10G Ethernet              0       0        0       0        0       0

[local]ASR5000> show port info | grep -i "Link Aggregation State"
  Link Aggregation State  : Port distributing
  Link Aggregation State  : Agreed with LACP peer
  Link Aggregation State  : Port distributing
  Link Aggregation State  : Agreed with LACP peer
```

```
  Link Aggregation State  : Port distributing
  Link Aggregation State  : Agreed with LACP peer
  Link Aggregation State  : Port distributing
  Link Aggregation State  : Agreed with LACP peer
```

Below is an example of a LACP timeout. In the output below, the chassis is unable to establish LACP via port 23/1 due to timeouts. To identify the timeouts run the following CLI commands: 'show port utilization table', 'show port datalink counters'. Also check LACP status in the device to which this port is connected to.

```
[local]ASR5000> show port table

Port  Role Type                      Admin    Oper Link State    Pair  Redundant
----- ---- ------------------------  -------- ---- ---- -------  ----- ---------
19/1  Srvc 10G Ethernet              Enabled  -    Up   -        None  LA~ 19/1
20/1  Srvc 10G Ethernet              Enabled  Up   Up   Active   None  LA+ 19/1
21/1  Srvc 1000 Ethernet             Enabled  -    Up   -        37/1  L2 Link
23/1  Srvc 10G Ethernet              Enabled  Up   Up   Active   None  LA! 19/1
24/1  Mgmt 1000 Ethernet Dual Media  Enabled  Down Up   Standby  25/1  L2 Link
24/2  Mgmt 1000 Ethernet Dual Media  Disabled Down Down Active   25/2  L2 Link
24/3  Mgmt RS232 Serial Console      Enabled  Up   Up   Active   25/3  L2 Link
24/4  Mgmt BITS T1/E1 Timing         Disabled Down Down Active   25/4  L2 Link
25/1  Mgmt 1000 Ethernet Dual Media  Enabled  Up   Up   Active   24/1  L2 Link
25/2  Mgmt 1000 Ethernet Dual Media  Disabled Down Down Standby  24/2  L2 Link
25/3  Mgmt RS232 Serial Console      Enabled  Down Up   Standby  24/3  L2 Link
25/4  Mgmt BITS T1/E1 Timing         Disabled Down Down Standby  24/4  L2 Link
26/1  Srvc 10G Ethernet              Enabled  Up   Up   Active   None  LA+ 19/1
27/1  Srvc 10G Ethernet              Enabled  Up   Up   Active   None  LA~ 19/1
28/1  Srvc 10G Ethernet              Enabled  Up   Up   Active   None  LA+ 19/1
29/1  Srvc 10G Ethernet              Enabled  Up   Up   Active   None  LA~ 19/1
30/1  Srvc 10G Ethernet              Enabled  Up   Up   Active   None  LA+ 19/1
37/1  Srvc 1000 Ethernet             Enabled  -    Up   -        21/1  L2 Link
```

Example Scenarios

Multiple ports bounces in LAGs followed by LAGs lockup and unable to process any traffic due to flow control disabled.

Problem observed:

Observe LC bounces on their 2 LAG groups intermittently. Both LAG groups are affected with various ports bounces.

- LAGs went down and stopped processing any traffic even after majority of the traffic off both LAGs.
- LAGs' ports reviewed traffic spike during the issue. The traffic was above of the processing capabilities of the LCs.

Logs collection:

- Collect 2 or more “show support details”
- Collect syslog
- Collect bulkstats/KPI for attach success rate and reject reason
- "monitor subscriber IMSI [value]" (verbosity 2)
- Collect external packet capture

CLI used to troubleshoot:

> Below CLI commands requires CLI test-commands password configured in the chassis. Please use the command with caution!
> Many TEST commands are processor-intensive and can cause serious system problems if used too frequently.

```
show port utilization table
 show port info
 show port datalink counters
 show lagmgr lacp-port
 show lagmgr counters
 show npu stats debug all | grep -i lag
 show lagmgr events
```

Analysis:

From the output of **'show port datalink counters** <port>', TX PAUSE counts incrementing for the LAG ports. This indicates that at some point LCs were hit with a high rate data which was more than what it could handle, which caused flow control to kick in.

Monitoring the '**show npu stats debug slot <>**' output showed that **rx-lag-cntl-pkt-cnt** counter was constant and not incrementing. This indicates that the LCs got stuck/clogged (probably due to flow control not working correctly, this is yet to be root caused) leading to the LC to PSC NPU communication getting lost.

With a broken LC to NPU path, LACP packets from the LC could not reach corresponding NPU and hence do not get processed. This results in LAG down/bounce.

The issue is reproducible only when flow control is disabled on the next hop switch. The root cause of lockup is deemed to be hardware misbehavior in the MAC chip under maximum load and without flow control. The issue is not dependent on LAG itself, but LAG detects the lockup.

Workaround:

Resetting individual LC in LAG group normalized the LAGs for short time.

Resolution:

Enable the flow control on next hop switch to avoid traffic storm and LC clogging.

Consider adjusting LACP timeout values on next hop switch for a faster convergence.

LACP period short <<<< To let 5k send 1 LACP PDU per second, instead of 1 per 30 seconds.
flow-control bidirectional <<<<< to slow down the flow rate from Router to ASR 5x00 has sent flow control beacon to Router when ASR 5x00 is throttled.

```
P/0/RSP0/CPU0:-D#show int ten 0/1/1/1
TenGigE0/1/1/1 is up, line protocol is up
  Interface state transitions: 1
  Hardware is TenGigE, address is 4055.395f.8031 (bia 4055.395f.8031)
  Layer 1 Transport Mode is LAN
  Internet address is Unknown
  MTU 9216 bytes, BW 10000000 Kbit (Max: 10000000 Kbit)
     reliability 255/255, txload 0/255, rxload 0/255
  Encapsulation ARPA,
  Full-duplex, 10000Mb/s, link type is force-up
  output flow control is off, input flow control is off   << ingress/egress flow control off
by default
  loopback not set,
  Last input 00:00:00, output 00:00:00
  Last clearing of "show interface" counters never
  30 second input rate 0 bits/sec, 1 packets/sec
  30 second output rate 2000 bits/sec, 3 packets/sec
     923663 packets input, 81852921 bytes, 0 total input drops
     0 drops for unrecognized upper-level protocol
     Received 2 broadcast packets, 266014 multicast packets
              0 runts, 0 giants, 0 throttles, 0 parity
     0 input errors, 0 CRC, 0 frame, 0 overrun, 0 ignored, 0 abort
     1149759 packets output, 121149359 bytes, 0 total output drops
     Output 2 broadcast packets, 527159 multicast packets
     0 output errors, 0 underruns, 0 applique, 0 resets
     0 output buffer failures, 0 output buffers swapped out
     1 carrier transitions
RP/0/RSP0/CPU0:ASR9006-D#show lacp bundle-ether 1
State: a - Port is marked as Aggregatable.
       s - Port is Synchronized with peer.
       c - Port is marked as Collecting.
       d - Port is marked as Distributing.
       A - Device is in Active mode.
       F - Device requests PDUs from the peer at fast rate.
       D - Port is using default values for partner information.
       E - Information about partner has expired.
Bundle-Ether1
   Port          (rate)  State    Port ID       Key    System ID
  --------------------  -------- ------------- ------ -------------------------
```

```
  Local
   Te0/1/1/1         1s  ascdA--- 0x8000,0x0005 0x0001 0x8000,40-55-39-60-51-f4
    Partner         30s  ascdAF-- 0x8000,0x0008 0x0097 0x8000,40-55-39-5b-ae-94   <<<< ROUTER
receives one LACP-PDU/30s from 5k.
   Port                  Receive    Period Selection  Mux       A Churn P Churn
   --------------------  ---------- ------ ---------- --------- ------- -------
 Local
   Te0/1/1/1             Current    Fast   Selected   Distrib   None    None
```

Switch Fabric & NPU Troubleshooting

Overview

This section provides basic health checks for monitoring Switch Fabric and NPU related issues.

Switch Fabric

The switch fabric provides backplane connectivity among all the cards in ASR 5500 chassis. Both control plane and data plane connectivity within the chassis are through the switch fabric.

For ASR 5000, control plane and data plane are separated and use different hardware.

Health Check of switch fabric for ASR 5500

To look for switch fabric issues, run the following CLI command:

- **show fabric health**

For each device that is functioning properly, the following output will be shown:

```
Command: fe600 system-device-id 47
Command: show health
FE600 47=16/1
is OK

Command: fe600 system-device-id 48
Command: show health
FE600 48=16/2
is OK
```

Additionally, to check health of the switch fabric on ASR 5500, please inspect in SSD for the command "**show fabric support details**" and check all sub-commands: "**show serdes all-serdes summary**" and confirm if the Last Change is GOOD for all FAP (Fabric Access Processor - can be DPCs or MIOs):

```
Command: show serdes all-serdes summary
Fabric Status:
 Status OK(+)-------------------------+
 Topology fault(T)-------------------+|
 Far side not expected(*)----------+||
 Logically not connected(L)-------+|||
 Physically not connected(P)-----+||||           NIF Status:
 Rx Down(*)----------------------+|||||  +----------NIF powered off(*)
 Tx Down(*)---------------------+||||||  |+---------SERDES powered off(*)
 Code Group(G)-----------------+|||||||  ||+--------Local side down(l)
 Misalignment(M)--------------+||||||||  |||+-------Remote side down(r)
 Cell Size(C)----------------+|||||||||  ||||+------Rx activity(r)
 Internally fixed(I)--------+|||||||||||  |||||+-----Tx activity(t)
 Not Accept Cells(A)------+|||||||||||||  ||||||+----Status OK(+)
                          |||||||||||||  |||||||
SERDES Status:            |||||||||||||  |||||||
 Status OK(+)-----------+ |||||||||||||  |||||||
 Rx power off(*)--------+| |||||||||||||  |||||||
 Tx power off(*)-------+|| |||||||||||||  |||||||
 Sig not locked(S)----+||| |||||||||||||  |||||||
 Rx signal loss(*)---+|||| |||||||||||||  |||||||
 Modified Parms(m)--+||||| |||||||||||||  |||||||
 Admin down(D)-----+|||||| |||||||||||||  |||||||
                   |||||||  |||||||||||||  |||||||
Fabric lane------+ |||||||  |||||||||||||  |||||||
SERDES lane---+  | |||||||  |||||||||||||  |||||||                                        Config
Source  Dev SL FL vvvvvvv vvvvvvvvvvvv vvvvvvv     Rate     Topology CRC Errs  Remote Dev SL FL
Last Change
 ------- --- -- -- ------- ------------ ------- ------------ -------- -------- ------- --- -- -- ------
----------------
  4= 2/2 FAP  0  -       +                  rt+ 3125.00 Mbps        -        - CP1 XAUI          GOOD
  4= 2/2 FAP  1  -       +                  rt+ 3125.00 Mbps        -        - CP1 XAUI          GOOD
  4= 2/2 FAP  2  -       +                  rt+ 3125.00 Mbps        -        - CP1 XAUI          GOOD
  4= 2/2 FAP  3  -       +                  rt+ 3125.00 Mbps        -        - CP1 XAUI          GOOD
  4= 2/2 FAP  4  -       +                  rt+ 3125.00 Mbps        -        - CP2 XAUI          GOOD
  4= 2/2 FAP  5  -       +                  rt+ 3125.00 Mbps        -        - CP2 XAUI          GOOD
  4= 2/2 FAP  6  -       +                  rt+ 3125.00 Mbps        -        - CP2 XAUI          GOOD
```

Health Check of switch fabric for ASR 5000

For ASR 5000, check "**show npu sf**" state in SSD. If any card is active / standby but SF link shows as "**dis**" then indicates SF link level issue.

```
# show npu sf state

SPC 8 882 mask real f
SPC 9 882 mask real f
SPC 8 882 mask used f
SPC 9 882 mask used f

SPC 9 882 #4 -------------+---------+---------+--------------+---------+---------+---------+
SPC 9 882 #3 -------------+---------+---------+--------------+---------+---------+         |
SPC 9 882 #2 -------------+---------+---------+--------------+---------+         |         |
SPC 9 882 #1 -------------+---------+---------+--------------+         |         |         |
                                                              |         |         |         |
SPC 8 882 #4 -------------+---------+---------+              |         |         |         |
SPC 8 882 #3 -------------+---------+         |              |         |         |         |
SPC 8 882 #2 -------------+         |         |              |         |         |         |
SPC 8 882 #1 ---+         |         |         |              |         |         |         |
pac             |         |         |         |              |         |         |         |
 |              |         |         |         |              |         |         |         |
 1            dis       dis       dis       dis            dis       dis       dis       dis
 2            dis       dis       dis       dis            dis       dis       dis       dis
 3            dis       dis       dis       dis            dis       dis       dis       dis
 4            dis       dis       dis       dis            dis       dis       dis       dis
 5           oper      oper      oper      oper           oper      oper      oper      oper
 6           oper      oper      oper      oper           oper      oper      oper      oper
 7            dis       dis       dis       dis            dis       dis       dis       dis
10            dis       dis       dis       dis            dis       dis       dis       dis
11           oper      oper      oper      oper           oper      oper      oper      oper
12           oper      oper      oper      oper           oper      oper      oper      oper
13            dis       dis       dis       dis            dis       dis       dis       dis
14            dis       dis       dis       dis            dis       dis       dis       dis
15            dis       dis       dis       dis            dis       dis       dis       dis
16            dis       dis       dis       dis            dis       dis       dis       dis
```

Also, check "**show npu stats sft**" command in SSD to see if "**lost_fails**" count is increasing or not, as that indicates a loss of internal fabric monitoring packets.

```
# show npu stats sft


lost_fails ------------------------------------------------------------------------+
bonus_fails ---------------------------------------------------------------------+     |
length_fails -------------------------------------------------------------+     |     |
data_fails ---------------------------------------------------------+     |     |     |
last_valid_packet_number ---------------------------------+         |     |     |     |
valid_rcvd_pkts ------------------------------------+         |         |     |     |     |
received_pkts --------------------------+         |         |         |     |     |     |
sent_pkts ----------------------+         |         |         |         |     |     |     |
gen_pkts -------------+         |         |         |         |         |     |     |     |
cpu/inst +            |         |         |         |         |         |     |     |     |
sl       |            |         |         |         |         |         |     |     |     |
 2      0/0 ->       12        12        12        12        12 ->     0     0     0     0
 4      0/0 -> 17042263 17042263 17042263 17042263 17042263 ->     0     0     0     0
16      0/0 ->    89488    89488    89418    89418    89488 ->     0     0     0    70
```

NPU

The NPU (Network Processor Unit) is required to forward a packet from a port to the CPU / process inside the chassis, and vice versa. The NPU subsystem contains a flow database. A flow is a set of packets with similar characteristics, for example: all HTTP uplink packets from a subscriber to a specific server on the internet.

To check NPU on ASR 5500, look for "**show npumgr utilization**" information in the SSD.

```
******** show npumgr utilization information *******


          ---------npu--------
     npu      now    5min  15min
--------  ------ ------ ------
  01/0/1       0%     0%     0%
  01/1/1       0%     0%     0%
  02/0/1       0%     0%     0%
  02/1/1       0%     0%     0%
```

```
03/0/1      0%      0%      0%
03/1/1      0%      0%      0%
04/0/1      0%      0%      0%
04/1/1      0%      0%      0%
05/0/1      0%      0%      0%
05/0/2      0%      0%      0%
05/0/3      0%      0%      0%
05/0/4      0%      0%      0%
06/0/1      0%      0%      0%
06/0/2      0%      0%      0%
06/0/3      0%      0%      0%
06/0/4      0%      0%      0%
07/0/1      0%      0%      0%
07/1/1      0%      0%      0%
08/0/1      0%      0%      0%
08/1/1      0%      0%      0%
09/0/1      0%      0%      0%
09/1/1      0%      0%      0%
10/0/1      0%      0%      0%
10/1/1      0%      0%      0%
```

For ASR 5000, look for "**show npu utilization info card [num]**" in the SSD.

```
 ******** show npu utilization info card 1 *******
Card: 1
  5-Second Average:
    NPU Receive From:
      CPU                 :      0.419 kpps (  0.01%),      4.034 mbps (  0.04%)
      Fabric A            :      0.125 kpps (  0.00%),      0.487 mbps (  0.01%)
      Fabric B            :      0.397 kpps (  0.01%),      1.128 mbps (  0.01%)
      Total               :      0.940 kpps (  0.03%),      5.649 mbps (  0.06%)
    NPU Transmit To:
      CPU                 :      0.451 kpps (  0.02%),      1.173 mbps (  0.01%)
      Fabric A            :      0.418 kpps (  0.01%),      4.003 mbps (  0.04%)
      Fabric B            :      0.071 kpps (  0.00%),      0.443 mbps (  0.00%)
      Total               :      0.940 kpps (  0.03%),      5.618 mbps (  0.06%)
    NPU ME Utilization:
      SCH                 :   Scheduler     (  0.00%)
      QM                  :   Queue Mgr     (  0.00%)
```

```
TX                  :   Csix Tx        (  0.00%)
M1a                 :   Frame Parser   (  0.00%)
M2a                 :   Flow Lkup      (  0.00%)
M3                  :   IP Fwd         (  0.00%)
M4a                 :   Frame Modify   (  0.00%)
M5                  :   IP Fragmnt     (  0.00%)
REAS                :   IP Reassemb    (  0.00%)
ACL                 :   ACL/Exceptn    (  0.00%)
```

If reporting a suspected NPU issue to Cisco Support, please collect SSD, "**show support details to file /flash/[name].tar.gz compress**".

Session Imbalances

Overview

Within StarOS system there are different ways in which sessions may become unbalanced. Assuming normal operation, calls within the system should be equally distributed among the various Active Session Manager (SessMgr) tasks. There are issues that could come up within the system where a noted imbalance in session distribution may be a symptom of a problem either within StarOS or within the network. Some examples of session imbalance would be:

1. Some SessMgr instances have more or fewer calls than others.
2. The distribution of sessions on a particular processor card is different than others.
3. Some call types are notably off from their expected session counts.

Troubleshooting

This section will cover debugging the three scenarios listed above.

1) Some SessMgr instances have more or fewer calls than others.

Identify the task instance(s) of SessMgr which has the unexpected session count. Also confirm that the CPU and Memory utilization for this task are within the defined limits. If the task is over on CPU or Memory, please refer to the section on CPU/Memory issues in the software troubleshooting chapter.

```
[local]5500# show task resources facility sessmgr all
                   task    cputime        memory     files      sessions
 cpu facility      inst used allc   used  alloc used allc  used  allc S status
----------------------- --------- ------------- --------- ------------- ------
 1/0 sessmgr       5008 0.2%  50% 82.41M 230.0M   32  500    --    -- S   good
 1/0 sessmgr         20  12% 100% 444.3M 900.0M   43  500  4068 12000 I   good
 1/0 sessmgr         27  11% 100% 446.0M 900.0M   39  500  4056 12000 I   good
 1/0 sessmgr         59  11% 100% 445.6M 900.0M   40  500  244  12000 I   good
 1/0 sessmgr         72  13% 100% 447.5M 900.0M   42  500  4088 12000 I   good
 1/0 sessmgr        118  13% 100% 446.4M 900.0M   43  500  4071 12000 I   good
```

```
1/0 sessmgr        121  11% 100% 446.0M 900.0M   40  500  4076 12000 I   good
1/0 sessmgr        164  12% 100% 443.8M 900.0M   42  500  4067 12000 I   good
1/0 sessmgr        169  12% 100% 444.3M 900.0M   43  500  4077 12000 I   good
1/0 sessmgr        191  11% 100% 447.8M 900.0M   43  500  4083 12000 I   good
1/0 sessmgr        220  12% 100% 444.4M 900.0M   42  500  4070 12000 I
```

Did this SessMgr crash? If the task did crash, and if this crash was not previously reported to Cisco, please capture SSD ("**show support details to file /flash/[filename].tar.gz -compress**") and contact Cisco technical support.

CLI: "**show crash list**" in "Software Crashes" section in Platform Troubleshooting.

- Check for recent calls. Compare the SessMgr in question to ones with normal load. In this example, SessMgr instance 59 (as seen above) is the one with low session count.

```
[local]5500# show subscribers summary connected-time less-than 60 smgr-instance 59 | grep
Total
 Total Subscribers:             48
```

Run this same command against other SessMgr instances. This will show the number of total sessions that have been connected to this instance for 60 seconds or less.

- Check the historical info for the SessMgr.

```
[local]5500# show session subsystem facility sessmgr instance 59
~~Output is not being shown as results are very configuration dependent.
```

Look for setup times, disconnect reasons, call types, and data statistics. There are MANY fields that can be examined and this could take some time. These fields can also be compared to the same output for SessMgr instances that are not having issues, to try and identify where the issue might be.

- Look for logs that report call setup issues for particular SessMgr instances
- If nothing seems out of the ordinary with SessMgr in question .i.e. new calls are successfully attaching, existing calls are passing traffic, and the manager itself appears

in working order, then this issue could have been caused by a transient event (internal or external), that has self-corrected. If this is the case, check historical data such as bulkstats, SNMP traps or logs, or outstanding alarms to see if a start time for the imbalance can be identified.

- Monitor to make sure the session counts continue to equalize (catch up) with other working SessMgrs over time.

> Below CLI commands requires CLI test-commands password configured in the chassis. Please use the command with caution!
> Many TEST commands are processor-intensive and can cause serious system problems if used too frequently.

If required to check specific type of calls the following method can be used:

```
show session subsystem data-info verbose | grep "PDN-TYPE-IPv4 CONNECTED"
```

or any other "In-progress calls" which can be found in commands output:

```
show session subsystem facility sessmgr all debug-info
```

To filter In-progress calls types, the following options can be used with grep in above "show session subsystem data-info verbose"

```
CSCF-CALL-ARRIVED, CSCF-REGISTERING, CSCF-REGISTERED, LCP-NEG, LCP-UP, AUTHENTICATING, BCMCS
SERVICE AUTHENTICATING, AUTHENTICATED, PDG AUTHORIZING, PDG AUTHORIZED, IMS AUTHORIZING, IMS
AUTHORIZED, MBMS UE AUTHORIZING, MBMS BEARER AUTHORIZING, DHCP PENDING, L2TP-LAC CONNECTING,
MBMS BEARER CONNECTING, CSCF-CALL-CONNECTING, IPCP-UP, NON-ANCHOR CONNECTED, AUTH-ONLY CON-
NECTED, SIMPLE-IPv4 CONNECTED, SIMPLE-IPv6 CONNECTED, SIMPLE-IPv4+IPv6 CONNECTED, MOBILE-IPv4
CONNECTED, MOBILE-IPv6 CONNECTED, GTP CONNECTING, GTP CONNECTED, PROXY-MOBILE-IP CONNECTING,
PROXY-MOBILE-IP CONNECTED, EPDG RE-AUTHORIZING, HA-IPSEC CONNECTED, L2TP-LAC CONNECTED, HNBGW
CONNECTED, PDP-TYPE-PPP CONNECTED, IPSG CONNECTED, BCMCS CONNECTED, PCC CONNECTED, MBMS UE CON-
NECTED, MBMS BEARER CONNECTED, PAGING CONNECTED, PDN-TYPE-IPv4 CONNECTED, PDN-TYPE-IPv6 CON-
NECTED, PDN-TYPE-IPv4+IPv6 CONNECTED, CSCF-CALL-CONNECTED, MME ATTACHED, HENBGW CONNECTED
```

For sessmgr imbalance in some cases it is useful to compare In-Progress Call Duration Statistics (1min, 2min, 15min, 1h ...)

```
show session subsystem facility sessmgr debug-info verbose | grep 2min
```

In some cases it is useful to check the differences in Setup Time Statistics (different ranges):

```
show session subsystem facility sessmgr debug-info verbose | grep "400..500ms"
```

The same methodology can be used for aaamgr's imbalance issues for specific counters:

```
show session subsystem facility sessmgr debug-info verbose | grep "Current aaa acct archived"
```

For more info please see the command "**show session subsystem facility sessmgr all debug-info**" which tracks a ton of information on a sessmgr instance basis. Any problem with a sessmgr will most likely be found analyzing the output of this command, especially if multiple snapshots are taken. Getting to the root cause though may not necessarily be as straightforward.

2) The distribution of sessions on a particular processor card is different than others.

In case where all Session Managers on a card are off from the rest of the chassis, it is more likely that the behavior being seen on the SessMgr instances are symptomatic of another issue that affects an entire card. The initial steps to go through are described in "*(1) Some SessMgr instances have more or fewer calls than others*".

Check disconnect reasons. There are many valid reasons why calls will disconnect from the system. However, in case of an issue on an entire processor card, to identify a particular failure reason this ouput will further pinpoint where to look in the system. For a system that has been up for some time, it might be best to clear the disconnect reasons after initial check to see what is incrementing.

CLI:

- show session disconnect-reasons (to check the stats)
- clear session disconnect-reasons (to clear the stats)

```
[local]5500# show session disconnect-reasons
 Session Disconnect Statistics
 Total Disconnects: 437042538
 Disconnect Reason                                    Num Disc  Percentage
-----------------------------------------------------  ----------  ----------
Remote-disconnect                                    169318214    38.74182
Idle-Inactivity-timeout                                 326879     0.07479
Invalid-source-IP-address                                  657     0.00015
MIP-remote-dereg                                     127903569    29.26570
MIP-lifetime-expiry                                      99599     0.02279
static-ip-validation-failed                                 16     0.00000
Local-purge                                          139393476    31.89472
gtp-user-auth-failed                                        12     0.00000
No-response                                                116     0.00003
  [local]5500# clear session disconnect-reasons
   [local]5500# show session disconnect-reasons
Session Disconnect Statistics
 Total Disconnects: 1066
 Disconnect Reason                                    Num Disc  Percentage
-----------------------------------------------------  ----------  ----------
Remote-disconnect                                         1063    99.71857
Local-purge                                                  3     0.28143
```

Check diameter routing if using diameter proxy. In many configurations utilizing diameter servers across various interfaces (ie: s6b, Gx, Gy, Rf, etc.) is done with Diameter proxy. This means that each processor card maintains its own TCP connection to different servers in the network. It is possible there could be an issue relating back to one particular card.

CLI:

- show diameter peers full all | grep "Peers in"
- show diameter endpoints
- show subscribers data-rate card-num 3
- show subscribers summmary card-num 3
- show snmp trap history verbose | more
- show alarm outstanding
- show session counters historical all

Below are examples of above CLI commands.

```
[local]5500# show diameter peers full all | grep "Peers in"
Tuesday May 05 11:44:31 EDT 2015
  Peers in OPEN state: 266
   Peers in CLOSED state: 0
   Peers in intermediate state: 0
```

If some peers show as either "closed" or "intermediate" take a look at the individual diameter endpoints and see if these peers all relate back to a particular processor card.

First, get a list of the endpoints:

```
[local]5500# show diameter endpoints
 Tuesday May 05 11:49:59 EDT 2015
  Context: Ingress1                Endpoint: GSM3G-GY
                                     Context: Ingress2                Endpoint: PGW-LTE-GX1
                                    Context: Ingress2                Endpoint: PGW-LTE-S6B1
                            Context: Ingress2                Endpoint: PGW-LTE-S6B2
```

Look at individual end points. NOTE: The leading number in the "Local Hostname" row indicates which processor card the connection is coming from, "0007" in the output below equates to the processor card in slot 7.

```
[local]5500# show diameter peers full endpoint PGW-LTE-GX1
 ~~~output cut to one instance~~~
  Peer Hostname: PGW-LTE-server1.test.com
  Local Hostname: 0007-diamproxy.PGW-LTE-client1.test.com
  Peer Realm: test1.com
  Local Realm: test2.com
  Peer Address: xx:xx:xxxx:xxxx:xxx:xx:::3899
  Local Address: xx:xx:xxx:xxxx:xxx:xx:::52119
  State: OPEN [TCP]
  CPU: 3/1                                Task: diamproxy-55
                      Messages Out/Queued: N/A
                Supported Vendor IDs: 8164
  Admin Status: Enable
```

```
 DPR Disconnect: N/A
Peer Backoff Timer running:N/A
Peers Summary:
Peers in OPEN state: 14
 Peers in CLOSED state: 0
 Peers in intermediate state: 0
 Total peers matching specified criteria: 14
```

Another potential failure point per-card would be if traffic was somehow not getting from sessions on the card to linecard / port on the chassis and out to the network. To check for this, we need to see if new sessions are attaching to the card, and whether existing sessions are passing traffic. See example below.

To check if sessions are passing traffic:

```
[local]5500# show subscribers data-rate card-num 3
Tuesday May 05 13:11:23 EDT 2015
 Total Subscribers       : 605342
    Active                  : 605342        Dormant                 : 0
         peak rate from user(bps): n/a*          peak rate to user(bps)  : n/a*
ave rate from user(bps) : 178625806     ave rate to user(bps)   : 1342658979
  sust rate from user(bps): 178592595     sust rate to user(bps)  : 1342448300
  peak rate from user(pps): n/a*          peak rate to user(pps)  : n/a*
ave rate from user(pps) : 7136          ave rate to user(pps)   : 1494
        sust rate from user(pps): 13578         sust rate to user(pps)  : 7152
```

* Peak rates cannot be computed for multiple subscribers

To check if new sessions are attaching to the card, run the following command multiple times to see if the Total Subscribers, as well as the various types of subscribers, increases between iterations. Please be aware that the call count would go both up and down over time as calls connect and disconnect.

```
[local]5500# show subscriber summary card-num 3
Tuesday May 05 13:15:46 EDT 2015
 Total Subscribers:             597831
    Active:                         597831        Dormant:                        0
```

```
        LAPI Devices:                  0
        pdsn-simple-ipv4:              0             pdsn-simple-ipv6:              0
        pdsn-mobile-ip:                0             ha-mobile-ipv6:                0
        hsgw-ipv6:                     0             hsgw-ipv4:                     0
        hsgw-ipv4-ipv6:                0             pgw-pmip-ipv6:                 104399
    pgw-pmip-ipv4:                  0             pgw-pmip-ipv4-ipv6:            76648
     pgw-gtp-ipv6:                  253637         pgw-gtp-ipv4:                  0
        pgw-gtp-ipv4-ipv6:             194146        sgw-gtp-ipv6:                  0
        sgw-gtp-ipv4:                  0             sgw-gtp-ipv4-ipv6:             0
        sgw-pmip-ipv6:                 0             sgw-pmip-ipv4:                 0
        sgw-pmip-ipv4-ipv6:            0             pgw-gtps2b-ipv4:               0
```

3) Some call types are notably off from their expected session counts.

Troubleshooting a scenario where certain call types are failing should start with commands mentioned earlier in this section. In particular "show session disconnect-reasons" and "show sub summary smgr-instance <SessMgr instance>". Looking for other services that are either in a bad state or down, as with the diameter peering commands above, would also be a good place to start. If a timestamp can be found relating to the start of the call loss, historical data from the chassis, or in off-chassis storage (bulkstats, syslog servers, SNMP trap servers, etc) should be consulted to see if there were any chassis or network events corresponding to start of the call degradation. "show session subsystem facility sessmgr" reports call type related information. Logs and data on the chassis can also be parsed for clues:

```
[local]5500# show snmp trap history verbose | more
Tuesday May 05 13:50:40 EDT 2015
There are 673 historical trap records (5000 maximum)

Timestamp                Trap Information
------------------------ ------------------------------------------------------
   ~~~TRAPS

[local]5500# show logs level error | more
   ~~~ Show only "error" level logs.

[local]5500# show logs level error | more
   ~~~ Show all logs.
```

```
[local]5500# show alarm outstanding
Tuesday May 05 13:54:20 EDT 2015
Sev Object          Event
--- ----------      ------------------------------------------------------------

   ~~~ Outstanding alarms

[local]5500# show session counters historical all
Tuesday May 05 13:55:51 EDT 2015
                          ------------------- Number of Calls ------------------
(A+R+D+F+H+R)
 Intv  Timestamp              Arrived   Rejected  Connected    Disconn     Failed      Handoffs
Renewals       CallOps
 ----  ------------------- ---------- ---------- ---------- ---------- ---------- -------------
------------- -------------
    1  2015:05:05:13:45:00     994093          0     618819     619685          0        750050
1270760       3634588
    2  2015:05:05:13:30:00     908881          0     699786     465012          0        421090
273136        2068119
    3  2015:05:05:13:15:00     997676          0     622896     649368          0        750058
311257        2708359

   ~~~ Historic Session counters. Look for big moves in any of the captures. This may help
pinpoint when an issue started.
```

CDMA

CDMA Overview

Overview

This chapter covers components of a CDMA network, different interfaces in the network and basic call flows involved in an UE registration. This chapter also includes various ASR 5000/ASR 500 platform commands to verify functionality of CDMA and available troubleshooting commands.

General Architecture


The ASR 5000/ASR 5500 provides wireless carriers with a flexible solution that functions as a Packet Data Serving Node (PDSN) in CDMA 2000 wireless data networks.

When supporting Simple IP data applications, the system is configured to perform the role of a Packet Data Serving Node (PDSN) within the carrier's 3G CDMA2000 data network. The PDSN terminates the mobile subscriber's Point-to-Point Protocol (PPP) session and then routes data to and from the Packet Data Network (PDN) on behalf of the subscriber. The PDN can consist of Wireless Application Protocol (WAP) servers or it can be the Internet.

When supporting Mobile IP and/or Proxy Mobile IP data applications, the system can be configured to perform the role of the PDSN/Foreign Agent (FA) and/or the Home Agent (HA) within the carrier's 3G CDMA2000 data network. When functioning as an HA, the system can either be located within the carrier's 3G network or in an external enterprise or ISP network. The PDSN/FAs function is to terminate the mobile subscriber's PPP session, and then route data to and from the appropriate HA on behalf of the subscriber.

The below diagram depicts a sample network configuration wherein the PDSN/FA and HA are separate systems.

Image - PDSN/FA and HA Network Deployment Configuration Example



Interface Descriptions

This section describes the primary interfaces used in a CDMA2000 wireless data network deployment.

R-P Interface

This interface exists between the Packet Control Function (PCF) and the PDSN/FA and implements the A10 and A11 (data and bearer signaling respectively) protocols defined in 3GPP2 specifications.

The PCF can be co-located with the Base Station Controller (BSC) as part of the Radio Access Node (RAN).

Pi Interfaces

The Pi interface provides connectivity between the HA and its corresponding FA. The Pi interface is used to establish a Mobile IP tunnel between the PDSN/FA and HA.

PDN Interfaces

PDN interface provides connectivity between the PDSN and/or HA to packet data networks such as the Internet or a corporate intranet.

AAA Interfaces


Ethernet interfaces carry AAA messages to and from Radius accounting and authentication servers. User-based Radius messaging is transported using the Ethernet line cards.

Basic CDMA Call Flow

CDMA data consists of two main types of call flows; Simple IP (SIP) and Mobile IP (MIP).

For Simple IP, just a PDSN is required to communicate with the RAN, and an IP pool is required to provide an IP address to the subscriber. For Mobile IP, both an FA and HA are required in order to extend the anchor point of the call beyond the PDSN to either an entirely different HA node or to a co-located node.


The following figure and the text that follows provides a high-level view of the steps required to make a Simple IP call that is initiated by the MN to an end host:



Simple IP Call Flow Description:

1. Mobile Node (MN) secures a traffic channel over the air link with the RAN through the BSC/PCF.
2. The PCF and PDSN establish the R-P interface for the session.
3. The PDSN and MN negotiate Link Control Protocol (LCP).
4. Upon successful LCP negotiation, the MN sends a PPP Authentication Request message to the PDSN.
5. The PDSN sends an Access Request message to the Radius AAA server.
6. The Radius AAA server successfully authenticates the subscriber and returns an Access Accept message to the PDSN. The Accept message may contain various attributes to be assigned to the MN.
7. The PDSN sends a PPP Authentication Response message to the MN.
8. The MN and the PDSN negotiate the Internet Protocol Control Protocol (IPCP) that results in the MN receiving an IP address.
9. The PDSN forwards a Radius Accounting Start message to the AAA server, fully establishing the session allowing the MN to send/receive data to/from the PDN.
10. The PDSN returns a Mobile IP Registration Reply to the MN, establishing the session allowing the MN to send/receive data to/from the PDN.
11. Upon completion of the session, the MN sends an LCP Terminate Request message to the PDSN to end the PPP session.
12. The BSC closes the radio link while the PCF closes the R-P session between it and the PDSN. All PDSN resources used to facilitate the session are reclaimed (IP address, memory, etc.).
13. The PDSN sends accounting stop record to the AAA server, ending the session.

The following figure provides a high-level view of the steps required to make a Mobile IP call that is initiated by the MN to a HA and the text that follows, explains each step in detail:



Mobile IP Call Flow Description:

1. Mobile Node (MN) secures a traffic channel over the airlink with the RAN through the BSC/PCF.
2. The PCF and PDSN establish the R-P interface for the session.
3. The PDSN and MN negotiate Link Control Protocol (LCP).
4. The PDSN and MN negotiate the Internet Protocol Control Protocol (IPCP).

5 The PDSN/FA sends an Agent Advertisement to the MN.

6 The MN sends a Mobile IP Registration Request to the PDSN/FA.

7 The PDSN/FA sends an Access Request message to the visitor AAA server.

8 The visitor AAA server proxies the request to the appropriate home AAA server.

9 The home AAA server sends an Access Accept message to the visitor AAA server.

10 The visitor AAA server forwards the response to the PDSN/FA.

11 Upon receipt of the response, the PDSN/FA forwards a Mobile IP Registration Request to the appropriate HA.

12 The HA sends an Access Request message to the home AAA server to authenticate the MN/subscriber.

13 The home AAA server returns an Access Accept message to the HA.

14 Upon receiving response from home AAA, the HA sends a reply to the PDSN/FA establishing a forward tunnel. Note that the reply includes a Home Address (an IP address) for the MN.

15 The PDSN/FA sends an Accounting Start message to the visitor AAA server. The visitor AAA server proxies messages to the home AAA server as needed.

16 The PDSN returns a Mobile IP Registration Reply to the MN, establishing the session allowing the MN to send/receive data to/from the PDN.

17 Upon session completion, the MN sends a Registration Request message to the PDSN/FA with a requested lifetime of 0.

18 The PDSN/FA forwards the request to the HA.

19 The HA sends a Registration Reply to the PDSN/FA accepting the request.

20 The PDSN/FA forwards the response to the MN.

21 The MN and PDSN/FA negotiate the termination of LCP effectively ending the PPP session.

22 The PCF and PDSN/FA terminate the R-P session.

23 The HA sends an Accounting Stop message to the home AAA server.

24 The PDSN/FA sends an Accounting Stop message to the visitor AAA server.

25 The visitor AAA server proxies the accounting data to the home AAA server.

For more information, please refer to official Cisco ASR 5x00 PDSN/HA Administration Guides.

PDSN / FA

Overview

This section covers software implementation and basic troubleshooting for PDSN/FA.

Troubleshooting

Troubleshooting PDSN/FA requires an understanding of the following protocols and how they fit into the call flow for SIP and MIP. This chapter will provide troubleshooting assistance on the following protocols as they apply to both SIP and MIP.

- A10/A11 - link between the PDSN and Packet Control Function (PCF)
- PPP - Link between the PDSN and the subscriber
- Radius authentication and accounting - Link between the PDSN and the Radius server
- Mobile IP - Upper layer protocol residing on PPP and connecting between subscriber and PDSN, and then further via Pi interface between the FA and HA (the MIP tunnel)

The PDSN functionality is implemented in an A11 mgr facility.

PDSN Service

The PDSN service allows for communicating between the PDSN and the PCFs using A11 and PPP. The various links between PCFs and the PDSN are specified using an SPI config line for each link, which includes the IP address or range of IP addresses of the PCF(s) along with a unique SPI index value and a password (secret). Other configurables include IP source violation thresholds, the type of ppp authentication, a pointer to the FA destination context, and the bind address.

Verifying PDSN Service

The PDSN service will be automatically started when the bind address command is added. The service can be confirmed as started with "show service all" as well as with "show pdsn-service all" which will report back all the settings, both default and configured. In the following output there are two services started, one for EVDO Rev A call types and the other for EVDO 1X, but in

fact both types could be handled by one service - The provider in this case implemented separate services. Just the more significant parameters are shown:

```
[local]PDSN> show service all

ContextID   ServiceID   ContextName   ServiceName   State         MaxSessions   Type
---------   ---------   -----------   -----------   ----------    -----------   ----
2           1           source        OpenRp        Started       5000000       pdsn
2           2           source        OpenRp-1x     Started       5000000       pdsn
[local]PDSN> show pdsn-service all

Service name: OpenRp
  Context: source
  Bind:                 Done
  Local IP Address:     10.10.10.10       Local IP Port:          699
  Lifetime:             00h30m00s         Retransmission Timeout: 3 (secs)
  Max Retransmissions:  5                 Setup Timeout         : 60 (secs)
  MIP FA Context: destination

  PPP Authentication:  CHAP 1

  Max sessions:            5000000
  Simple IP Sessions:      Allowed
  A11 signalling packet IP header DSCP marking: 0x0
  IP SRC-Violation Reneg Limit: 50        IP SRC-Violation Drop Limit:  100
  IP SRC-Violation Clear-on-ValidPDU: Yes IP SRC-Violation Period:      60 secs

  SPI(s):
    Remote Addr: 10.204.3.160/27          Description:
      Hash Algorithm:  MD5                SPI Num:  257
      Replay Protection: Timestamp        Timestamp Tolerance: 6 (secs)
...

  Service Status:          Started
  Overload Policy:         Reject (Reject code: Insufficient Resources)
  Newcall Policy:          None
  Service Option Policy:   Enforce
  Service Options:         7,15,22,23,24,25,33,59,64,67
  Session license limit:   OK
```

```
  EV-DO Rev A PDSN Session license limit:   OK
  ROHC IP Header Compression : Disabled
```

In order to view the passwords associated with an SPI entry, use command "**show config context [name] showsecrets**":

```
pdsn-service PDSNsvc1
 spi remote-address 10.0.0.0/8 spi-number 256 secret testtesttesttest timestamp-tolerance 6
```

Example A11 messages

Examples of call control messages carried over the A11 link that one would want to be familiar with include the following. These could be captured in a monitor subscriber trace and statistics on their frequency can be retrieved.

- Registration Request (Connection Setup)
- Registration Reply
- Session Update - Communicate QoS info to PCF for EVDO Rev A
- Session Update Ack
- Registration Request (Active Start)
- Registration Request (Active Stop)
- Registration Reply (Accepted) (could be for any message)
- Registration Update - (Teardown)
- Registration Ack

show rp statistics [peer-address <peer address>] [pcf-summary]

To determine the number of and success rate of A11 messaging, run "**show rp statistics [peer-address]**". The information that can be analyzed is extensive, and here are a few snippets that may be the most interesting:

```
[local]PDSN-FA> show rp statistics
Session Stats:
  Total Sessions Current:         693060
  Total Setup:                    251690968 Total Released:          251004945
  Total Rev-A Sessions Current:   513608
  Total Rev-A Setup:              2902552440 Total Rev-A Released:    2905913531
```

```
Session Releases:
  De-registered:             625228420     Lifetime Expiry:          480874
  PPP Layer Command:         3902253655    PCF-Monitor Fail:         0
  GRE Key Mismatch:          2760239       Purged via Audit:         0
  Other Reasons:             15249053

A10 Stats:
...

Registration Request/Reply:
  Total RRQ/Renew/Dereg RX: 1865609874    Total Accept:             1771652785
  Total Denied:              74691983      Total Discard:            19265106
  Init RRQ RX:               334769449     Init RRQ Accept:          1605714446
  Init RRQ Denied:           72939567      Init RRQ Discard:         10136926
  Renew RRQ RX:              25059017      Renew RRQ Accept:         2591155576
  Renew Actv Start Accept:   1620013447    Renew Actv Stop Accept:   3172517390
  Renew RRQ Denied:          1553147       Renew RRQ Discard:        1495762
  Dereg RRQ RX:              1505783217    Dereg RRQ Accept:         3360918218
  Dereg Active Stop Accept: 2431998799
  Dereg RRQ Denied:          199269        Dereg RRQ Discard:        7634227
  Reply Send Error:          0             Airlink Seq Num Invalid: 3432185
  Intra PDSN Active Handoff                Intra PDSN Dormant Handoff
    RRQ Accepted:            99469754        RRQ Accepted:           1093610388
  Inter PDSN Handoff
   Total RRQ Accepted:       2976123951
   Init RRQ Accepted:        2940945806      Renew RRQ Accepted:     35178145
  Rev-A RRQ RX:              2907024794    Rev-A RRQ Accept:         2902311549
  Rev-A RRQ Denied:          1077569       Rev-A RRQ Discard:        3635676

Registration Request Denied:
  Unspecified Reason:        13185685      Admin Prohibited:         178
  Insufficient Resources:    5070          PCF Failed Auth:          235509
  Identification Mismatch:   2934
  Poorly Formed Request:     0
  Unknown PDSN Address:      71161403
...
RRQ Denied - Insufficient Resource Reasons:
...
```

```
RRQ Denied - Poorly Formed Request Reasons:
...
RRQ Denied - Unspecified Reasons:
  Null Packet Received:     0             LifeTime Zero In Initial RRQ: 18
  Session Manager NotReady: 938185        Closed RP Handoff In Progress:0
  No Airlink Setup:         2040273       Intra PDSN Handoff Triggered:  308109
  During Handoff:           72463
...
Registration Update/Ack:
...
Registration Update Send Reason:
...
Registration Update Denied:
  Reason Unspecified:       5367918
...
Security Violations:
  Total Violations:         235845        Bad SPI #:               343
  Bad Authenticator:        0             Unknown SPI #:           235502
```

A number of issues can be narrowed down to a specific PCF peer, in which case the [peer-address <peer address>] qualifier may turn out to be extremely valuable.

The table below is displayed on a PCF-basis when using the pcf-summary option:

```
[local]PDSN> show rp statistics pcf-summary
PDSN 10.211.28.133
PCF             A11        A11        Curr       Curr       RRQ        RRQ
IP              RRQ        RRP        Sess       RevA       Accept     Discard
10.204.221.65   9251103    9251090    487        516         9250804    13
10.204.221.66   9450869    9450855    518        551         9450581    14
10.204.221.67   9153903    9153896    493        525         9153630    7
10.204.221.68   9649240    9649228    487        529         9648930    12
10.204.221.70   9636193    9636182    550        590         9635899    12
10.204.221.72   9637108    9637097    484        513         9636825    11
10.204.221.74   9701789    9701777    520        561         9701466    12
10.204.221.76   9634613    9634603    509        541         9634383    10
10.204.221.78   9589452    9589441    479        519         9589091    11
```

```
10.204.221.80   9663444    9663436    467        494        9663125    8
10.204.221.193  5846030    5846027    342        349        5845925    3
```

show rp [summary | peer-address <peer>]

A11-related counters/statistics similar to "show rp stat" discussed above are available with "show rp summary" or on a peer address basis, though this command is not often used for troubleshooting.

```
[local]PDSN> show rp summary

RP Summary:
  430167 RP Sessions In Progress

Registration Request/Reply:
  Renew RRQ Accepted: 2578267             Discarded: 0
  Intra PDSN Active H/O RRQ Accept: 16682 Intra PDSN Dormant H/O RRQ Accept: 1353494
  Inter PDSN Handoff RRQ Accepted: 321301
  Reply Send Error: 0

Registration Update/Ack:
  Initial Update Transmitted: 1370184     Update Retransmitted: 18122
  Denied: 0                               Not Acknowledged: 21748
  Reg Ack Received: 1366559               Reg Ack Discarded: 5
  Update Send Error: 0

Registration Update Send Reason:
  Lifetime Expiry:  0                     Upper Layer Initiated: 8
  Other Reasons: 0                        Handoff Release: 1370176
  Session Manager Died: 0

Registration Update Denied:
  Reason Unspecified: 0                   Admin Prohibited: 0
  PDSN Failed Authentication: 0           Identification Mismatch: 0
  Poorly Formed Update: 0

Session Update/Ack:
  Initial Update Transmitted: 389872      Update Retransmitted: 25
```

```
  Denied: 0                              Not Acknowledged: 21748
  Sess Update Ack Received: 389869       Sess Update Ack Discarded: 0
  Update Send Error: 0

Session Update Send Reason:
  Always On:          0                  QoS Info:           389872
  TFT Violation:      0                  Traffic Violation:  0
  Traffic Policing:   0                  Operator Triggered: 0

Session Update Denied:
  Reason Unspecified: 0                  Insufficient Resources: 0
  Admin Prohibited: 0                    Parameter not updated: 0
  PDSN Failed Authentication: 0
  Identification Mismatch: 0
  Poorly Formed Update: 0
  Profile Id Not Supported: 0            Handoff In Progress:     0

Data:
  GRE Packets Received: 2339908401       GRE Bytes Received: 2318464329
  GRE Packets Sent: 3561128876           GRE Bytes Sent: 2379694759
  GRE Packets Sent in SDB Form: 0        GRE Bytes Sent in SDB Form: 0
  GRE Packets Received with Segmentation Indication: 0
  GRE Packets Sent with Segmentation Indication: 0
  Total Successful Reassembly:                   0
  Total packets processed without proper reassembly: 0
```

show session counters pcf-summary [call-types]

This command lists every PCF and a current count of the number of calls and the type of those calls with the call-types option.

```
[local]PDSN> show session counters [pcf-summary] [call-types]

PCF IP Addr    Sessions  Active  Dormant   SIP   MIP  PMIP  L2TP-LAC  BCMCS  MISC
-----------    --------  ------  -------   ---   ---  ----  --------  -----  ----
10.204.221.65         577      45      532    0  577     0         0      0     0
10.204.221.66         522      41      481    0  522     0         0      0     0
```

```
10.204.221.67          513       60       453     0   512      0          0       0      0
10.204.221.68          565       64       501     0   565      0          0       0      0
10.204.221.70          534       57       477     1   532      0          1       0      0
10.204.221.72          507       50       457     0   506      0          1       0      0
10.204.221.74          529       38       491     0   528      0          0       0      0
PCF IP Addr: 10.204.221.66  , Context name: source
-----------------------------------------------------
Total session connected: 3222457  Current sessions: 529
     529 In-progress calls
      54 In-progress active calls
     475 In-progress dormant calls
       0 In-progress calls @ LCP-NEG state
       0 In-progress calls @ LCP-UP state
       0 In-progress calls @ AUTHENTICATING state
       0 In-progress calls @ BCMCS SERVICE AUTHENTICATING state
       0 In-progress calls @ AUTHENTICATED state
       0 In-progress calls @ L2TP-LAC CONNECTING state
       0 In-progress calls @ IPCP-UP state
       0 In-progress calls @ SIMPLE-IP CONNECTED state
     528 In-progress calls @ MOBILE-IP CONNECTED state
       0 In-progress calls @ PROXY-MOBILE-IP CONNECTED state
       1 In-progress calls @ L2TP-LAC CONNECTED state
       0 In-progress calls @ BCMCS CONNECTED state
       0 In-progress calls @ DISCONNECTING state
Total Statistics:
Packets In: 4337883489        Packets Out: 6371860909
Octets In : 803185429003      Octets Out : 5309260640778
```

show subscriber pcf <pcf address>

Run "show subscriber pcf <pcf address>" to view a list of the current subs for that PCF.

```
[local]PDSN> show sub pcf 1.1.1.1
+-----Access  (S) - pdsn-simple-ip     (M) - pdsn-mobile-ip  (H) - ha-mobile-ip
|     Type:   (P) - ggsn-pdp-type-ppp  (h) - ha-ipsec        (N) - lns-l2tp
|             (I) - ggsn-pdp-type-ipv4 (A) - asngw-simple-ip (G) - IPSG
|             (V) - ggsn-pdp-type-ipv6 (B) - asngw-mobile-ip (C) - cscf-sip
```

```
|             (z) - ggsn-pdp-type-ipv4v6
|             (R) - sgw-gtp-ipv4       (O) - sgw-gtp-ipv6    (Q) - sgw-gtp-ipv4-ipv6
|             (W) - pgw-gtp-ipv4       (Y) - pgw-gtp-ipv6    (Z) - pgw-gtp-ipv4-ipv6
|             (@) - saegw-gtp-ipv4     (#) - saegw-gtp-ipv6  ($) - saegw-gtp-ipv4-ipv6
|             (&) - cgw-gtp-ipv4       (^) - cgw-gtp-ipv6    (*) - cgw-gtp-ipv4-ipv6
|             (p) - sgsn-pdp-type-ppp  (s) - sgsn            (4) - sgsn-pdp-type-ip
|             (6) - sgsn-pdp-type-ipv6 (2) - sgsn-pdp-type-ipv4-ipv6
|             (L) - pdif-simple-ip     (K) - pdif-mobile-ip  (o) - femto-ip
|             (F) - standalone-fa      (J) - asngw-non-anchor
|             (e) - ggsn-mbms-ue       (i) - asnpc           (U) - pdg-ipsec-ipv4
|             (E) - ha-mobile-ipv6     (T) - pdg-ssl         (v) - pdg-ipsec-ipv6
|             (f) - hnbgw-hnb          (g) - hnbgw-iu        (x) - s1-mme
|             (a) - phsgw-simple-ip    (b) - phsgw-mobile-ip (y) - asngw-auth-only
|             (j) - phsgw-non-anchor   (c) - phspc           (k) - PCC
|             (X) - HSGW               (n) - ePDG            (t) - henbgw-ue
|             (m) - henbgw-henb        (q) - wsg-simple-ip   (r) - samog-pmip
|             (D) - bng-simple-ip      (l) - pgw-pmip        (u) - Unknown
|             (+) - samog-eogre
|
|+----Access  (X) - CDMA 1xRTT         (E) - GPRS GERAN      (I) - IP
||    Tech:   (D) - CDMA EV-DO         (U) - WCDMA UTRAN     (W) - Wireless LAN
||            (A) - CDMA EV-DO REVA    (G) - GPRS Other      (M) - WiMax
||            (C) - CDMA Other         (N) - GAN             (O) - Femto IPSec
||            (P) - PDIF               (S) - HSPA            (L) - eHRPD
||            (T) - eUTRAN             (B) - PPPoE           (F) - FEMTO UTRAN
||            (H) - PHS                (Q) - WSG             (.) - Other/Unknown
||
||+---Call    (C) - Connected          (c) - Connecting
|||   State:  (d) - Disconnecting      (u) - Unknown
|||           (r) - CSCF-Registering   (R) - CSCF-Registered
|||           (U) - CSCF-Unregistered
|||
|||+--Access  (A) - Attached           (N) - Not Attached
||||  CSCF    (.) - Not Applicable
||||  Status:
||||
||||+-Link    (A) - Online/Active      (D) - Dormant/Idle
||||| Status:
|||||
```

```
|||||+Network (I) - IP                (M) - Mobile-IP         (L) - L2TP
||||||Type:   (P) - Proxy-Mobile-IP   (i) - IP-in-IP          (G) - GRE
||||||        (V) - IPv6-in-IPv4       (S) - IPSEC             (C) - GTP
||||||        (A) - R4 (IP-GRE)        (T) - IPv6              (u) - Unknown
||||||        (W) - PMIPv6(IPv4)       (Y) - PMIPv6(IPv4+IPv6) (R) - IPv4+IPv6
||||||        (v) - PMIPv6(IPv6)       (/) - GTPv1(For SAMOG)  (+) - GTPv2(For SAMOG)
||||||
||||||
vvvvvv CALLID   MSID            USERNAME               IP                           TIME-IDLE
------ -------- --------------- ---------------------- ---------------------------- ---------
MACNDM 000a0360 123451234567899 1234568435@cisco.com   55.55.55.55                  00h13m49s
```

Monitoring subscriber sessions

Monitoring specific subscriber sessions with mon sub is probably one of the most valuable troubleshooting approaches available. By default, mon sub will automatically capture all A11, PPP and Radius protocol output as well as user-plane data. Increasing the verbosity to level 2 should be sufficient. For dataplane issues, the Hex/ASCII options are of course always available.

If the issue being troubleshot is specifically related to A11, then note that monitoring by username will miss the A11 exchanges due to the fact that the username is not known at the beginning of the flow. In such cases, take an initial trace by username, then note down the MSID from the A11 RRQ (or Radius Auth msg), and then re-run the mon sub by MSID to catch output from the start.

If using the monitor subscriber menu, the following options are valuable for both MIP and SIP.

- Because the initial call setup messages indicate the RAN technology, options for EVDO Rev 0, Rev A, and 1X exist for distinguishing such calls
- Since some issues encountered are specific to a PCF (or range of PCFs), the monitor by PCF IP option may prove to be very valuable

```
a) By MSID/IMSI
b) By Username
c) By Callid
d) By IP Address
f) Next-Call
k) Next-1xRTT Call
```

```
       m) Next-CLOSEDRP Call - refers to a Nortel proprietary PDSN service that uses L2TP
protocol
       n) Next-EVDO-Rev0 Call
       o) Next-EVDO-RevA Call
       z) By PCF IP Address
      13) Next-OpenRP Call
```

show rp counters (callid | msid | username) <call identifier>

RP-related counters can be retrieved with "show rp counters (callid | msid | username) <call identifier>" and may be useful in very specific troubleshooting scenarios where counts of messaging for a subscriber over a period of time may be useful.

```
 Username: 1234551212@cisco.com  Callid: 00082704 Msid: 123451234567899
 Registration Request/Reply:
   Renew RRQ Accepted: 718                 Discarded: 0
   Intra PDSN Active H/O RRQ Accept: 0     Intra PDSN Dormant H/O RRQ Accept: 2
   Inter PDSN Handoff RRQ Accepted: 1
   Reply Send Error: 0

 Registration Update/Ack:
   Initial Update Transmitted: 2           Update Retransmitted: 10
   Denied: 0                               Not Acknowledged: 12
   Reg Ack Received: 0                     Reg Ack Discarded: 0
   Update Send Error: 0

 Registration Update Send Reason:
   Lifetime Expiry:  0                     Upper Layer Initiated: 0
   Other Reasons: 0                        Handoff Release: 2
   Session Manager Exited: 0

 ...

 Session Update/Ack:
   Initial Update Transmitted: 1           Update Retransmitted: 0
   Denied: 0                               Not Acknowledged: 0
   Sess Update Ack Received: 1             Sess Update Ack Discarded: 0
   Update Send Error: 0
```

```
Session Update Send Reason:
  Always On:        0                    QoS Info:           1
  TFT violation:    0                    Traffic Violation:  0
  Traffic Policing: 0                    Operator Triggered: 0


GRE Receive:
  Total Packets Received:   3995         Protocol Type Error:     0
  Total Bytes Received:     346893       GRE Key Absent:          0
                                         GRE Checksum Error:      0
                                         Invalid Packet Length:   0

GRE Send:
  Total Packets Sent:       2439
  Total Bytes Sent:         395120
  Total Packets Sent in SDB:0
  Total Bytes Sent in SDB:  0
```

show rp full (callid | msid | username) <call identifier>

Another view of A11-related information for a subscriber can be found with "show rp full". Fields of interest may be the service option, remaining lifetime and handoff info.

```
[local]PDSN-FA> show rp full msid 123456789123456

Username: 1234567890@cisco.com  Callid: 00082704 Msid: 123456789123456
A10 Connection #1:(Main)
  PCF Address: 192.168.1.10              PDSN Address: 192.168.1.1
  MN Sess Ref ID: 1                      GRE Key: 172481
  Service Option: 59
Flow Control State : XON
  Lifetime: 00h30m00s                    Remaining Lifetime: 00h23m39s
 GRE Receive:
  Total Packets Rcvd: 226                Total Bytes Rcvd: 19912
 GRE Send:
  Total Packets Sent: 151                Total Bytes Sent: 23828
  Data Over Signaling Packets: 0         Data Over Signaling Bytes: 0
```

```
 IP Header compression:
    Forward: ROHC not negotiated
    Reverse: ROHC not negotiated
...

  SPI: 257
  Prev System Id: 0                       Current System Id: 0
  Prev Network Id: 0                      Current Network Id: 0
  Prev Packet Zone Id: 0                  Current Packet Zone Id: 0
  BSID: 007700050003                      GRE Segmentation : Disabled

Registration Request/Reply:
  Renew RRQ Accepted: 719                 Discarded: 0
  Intra PDSN Active H/O RRQ Accept: 0     Intra PDSN Dormant H/O RRQ Accept: 2
  Inter PDSN Handoff RRQ Accepted: 1
  Reply Send Error: 0

Registration Update/Ack:
  Initial Update Transmitted: 2           Update Retransmitted: 10
  Denied: 0                               Not Acknowledged: 12
  Reg Ack Received: 0                     Reg Ack Discarded: 0
  Update Send Error: 0

Registration Update Send Reason:
  Lifetime Expiry:  0                     Upper Layer Initiated: 0
  Other Reasons: 0                        Handoff Release: 2
  Session Manager Exited: 0

Registration Update Denied:
  Reason Unspecified: 0                   Admin Prohibited: 0
  PDSN Failed Authentication: 0           Identification Mismatch: 0
  Poorly Formed Update: 0

Session Update/Ack:
  Initial Update Transmitted: 1           Update Retransmitted: 0
  Denied: 0                               Not Acknowledged: 0
  Sess Update Ack Received: 1             Sess Update Ack Discarded: 0
  Update Send Error: 0
```

```
Session Update Send Reason:
  Always On:        0                    QoS Info:           1
  TFT violation:    0                    Traffic Violation:  0
  Traffic Policing: 0                    Operator Triggered: 0

Session Update Denied:
  Reason Unspecified: 0                  Insufficient Resources: 0
  Admin Prohibited: 0                    Parameter not updated: 0
  PDSN Failed Authentication: 0
  Identification Mismatch: 0
  Poorly Formed Update: 0
  Profile Id Not Supported: 0            Handoff In Progress :    0

GRE Receive:
  Total Packets Received:   3998         Protocol Type Error:     0
  Total Bytes Received:     347135       GRE Key Absent:          0
                                         GRE Checksum Error:      0
                                         Invalid Packet Length:   0

GRE Send:
  Total Packets Sent:       2440
  Total Bytes Sent:         395271
...
```

```
Connectivity with PCF
```

```
ping <dest IP> src <src IP> count x
 traceroute <dest IP>
```

Use these commands as one normally would to confirm reachability to the PCF from the context

PPP Settings

Note: Unlike the way the PDSN service controls the behavior for A11, PPP behavior is controlled by settings in the context where the PDSN service is located, and there is no specific "service"

to start, for example:

```
ppp max-retransmissions 5
ppp dormant send-lcp-terminate
ppp negotiate default-value-options
ppp lcp-start-delay 50
```

show ppp statistics [pcf-address <pcf address>]

PPP stats are certainly useful in troubleshooting many issues. Issues are often where PPP negotiation does not complete due to timeouts and retries.

```
[local]PDSN> show ppp statistics
PPP statistics
  total sessions initiated:  926984043     session re-negotiated:     302568379
  successful sessions:       794350472     failed sessions:           132634235
  total sessions released:   927123561     failed re-negotiations:    76565889
  released by local side:    837559870     released by remote side:   89563691
Session Failures
  LCP failure max-retry:     30279177      LCP failure option-issue:  0
  LCP failure unknown:       0             IPCP failure max-retry:    4136030
  IPCP failure option-issue: 0             IPCP failure unknown:      0
  IPv6CP failure max-retry:  0
  IPv6CP failure option-iss: 0             IPv6CP failure unknown:    0
  VSNCP failure max-retry:   387           VSNCP failure option-iss:  188
  VSNCP failure unknown:     0
  Authentication failures:   108004150     Authentication aborted:    461813
  remote terminated:         1517843       lower layer disconnected:  0
  miscellaneous failures:    57092177
Session Progress
  sessions (re)entered LCP:  1222172532    sessions (re)entered Auth: 144745436
  sessions (re)entered IPCP: 1002603438    sessions (re)enter IPv6CP: 0
  successful LCP:            1123620704
  successful Authentication: 30978699
VSNCP Statistics
  Attempted:                 8183          Connected:                 1508
  Failed:                    12            Released by local side:    0
  Released by remote side:   218754167
```

```
VSNCP Error Codes
  General Error:              12            Unauthorized APN:          0
  PDN Limit Exceeded:         0             No PDN-GW Available:       0
  PDN-GW Unreachable:         0             PDN-GW Reject:             0
  Insufficient Param:         0             Resource Unavailable:      0
  Admin Prohibited:           0             PDN-ID Already In Use:     0
  Subscription Limitation:    0             PDN Already Exists for APN:0
Session Re-negotiations
  initiated by local:         33186628      initiated by remote:       269381751
  address mismatch:           26777483      lower layer handoff:       6409145
  parameter update:           0             other reasons:             0
  connected session re-neg:   287894901
Session Authentication
  CHAP auth attempt:          139456900     CHAP auth success:         30965825
  CHAP auth failure:          107984174     CHAP auth aborted:         461407
  PAP auth attempt:           33233         PAP auth success:          12874
  PAP auth failure:           19975         PAP auth aborted:          377
  MSCHAP auth attempt:        0             MSCHAP auth success:       0
  MSCHAP auth failure:        0             MSCHAP auth aborted:       0
  EAP auth attempt:           0             EAP auth success:          0
  EAP auth failure:           0             EAP auth aborted:          9
  sessions skipped PPP Auth:  978875268
Session Disconnect reason
  remote initiated:           89510680      remote disc. lower layer:  215001365
  admin disconnect:           0             local disc. lower layer:   9281
  idle timeout:               5417055       absolute timeout:          15449999
  keep alive failure:         0             no resource:               0
  flow add failure:           0             exceeded max LCP retries:  30274284
  exceeded max IPCP retries:  3984670       exceeded max setup timer:  2438549
  invalid dest-context:       0             LCP option-neg failed:     0
  IPCP option-neg failed:     0             no remote-ip address:      5068
  call type detect failed:    3947419       source address violation:  10087951
  exceeded max IPv6CP retrie:0              IPv6CP option-neg failed:  0
  remote disc. upper layer:   133633654     long duration timeout:     0
  PPP auth failures:          107998422     miscellaneous reasons:     309365086
Session Data Compression
  sessions negotiated comp:   0             STAC Compression:          0
  MPPC compression:           0             Deflate Compression:       0
  CCP negotiation failures:   0
```

```
 Session Header Compression
   VJ compression:            7075
   ROHC compression:          0
 LCP Echo Statistics
   total LCP Echo Req. sent:  0             LCP Echo Req. resent:      0
   LCP Echo Reply received:   21            LCP Echo Request timeout:  0
 LCP Vendor Specific Statistics
   total LCP VSE Req. sent:   0             LCP VSE Req. resent:       0
   LCP VSE Reply received:    0             LCP VSE Req. proto. rej.:  0
   LCP VSE Req. timeout:      0             LCP VSE Req. max-retry:    0
 Receive Errors
   bad FCS errors:            1542748128    unknown protocol errors:   100893
   bad Address errors:        0             bad control field errors:  0
   bad pkt length:            300
```

There are also a number of PPP-related disconnect reasons that can be examined:

```
 [local]PDSN> show session disconnect-reasons | grep -i ppp
 PPP-LCP-max-retry-reached                          1107275     3.41101
 PPP-Auth-failed                                    3197373     9.84964 <= this is
actually due to Radius failures
 PPP-Auth-failed-max-retry-reached                    15687     0.04832
 PPP-IPCP-max-retry-reached                          143205     0.44115
 PPP-LCP-remote-disconnect                          2872204     8.84794
```

subscriber profile

The subscriber profile is a critical part of the configuration and is located in the source context. It specifies items such as:

- The AAA group that itself describes connectivity to the Radius server(s)
- Primary and secondary DNS servers to be assigned to the subscribers
- Idle and absolute timeouts
- Destination context name

The subscriber profile that will be used is based on the domain of the username of the subscriber which is presented either thru a PPP CHAP response (SIP) or a MIP Registration Request (MIP). For this to happen, domain statements are configured to pair each possible domain with a named subscriber profile. Note that up to the point in time that the username has not yet been received in the call flow (MIP or SIP), the default subscriber profile with its settings will be used.

```
domain serviceprovider.com default subscriber serviceprovider
    subscriber name serviceprovider
      aaa group default
      dns primary <dns 1>
      dns secondary <dns 2>
      timeout idle 7500
      timeout absolute 86400
      no ip header-compression
      ip context-name destination
      active-charging rulebase SIP
    exit
```

Radius Settings

Radius protocol is used to authenticate subscribers during the call flow, and to report data usage during a subscriber's session, or on disconnect. Settings are configured in a aaa group section and include timers, retries, and the Radius server IPs themselves, along with server priorities (or round robin). Similar to the above with PDSN SPIs, the encrypted passwords can be viewed with the showsecrets option. Please see the Radius Chapter for details on troubleshooting Radius, which will apply to MIP, SIP, or any other protocol. The biggest area where issues are seen is with reachability to the Radius servers, which is reported by "show radius counters all".

FA Service

The FA service allows for passing through communications from the PDSN, to the Pi interface connecting the FA and HA services (MIP tunnel). It is NOT used with SIP but with MIP only. The service can be located in the same context as PDSN, but it is often located in a separate (egress - towards the network/internet) context. As with PDSN and PCFs, there are SPI settings that

secure the FA-HA connection. Other configurables include the MIP lifetime, Registration message timeout (between FA and HA) and the bind address.

The FA functionality is implemented in famgr facility.

The FA service will be automatically started when the bind address command is added. The service can be confirmed as started with "show service all" as well as with "show fa-service all" which will report back all the settings, default and configured. In the following output there are three services started. Just the more significant parameters are displayed:

show service all

show fa-service all

```
[local]PDSN-FA> show service all
ContextID   ServiceID   ContextName   ServiceName   State         MaxSessions   Type
---------   ---------   -----------   -----------   ----------    -----------   ----
3           4           destination   FA1           Started       5000000       fa
3           5           destination   FA2           Started       5000000       fa
3           6           destination   FA3           Started       5000000       fa

[local]PDSN-FA> show fa-service name FA2

Service name:       FA2
  Context:          destination
  Bind:             Done                Max Subscribers:      5000000
  Local IP Address: 10.10.10.20         Local IP Port:        434
  Lifetime:         02h00m00s           Registration Timeout: 45 (secs)
  Advt Lifetime:    02h00m00s           Advt Interval:        5000 (msecs)

  Reverse Tunnel:   Enabled             GRE Encapsulation:    Enabled

  SPI(s) in SPI-list: FA-SPI
  FAHA: Remote Addr: 192.168.10.0/24    Description: test Roaming
    Hash Algorithm:    MD5              SPI Num:  5653
    Replay Protection: Timestamp        Timestamp Tolerance: 60
    HA Monitoring:    Disabled
...
```

```
  Registration Revocation:    Enabled
  Reg-Revocation I Bit:   Enabled
  Reg-Revocation Max Retries: 3         Reg-Revocation Timeout: 1 (secs)

  Service Status:         Started
  MN-AAA Auth Policy:     Renew-and-dereg-noauth  Optimize-Retries: Enabled
  MN-HA Auth Policy:      Allow-noauth

  Newcall Policy:         None

  HA Failover:    Disabled
     Retrans Timeout: 2 (secs)    Retries
```

show mipfa statistics [peer-address <peer>] | [fa-service <fa service**>]**

Probably the most important command for the FA service, this tracks all MIP protocol activity between the FA and HA services. The peer-address option is fantastic for troubleshooting issues with particular HA peers, while the fa-service option will narrow down to a particular FA service if there are multiple FA services configured.

```
[local]PDSN> show mipfa statistics
  Agent Advt Sent:            989603885    Agent Solicit Rcvd:     11645690

MIP AAA Authentication:
  Attempts:                   943977906    Success:                830323604
  Total Failures:             111922933
  Actual Auth Failures:       110577641    Misc Auth Failures:     87773
  DMU Auth Failures:          1257519

Registration Request Received:
  Total Received Reg:         1310432155   Accepted Reg:           1144881296
  Rejected Reg:               161584022
    Denied Reg:               161584021      Discarded Reg:        1
  Relayed Reg:                1192737581   Auth Failed Reg:        111922933
  FA Denied Reg:              116634395    HA Denied Reg:          44764702
  Rcvd with MIP Key Data:     266660

  Init RRQ Received:          948975318    Init RRQ Accepted:      785032497
```

```
  Init RRQ Rejected:          159928015
    Init RRQ Denied:          159928015      Init RRQ Discarded:   0
  Init RRQ Relayed:           832558995    Init RRQ Auth Failed:   110665414
  Init PMIP RRQ Xmit:         1            Init PMIP RRQ Re-Xmit:  0
  Init RRQ Denied by FA:      115348237    Init RRQ Denied by HA:  44579778

  Renew RRQ Received:         217036742    Renew RRQ Accepted:     215550059
  Renew RRQ Rejected:         1469277
    Renew RRQ Denied:         1469277        Renew RRQ Discarded:  0
  Renew RRQ Relayed:          215760207    Renew RRQ Auth Failed:  0
  Renew PMIP RRQ Xmit:        0            Renew PMIP RRQ Re-Xmit: 0
  Renew RRQ Denied by FA:     1284353      Renew RRQ Denied by HA: 184924

  Dereg RRQ Received:         144579389    Dereg RRQ Accepted:     144579390
  Dereg RRQ Rejected:         1805
    Dereg RRQ Denied:         1805           Dereg RRQ Discarded:  0
  Dereg RRQ Relayed:          144418379    Dereg RRQ Auth Failed:  0
  Dereg PMIP RRQ Xmit:        1            Dereg PMIP RRQ Re-Xmit: 0
  Dereg RRQ Denied by FA:     1805         Dereg RRQ Denied by HA: 0

Denied by FA:
  Unspecified error:          0            Reg Timeout:            11650
  Admin Prohibited:           1051975      No Resources:           3255
  MN Auth Failure:            110665414    HA Auth Failure:        4
  Lifetime too long:          0            Poorly formed Request:  58490
  Poorly formed Reply:        0            MN Too Distant:         0
  Invalid COA:                0            Missing NAI:            13
  Missing Home Agent:         6438         Missing Home Addr:      0
  Unknown Challenge:          3559526      Missing Challenge:      4
  Stale Challenge:            0
  Encap Unavailable:          0            Rev Tunnel Unavailable: 0
  Rev Tunnel Mandatory:       19961        HA Network Unreachable: 0
  Delivery Style Unavailable: 0            HA Host Unreachable:    0
  HA Port Unreachable:        117          HA Unreachable:         29
  Unknown CVSE Rcvd:          0            MIP Key Request:        997189
  AAA Authenticator:          260330       Public Key Invalid:     0

Discarded by FA:
  Invalid Extn:               0            Invalid UDP Checksum:   1
```

```
Denied by HA:
  FA Auth Failure:            4            Poorly formed Request:  0
  Mismatched ID:              121798       Simul Bindings Exceeded:0
  Unknown HA:                 139821       Rev Tunnel Unavailable: 0
  MN Auth Failure:            25538792     No Resources:           64114
  Admin Prohibited:           16440820     Rev Tunnel Mandatory:   0
  Encap Unavailable:          0            Unspecified Reason:     2459357
  Unknown CVSE Rcvd:          0

Registration Reply Rcvd:
  Total:                      1190381235   Relayed:                1189645996
  Errors:                     12944

  Init RRP Rcvd:              829612277    Init RRP Relayed:       829612276
  Renew RRP Rcvd:             215562911    Renew RRP Relayed:      215562911
  Dereg RRP Rcvd:             144470810    Dereg RRP Relayed:      144470809
  RRP with Dyn HA Rcvd:       0            RRP with Dyn HA Denied: 0

Registration Reply Sent:
  Total:                      1306280391   Accepted Reg:           1000582555
  Accepted DeReg:             144298739    Denied:                 161399097
  Send Error:                 0

Registration Revocation:
  Sent:                       171819969    Retries Sent:           24865
  Ack Rcvd:                   171073569    Not Acknowledged:       6815
  Rcvd:                       296327182    Ack Sent:               296276746

Tunnel Data Received:
  Total Packets :             2840315898
    IPIP:                     2840315898   GRE:                    0
  Total Bytes :               2339067050
    IPIP:                     2339067050   GRE:                    0
  Errors:
    Protocol Type Error:      0            GRE Key Absent:         0
    GRE Checksum Error :      0            Invalid Pkt Length:     0
    No Session Found   :      0
```

```
Tunnel Data Sent:
  Total Packets :             3938537179
    IPIP:                     3938537179   GRE:                    0
  Total Bytes :               3622386074
    IPIP:                     3622386074   GRE:                    0

Total Disconnects/Failures:   947864140
  Lifetime expiry:            28117822     Deregistrations:        144458033
  Admin Drops:                0            Ingress Filtering:      5285913
  Auth Failures:              111922933    Other Reasons:          387489164
  HA Revocations:             270590275

Failover:
  Number of Failovers (to Alternate HA): 0
  Number of Registration Successful after Failover: 0
  Number of Registration Failures after Failover: 0

HA Monitoring:
  Total Inactivity Timeouts:  0
  Total Monitor RRQ Sent:     0
      Initial:                0             Retransmit:           0
  Monitor RRP Received:       0

Invalid Packets:
  Discarded:                  23012
```

show mipfa peers fa-service <fa service> [peer-address <peer>]

Lists all HA peers and the total number of sessions ever connected and the current number of sessions connected. Must specify an FA service as part of the command - Cannot run this generically for all FA services (if multiple exist).

```
[local]PDSN> show mipfa peers fa-service FA2
Context: destination
FA Service: FA2
Peer              Current   Total       IP        FA-HA           HA Monitor
Address           Sessions  Sessions    Security  Authentication  Status
----------------  --------  ----------  --------  --------------  ----------
```

```
192.168.6.147       0          0           Disabled  Enabled         Disabled
192.168.80.12       0          157         Disabled  Enabled         Disabled
192.168.20.195      0          2           Disabled  Enabled         Disabled
192.168.168.195     0          0           Disabled  Enabled         Disabled
192.168.33.195      1          30239       Disabled  Enabled         Disabled
```

show mipfa counters [peer-address]

MIP-specific protocol counters such as Initial/Renewal/De-Registration request received, accepted, rejected, Replies Received/Replied, Denied by FA or HA, etc., for specific subscriber(s).

show mipfa full [callid | msid | username] <user identity>

Reports MIP-specific information stored for the subscriber, such as remaining lifetime. Some of this is already in "show sub full".

```
[local]PDSN> show mipfa full
Username: 12551212@cisco.com          Callid: 00085bb0
MSID:  123281234567899
Num Agent Advt Sent: 1     Num Agent Solicit Rcvd: 0

  Home Address #1: 10.235.80.171       NAI:  12551212@cisco.com
    FA Address: 10.20.0.3              HA Address: 10.20.0.2
    Lifetime: 02h00m00s                Remaining Lifetime: 00h04m36s
    Reverse Tunneling: On              Encapsulation Type: IP-IP
    GRE Key: n/a                       IPSec Required: No
    IPSec Ctrl Tunnel Estab.: No       IPSec Data Tunnel Estab.: No
    MN-AAA Removal: No                 Proxy MIP: Disabled
    DMU Auth Failures: 0               Send Terminal Verification: Disabled
    Revocation Negotiated: YES         Revocation I Bit Negotiated: YES
    MN-HA-Key-Present: FALSE           MN-HA-SPI: n/a
    FA-HA-Key-Present: TRUE            FA-HA-SPI: 8832
    MN-FA-Key-Present: FALSE           MN-FA-SPI: n/a
    HA-RK-KEY-Present: FALSE           HA-RK-SPI: n/a
    HA-RK-Lifetime:    n/a             HA-RK-Remaining-Lifetime: n/a
    Send Host Config: Disabled
```

General troubleshooting

show session disconnect-reasons

There are many session disconnect reasons that are related to call failures for the PPP, A11, Radius, and MIP protocols. Contact Cisco for a list of disconnect reasons that could apply to these protocols.

show subscriber [summary] [HA <HA address>]

Use this command to quickly see all the subscribers by call type. Peer HA address option allows troubleshooting for a specific HA address which can be very valuable. Remove the summary keyword to list all the subscribers, and add the full keyword to get "show sub full". Shown below are snippets of call types for CDMA.

```
[local]PDSN> show sub [summary] [HA] <HA address>
Total Subscribers:              419815
Active:                         30034         Dormant:                        389781
pdsn-simple-ipv4:               579           pdsn-simple-ipv6:               0
pdsn-mobile-ip:                 419109        ha-mobile-ipv6:                 0
sgsn-pdp-type-ipv4-ipv6:        0             type not determined:            127
cdma 1x rtt sessions:           100245        cdma evdo sessions:             2030
cdma evdo rev-a sessions:       317540        cdma 1x rtt active:             3679
cdma evdo active:               104           cdma evdo rev-a active:         26251
```

HA

Overview

The Home Agent (HA) is the Mobile IP session anchor for CDMA 3G calls. The HA provides the location in the provider network where the session attaches. This one attach point is what allows the mobility of sessions to traverse multiple PCFs, PDSNs, or FAs. The HA also allows roaming between another provider's FAs to its HA.

A typical connection on an HA is fairly straight forward. The Mobile IP Session Request will come in to the HA from an FA. The HA will authenticate the sessions, usually via Radius, and if successful, send a Session-Accept back to the FA. Once the session is attached, other services may come into play, ACS for example, but these are handled in other parts of this document. Similarly, for issues with ICSR, please see the dedicated ICSR section.

The HA functionality is implemented in hamgr facility.

Troubleshooting of HA

Following are useful commands in troubleshooting issues on HA side.

General

show ha-service all - Check service status, it should be "Started"
show lns-service all - Check service status, it should be "Started"
show subscribers summary ha-service <NAME> - Check active HA sessions and any dropped counters
show subscribers summary lns-service <NAME> - Check active LNS sessions and any dropped counters

```
[local]ASR5500# show ha-service all | grep -i "Service Status"
  Service Status:          Started
```

Pi interface

show mipha - Displays the call information for all mobile IP HA calls and statistics

AAA interface. Below are some major commands. Please note all commands are context specific. Please refer to Radius chapter for details on troubleshooting:

show radius counters all
show radius counters summary
show radius accounting servers
show radius authentication servers
show radius client status

Gx and Gy interfaces. Please refer to Diameter chapter for details on troubleshooting:

show diameter peers full - Check Diameter peers config and status

IP Pool

show ip pool - Displays ip address usage (Context Specific).

Below are variations for the IP Pools, which are also context-specific:

show ip pool summary wide
show ip pool groups
show ip pool group-name <name>
show ip pool pool-name <pool name>

Proxy DNS Intercept

show dns-proxy statistics
show dns-proxy intercept-list <name> statistics
show dns-proxy intercept-list <name> rule <rule> statistics
show subscribers counters dns-proxy username <username>

NTP

show ntp status - Verify NTP status

CDRs - Please refer to CDR chapter for details on troubleshooting:

show active-charging edr-udr-file statistics / show cdr statistics

Troubleshooting a subscriber connecting to HA:

- monitor subscriber - Collect and analyze a subscriber HA call with monitor subscriber from the beginning of a call till an issue with verbosity 3, option 19.
- show subscribers full username - Provides information on a subscriber session information.
- show active-charging sessions full username - Provides information on a subscriber ACS session information.

Example Scenarios

HA Proxy-DNS Intercept not working

Problem Description:

HA Proxy DNS Intercept does not work

Analysis:

The HA Proxy DNS Intercept feature is designed to allow Mobile IP subscribers roaming through a Foreign Agent to be able to reach their home network's DNS server instead of the roaming partner's DNS server which may not be reachable from the subscriber's home network.

When configured properly, the intercept list created will include redirect lines for all of the roaming partners for which DNS packets should be redirected, and pass-through lines for all of the roaming partners for which DNS packets should be passed through without changes.

If redirect does not seem to be working, firstly DNS addresses from roaming partners should be confirmed. Note that if a roaming partner is also using Cisco PDSN/FA, then the DNS addresses can be found in the default subscriber template ("dns (primary | secondary) <address>") of the source context, and NOT in any named subscriber template, because the username (NAI) is

NOT known at the time that the DNS address is passed to the subscriber via PPP negotiation. Here is an example of the PPP DNS exchange that would take place on the FA during call setup:

```
INBOUND>>>>> 16:54:34:471 Eventid:25000(0)
PPPRx PDU (18)
IPCP18: Conf-Req(34), Pri-DNS=0.0.0.0, Sec-DNS=0.0.0.0


<<<<OUTBOUND 16:54:34:472 Eventid:25001(0)
PPPTx PDU (20)
IPCP20: Conf-Nak(34), Pri-DNS=2.2.2.2, Sec-DNS=1.1.1.1


INBOUND>>>>> 16:54:34:623 Eventid:25000(0)
PPPRx PDU (18)
IPCP18: Conf-Req(35), Pri-DNS=2.2.2.2, Sec-DNS=1.1.1.1


<<<<OUTBOUND 16:54:34:623 Eventid:25001(0)
PPPTx PDU (20)
IPCP20: Conf-Ack(35), Pri-DNS=2.2.2.2, Sec-DNS=1.1.1.1
```

In HA troubleshooting, a monitor subscriber trace should be collected with verbosity 3 and option 19. DNS packets are easy to identify and they use port 53. The DNS requests are being seen coming from the FA, and if working, DNS responses are being sent back to the mobile, and if so, it is likely working (unless they are being passed through and successfully responded to, which is unlikely). Here is an example of a request to get the IP address of www.yahoo.com, and the response, where FA = 10.10.10.10, HA = 10.20.20.20, mobile device = 10.30.30.30, DNS server = 10.50.50.50, and returned address for www.yahoo.com is 69.147.76.15, just to give an idea of what to look for.

```
INBOUND>>>>> 16:20:30:728 Eventid:27000(0)
MIP-TUNNEL(IPv4-IPv4) Rx PDU
10.10.10.10> 10.20.20.20: 10.30.30.30.2467 > 10.50.50.50.53:  [udp sum ok] 3+ A?www.yahoo.com.
[|domain] (ttl 127,  id 62019, len 59) (ttl 251, id 0, len 79)
  <<<<OUTBOUND 16:20:30:731 Eventid:27001(0)
MIP-TUNNEL(IPv4-IPv4) Tx PDU
10.20.20.20> 10.10.10.10: 10.50.50.50.53 > 10.30.30.30.2467:  [udp sum ok] 3 q: A?
```

```
www.yahoo.com. 3/2/2 www.yahoo.com.  CNAME www.wa1.b.yahoo.com.,www.wa1.b.yahoo.com. CNAME www-
real.wa1.b.yahoo.com., www-real.wa1.b.yahoo.com.A 69.147.76.15  ns: wa1.b.yahoo.com. NS
yf2.yahoo.com., wa1.b.yahoo.com. NSyf1.yahoo.com. ar: yf1.yahoo.com. A 68.142.254.15,
yf2.yahoo.com. A68.180.130.15 (162) (DF) (ttl 245, id 46647, len 190) (ttl 255, id 0, len 210)
```

If packets are only coming from the FA without response, then confirm that the source address is what is expected, and if not, then a trace from the FA side is needed to determine why.

Confirm that there is a redirect rule in the intercept list that matches the destination DNS server address, which should already be the case if configured properly.

Note that monitor subscriber trace will NOT display the redirect address (if it is redirected) in either direction. (The monitor subscriber output is generated before the packet's destination address is changed by the system (going TO the DNS server) and before the packet's source address is changed by the system (coming FROM the DNS server)).

In order to confirm redirects are occurring for a specific subscriber, run command "show subscriber full ...". First note whether the proxy list has been applied to the user, as seen in the "Proxy DNS Intercept List" field. If not, then check the configuration to make sure the list name is applied to the subscriber template. As DNS requests are attempted, observe the counters “ipv4 proxy-dns redirect”, “ipv4 proxy-dns pass-thru”, and “ipv4proxy-dns drop” to see which, if any counter is incrementing for each request. As a side note, the output for fields “Primary DNS Address” and “Secondary DNS Address” have NO relevance on show subscriber full on the HA when using the Intercept feature.

The meaning of each counter is self-explanatory: Redirect means the packet was redirected according to a rule, pass-thru means the packet was passed through untouched according to a rule, and dropped means it was dropped because no rule existed. If the count does not add up to the total DNS packets, then it is also possible for packets to have been dropped by other Access Control Lists applied to subscribers, as such rules are applied first before the DNS proxy list. The active input/output acl fields will indicate which if any ACL lists are applied, and “ipv4 input/output acl drop” counters will track the numbers dropped. Then check the rules for such ACLs to see if any matches would cause a drop to occur.

There are some useful statistics that can be displayed if the issue seems to be widespread and tied to all subscribers of a particular type versus just a specific subscriber:

show dns-proxy statistics *This includes statistics for each intercept list.*

show dns-proxy intercept-list <list name> statistics *Shows counts for redirected, passed-through, dropped, for EACHRULE in the particular intercept list*

show dns-proxy intercept-list <list name> rule<rule> statistics *For EACH RULE, this adds counters for the number of requests sent to the DNS redirect server(s), the number of responses received from the server(s), and number of timeouts.*

Note when a redirect is applied, by default, the source address of the DNS packet is also changed, from the subscriber's address to the address specified in the configuration in the respective destination context, with command:

ip dns-proxy source-address <interface source address for redirected DNS packets>

This will be different than non-redirected DNS packets which will maintain their subscriber source address, and, this could lead to unexpected routing/firewall issues where re-directed packets never make it to the DNS server or don't make it back due to this changed source address. It is possible to specify that the DNS packet source address NOT be changed using the appropriate subscriber template command "proxy-dns use-subscriber-address-as-source", and this could be used as a temporary (or permanent) solution.

Resolution:

Multiple scenarios are discussed above. The solution relies on a particular scenario.

PDNS with static IP addresses cannot register in the HA

Problem Description:

A group of subscribers on a PDNS with static IP addresses cannot register in the HA and the call fails from MIP to SIP.

Analysis:

The following traces were collected on the PDNS/FA and HA side.

- monitor subscriber username verbosity 3 and option 19 *on HA side*
- monitor subscriber msid verbosity 3 and option 19 *on PDSN/FA side*

In trace below the PDSN received a call of a subscriber from the group and sent Registration Request to the HA. The HA received the Registration Request, assigned static IP address, and sent Registration Reply back to the PDSN. However, PDSN did not receive the reply, and the call fails to SIP. Monitor subscriber traces showed that packets from HA did not reach out PDSN. A ping test from destination context of PDSN to the HA was failing.

PDSN Trace

```
 <<<<OUTBOUND  From sessmgr:40 mipfa_common.c:282 (Callid 0ba9afb7) 15:50:24:158
Eventid:26001(3)
 MIP Tx PDU, from 10.10.10.10:434 to 10.20.20.20:434 (140)
         Message Type: 0x01 (Registration Request)
                Flags: 0x02
             Lifetime: 0x1C20
         Home Address: 0.0.0.0
    Home Agent Address: 255.255.255.255
       Care of Address: 10.10.10.10
 MN-NAI Extension Follows:
               MN-NAI: <1234567890@test.cisco.com>
 Mobile Home Auth Extension Follows:
 MN-FA Challenge Extension Follows:
 Generalized Mobile IP Auth Extension Follows:
 MIP Revocation Extension Follows:
 Foreign Home Auth Extension Follows:

 <<<<OUTBOUND  From sessmgr:40 pfa_proto_fsm.c:10396 (Callid 0ba9afb7) 15:50:25:993
Eventid:26001(3)
 MIP Tx PDU, from 10.10.10.10:47128 to 255.255.255.255:434 (60)
         Message Type: 0x03 (Registration Reply)
                 Code: 0x4E (Registration Timeout)
             Lifetime: 0x1C20
         Home Address: 0.0.0.0
    Home Agent Address: 10.20.20.20
 MN-NAI Extension Follows:
               MN-NAI: <1234567890@test.cisco.com>


 <<<<OUTBOUND  From sessmgr:40 pppfuncs.c:1203 (Callid 0ba9afb7) 15:50:25:994 Eventid:25001(0)
```

```
 PPP Tx PDU (92)
 IP 92: 10.10.10.10.434 > 255.255.255.255.47128:  [udp sum ok]
         Message Type: 0x03 (Registration Reply)
                 Code: 0x4E (Registration Timeout)
             Lifetime: 0x1C20
         Home Address: 0.0.0.0
   Home Agent Address: 10.20.20.20
 MN-NAI Extension Follows:
               MN-NAI: <1234567890@test.cisco.com>


 <<<<OUTBOUND  From sessmgr:40 pfa_proto_fsm.c:10396 (Callid 0ba9afb7) 15:50:27:597
Eventid:26001(3)
 MIP Tx PDU, from 10.10.10.10:47128 to 255.255.255.255:434 (60)
         Message Type: 0x03 (Registration Reply)
                 Code: 0x4E (Registration Timeout)
             Lifetime: 0x1C20
         Home Address: 0.0.0.0
   Home Agent Address: 10.20.20.20
 MN-NAI Extension Follows:
               MN-NAI: <1234567890@test.cisco.com>
```

HA trace

```
 INBOUND>>>>>  From sessmgr:117 mipha_fsm.c:8250 (Callid 22928a91) 20:52:16:459
Eventid:26000(3)
 MIP Rx PDU, from 10.10.10.10:434 to 10.20.20.20:434 (198)
         Message Type: 0x01 (Registration Request)
                Flags: 0x02
             Lifetime: 0x1C20
         Home Address: 0.0.0.0
   Home Agent Address: 255.255.255.255
      Care of Address: 10.10.10.10
 MN-NAI Extension Follows:
               MN-NAI: <1234567890@test.cisco.com>
```

```
 <<<<OUTBOUND  From sessmgr:117 mipha_fsm.c:6509 (Callid 22928a91) 20:52:16:459
Eventid:26001(3)
 MIP Tx PDU, from 10.20.20.20:434 to 10.10.10.10:434 (112)
         Message Type: 0x03 (Registration Reply)
                 Code: 0x00 (Accepted)
             Lifetime: 0x1C20
         Home Address: 10.10.150.155
    Home Agent Address: 10.20.20.20
 MN-NAI Extension Follows:
               MN-NAI: <1234567890@test.cisco.com>
```

Resolution:

The issue was in the routing between PDSN and HA and it was fixed outside of the HA and PDSN themselves.

UMTS

UMTS Overview

Overview

UMTS architecture and major call flows are covered in this section.

Architecture and Call Flows

GPRS and UMTS are evolutions of the global system for mobile communication (GSM) networks.

GSM is a digital cellular technology that is used worldwide and is one of the world's leading standards in digital wireless communications. GPRS is a 2.5G mobile communications technology that enables mobile wireless service providers to offer their mobile subscribers packet data services over GSM networks. Common applications of GPRS include the following: Internet access, intranet/corporate access, instant messaging, and multimedia messaging.

GPRS is standardized by the Third Generation Partnership Program (3GPP).

UMTS is a 3G mobile communications technology that provides wideband code division multiple-access (WCDMA) radio technology. The CDMA technology offers higher throughput, real-time services, and end-to-end quality of service (QoS), and delivers pictures, graphics, video communications, and other multimedia information as well as voice and data, to mobile wireless subscribers. UMTS is standardized by the 3GPP.


The GPRS/UMTS packet core comprises two major network elements:

- GGSN
- SGSN

Gateway GPRS support node (GGSN) is the mobility anchor point within the Mobile Packet Core network, a gateway that provides mobile cell phone users access to a packet data network (PDN)/ Internet or specified private IP network (Intranet) or corporate networks. It also maintains the necessary routing information needed to route the subscriber traffic uplink/downlink towards the Packet Data Network, and the SGSN respectively.

SGSN – Serving GPRS Support Node, SGSN performs the following functions: Mobility Management, Subscriber Data Management, Session Management, Payload handling, Charging, Security (Authentication,Ciphering,Integrity) and connections to a radio network.

Image - Architecture Overview




This section illustrates some of the GPRS mobility management (GMM) and session management (SM) procedures that SGSN implements as part of the call handling process. All SGSN call flows are compliant with those defined by 3GPP TS 23.060.

First-Time GPRS Attach

The following outlines the setup procedure for a UE that is making an initial attach.

Image - First time GPRS Attach



1) The MS/UE sends an Attach Request message to the SGSN. Included in the message is information, such as:

- Routing area and location area information
- Mobile network identity
- Attach type

2) Authentication is mandatory if no MM context exists for the MS/UE:

- The SGSN gets a random value (RAND) from the HLR to use as a challenge to the MS/UE.
- The SGSN sends a Authentication Request message to the UE containing the random RAND.
- The MS/UE contains a SIM that contains a secret key (Ki) shared between it and the HLR called an Individual Subscriber Key.
- The UE uses an algorithm to process the RAND and Ki to get the session key (Kc) and the signed response (SRES).
- The MS/UE sends a Authentication Response to the SGSN containing the SRES.

3) The SGSN updates location information for the MS/UE:

- The SGSN sends an Update Location message, to the HLR, containing the SGSN number, SGSN address, and IMSI.
- The HLR sends an Insert Subscriber Data message to the "new" SGSN. It contains subscriber information such as IMSI and GPRS subscription data.
- The "New" SGSN validates the MS/UE in new routing area:

  If invalid: The SGSN rejects the Attach Request with the appropriate cause code.

  If valid: The SGSN creates a new MM context for the MS/UE and sends a Insert Subscriber Data Ack back to the HLR.

- The HLR sends a Update Location Ack to the SGSN after it successfully clears the old MM context and creates new one

4) The SGSN sends an Attach Accept message to the MS/UE containing the P-TMSI (included if it is new), VLR TMSI, P-TMSI Signature, and Radio Priority SMS.


At this point the GPRS Attach is complete and the SGSN begins generating M-CDRs.

If the MS/UE initiates a second call, the procedure is more complex and involves information exchanges and validations between "old" and "new" SGSNs and "old" and "new" MSC/VLRs. The details of this combined GPRS/IMSI attach procedure can be found in 3GPP TS23.060.

PDP Context Activation Procedures

The following figure provides a high-level view of the PDP Context Activation procedure performed by the SGSN to establish PDP contexts for the MS with a BSS-Gb interface connection or a UE with a UTRAN-Iu interface connection.

Image: PDP context activation



1) The MS/UE sends a PDP Activation Request message to the SGSN containing an Access Point Name (APN).

2) The SGSN sends a DNS query to resolve the APN provided by the MS/UE to a GGSN address. The DNS server provides a response containing the IP address of a GGSN.

3) The SGSN sends a Create PDP Context Request message to the GGSN containing the information needed to authenticate the subscriber and establish a PDP context.

4) If required, the GGSN performs authentication of the subscriber.

5) If the MS/UE requires an IP address, the GGSN may allocate one dynamically via DHCP.

6) The GGSN sends a Create PDP Context Response message back to the SGSN containing the IP Address assigned to the MS/UE.

7) The SGSN sends a Activate PDP Context Accept message to the MS/UE along with the IP Address. Upon PDP Context Activation, the SGSN begins generating S-CDRs. The S-CDRs are updated periodically based on Charging Characteristics and trigger conditions.

A GTP-U tunnel is now established and the MS/UE can send and receive data.

SGSN Overview

The ASR 5000 provides a highly flexible and efficient Serving GPRS Support Node (SGSN) service to the wireless carriers. Functioning as an SGSN, the system readily handles wireless data services within 2.5G General Packet Radio Service (GPRS) and 3G Universal Mobile Telecommunications System (UMTS) data networks.

In a GPRS/UMTS network, the SGSN works in conjunction with radio access networks (RANs) and Gateway GPRS Support Nodes (GGSNs) to:

- Communicate with home location registers (HLR) via a Gr interface and mobile visitor location registers (VLRs) via a Gs interface to register a subscriber's user equipment (UE), or to authenticate, retrieve or update subscriber profile information.
- Support Gd interface to provide short message service (SMS) and other textbased network services for attached subscribers.
- Activate and manage IPv4, IPv6 type packet data protocol (PDP) contexts for a subscriber session.
- Setup and manage the data plane between the RAN and the GGSN providing high-speed data transfer.
- Provide mobility management, location management, and session management for the duration of a call to ensure smooth handover.
- Provide various types of charging data records (CDRs) to attached accounting/billing storage mechanisms such as our SMC-based hard drive or a GTPP Storage Server (GSS) or a charging gateway function (CGF).
- Provide CALEA support for lawful intercepts.

Services in 3G/2G SGSN

All the parameters specific to the operation of an SGSN in a UMTS network are configured in an SGSN service configuration. SGSN services use other service configurations such as those listed below, to communicate with other elements in the network.

- The **IuPS-Service** that facilitates the communication with/from the RNCs. IuPS is using the SS7 support configuration (SCCP Networks, SS7 Routing Domains) to communicate with the RNCs.
- The **SGTP-Service** that facilitates the communication with/from other SGSNs and the GGSN's over the Gn/Gp core packet network.
- The **Gs-Service** facilitates the communication with/from VLRs
- The **MAP-Service** that facilitates the communication to/from the call control SS7elements (the HLR, EIR, SMS). MAP-Service is using the SCCP Network support layer configured on the chassis to route the messages to the appropriate destinations.

All of the parameters needed for the system to perform as an SGSN in a GPRS network are configured in the GPRS service. The GPRS service uses other configurations such as SGTP and MAP to communicate with other network entities and setup communications between the BSS and the GGSN.

SGSN Related Software Tasks

IMSIMgr Task will be created as soon as SGSN/GPRS service is started.

The IMSIMg task Started by the Session Controller, performs the following functions:

- Selects SessMgr, when not done by LinkMgr or SGTPCMgr, for calls sessions based on IMSI/P-TMSI.
- Load-balances across SessMgrs to select one for assigning subscriber sessions to.
- Maintains records for all subscribers on the system.
- Maintains mapping between the IMSI/P-TMSI and SessMgrs.

Important: For ASR 5x00s with session recovery enabled, this Demux manager is usually established on one of the CPUs on the first active Demux PSC. The IMSIMgr will not start on a PSC in which SessMgrs are already started.

SGTPCMgr Task will be spawned as soon the SGTP Service is created.

Created by the Session Controller for each VPN context in which an SGSN service is configured, the SGTPC Manager task performs the following functions:

- Terminates Gn/Gp and GTP-U interfaces from peer GGSNs and SGSNs for SGSN Services.
- Terminates GTP-U interfaces from RNCs for IuPS Services.
- Controls standard ports for GTP-C and GTP-U.
- Processes and distributes GTP-traffic received from peers on these ports.
- Performs all node level procedures associated with Gn/Gp interface.

LinkMgr Task will be spawned as soon as SS7 routing domain is created.

Created by the Session Controller when the first SS7RD (routing domain) is activated, the LinkMgr performs the following functions:

- Multi-instanced for redundancy and scaling purposes.
- Provides SS7 and Gb connectivity to the platform.
- Routes per subscriber signalling across the SS7 (including Iu) and Gb interfaces to the SessMgr

GGSN Overview

Gateway GPRS Support Node (GGSN) is a gateway from a cellular network to an IP network that allows mobile user equipment (UE) to access the public data network (PDN) or specified private IP networks.

There is a dedicated link between the UE and the GGSN. This link is created through the Packet Data Protocol (PDP) Context activation process. PDP Context is used to allocate the PDP address. There are three different types of PDP Contexts: IPv4, IPv6 and Point-to-Point Protocol (PPP).

The GGSN works in conjunction with Serving GPRS Support Nodes (SGSNs) within the network to perform the following functions:

- Establish and maintain subscriber Internet Protocol (IP) or Point-to-Point Protocol (PPP) type Packet Data Protocol (PDP) contexts originated by either the mobile or the network, and route traffic to PDN networks (Packet Data Network).

- Allow mobile network operator to control authentication and authorization for each subscriber, and providing accounting management for the user sessions (online and offline)
- Performing shallow and deep packet inspection for user traffic and perform action base on traffic type (charging categories, firewalling, filtering, traffic shaping, blacklisting, etc.)
- PDNs are associated with Access Point Names (APNs) configured on the system. Each APN consists of a set of parameters that dictate how subscriber authentication and IP address assignment is to be handled for that APN.

The Cisco ASR 5000/ASR 5500 chassis provides wireless carriers with a flexible solution that functions as a Gateway GPRS Support Node (GGSN) in General Packet Radio Service (GPRS) or Universal Mobile Telecommunications System (UMTS) wireless data networks.

GGSN related software tasks

When ggsn-service is configured, the system will create "**gtpcmgr**" task. This task is created by Session Controller for each context in which a GGSN service is configured, the GTPC Manager task performs the following functions:

- Receives the GTP sessions from the SGSN and distributes them to different Session Manager tasks for load balancing.
- Maintains a list of current Session Manager tasks to aid in system recovery.
- Verifies validity of GTPC messages.
- Maintains a list of current GTPC sessions.
- Handles GTPC Echo messaging to/from SGSN.

When gtpu-service is configured, the system will create "**gtpumgr**" task. This task is created by the Session Controller for each context in which a GTPU service is configured, the GTPU Manager performs the following functions:

- Maintains a list of the GTPU-services available within the context and performs load-balancing (of only Error-Ind) for them.
- Supports GTPU Echo handling.
- Provides Path Failure detection on no response for GTPU echo.
- Receives Error-Ind and demuxes it to a particular Session Manager.

Troubleshooting SGSN

Overview

This section focuses on CLI commands in ASR 5000/ASR 5500 used to troubleshoot different interfaces on SGSN along with multiple example issue scenarios.

Troubleshooting Commands

SGSN functionality in ASR 5000/ASR 5500 is configured per the *GPRS-service* entity for 2G-SGSN and by SGSN-*Service* in case of 3G-SGSN.

CLI:

- show gprs-service all
- show sgsn-service all

Check the status of the service (should be "**STARTED**")

```
******** show gprs-service all *******
Service name               : GPRS-SVC
Context                    : gbctx
Status                     : STARTED
Accounting Context Name    : gbctx
SGSN Number                : XXXXXXXXXX
Self PLMN Id               : MCC: XXX, MNC:  XX
```

```
******** show sgsn-service all *******
Service name               : SGSN-SVC
 Context                    : gnctx
Status                     : STARTED
Accounting Context Name    : gnctx
SGSN Number                : XXXXXXXXXX
```

Troubleshooting Gb Interface

CLI:

- show gprsns status nsvc-status-all nse all
- show gprsns status nsvc-status-consolidated nse <>
- show network-service-entity ip-config
- show gmm-sm statistics verbose
- show sgtpc statistics verbose
- show map statistics
- show bssgp statistics verbose
- show llc statistics verbose
- show gprsns statistics sns-msg-stats
- show session disconnect-reasons verbose

This is the SGSN's interface to the Base Station System (BSS) in a 2G Radio Access Network (RAN). It connects the SGSN via UDP/IP (via an Ethernet interface) or Frame Relay (via a Channelized SDH or SONET interface) to the network.

The following CLIs provide information on the status of Gb links between SGSN and BSCs.

- **show gprsns status nsvc-status-all nse all**. Check the status (should be "**ENABLED**")

```
[local]asr5000# show gprsns status nsvc-status-all nse all

GbManager      :   1

-------------------------------------------------------------------------------------------------------------
| nsei   | nsvci |          IP/PORT          |      Alive-State     |     Mgmt-State          |      STATUS        |
|        |       |---------------------------------------------------------------------------------------------
|        |       | L |     X.X.X.X/ 5001 | P | WAITNG-ALIVE-ACK | P |            DISABLED |                    |
|    10  |     0 | ------------------------------------------------------------------------|            ENABLED |
|        |       | R |   X.X.X.X/ 6001 | C | WAITNG-ALIVE-ACK | C |            DISABLED |                    |
|-------------------------------------------------------------------------------------------------------------|
|        |       | L |     X.X.X.X/ 5001 | P | WAITNG-ALIVE-ACK | P |            DISABLED |                    |
|    10  |     1 | ------------------------------------------------------------------------|            ENABLED |
|        |       | R |   X.X.X.X/ 6002 | C | WAITNG-ALIVE-ACK | C |            DISABLED |                    |
|-------------------------------------------------------------------------------------------------------------|
|        |       | L |     X.X.X.X/ 5001 | P | WAITNG-ALIVE-ACK | P |            DISABLED |                    |
|    10  |     2 | ------------------------------------------------------------------------|            ENABLED |
|        |       | R |   X.X.X.X/ 6003 | C | WAITNG-ALIVE-ACK | C |            DISABLED |                    |
```

```
|-------------------------------------------------------------------------------------------------------------|
|       |       | L |     X.X.X.X/ 5001 | P | WAITNG-ALIVE-ACK | P |            DISABLED |                    |
|    10 |     3 | ------------------------------------------------------------------------|            ENABLED |
|       |       | R |   X.X.X.X/ 6004 | C | WAITNG-ALIVE-ACK | C |            DISABLED |                    |
|-------------------------------------------------------------------------------------------------------------|
|       |       | L |     X.X.X.X/ 5001 | P | WAITNG-ALIVE-ACK | P |            DISABLED |                    |
|    11 |     0 | ------------------------------------------------------------------------|            ENABLED |
|       |       | R |   X.X.X.X/ 5001 | C | WAITNG-ALIVE-ACK | C |            DISABLED |                    |
|-------------------------------------------------------------------------------------------------------------|
|       |       | L |     X.X.X.X/ 5001 | P | WAITNG-ALIVE-ACK | P |            DISABLED |                    |
|    11 |     1 | ------------------------------------------------------------------------|            ENABLED |
|       |       | R |   X.X.X.X/ 5002 | C | WAITNG-ALIVE-ACK | C |            DISABLED |                    |
|-------------------------------------------------------------------------------------------------------------|
```

- **show gprsns status nsvc-status-consolidated nse 11**

This CLI used to check the status of individual NSEs. NSE Status should be **Enabled**

```
[local]asr5000# show gprsns status nsvc-status-consolidated nse 11
 Peer Nse Id         :     11          Nse Status          :   all nsvc enabled
 Num Nsvc enabled    :      4          Num Nsvc Congested  :      0
 Num Nsvc disabled   :      0
```

- **show network-service-entity ip-config**

This CLI helps to check the status of the BVCIs under each NSEI. Status should be **UNBLKD**.

```
Learned BVC table:


-------------------------------------------------------------------------
| BVCI   | MCC | MNC |  LAC   |  RAC  |  CI    |  STATUS   | BSIZE | LRATE |
-------------------------------------------------------------------------
|    131|  XXX|   YY|  XXXXX|    101|  11271|   UNBLKD |  65535|   4000|
|    132|  XXX|   YY|  XXXXX|    101|  11272|   UNBLKD |  65535|   4000|
|    133|  XXX|   YY|  XXXXX|    101|  11273|   UNBLKD |  65535|   4000|
|    141|  XXX|   YY|  XXXXX|    100|  38721|   UNBLKD |  65535|    800|
|    142|  XXX|   YY|  XXXXX|    100|  38722|   UNBLKD |  65535|    800|
```

```
|    143|  XXX|   YY|  XXXXX|    100|  38723|   UNBLKD |  65535|   4800|
|    151|  XXX|   YY|  XXXXX|    100|  11361|   UNBLKD |  65535|  12800|
|    152|  XXX|   YY|  XXXXX|    100|  11362|   UNBLKD |  65535|   4000|
```

- Following CLIs provide more information on the SGSN statistics. Watch for significant sections of the command output below:

```
show gmm-sm statistics verbose
Attach Request:
 Decode Error:


Attach Reject:
  Total-Attach-Reject:                 0
  3G-Network Failure:                  0   2G-Network Failure:
 GPRS-Attach Network Failure Cause:
 Comb-Attach Reject Causes:
 Attach Failure:
  Total-Attach-Failure:                0
  3G-Attach-Failure:                   0   2G-Attach-Failure:                   0
 Routing Area Update Reject:
  Total-RAU-Reject:                       0
 Routing Area Update Failure:
  Total-RAU-Failure:                 0
 Service Reject:
  Total-Serv-Rej:                   0
 Gmm Status Message:
  Total-Gmm-Status-Sent:          0
 Inter-System Attach Statistics:
  3G-Attach-Rej:                       0   2G-Attach-Rej:                       0
  3G-Comb-Attach-Rej:                  0   2G-Comb-Attach-Rej:                  0
 Authentication And Ciphering Reject:
  Total-Auth-Cipher-Rej:               0
 Authentication And Ciphering Failure:
Total-Auth-Cipher-Failure:             0
 Ranap Procedures:
  Security Mode Reject:               0
  Relocation Failure:              0     Relocation Prep Failure:       52626
  (look out for Relocation Failure Causes :)
```

```
 RIM Message Statistics:
 RIM Messages dropped:
 Counters under 'Drop Reason:'
 Counters under 'Forward Relocation Reject Causes :'
 Activate Context Reject:
  Total-Actv-Reject:                          0
Activate Context Failure:
  Total-Actv-Failure:                          0
 Request Pdp Context Activation Reject:
  Total-Request-Pdp-Ctxt-Reject:               0
 Counters under 'Request Pdp Context Activation Denied:'
 Modify Context Reject:
  Total-Modify-Reject:                         0
 SGSN Initiated RAB Messages:
Rab Setup/Mod Timer Expired:              0  Rab Setup/Mod Failed:    0
```

show sgtpc statistics verbose

```
Tunnel Management Messages:
Create PDP Context Response:
        Total Denied:
 Update PDP Context Response:
  Denied   TX:                          0   Denied   RX:
Identification Response:
  Denied   TX:                          0   Denied   RX:
SGSN Context Response:
  Denied   TX:                          0   Denied   RX:
SGSN Context Ack:
  Denied   TX:                          0   Denied   RX:
Forward Relocation Response:
  Denied   TX:                          0   Denied   RX:
Forward Relocation Complete Ack:
  Denied   TX:                          0   Denied   RX:

Counters under 'Path Failure Statistics:'
 RAN info Relay Msg:
 Total messages dropped:                   0
```

```
show map statistics
MAP Statistics:
 Authentication Req
  Failed:
Check IMEI Req
  Failed:
GPRS Loc Upd Req TX:
  Failed :
```

```
show bssgp statistics verbose
 Total BSSGP user requests dropped                 :    0
 BvcStatus messages transmitted                    :    0
 DL packets Dropped                                :    0
In response to MS originated Messages
   BVC Status received                             :    0
   BVC Status transmitted                          :    0
 RIM Messages
  RIM messages dropped
```

```
show llc statistics verbose
 XID Rx                 :                    0
   Total Discarded      :                    0
```

```
show gprsns statistics sns-msg-stats
 failures in SNS-Size received     :
 Failures in SNS-Config received
```

Troubleshooting Gr Interface

MAP is the application-layer protocol used to access the Home Location Register (HLR), Visitor Location Register (VLR), Mobile Switching Center (MSC), Equipment Identity Register (EIR), Authentication Center (AUC), Short Message Service Center (SMSC) and Serving GPRS Support Node (SGSN).

Gr functionality in ASR 5000/ASR 5500 is configured in the *MAP-service* entity.

- Check the status of MAP-Service (should be "**STARTED**").

The generated display includes MAP service features, MAP operational configuration, and some related HLR and EIR configuration information

```
[local]asr5000# show map-service all
Service name             :  MAP-SVC
State                    :  Started
Context                  :  MAP
SGSN MAP SCCP Network    :  4
MSC MAP SCCP Network     : Not Configured
```

- Check the SCTP and M3UA status for Gr interface, SCTP path status should be in **Active** state

```
[local]asr5000# show ss7-routing-domain 4 sctp asp all status peer-server all peer-server-
process all
   ss7 routing domain : 4
  *Peer Server Id :        1   Peer Server Process Id:        1

  Association State : ESTABLISHED
  ---------------------------------------------------------------------------------------
  |       Source Address       |     Destination Address    |          Path Status       |
  ---------------------------------------------------------------------------------------
  |     XXX.XXX.XXX.X /     2905 |   XXX.XXX.XXX.X /     2905 |Active  (Primary Path)      |
  ---------------------------------------------------------------------------------------

  *Peer Server Id :        2   Peer Server Process Id:        1

  Association State : ESTABLISHED
  ---------------------------------------------------------------------------------------
  |       Source Address       |     Destination Address    |          Path Status       |
  ---------------------------------------------------------------------------------------
  |     XXX.XXX.XXX.X /     2905 |   XXX.XXX.XXX.X /     2905 |Active  (Primary Path)      |
  ---------------------------------------------------------------------------------------
```

```
[local]asr5000# show ss7-routing-domain 4 m3ua status peer-server all
  ss7 routing domain : 4

       ---------------------------------------------------------------------------------------------
       | PS ID       (State) | PSP Instance | Routing Context | Registration Mode |        State |
       ---------------------------------------------------------------------------------------------
       |     1   (AS-ACTIVE) |            1 |               1 |            STATIC |   ASP-ACTIVE |
       |     2   (AS-ACTIVE) |            1 |               1 |            STATIC |   ASP-ACTIVE |
       ---------------------------------------------------------------------------------------------
```

- The following displays destination-point-code's routing table, route status should be in **Available** state

```
[local]asr5000# show ss7-routing-domain all routes

  ss7-routing-domain : 4

       ---------------------------------------------------------------------------------------------
----------------
     |            Destination-Point-Code | Peer-Server-Id | LinkSet-Id |                      Status
| Priority |
     ---------------------------------------------------------------------------------------------
-------------
     |                 0.4.2 (      34) |              1 |          - |                   Available
|        0 |
     |                 0.4.3 (      35) |              2 |          - |                   Available
|        0 |
     ---------------------------------------------------------------------------------------------
-------------

     Total Number of Routes: 2
```

- Check the SS7 Signalling Connection Control Part (SCCP) network configuration and subsystem status should be "**Subsystem user in service**" state.

```
[local]asr5000# show sccp-network all status all

    Sccp Network  4 :
    ------------------------------------------------------------------------------------------
------
    |                   dpc |                        status | ssn |              subsystem
status |
    ------------------------------------------------------------------------------------------
------
    |       0.4.2 (      34) |   Signalling Point Accessible |   6 |     Subsystem user in
service |
    |       0.4.3 (      35) |   Signalling Point Accessible |   9 |     Subsystem user in
service |
    ------------------------------------------------------------------------------------------
------
```

Troubleshooting IuPS Interface

The SGSN provides an IuOATM / IuOIP interface between the SGSN and the RNCs in the 3G UMTS Radio Access Network (UTRAN). RANAP is the control protocol that sets up the data plane (GTP-U) between these nodes. SIGTRAN (M3UA/SCTP) handle IuPS-C (control) for the RNCs.

IuPS functionality in ASR 5000/ASR 5500 is realized in the IuPS-service entity.

CLI and logs to collect for troubleshooting

> Below CLI commands require CLI test-commands password configured in the chassis. Please use the command with caution!
> Many TEST commands are processor-intensive and can cause serious system problems if used too frequently.

- show subscribers data-rate sgsn-only rnc id <> mcc <> mnc <>
- show gmm-sm statistics iups-service iups_H rnc mcc <> mnc <> rnc-id <> verbose
- show iups-service name iups_H rnc id <>

- show sgtpu statistics rnc-address <>
- logging filter active facility gmm level unusual.
- logging filter active facility sccp level unusual
- logging filter active facility pmm-app level unusual
- logging filter active facility sessmgr level unusual
- logging filter active facility linkmgr level unusual
- logging filter active facility sgsn-app level unusual

Check the Status of the IuPS service and it should be in **Started** state.

```
******** show iups-service all *******

Service name                 : IUPS-SVC
Service-Id                   : 1
State                        : STARTED
SCCP Network Id              : 2
Context                      : iuuctx
```

- Check the Status of RNC and it status should be in **Available** state

```
[local]asr5000# show iups-service name IUPS-SVC rnc all
  Iups Service : IUPS-SVC
  Context : IuPS
    ------------------------------------------------------------------------------
    |   rnc-mcc |   rnc-mnc |    rnc-id |  3GPP release  |         status          |
    |           |           |           |  compliance    |                         |
    ------------------------------------------------------------------------------
    |       XXX |       YYY |         1 |      Release-7 |              Available  |
    |       XXX |       YYY |         2 |      Release-7 |              Available  |
    |       XXX |       YYY |         3 |      Release-7 |              Available  |
    ------------------------------------------------------------------------------
```

- Check for the SCTP and M3UA status for Iu-PS interface the SCTP path status should be in **Active** state.

```
 [local]asr5000# show ss7-routing-domain 3 sctp asp all status peer-server all peer-server-
process all
   ss7 routing domain : 3
  *Peer Server Id :        1   Peer Server Process Id:        1

  Association State : ESTABLISHED
  ------------------------------------------------------------------------------------------
  |       Source Address       |     Destination Address    |          Path Status       |
  ------------------------------------------------------------------------------------------
  |     XXX.XXX.X.X /     2905 |   XXX.XXX.X.XXX /     2905 |Active  (Primary Path)      |
  ------------------------------------------------------------------------------------------

  *Peer Server Id :        2   Peer Server Process Id:        1

  Association State : ESTABLISHED
  ------------------------------------------------------------------------------------------
  |       Source Address       |     Destination Address    |          Path Status       |
  ------------------------------------------------------------------------------------------
  |     XXX.XXX.X.X /     2905 |   XXX.XXX.X.XXX /     2905 |Active  (Primary Path)      |
  ------------------------------------------------------------------------------------------

  *Peer Server Id :        3   Peer Server Process Id:        1

  Association State : ESTABLISHED
  ------------------------------------------------------------------------------------------
  |       Source Address       |     Destination Address    |          Path Status       |
  ------------------------------------------------------------------------------------------
  |     XXX.XXX.X.X /     2905 |   XXX.XXX.X.XXX /     2905 |Active  (Primary Path)      |
  ------------------------------------------------------------------------------------------
```

```
 [local]asr5000# show ss7-routing-domain 3 m3ua status peer-server all
   ss7 routing domain : 3

        ------------------------------------------------------------------------------------
-----
         | PS ID       (State) | PSP Instance | Routing Context | Registration Mode |
State |
```

```
        ------------------------------------------------------------------------------------------
-----
        |     1   (AS-ACTIVE) |            1 |               1 |            STATIC |   ASP-
ACTIVE |
        |     2   (AS-ACTIVE) |            1 |               1 |            STATIC |   ASP-
ACTIVE |
        |     3   (AS-ACTIVE) |            1 |               1 |            STATIC |   ASP-
ACTIVE |
        ------------------------------------------------------------------------------------------
-----
```

- Check for the destination-point-code's routing table, the route status should be in **Available** state

```
 [local]asr5000# show ss7-routing-domain all routes

   ss7-routing-domain : 3

     ------------------------------------------------------------------------------------------
---------------------
     |            Destination-Point-Code | Peer-Server-Id | LinkSet-Id |
Status | Priority |
     ------------------------------------------------------------------------------------------
---------------------
     |                  0.3.2 (      26) |              1 |          - |
Available |        0 |
     |                  0.3.3 (      27) |              2 |          - |
Available |        0 |
     |                  0.3.4 (      28) |              3 |          - |
Available |        0 |
     ------------------------------------------------------------------------------------------
---------------------

     Total Number of Routes: 3
```

- Check the SS7 Signalling Connection Control Part (SCCP) network configuration and subsystem status should be "**Subsystem user in service**" state.

```
 [local]asr5000# show sccp-network all status all


   Sccp Network  3 :
     ------------------------------------------------------------------------------------------
------
     |                   dpc |                        status | ssn |              subsystem
status |
     ------------------------------------------------------------------------------------------
------
     |       0.3.2 (      26) |   Signalling Point Accessible | 142 |     Subsystem user in
service |
     |       0.3.3 (      27) |   Signalling Point Accessible | 142 |     Subsystem user in
service |
     |       0.3.4 (      28) |   Signalling Point Accessible | 142 |     Subsystem user in
service |
     ------------------------------------------------------------------------------------------
------
```

Example Scenarios

PDP Activation Reject

Problem Description:

SGSN is rejecting the Activate PDP request with the cause code # 26: insufficient resources

Expected Behaviour:

SGSN sends the Activate PDP Contex Accept Message to UE.

Data collection:

- Collect 2 or more “Show support details”
- Collect syslog

- Collect bulkstats/KPI for attach success rate and reject reason
- "monitor subscriber imsi [value]" (verbosity 2)
- Collect external packet capture

CLI used to troubleshoot the issue:

- show gmm-sm statistics verbose
- show port datalink counters
- show snmp traps history verbose
- show subscriber sgsn-o full imsi [value]
- monitor subscriber imsi [value]

Analysis:

As per Spec 24.008, cause value = 26 Insufficient resources. This cause code is used by the MS or by the network to indicate that a PDP context activation request, secondary PDP context activation request, PDP context modification request, or MBMS context activation request cannot be accepted due to insufficient resources.

Below is the call flow explaining this scenario.

1. SGSN sends RAB-Assignment Request to RNC.

2. RNC responds with RAB-Assignment Response with cause: release-due-to-utran-generated-reason.

3. SGSN sends Activate PDP reject with SM Cause: insufficient resources.

```
Activate Primary PDP Context Insufficient Resource Cause Segregation:

Total 3G-Insuff res triggers: 2732122
Total 3G-Insuff res external triggs: 2732122
3G-Qos Negotiation Fail: 0
3G-Operator Policy Fail: 0
3G-GGSN Has No Resources: 2339
3G-GGSN Changed PDP Type: 0
3G-GGSN PDP Addr Alloc Fail: 3
3G-RNC GTPU Path Failure: 0
```

```
3G-RNC RAB Establishment Fail: 2729025
Total 3G-Insuff res internal triggs: 0
3G-SGSN Has No Memory: 0

Activate Secondary PDP Context Insufficient Resource Cause Segregation:

Total 3G-Insuff res triggers: 42
Total 3G-Insuff res external triggs: 42
3G-Qos Negotiation Fail: 0
3G-Operator Policy Fail: 0
3G-Primary is GTPV0: 0
3G-GGSN Has No Resource: 0
3G-PDP Addr Type Mismatch: 0
3G-RNC GTPU Path Failure: 0
3G-RNC RAB Establishment Fail: 36
3G-Ongoing Bundle Deactivation: 0
Total 3G-Insuff res internal triggs: 0
3G-SGSN Has No Memory: 0
```

```
<<<<OUTBOUND  01:36:48:307 Eventid:87731(0)

===> Radio Access Network Application Part (RANAP) (78 bytes)
  RANAP PDU
  | 0... .... | Ext bit : 0
  | .00. .... | Choice index : Initiating Message (0)
    Procedure Code : id-RAB Assignment (0)
    Criticality
      | 00.. .... | Reject (0)
    RAB Assignment Value :
      | .100 1010 | Length Determinant : 74
      Value :
        RAB Assignment Request
          | 0... .... | Ext bit : 0
          Bit map :
            | .0.. .... | RAB Assignment Request Extensions : Not present
          RAB Assignment Request IEs

INBOUND>>>>>  01:36:48:601 Eventid:87730(0)
```

```
===> Radio Access Network Application Part (RANAP) (21 bytes)
  RANAP PDU
  | 0... .... | Ext bit : 0
  | .11. .... | Choice index : Outcome (3)
    Procedure Code : id-RAB Assignment (0)
    Criticality
      | 00.. .... | Reject (0)
    RAB Assignment Value :
      | .001 0001 | Length Determinant : 17
      Value :
        RAB Assignment Response
          | 0... .... | Ext bit : 0

......

 Cause
 | ..0. .... | Ext bit : 0
 | ...0 00.. | Choice index : 0
 Radio Network
 | .... ..00 | | 1110 .... | release-due-to-utran-generated-reason (15) (0x0f)

<<<<OUTBOUND  01:36:48:612 Eventid:88113(0)

===>GPRS Mobility/Session Management Message (43 Bytes)
Protocol Discriminator : SM message
1... .... : TI Flag : (1) allocated by receiver
.000 .... : TIO : (0)
.... 1010 : Protocol Discriminator : (10)
Message Type: 0x43 (67)
Message : Activate PDP Reject
  SM Cause : (26) Insufficient resources
```

Resolution:

As per Spec, there is no valid cause code defined if RAB is rejected by RNC. SGSN is sending Insufficient Resources in activation-reject which is correct. As RAB is not allocated by RNC, it is considered as "resources not available" from the Network side.

SGSN rejecting the ACTIVATION with SM Cause : (33) Requested service option not subscribed

Problem Observed:

SGSN rejecting the ACTIVATION with SM Cause : (33) Requested service option not subscribed

Expected Behavior:

SGSN should send Activate accept to UE

Data collection:

- Collect 2 or more “Show support details”
- Collect syslog
- Collect bulkstats/KPI for attach success rate and reject reason
- Monitor subscriber imsi [value] (verbosity 2)
- Collect external packet capture

CLI used to troubleshoot the issue:

- show gmm-sm statistics verbose
- show sgtpc statistics
- show port datalink counters
- show snmp traps history verbose
- show subscriber sgsn-o full imsi [value]
- Monitor subscriber imsi [value]


Analysis:

Verify the link between SGSN and GGSN (Gn-interface)
Verify no packet drops in SGSN.
Check the network latency using ping test.
Verify no port flaps or port drops in SGSN.

Collect "monitor subscriber imsi" trace or external packet capture (between SGSN and GGSN) for the subscriber. Inspect this data to see if the SGSN is sending ACTVATE PDP reject (SM Cause : (33) Requested service option not subscribed).

Traces clearly show that UE is sending Activate request with APN XXXXX.com to SGSN, SGSN verifying the HLR subscription received from the subscriber, but there is no APN available in subscription hence SGSN is sending ACTIVATE PDP CONTEXT reject with SM Cause : (33) "Requested service Option not subscribed".

Image - Requested Service Option Not Subscribed




```
show subs sgsn-o full imsi 123456789012345
Username:
  Access Type: sgsn                        msid: 123456789012345
  state: attached
  Current PTMSI : 0xc0000802
          Subscription Data:
 MSISDN : 112233445566778
  Charging Characteristics: none
  ODB-General-Data:
GPRS Subscription:
  PDP Subscription Data:
    PDP Context Id: 1
                              APN: cisco.com
           PDP Type: IPv4
                               PDP Address Type: Dynamic
      Charging Characteristics:  Normal Billing Prepaid Billing Flat Billing Hot Billing
    VPLMN Address Allowed : Not Allowed
    Source Statistics Descriptor        : Unknown
    Signalling Indication               : Optimised for signalling traffic
    Max Bit Rate Downlink (Ext)         : 8800 kbps
    Guaranteed Bit Rate Downlink (Ext)  : (0) Use the value indicated by the Guaranteed bit
rate for downlink
```

Trace:

```
 INBOUND>>>>>  From sessmgr:2 n_ccpu_sm_log.c:1121 (Callid 004c9973) 16:07:17:912
Eventid:88112(0)
 ===>GPRS Mobility/Session Management Message (32 Bytes)
 Protocol Discriminator : SM message
 0... .... : TI Flag : (0) allocated by sender
 .101 .... : TIO : (5)
 .... 1010 : Protocol Discriminator : (10)
 Message Type: 0x41 (65)
 Message : Activate PDP Context Request
 Requested NSAPI : NSAPI 5
   Requested LLC SAPI : (3) SAPI 3
   Requested Qos
     Length of Qos: 11
   Requested PDP address
    PDP type number: (33) IPv4 address
     Dynamic Addressing&#10:   Access Point Name
   Access Point Name Value: cisco1.com  >>> UE comes with wrong APN
       ===>GPRS Mobility/Session Management Message (3 Bytes)
                       Protocol Discriminator : SM message
                       1... .... : TI Flag : (1) allocated by receiver
                       .101 .... : TIO : (5)
                       .... 1010 : Protocol Discriminator : (10)
                       Message Type: 0x43 (67)
                       Message : Activate PDP Reject
                         SM Cause : (33) Requested service option not subscribed
```

Workaround :

If UE is requesting the incorrect APN, the APN aliasing feature will remap the session to a default APN which will circumvent this issue.

Resolution:

Correct the APN name in the UE or the Operator can rectify the subscriber configuration using Over-the-Air provisioning system to correct the home subscriber APN in the UE.

SGSN Rejecting Activation with SM cause (Missing or Unknown APN(#27))

Problem Description:

SGSN rejecting the ACTIVATION with SM Cause (SM Cause : (27) Missing or unknown APN)

Expected Behavior:

SGSN sends activation accept to UE.

Data collection:

- Collect 2 or more “Show support details”
- Collect syslog
- Collect bulkstats/KPI for attach success rate and reject reason
- Monitor subscriber imsi [value] (verbosity 2)
- Collect external packet capture

CLI used to troubleshoot the issue:

- show gmm-sm statistics verbose
- show dns-client [value]cache
- show dns-client statistics [value]
- show sgtpc statistics
- show port datalink counters
- show snmp traps history verbose
- show subscriber sgsn-o full imsi [value]
- Monitor subscriber imsi [value]


Analysis:

Verify the DNS configuration.

Verify the SGSN Gn link is working.

Collect the "monitor subscriber" trace or external packet capture. From the trace see that SGSN is receiving GTP_Unknown_APN from GGSN in Create-PDP-Context response..

Image - Missing or Unknown APN



Statistics:

```
show session disconnect-reasons
Total Disconnects: 2
Disconnect Reason                                      Num Disc   Percentage
-----------------------------------------------------  ---------  ----------
sgsn-ms-init-detach                                           1    50.00000
sgsn-actv-rejected-by-ggsn                                    1    50.00000
```

```
show gmm-sm statistics verbose
 Activate Context Request:
  Total-Actv-Request:                  1
    3G-Actv-Request:                   1    2G-Actv Request:                  0
    PDP Type IPv4v6:                   0    PDP Type IPv4v6:                  0
 Activate Context Reject:
  Total-Actv-Reject:                  1
    3G-Actv-Reject:                   1    2G-Actv-Reject:                   0
 Activate Primary PDP Context Denied:
  3G-Network Failure:                  0  2G-Network Failure:                  0
  3G-Missing or Unknown APN:           1  2G-Mising or Unknow APN:            0
```

```
show sgtpc statistics verbose | grep -i "missing"
  Unknown/Missing APN:                1    System Failure:                          0
```

Trace:

```
===>GPRS Mobility/Session Management Message (31 Bytes)
  Protocol Discriminator : SM message
    0... .... : TI Flag : (0) allocated by sender
     .101 .... : TIO : (5)
       .... 1010 : Protocol Discriminator : (10)
     Message Type: 0x41 (65)
      Message : Activate PDP Context Request
      Requested NSAPI : NSAPI 5
      Requested LLC SAPI : (3) SAPI 3
      Requested Qos
      Access Point Name
      Access Point Name Value: cisco.com
GTPC Rx PDU, from 192.168.5.52:2123 to 192.168.4.160:19001 (14)
TEID: 0x80014001, Message type: GTP_CREATE_PDP_CONTEXT_RES_MSG (0x11)
Sequence Number:: 0x0082 (130)
GTP HEADER FOLLOWS:
             Version number: 1
              Protocol type: 1 (GTP C/U)
       Extended header flag: Not present
       Sequence number flag: Present
           NPDU number flag: Not present
               Message Type: 0x11 (GTP_CREATE_PDP_CONTEXT_RES_MSG)
             Message Length: 0x0006 (6)
                  Tunnel ID: 0x80014001
            Sequence Number: 0x0082 (130)
GTP HEADER ENDS.
INFORMATION ELEMENTS FOLLOW:
                      Cause: 0xDB (GTP_MISSING_OR_UNKNOWN_APN)
INFORMATION ELEMENTS END.
                       ===>GPRS Mobility/Session Management Message (3 Bytes)
Protocol Discriminator : SM message
 1... .... : TI Flag : (1) allocated by receiver
   .101 .... : TIO : (5)
```

```
.... 1010 : Protocol Discriminator : (10)
    Message Type: 0x43 (67)
    Message : Activate PDP Reject
    SM Cause : (27) Missing or unknown APN
```

Resolution:

1.The most common reason for these failures is wrong DNS entries for APN to GGSN IP address mapping .

SGSN Rejecting Attach with GMM (MS not derived from network (#9))

Problem Observed:

SGSN rejecting the PTMSI ATTACH with cause code (MS not derived from network (#9))

Expected behavior:

SGSN send the Attach Accept to UE.

Data collection:

- Collect 2 or more “Show support details”
- Collect syslog
- Collect bulkstats/KPI for attach success rate and reject reason
- Monitor subscriber imsi [value] (verbosity 2)
- Collect external packet capture

CLI used to troubleshoot the issue:

- show gmm-sm statistics verbose
- show snmp traps history verbose
- show dns-client statistics client xxxx >>> where "xxxx" dns-client name
- show dns-client cache
- show session disconnect-reason
- show sgtpc statistics verbose.
- Monitor subscriber imsi [value]

Analysis:

Collect the "monitor subscriber imsi" trace for the subscriber, look for the SGSN sending Attach reject (MS not derived from network).

SGSN is deriving the previous MS location using the old RAI from the attach request after which it is sending an Identification request to the Peer-SGSN. The peer-SGSN is not responding with an Identification response. SGSN is sending an MS ID not dervied from Network to MS.

Resolution:

```
<<<<OUTBOUND  12:41:08:735 Eventid:116004(3)
 GTPC Tx PDU, from 192.168.3.20:19004 to 192.168.3.40:2123 (28)
TEID: 0x00000000, Message type: GTP_IDENTIFICATION_REQ_MSG (0x30)
GTP HEADER FOLLOWS:
Version number: 1
Protocol type: 1 (GTP C/U)
 Message Type: 0x30 (GTP_IDENTIFICATION_REQ_MSG)
Tunnel ID: 0x00000000
ROUTING AREA IDENTITY (RAI) FOLLOWS:
MCC: xxx  MNC: 09  LAC:4660  RAC:20
PTMSI: 0xC0000101
PTMSI Signature: 0x000000
INFORMATION ELEMENTS END
```

```
******** show gmm-sm statistics verbose *******
 Gprs-Attach Reject Causes:
   3G-GPRS service not allowed:      54805   2G-GPRS service not allowed:    2875524
   3G-GPRS and Non-GPRS service              2G-GPRS and Non-GPRS service
      not allowed:                  107046      not allowed:                 1025662
   3G-MsId not derived by Nw:            0   2G-MsId not derived by Nw:      1100384 >>>
```

```
******** show sgtpc statistics verbose *******
Mobility Management Messages:
 Identification Request:   Total   Ident-Req TX:          5627634 <<< Total   Ident-Req RX:
1343858
```

```
   Initial Ident-Req TX:          1171550   Initial Ident-Req RX:              1343858
    Ident-Req-TX (V1):             608891    Ident-Req-RX (V1):                1343858
   Identification Response:   Total Ident-Rsp TX:            1343858   Total Ident-Rsp RX:
3244 <<<
    Denied   TX:                   338536   Denied   RX:                         1818
    Accepted TX:                  1005322   Accepted RX:                         1426
     Initial Ident-Rsp TX:        1005322    Initial Ident-Rsp RX:               1426
```

Analysis found that the DNS response for the RAI is coming in with the wrong SGSN IP address. Because of this the SGSN is not receiving the identification response.

Correcting the DNS entries resulted in SGSN receiving the proper identification response for foreign PTMSI and Attach were getting successful

SGSN rejecting the Attach with GMM Cause :Auth_Ciphering_Reject

Problem Observed:

SGSN rejecting the Attach with AuthFailure in GMM Cause : Auth_Ciphering_Reject.

Expected behavior:

SGSN sends the Attach Accept to UE.

Data collection:

- Collect 2 or more “Show support details”
- Collect syslog
- Collect bulkstats/KPI for attach success rate and reject reason
- Monitor subscriber imsi [value] (verbosity 2)
- Collect external packet capture

CLI used to troubleshoot the issue:

- show gmm-sm statistics verbose
- show snmp traps history verbose
- show map statistics

- monitor subscriber imsi [value]

Analysis:


In collected "monitor subscriber imsi" trace for the subscriber it is clear that SGSN is sending Attach reject(Authentication_ciphering_reject).

From the trace:

- MS sending Attach request to SGSN
- SGSN is sending SAI Request to HLR.
- HLR is sending Triplets to SGSN
- SGSN is sending Auth_ciphering_request with RAND value to MS
- MS is sending SRES in Auth_Ciphering_response based on the RAND
- SGSN verifies the SRES value received from HLR and MS

SRES didn't match,hence SGSN is sending Auth_ciphering_reject to MS and also SGSN is reporting this auth failure to HLR in MAP Auth_Failure_report.

Image - Auth Ciphering Reject



Statistics:

```
show map statistics
  Auth Fail Rep Req TX :              1    Successful:                    1
  Failed :                            0    Timed Out                      0
```

```
show session disconnect-reasons
Disconnect Reason                                      Num Disc  Percentage
-----------------------------------------------------  ----------  ----------
sgsn-auth-failure                                             2    40.00000
sgsn-ms-init-detach                                           1    20.00000
sgsn-sai-failure                                              1    20.00000
sgsn-detach-init-deact                                        1    20.00000
```

```
show gmm-sm statistics verbose
 GPRS-Attach Network Failure Cause:
Total 3G-Network Fail rejects:         1
Total 3G-external Triggers:            1  Total 2G-external Triggers:            0
3G-Data missing from HLR:              1   2G-Data missing from HLR:             0
```

Trace:

```
===> GSM Mobile Application (MAP)
 MAP Send Authentication Info Response
             Send Authentication Info Response Tag
            Authentication Triplet
                        RAND
                          Value  : 0x79 df 0d 86 48 70 00 00 09 00 01 02 03 04 05 06
                        SRES
                       Value  : 0x79 df 0d 86
                        Kc
                          Value  : 0x01 02 03 04 05 06 07 08
 ===>GPRS Mobility/Session Management Message
 Protocol Discriminator : GMM message
```

```
Message Type: 0x12 (18)
Message : Authentication and Ciphering Request
  IMEISV Request : (0) IMEISV not requested
  Authentication RAND
    Element ID: 33
    RAND Value: 79 df 0d 86 48 70 00 00 09 00 01 02 03 04 05 06
  Ciphering Key Sequence : 0x0 (0)
   ===>GPRS Mobility/Session Management Message
Message : Authentication and Ciphering Request
                        Authentication RAND
                         RAND Value: 79 df 0d 86 48 70 00 00 09 00 01 02 03 04 05 06
    ===>GPRS Mobility/Session Management Message
                   Message : Authentication and ciphering Response
                      SRES Value: 0b 01 00 00   >>> SRES Value Not matching with HLR
                       Mobile Identity - IMEISV
                     BCD Digits: 2000154203230000
 ===> GSM Mobile Application (MAP)
MAP Authentication Failure Report Request
  ===>GPRS Mobility/Session Management Message
Protocol Discriminator : GMM message
Message : Authentication and ciphering Reject >>>
  ===> GSM Mobile Application (MAP)
MAP Authentication Failure Report Response
```

Resolution:

SGSN is behaving as expected since HLR keys and USIM in MS is not matching,

HLR/AUC needs to update the key DB for the user. Issue must be HLR or UE may be at fault for not sending proper SRES to SGSN.

SGSN rejecting the ATTACH with GMM Cause : (8) GPRS services not allowed)

Problem Description:

SGSN rejecting the IMSI/PTMSI ATTACH with GMM Cause : (8) GPRS services and non-GPRS services not allowed)

Expected behavior:

SGSN send the Attach Accept to UE.


Data collection:

- Collect 2 or more “Show support details”
- Collect syslog
- Collect bulkstats/KPI for attach success rate and reject reason
- Monitor subscriber imsi [value] (verbosity 2)
- Collect external packet capture

CLI used to troubleshoot the issue:

- show gmm-sm statistics verbose
- show snmp traps history verbose
- Monitor subscriber imsi [value]

Image - GPRS Service not Available



Trace:

```
===> GSM Mobile Application (MAP) (0x36) (54 bytes)
MAP Send Authentication Info Request
IMSI
Value : 123456789012345
Number Of Requested Vectors
Value : 1 (0x01)
Requesting Node Type
 Value : sgsn
 ===> GSM Mobile Application (MAP)
Component : Return Error(3)
Return Error Invoke ID
Unknown Subscriber  Unknown Subscriber Param
Value : IMSI Unknown
 ===>GPRS Mobility/Session Management Message
 Protocol Discriminator : GMM message
.... 1000 : Protocol Discriminator : (8)
Message Type: 0x4
Message : Attach Reject
GMM Cause : (8) GPRS services and non-GPRS services not allowed
```

Analysis:

Collected the "monitor subscriber imsi" trace for the subscriber. Analyze to find that the SGSN is sending an Attach reject (GPRS services and non-GPRS services not allowed).

In the trace, SGSN is sending SAI request to HLR and HLR is sending "IMSI Unknown "for that subscriber imsi. This means the subscriber doesn't exist with a valid GPRS subscription and is not a valid subccriber.

SGSN rejecting the ATTACH with GMM cause : Network Failure (17)

Problem Observed:

SGSN rejecting the ATTACH with GMM cause code : Network Failure (17)

Expected behavior:

SGSN send the Attach Accept to UE.

Data collection:

- Collect 2 or more “Show support details”
- Collect syslog
- Collect bulkstats/KPI for attach success rate and reject reason
- Monitor subscriber imsi [value] (verbosity 2)
- Collect external packet capture

CLI used to troubleshoot the issue:

- show gmm-sm statistics verbose
- show map statistics
- show snmp traps history verbose
- monitor subscriber imsi [value]
- show port datalink counters

Analysis:

Verify the link between SGSN and STP/HLR is working fine.


Verify there are no packet drops towards STP/HLR (ping test).

Verify no port flaps or port drops in SGSN.

Collect "monitor subscriber imsi" trace or external packet capture (between SGSN and HLR/STP) for the subscriber. Analyze the data to find if the SGSN is sending Attach reject(Network Failure).

In the trace, SGSN is sending SAI request to HLR and the SGSN waiting for 15 sec to get response from HLR. Since there is no response received from HLR, SGSN sends Network failure to MS

Image - Network Failure



Trace

```
 >>>>>>> INBOUND
 ===>GPRS Mobility/Session Management Message (33 Bytes)
 Protocol Discriminator : GMM message
  0000 .... : Skip Indicator : (0)
   Message Type: 0x1 (1)
   Message : Attach Request
  MS Network Capability
  <<<<OUTBOUND  From sessmgr:1 n_ccpu_sm_log.c:1399 (Callid 00004e31) 15:12:30:308
Eventid:87114(0)
 ===> GSM Mobile Application (MAP)
   Component : Invoke(1)
   Component Length : Indefinite length format (0x80)
       MAP Send Authentication Info Request
        IMSI
        Value  : 231456789012345
             Number Of Requested Vectors
        Value  : 1
             Requesting Node Type
        Value  : sgsn
  <<<<OUTBOUND  From sessmgr:1 n_ccpu_sm_log.c:1174 (Callid 00004e31) 15:12:45:303
 ===>GPRS Mobility/Session Management Message
 Protocol Discriminator : GMM message
 0000 .... : Skip Indicator : (0)
 .... 1000 : Protocol Discriminator : (8)
 Message Type: 0x4 (4)
 Message : Attach Reject
```

```
GMM Cause : (17) Network failure
```

Resolution:

SGSN is behaving as expected. HLR didn't send any response to the SGSN's SAI Request hence SGSN is rejecting the call with Network failure #17.

Routing Area Update Reject with cause code MS not derived from network (#9)

Problem Observed:

SGSN rejecting the routing area update with cause code MS not derived from network (#9))

Expected behavior:

SGSN send the routing area update Accept to UE.

Data collection:

- Collect 2 or more "Show support details"
- Collect syslog
- Collect bulkstats/KPI for attach success rate and reject reason
- Monitor subscriber imsi [value] (verbosity 2)
- Collect external packet capture

CLI used to troubleshoot the issue:

- show gmm-sm statistics verbose
- show snmp traps history verbose
- show dns-client statistics client xxxx >>> where "xxxx" is dns-client name
- show dns-client cache
- show session disconnect-reason
- show sgtpc statistics verbose


Analysis:

In "monitor subscriber IMSI" trace the SGSN is sending routing area reject (MS not derived from network).

The SGSN is deriving previous MS location from PTMSI (NRI) & OLD RAI from the routing area update request after which it's sending GTP SGSN Context Request to Peer-SGSN/MME. Peer-SGSN/MME is not responding with GTP SGSN Context Response.

As a result SGSN is sending MS ID that is not dervied from the Network to MS after retry timer expiry "gtpc max-retransmissions". In this case gtpc retransmission-timeout is 5sec.

Image - callflow for MS not derived from network




```
  Message Type: 0x32 (GTP_SGSN_CONTEXT_REQ_MSG)
            Message Length: 0x0022 (34)
                 Tunnel ID: 0x00000000
           Sequence Number: 0x08C7 (2247)
GTP HEADER ENDS.
INFORMATION ELEMENTS FOLLOW:
ROUTING AREA IDENTITY (RAI) FOLLOWS:
                       MCC: XXX
                       MNC: YYY
                       LAC:9C42
```

```
                        RAC:F8
ROUTING AREA IDENTITY (RAI) ENDS.
                      PTMSI: 0xC0F85029
             PTMSI Signature: 0x03BB61
                MS Validated: 0
        Tunnel ID Control I: 0x00000001
              GSN Address I: 0xD1E21F64 (172.18.31.100)
===>GPRS Mobility/Session Management Message (4 Bytes)
Protocol Discriminator : GMM message
0000 .... : Skip Indicator : (0)
.... 1000 : Protocol Discriminator : (8)
Message Type: 0xb (11)
Message : Routing Area Update Reject
  GMM Cause : (9) MS identity cannot be derived by the network
  Force To Standby : (0) Force to standby not indicated
  Spare half octet: (0)
  ******** show gmm-sm statistics verbose *******
Routing Area Update Reject:
    Total-PS-Inter-RAU-Rej:          88564095
     3G-PS-Inter-RAU-Rej:              974863   2G-PS-Inter-RAU-Rej:           87589232 >>
    Total-Comb-Inter-RAU-Rej:            166
 Inter SGSN PS Only Routing Area Update Reject Causes:
  3G-GPRS service not allowed:          0   2G-GPRS service not allowed:          0
  3G-GPRS and Non-GPRS service              2G-GPRS and Non-GPRS service
     not allowed:                       0      not allowed:                       0
  3G-MsId not derived by Nw:       973586   2G-MsId not derived by Nw:     83884662
  3G-Implicitly Detached:               0   2G-Implicitly Detached:           607896
  3G-PLMN not allowed:                  0   2G-PLMN not allowed:                  0
  3G-Location Area not allowed:         0   2G-Location Area not allowed:         0
```

Troubleshooting Steps:

1. Check the Configuration under Call-Control profile. SGSN selects the call control profile from SGSN Global config on the basis of RAI in RAU.

```
sgsn-global
imsi-range mcc XXX mnc YYY plmnid XXXYYY operator-policy home_oper1
 operator-policy name home_oper1
```

```
associate call-control-profile home_cc1
 call-control-profile home_cc1
sgsn-address rac 176 lac 11600 nri 8 prefer local address ipv4 172.18.201.230 interface gn
```

2 Check the DNS response, make sure it returns correct IP address.

3 Check the IP connectivity.

Resolution:

1 If the DNS responds with incorrect IP address, correct the IP address in the DNS.

2 If there is a connectivity issue, then correct the routing problem.

Routing area update reject with cause code Network Failure #17

Problem Observed:

SGSN rejecting the Routing area update with cause code Network Failure #17

Expected behavior:

SGSN send the Routing area update Accept to UE.

Data collection:

- Collect 2 or more “Show support details”
- Collect syslog
- Collect bulkstats/KPI for attach success rate and reject reason
- Monitor subscriber imsi [value] (verbosity 2)
- Monitor protocol (Verbosity 2) -- Use caution when running this command in a Production network.
- Collect external packet capture

CLI used to troubleshoot the issue:

- show gmm-sm statistics verbose
- show snmp traps history verbose


- show session disconnect-reason
- show sgtpc statistics verbose

Analysis:

There are different reasons for Network Failure, the most common problem is when the IMSI range is not configured under the SGSN Global config.

1. UE sends the RAU request with the remote PTMSI.
2. SGSN identifies the IMSI from the GTP SGSN Context response.
3. SGSN checks the IMSI range in the sgsn-global config to apply the appropriate Call-control profile.
4. If the IMSI range is missing in the sgsn-global config then SGSN sends the RAU reject to UE with cause code Network failure #17“

Image:




```
===>GPRS Mobility/Session Management Message (4 Bytes)
Protocol Discriminator : GMM message
Message : Routing Area Update Reject
  GMM Cause : (17) Network failure
 ******** show gmm-sm statistics verbose *******
   (Need to Add the information)
 ******** show sgtpc statistics verbose *******
 (Need to Add the information)
```

Other Cause Codes:

1 The Network failure cause code sent to the UE if the following rejection happens on the MAP.

MAP Cause code	GMM Cause code
MAP_PMM_RESULT_UNKNOWN_ERROR	NETWORK FAILURE (17)
MAP_PMM_RESULT_TIMEOUT	NETWORK FAILURE (17)
MAP_PMM_RESULT_DATA_MISSING_FROM_HLR	NETWORK FAILURE (17)
MAP_PMM_RESULT_UNKNOWN_ERROR	NETWORK FAILURE (17)
MAP_PMM_RESULT_DATA_MISSING_FROM_HLR	NETWORK FAILURE (17)

Trouble shooting Steps:

1 Check the IMSI range configuration under sgsn-global.

```
sgsn-global
imsi-range mcc XXX mnc YYY plmnid XXXYYY operator-policy home_oper1
```

2 Check that the MAP logs have no errors.

3 Check the IP connectivity.

Resolution:

1 If the IMSI range is missing, then add the IMSI range under the SGSN-Global config.

2 If this is a connectivity issue, then correct the routing problem.

3 Correct the subscriber profile into the HLR.

Troubleshooting GGSN

Overview

This section focuses on CLI commands in ASR 5000/ASR 5500 used for troubleshooting different interfaces on GGSN and UMTS along with multiple issue scenarios.

Troubleshooting Commands

- **show gtpc statistics verbose**

  Description:

  View GTPC statistics (this command is present in every #show support details). Following are most important sections of the command output:

  Red - If counters marked with red start to increase and there is an issue on the system then please contact Cisco TAC.

  Blue - If counters marked with blue start to increase, there is an issue in communication between the Client (GGSN) and AAA servers (Radius server, Online charging server/OCS, PCRF)

  Orange - If counters marked with Orange start to increase, there is an issue regarding IP address assignment from the IP pool that is configured on GGSN.

```
Session Release Reasons:
  SGSN Initiated:                0   Secondary Teardown:            0
  Session Mgr. Died:             0   Admin Releases:                0
  APN Removed:                   0   Call Aborted:                  0
  Idle Timeout:                  0   Absolute Timeout:              0
  Source Addr Violation:         0   Flow Addition Failure:         0
  DHCP Renewal Failure:          0   Long Duration Timeout:         0
  Error Indication:              0   Context replacement:           0
  Other Reasons:                 0   Purged via Audit:              0
  Update Handoff Reject:         0
```

```
   Total Path Failures:            0
    SGSN Restart:                     Timeout:
     Create PDP Req:                0   GTPC Echo Timeout:              0
     Update PDP Req:                0   GTPU Echo Timeout:              0
     Echo Response:                 0   GGSN Req Timeout:               0
  Create PDP Context Denied:
   No Resources:                    0   No Memory:                      0
   All Dyn Addr Occupied:           0   User Auth Failed:               0
   Unknown/Missing APN:             0   System Failure:                 0
   Unknown PDP Addr/Type:           0   Unsupported Version:            0
   Semantic Error in TFT:           0   Syntactic Error in TFT:         0
   Semantic Error in                    Mandatory IE Incorrect:         0
      Packet Filter:                0   Mandatory IE Missing:           0
   Syntactic Error in                   Optional IE Incorrect:          0
      Packet Filter:                0   Invalid Message Format:         0
   Context Not Found:               0   Service Not Supported:          0
   APN restriction                      No APN Subscription:            0
      Incompatibility:              0
  Create PDP Denied - No Resource Reasons:
   PLMN Policy Reject:              0   New Call Policy Reject:         0
   APN/Svc Capacity:                0   Input-Q Exceeded:               0
   No Session Manager:              0   Session Manager Dead:           0
   Secondary For PPP:               0   Other Reasons:                  0
   Session Mgr Retried:             0   Session Mgr Not Ready:          0
   Session Setup Timeout:           0   Charging Svc Auth Fail:         0
   APN Reject Policy:               0   ICSR State Invalid:             0
   DHCP IP Address Not Present:                                         0
   Radius IP Validation Failed:                                         0
   S6B IP Validation Failed:                                            0
   Congestion Policy Applied:                                           0
    Exceeded secondary-pdp-context limit per-subscriber:                 0
    GTP-v0 IP address allocation/validation failed:                      0
    Mediation Delay GTP Response Accounting Start failed:                0
  Create PDP Denied - Auth Failure Reasons:
   Authentication Failed:           0    >>> Radius Reject Acsess Request
   AAA Auth Req Failed:             0    >>> Client (GGSN) has issues with sending Req to
Radius (server)
   APN selection-mode mismatch:     0    >>> SGSN and GGSN selection mode not match
   Non-existent virtual APN:        0
```

```
 Reject Foreign Subscriber:           0
 IMS Authorization Fail:              0    >>> PCRF Reject the subscriber
Create PDP Denied - Dynamic Address Occupied:
 DHCP No IP Address Alloc:                                          0
 DHCP Timer Notification:                                           0
 Local IP Validation Failed:                                        0
 Local IP Pool All Address Occupied:                                0
```

- **show ggsn-service all**

  Description:

  Use this command for quick a check regarding parameters configured in the GGSN service, for example GTPC Echo timers.

- **show ggsn-service sgsn-table**

  Description:

  Use this command to check which SGSNs this GGSN is communicating with.

- **show subscribers ggsn-only full imsi [value]**

  Description:

  Use this command to check only GGSN relevant information per IMSI.

Example Scenarios

PDP Context Reject - User Authentication failed

Problem Description:

Mobile operator reports that subscriber cannot establish PDP session.

Data collection:

- Collect mulitiple SSDs
- Collect external PCAP
- Collect sample "monitor subscriber" at verbosity 2 showing the error behavior
- Collect syslog


CLI used to troubleshoot the issue:

#show gtpc statistics verbose

#show session disconnect-reasons

monitor subscriber

Image - callflow for user authentication failed



Analysis:

1. Run multiple iterations of the command **show gtpc statistics verbose**. Compare counter values to see which ones increased in section "Create PDP Context Denied". In this case, the counter "User Auth Failed" increased. The counter "Authentication Failed" also increased in the output of "Create PDP Denied - Auth Failure Reasons:"

```
Create PDP Context Denied:
  No Resources:                    0    No Memory:                       0
```

```
  All Dyn Addr Occupied:           0   User Auth Failed:                1
  Unknown/Missing APN:             0   System Failure:                  0
  Unknown PDP Addr/Type:           0   Unsupported Version:             0
  Semantic Error in TFT:           0   Syntactic Error in TFT:          0
  Semantic Error in                    Mandatory IE Incorrect:          0
     Packet Filter:                0   Mandatory IE Missing:            0
  Syntactic Error in                   Optional IE Incorrect:           0
     Packet Filter:                0   Invalid Message Format:          0
  Context Not Found:               0   Service Not Supported:           0
  APN restriction                      No APN Subscription:             0
     Incompatibility:              0  Create PDP Denied - Auth Failure Reasons:
  Authentication Failed:               1
  AAA Auth Req Failed:                 0
  APN selection-mode mismatch:         0
  Non-existent virtual APN:            0
  Reject Foreign Subscriber:           0
  IMS Authorization Fail:              0
 Total Disconnects: 1
```

2 Take a few samples of the command **show session disconnect-reasons**. Compare counter values to see which ones increased the most. In this case it is "user authentication failiure".

```
Disconnect Reason                                      Num Disc   Percentage
-----------------------------------------------------  ----------  ----------
gtp-user-auth-failed                                          1    100.00000
```

3 Collect "monitor subscriber next-call" data, until a session experiencing the disconnect is caught. If information like MSISDN, IMSI or APN are available, the "mon sub" can be narrowed by using them as a filter. In this scenario, the Radius server rejected this subscriber.

```
-------------------------------------------------------------------------
(Switching Trace) - New Incoming Call:
-------------------------------------------------------------------------
 MSID/IMSI   : 450061234554321            Callid      : 00004e21
```

```
 IMEI        : n/a                          MSISDN      : 64211234567
 Username    : 64211234567                  SessionType : ggsn-pdp-type-ipv4
 Status      : Active                       Service Name: GGSN-SVC
 Src Context : Gn
-------------------------------------------------------------------------
 Tuesday May 05 2015
INBOUND>>>>>  14:00:57:503 Eventid:47000(3)
GTPC Rx PDU, from 192.168.2.138:2123 to 192.168.2.1:2123 (187)
TEID: 0x00000000, Message type: GTP_CREATE_PDP_CONTEXT_REQ_MSG (0x10)
Sequence Number:: 0x7FFF (32767)
INFORMATION ELEMENTS FOLLOW:
                      IMSI: 450061234554321
                  Recovery: 0x08 (8)
             Selection Mode: 0x0 (MS or network provided APN, subscribed verified
(Subscribed))
           Tunnel ID Data I: 0x00000400
        Tunnel ID Control I: 0x00000400
                    NSAPI: 0x05 (5)
 CHARGING CHARACTERISTIC FOLLOWS:
                 Charging Chars # 1: 0x0800 (Normal)
CHARGING CHARACTERISTIC ENDS.
END USER ADDRESS FOLLOWS:
      PDP Type Organisation: IETF
            PDP Type Number: IPv4
                    Address: Empty
END USER ADDRESS ENDS.
           Access Point Name: ecs-apn
PROTOCOL CONFIG. OPTIONS FOLLOW:
                  IE Length: 0x55 (85)
     Configuration Protocol: (0) PPP
              Extension Bit: (1)
                 Protocol id: 0xC021 (LCP)
            Protocol length: 0x0E (14)
          Protocol contents: 0103000E0506088AA1020304C023
                Protocol id: 0xC021 (LCP)
            Protocol length: 0x0E (14)
          Protocol contents: 0203000E0506088AA1020304C023
                Protocol id: 0xC023 (PAP)
            Protocol length: 0x16 (22)
```

```
          Protocol contents: 0104001608746573747573657208746573747061737 3
                Protocol id: 0x8021 (IPCP)
            Protocol length: 0x16 (22)
          Protocol contents: 0101001603060000000081060000000830600000000
 PROTOCOL CONFIG. OPTIONS END.
              GSN Address I: 0xC0A8028A (192.168.2.138)
             GSN Address II: 0xC0A8028A (192.168.2.138)
                    MSISDN: 64211234567
                QOS Profile: 0x0122720D7396404886074048
 COMMON FLAGS FOLLOW:
  Prohibit Payload Compression: no
            MBMS Service Type: Multicast Service
         RAN Procedures Ready: no
    MBMS Counting Information: no
           No QoS negotiation: no
                         NRSN: no
        Upgrade QoS Supported: yes
     Dual Address Bearer Flag: no
 COMMON FLAGS END.
 INFORMATION ELEMENTS END.
  Tuesday May 05 2015
 <<<<OUTBOUND  14:00:57:526 Eventid:23901(6)
 RADIUS AUTHENTICATION Tx PDU, from 192.168.1.1:47218 to 192.168.1.128:1812 (323) PDU-
dict=starent-vsa1
  Code: 1 (Access-Request)
  Id: 1
  Length: 323
  Authenticator: D5 F2 57 46 BA D6 73 2D 7C 07 25 20 E6 4C 35 10
       Calling-Station-Id = 64211234567
       User-Name = testuser
       NAS-IP-Address = 192.168.1.1
       Service-Type = Framed
       Framed-Protocol = GPRS_PDP_Context
       NAS-Port-Type = Wireless_Other
       SN1-GTP-Version = GTP_VERSION_1
       3GPP-IMSI = 450061234554321
       3GPP-NSAPI = 5
       3GPP-Selection-Mode = 0
       3GPP-Charging-Id = 1
```

```
       3GPP-Negotiated-QoS-Profile = 99-22720D739640488607FFFF
       3GPP-Chrg-Char = 0800
       Called-Station-ID = ecs-apn
       3GPP-SGSN-Address = 192.168.2.138
       3GPP-SGSN-Mcc-Mnc = 123456
       3GPP-GGSN-Address = 192.168.2.1
       3GPP-GGSN-Mcc-Mnc = 123456
       3GPP-Negotiated-DSCP = 0A
       3GPP-User-Location-Info = 02 21 63 54 FF FE FF FF
       3GPP-PDP-Type = ipv4
       SN1-Service-Type = GGSN
       NAS-Port = 4097
       User-Password = 93 D8 5D 76 D3 24 EE E4 96 6C 61 44 B8 FD 29 C1
       3GPP-CG-Address = 192.168.7.128
 Tuesday May 05 2015
INBOUND>>>>>  14:00:57:526 Eventid:23900(6)
RADIUS AUTHENTICATION Rx PDU, from 192.168.1.128:1812 to 192.168.1.1:47218 (32) PDU-
dict=starent-vsa1
 Code: 3 (Access-Reject)
 Id: 1
 Length: 32
 Authenticator: 1F 3C 06 A0 C2 C7 B6 D2 47 11 AE D2 1F 79 F7 CC
       Service-Type = Framed
       Framed-Protocol = PPP
 Tuesday May 05 2015
<<<<OUTBOUND  14:00:57:529 Eventid:47001(3)
GTPC Tx PDU, from 192.168.2.1:2123 to 192.168.2.138:2123 (14)
TEID: 0x00000400, Message type: GTP_CREATE_PDP_CONTEXT_RES_MSG (0x11)
Sequence Number:: 0x7FFF (32767)
INFORMATION ELEMENTS FOLLOW:
                      Cause: 0xD1 (GTP_USER_AUTHENTICATION_FAILED)
INFORMATION ELEMENTS END.
 Tuesday May 05 2015
***CONTROL*** 14:00:57:542 Eventid:10285
CALL STATS: msisdn <64211234567>, apn <ecs-apn>, imsi <450061234554321>, Call-Duration(sec): 0
  input pkts: 0                        output pkts: 0
  input bytes: 0                       output bytes: 0
  input bytes dropped: 0               output bytes dropped: 0
   input pkts dropped: 0                output pkts dropped: 0
```

```
dlnk pkts exceeded bw: 0                dlnk pkts violated bw: 0
uplnk pkts exceeded bw: 0               uplnk pkts violated bw: 0
Disconnect Reason: gtp-user-auth-failed
Last Progress State: Authenticating
```

Resolution :

Check the Radius server for the subscriber getting rejected, and confirm whether the subscriber is allowed to connect to the network.

GGSN Rejecting PDP with cause ims-authorization-failed

Problem Description:

Mobile operator reports that subscribers for a specific APN can not establish PDP context connections.

Data Collection:

- Collect multiple SSDs
- Collect external PCAP
- Collect sample "monitor subscriber" traces at verbosity 2 showing the error behavior
- Collect syslog

CLI used to troubleshoot the issue:

- show gtpc statistics verbose
- show session disconnect-reasons
- monitor subscriber
- show ims-auth policy-control statsistics
- show task resources | grep -v good
- show diameter peers full all | grep -i state
- show port datalink counters
- show snmp traps history verbose

Troubleshooting steps:

Verify the configuration for the APN.


Verify all the neccessary interfaces associated for the APN are working.

Verify if any interfaces or ports are down using SNMP traps, or "show alarm outstanding" outputs.

Verify any packet drops observed in the network or in the GGSN using NPU commands.
Refer HW troubleshooting section

Verify latency in the network between GGSN and other connected network elements.

Image - Call Flow for ims-authorization-failed



Analysis:

1. GGSN is receving the CPC request from the SGSN and GGSN is sending CPC reponse with GTP_Authentication_failed. The end of the monitor subscriber trace shows the call is failed due to " Disconnect Reason: ims-authorization-failed".

```
-------------------------------------------------------------------
Incoming Call:
-------------------------------------------------------------------
```

```
 MSID/IMSI   : 123456000000002            Callid      : 000062af
 IMEI        : n/a                        MSISDN      : 9876543210
 Username    : 9876543210                 SessionType : ggsn-pdp-type-ipv4
 Status      : Active                     Service Name: ggsn
 Src Context : spgw
-------------------------------------------------------------------------
Wednesday May 06 2015
GTPC Rx PDU, from 10.201.251.5:2123 to 192.168.5.52:2123 (157)
TEID: 0x00000000, Message type: GTP_CREATE_PDP_CONTEXT_REQ_MSG (0x10)
Sequence Number:: 0x7FFF (32767)
GTP HEADER FOLLOWS:
             Version number: 1
              Protocol type: 1 (GTP C/U)
       Extended header flag: Not present
       Sequence number flag: Present
           NPDU number flag: Not present
              Message Type: 0x10 (GTP_CREATE_PDP_CONTEXT_REQ_MSG)
            Message Length: 0x0095 (149)
                 Tunnel ID: 0x00000000
           Sequence Number: 0x7FFF (32767)
GTP HEADER ENDS.
INFORMATION ELEMENTS FOLLOW:
                      IMSI: 123456000000002
                  Recovery: 0xE3 (227)
            Selection Mode: 0x1 (MS provided APN, subscription not verified (Sent by MS))
          Tunnel ID Data I: 0x00000400
        Tunnel ID Control I: 0x00000400
                    NSAPI: 0x05 (5)

CHARGING CHARACTERISTIC FOLLOWS:
                 Charging Chars # 1: 0x0800 (Normal)
CHARGING CHARACTERISTIC ENDS.
END USER ADDRESS FOLLOWS:
      PDP Type Organisation: IETF
            PDP Type Number: IPv4
                    Address: Empty
END USER ADDRESS ENDS.
           Access Point Name: cisco.com
PROTOCOL CONFIG. OPTIONS FOLLOW:
```

```
                IE Length: 0x36 (54)
    Configuration Protocol: (0) PPP
             Extension Bit: (1)

               Protocol id: 0xC021 (LCP)
           Protocol length: 0x0E (14)
PROTOCOL-1 CONTENTS FOLLOW:
        Conf-Req(3), Magic-Num=088aa102, Auth-Prot PAP
PROTOCOL-1 CONTENTS END.
               Protocol id: 0xC021 (LCP)
           Protocol length: 0x0E (14)
PROTOCOL-2 CONTENTS FOLLOW:
        Conf-Ack(3), Magic-Num=088aa102, Auth-Prot PAP
PROTOCOL-2 CONTENTS END.
               Protocol id: 0xC023 (PAP)
           Protocol length: 0x10 (16)
PROTOCOL-3 CONTENTS FOLLOW:
        Auth-Req(4), Name=test, Passwd=secret
PROTOCOL-3 CONTENTS END.
PROTOCOL CONFIG. OPTIONS END.
             GSN Address I: 0x0AC9FB05 (10.201.251.5)
            GSN Address II: 0x0AC9FB05 (10.201.251.5)
MSISDN FOLLOWS:
         Nature of address: 1 (International number)
            Numbering Plan: 1 (ISDN/Telephone numbering plan (E.164))
                   Address: 9876543210
MSISDN ENDS.
QOS PROFILE FOLLOWS (Length = 12)
  Alloc./Retention priority: 0x01 (1)
              Spare Octet1: 0x0 (0)
QOS PROFILE ENDS.
COMMON FLAGS FOLLOW:
 Prohibit Payload Compression: no
           MBMS Service Type: Multicast Service
        RAN Procedures Ready: no
    MBMS Counting Information: no
         No QoS negotiation: no
                       NRSN: no
       Upgrade QoS Supported: yes
```

```
      Dual Address Bearer Flag: no
 COMMON FLAGS END.
 INFORMATION ELEMENTS END.


 Wednesday May 06 2015
 <<<<OUTBOUND  From sessmgr:1 ggsnapp_util.c:662 (Callid 000062af) 09:33:58:098
Eventid:47001(3)
 GTPC Tx PDU, from 192.168.5.52:2123 to 10.201.251.5:2123 (71)
 TEID: 0x00000400, Message type: GTP_CREATE_PDP_CONTEXT_RES_MSG (0x11)
 Sequence Number:: 0x7FFF (32767)
 GTP HEADER FOLLOWS:
              Version number: 1
               Protocol type: 1 (GTP C/U)
        Extended header flag: Not present
        Sequence number flag: Present
            NPDU number flag: Not present
                Message Type: 0x11 (GTP_CREATE_PDP_CONTEXT_RES_MSG)
              Message Length: 0x003F (63)
                   Tunnel ID: 0x00000400
             Sequence Number: 0x7FFF (32767)
 GTP HEADER ENDS.
 INFORMATION ELEMENTS FOLLOW:
                       Cause: 0xD1 (GTP_USER_AUTHENTICATION_FAILED)
 PROTOCOL CONFIG. OPTIONS FOLLOW:
                   IE Length: 0x36 (54)
      Configuration Protocol: (0) PPP
                 Extension Bit: (1)

                  Protocol id: 0xC021 (LCP)
 PROTOCOL-3 CONTENTS END.
 PROTOCOL CONFIG. OPTIONS END.
 INFORMATION ELEMENTS END.


 Wednesday May 06 2015
 ***CONTROL*** From sessmgr:1 sessmgr_func.c:7497 (Callid 000062af) 09:33:58:183 Eventid:10285
 CALL STATS: msisdn <9876543210>, apn <cisco.com>, imsi <123456000000002>, Call-Duration(sec):
0
```

```
  input pkts: 0                          output pkts: 0
  input bytes: 0                         output bytes: 0
  input bytes dropped: 0                 output bytes dropped: 0
  dlnk pkts exceeded bw: 0               dlnk pkts violated bw: 0
  uplnk pkts exceeded bw: 0              uplnk pkts violated bw: 0
  Disconnect Reason: ims-authorization-failed
  Last Progress State: Authenticating
```

2. From the packet trace / monitor subscriber it was found that the Gx CCR-I was not leaving the GGSN. However, the Diameter interface status and peer Diameter status looked good .
3. When Gx IMS auth service was removed, the calls started working.
4. While verifying the configuration for the APN it was found that "IP access group <SERVICE>" was wrong, hence it was not redirecting the Gx CCR trigger towards PCRF. This caused the call to fail internally.

```
show diameter peers full all | grep -i state
  State: OPEN [TCP]
  State: OPEN [TCP]


show gtpc statistics verbose
Tunnel Management Messages:
  Total CPC Req:                  2
  CPC Req(V1):                    2   CPC Req(V0):                    0
  Primary CPC Req:                2   Secondary CPC Req:              0
  Initial CPC Req:                2   Retransmitted:                  0
  Total Accepted:                 0   Total Denied:                   2
  Total Discarded:                0
Create PDP Denied - Auth Failure Reasons:
  Authentication Failed:              0
  AAA Auth Req Failed:                0
  Reject Foreign Subscriber:          0
  IMS Authorization Fail:             2
```

```
show ims-authorization policy-control statistics
DPCA Session Stats:
  Total Current Sessions:    0
  Total IMSA Adds:           0            Total DPCA Starts:         0
  Total Fallback Session:    0            Total Session Updates:     0
  Total Terminated:          0            DPCA Session Failovers:    0

DPCA Message Stats:
  Total Messages Received:   0            Total Messages Sent:       0
  Total CCR:                 0            Total CCA:                 0
  CCR-Initial:               0            CCA-Initial:               0
  CCA-Initial Accept:        0            CCA-Initial Reject:        0
```

Resolution:

This issue was due to a mis-configuration in the APN where "IP access group <xxx>" was incorrect. Due to this the GGSN was not able to use active-charging, and that was preventing the use of Gx services. Once the APN configuration was corrected, successful Gx CCR-I messages were sent to PCRF, PCRF authenticated, and the subscriber calls were successful.

```
 config   context spgw     apn cisco.com       selection-mode subscribed sent-by-ms       ims-
auth-service gx       ip access-group ecs in >>>>            ip access-group ecs out >>>>
external-aaa group default context        ip context-name gi       ip address pool name
tmo_poolgroup       credit-control-group solo       active-charging rulebase cisco     exit
#exit end
```

GGSN Rejecting the PDP with DYNAMIC_PDP_ADDR_OCCUPIED

Problem Description:

Mobile provider reported a problem where subscribers could not establish a session as all IP addresses seem to be used.

Logs Collection:

- Collect multiple SSD
- Collect external PCAP
- Collect sample "monitor subscriber" at verbosity 2 showing the error behavior

- Collect syslog

CLI used to troubleshoot the issue:

- show gtpc statistics verbose
- show session disconnect-reasons
- monitor subscriber
- show ims-auth policy-control statsistics
- show task resources | grep -v good
- show diameter peers full all | grep -i state
- show port datalink counters
- show snmp traps history verbose

Troubleshooting steps:

Verify the configuration for the APN.


Verify all the necessary interfaces associated for the APN are working

Verify if any interfaces or ports are down using SNMP traps, or "show alarm outstanding" output.

Verify any packet drops observed in the network or in the GGSN using NPU commands.
Refer HW troubleshooting section

Verify latency in the network between GGSN and other connected network elements.

Image - Dynamic_PDP_ADDR_Occupied



Analysis:

1 The GGSN is receiving the CPC request from the SGSN, and GGSN is sending the CPC response with GTP_ALL_DYNAMIC_PDP_ADDR_OCCUPIED. The end of the "monitor subscriber" output shows the call has failed due to "Disconnect Reason: Gtp-all-dynamic-pdp-addr-occupied".

```
-------------------------------------------------------------------------
Incoming Call:
-------------------------------------------------------------------------
 MSID/IMSI    : 123456000000002             Callid      : 00006385
 IMEI         : n/a                         MSISDN      : 9876543210
 Username     : 9876543210                  SessionType : ggsn-pdp-type-ipv4
 Status       : Active                      Service Name: ggsn
 Src Context  : spgw
-------------------------------------------------------------------------

 Wednesday May 06 2015
 ***CONTROL*** 10:33:11:493 Eventid:10079
 Sessmgr-1 Failed to allocate an IPv4 address from context gi(3) for call
(errcode=VPN_MSG_STATUS_POOL_DYNAMIC_ADDRS_EXHAUSTED)

 Wednesday May 06 2015
 <<<<OUTBOUND  10:33:11:493 Eventid:47001(3)
```

```
GTPC Tx PDU, from 192.168.5.52:2123 to 10.201.251.5:2123 (71)
TEID: 0x00000400, Message type: GTP_CREATE_PDP_CONTEXT_RES_MSG (0x11)
Sequence Number:: 0x7FFF (32767)
GTP HEADER FOLLOWS:
             Version number: 1
              Protocol type: 1 (GTP C/U)
       Extended header flag: Not present
       Sequence number flag: Present
           NPDU number flag: Not present
               Message Type: 0x11 (GTP_CREATE_PDP_CONTEXT_RES_MSG)
             Message Length: 0x003F (63)
                  Tunnel ID: 0x00000400
            Sequence Number: 0x7FFF (32767)
GTP HEADER ENDS.
INFORMATION ELEMENTS FOLLOW:
                      Cause: 0xD3 (GTP_ALL_DYNAMIC_PDP_ADDR_OCCUPIED)
PROTOCOL CONFIG. OPTIONS FOLLOW:
                  IE Length: 0x36 (54)
     Configuration Protocol: (0) PPP
              Extension Bit: (1)
& INFORMATION ELEMENTS END.


Wednesday May 06 2015
***CONTROL*** 10:33:11:504 Eventid:10285
CALL STATS: msisdn <9876543210>, apn <cisco.com>, imsi <123456000000002>, Call-Duration(sec):
0
  input pkts: 0                         output pkts: 0
  input bytes: 0                        output bytes: 0
  uplnk pkts exceeded bw: 0             uplnk pkts violated bw: 0
  Disconnect Reason: Gtp-all-dynamic-pdp-addr-occupied
  Last Progress State: Authenticating
```

```
show session disconnect-reasons
Total Disconnects: 252
Disconnect Reason                                      Num Disc  Percentage
-----------------------------------------------------  ----------  ---------
Admin-disconnect                                              2    0.79365
```

```
path-failure                                          54   21.42857
Gtp-all-dynamic-pdp-addr-occupied                    188   74.60317
ims-authorization-failed                               2    0.79365
Gtp-context-replacement                                6    2.38095

show gtpc statistics verbose

Tunnel Management Messages:
  Total CPC Req:                256
  CPC Req(V1):                  256   CPC Req(V0):                    0
  Primary CPC Req:              227   Secondary CPC Req:             29
  Initial CPC Req:              256   Retransmitted:                  0
  Total Accepted:                66   Total Denied:                   1

Dynamic Address Allocation:
  IPv4 Attempt:                 227   Successful:                    37
  IPv6 Attempt:                   0   Successful:                     0


Create PDP Denied - Dynamic Address Occupied:
  DHCP No IP Address Alloc:                                           0
  DHCP Timer Notification:                                            0
  Local IP Validation Failed:                                         0
  Local IP Pool All Address Occupied:                               188

[gi]SPGW-1# show ip pool sum
context gi:
+-----Type:    (P) - Public    (R) - Private    (N) - NAT
|              (S) - Static    (E) - Resource   (O) - One-to-One NAT
|              (M) - Many-to-One NAT
|
|+----State:   (G) - Good      (D) - Pending Delete   (R)-Resizing
||             (I) - Inactive
||
||++--Priority: 0..10 (Highest (0) .. Lowest (10))
||||
||||+-Busyout: (B) - Busyout configured
|||||
|||||
```

```
vvvvv Pool Name               Start Address   Mask/End Address Used    Avail
----- ----------------------- --------------- ---------------  ----------------
MG00  NAT5                    112.79.35.0     255.255.255.0    0         254
MG00  NAT4                    112.79.39.0     255.255.255.0    0         254
MG00  NAT3                    112.79.38.0     255.255.255.0    0         254
MG00  NAT2                    112.79.37.0     255.255.255.0    0         254
MG00  NAT1                    112.79.36.0     255.255.255.0    0         254
PG00  user                     10.10.20.0      255.255.255.240  0         14
```

Resolution:

Increased the size of the IP Pool in the IP POOL group. This resolved the issue

```
 Config Before the issue:
 config
   context gi
     ip pool NAT1 112.79.36.0 255.255.255.0 napt-users-per-ip-address 1500 group-name
NAT_PUBLIC on-demand max-chunks-per-user 10 port-chunk-size 32
     ip pool NAT2 112.79.37.0 255.255.255.0 napt-users-per-ip-address 1500 group-name
NAT_PUBLIC on-demand max-chunks-per-user 10 port-chunk-size 32
     ip pool NAT3 112.79.38.0 255.255.255.0 napt-users-per-ip-address 1500 group-name
NAT_PUBLIC on-demand max-chunks-per-user 10 port-chunk-size 32
     ip pool NAT4 112.79.39.0 255.255.255.0 napt-users-per-ip-address 1500 group-name
NAT_PUBLIC on-demand max-chunks-per-user 10 port-chunk-size 32
     ip pool NAT5 112.79.35.0 255.255.255.0 napt-users-per-ip-address 1500 group-name
NAT_PUBLIC on-demand max-chunks-per-user 10 port-chunk-size 32
     ip pool user 10.10.20.0 255.255.255.240 public 0 group-name tmo_poolgroup address-hold-
timer 120

 After the config
     ip pool NAT1 112.79.36.0 255.255.255.0 napt-users-per-ip-address 1500 group-name
NAT_PUBLIC on-demand max-chunks-per-user 10 port-chunk-size 32
     ip pool NAT2 112.79.37.0 255.255.255.0 napt-users-per-ip-address 1500 group-name
NAT_PUBLIC on-demand max-chunks-per-user 10 port-chunk-size 32
     ip pool NAT3 112.79.38.0 255.255.255.0 napt-users-per-ip-address 1500 group-name
```

```
NAT_PUBLIC on-demand max-chunks-per-user 10 port-chunk-size 32
     ip pool NAT4 112.79.39.0 255.255.255.0 napt-users-per-ip-address 1500 group-name
NAT_PUBLIC on-demand max-chunks-per-user 10 port-chunk-size 32
     ip pool NAT5 112.79.35.0 255.255.255.0 napt-users-per-ip-address 1500 group-name
NAT_PUBLIC on-demand max-chunks-per-user 10 port-chunk-size 32
     ip pool user 10.10.20.0 255.255.255.240 public 0 group-name user_poolgroup address-hold-
timer 120
     ip pool user1 10.10.30.0 255.255.255.240 public 0 group-name user_poolgroup address-hold-
timer 120 >>>Newly added pool
     ipv6 pool tmo1 prefix 2600:100c:100::/56 public 0 group-name tmo_poolgroup
```

GGSN Rejecting the PDP with No Resources

Problem Observed:

Subscriber cannot establish PDP session.

Logs Collection:

Collect multiple SSD

Collect external PCAP

Collect sample "monitor subscriber" at verbosity 2 showing the error behavior

Collect syslog

CLI used to troubleshoot the issue:

- show gtpc statistics verbose
- show session disconnect-reasons
- monitor subscriber imsi [value]
- show task resources | grep -v good
- show diameter peers full all | grep -i state
- show port datalink counters
- show snmp traps history verbose

Troubleshooting steps:

Verify the configuration for the APN.


Verify all the necessary interfaces associated for the APN are working.

Verify if any interfaces or ports are down using SNMP traps or show outstanding alarm outputs.

Verify any packet drops observed in the network or in the GGSN using NPU commands. **[Refer HW troubleshooting section.]**

Verify latency in the network between GGSN and Other connected network elements.

Image - GGSN No Resources



Statistsics:

Analysis:

1. The GGSN is receiving the CPC request from the SGSN and GGSN is not sending CPC to SGSN. Within the GGSN system it was found that an internal task, sessmgr, was not started, hence calls were not handled in GGSN.

```
show gtpc statsistics
Create PDP Context Denied:
  No Resources:                  220   No Memory:                      0
  All Dyn Addr Occupied:           0   User Auth Failed:               0
  Unknown/Missing APN:             0   System Failure:                 0
      Incompatibility:              0

Create PDP Denied - No Resource Reasons:
  PLMN Policy Reject:              0   New Call Policy Reject:         0
  APN/Svc Capacity:                0   Input-Q Exceeded:               0
  No Session Manager:            198   Session Manager Dead:           0
  Secondary For PPP:               0   Other Reasons:                  0
  Session Mgr Retried:             0   Session Mgr Not Ready:          0
```

```
[local]SPGW-1# sho task resources | grep -i sessmgr
 1/0 sessmgr          1    -- 100%     -- 700.0M   --  500     0 15000 I  start
 1/0 sessmgr       5006 0.5%  50% 63.31M 80.00M   28  500    --    -- S   good
```

Note : The below is an SGSN side trace since GGSN sessmgr was not ready. Call is not reaching the sessmgr on GGSN.

```
<<<<OUTBOUND  13:27:03:017 Eventid:116004(3)
GTPC Tx PDU, from 192.168.4.160:19002 to 192.168.5.52:3386 (76)
GTP HEADER FOLLOWS:
             Version number: 0
              Protocol type: 1  (GTP C/U)
           SNDCP N-PDU flag: 0
              Message Type: 0x10 (GTP_CREATE_PDP_CONTEXT_REQ_MSG)
            Message Length: 0x0038 (56)
           Sequence Number: 0x0917 (2327)
               Flow Label : 0x0000 (0)
         SNDCP N-PDU Number: 0xFF   (255)
                       TID : 2143658709214355
GTP HEADER ENDS.

<<<<OUTBOUND  13:27:07:947 Eventid:116004(3)
```

```
GTPC Tx PDU, from 192.168.4.160:19002 to 192.168.5.52:3386 (76)
GTP HEADER FOLLOWS:
             Version number: 0
              Protocol type: 1  (GTP C/U)
           SNDCP N-PDU flag: 0
              Message Type: 0x10 (GTP_CREATE_PDP_CONTEXT_REQ_MSG)
             Message Length: 0x0038 (56)
            Sequence Number: 0x0917 (2327)
                Flow Label : 0x0000 (0)
         SNDCP N-PDU Number: 0xFF   (255)
                       TID : 2143658709214355
GTP HEADER ENDS.

 <<<<OUTBOUND  13:27:12:975 Eventid:116004(3)
GTPC Tx PDU, from 192.168.4.160:19002 to 192.168.5.52:3386 (76)
GTP HEADER FOLLOWS:
             Version number: 0
              Protocol type: 1  (GTP C/U)
           SNDCP N-PDU flag: 0
              Message Type: 0x10 (GTP_CREATE_PDP_CONTEXT_REQ_MSG)
             Message Length: 0x0038 (56)
            Sequence Number: 0x0917 (2327)
                Flow Label : 0x0000 (0)
         SNDCP N-PDU Number: 0xFF   (255)
                       TID : 2143658709214355
GTP HEADER ENDS.

<<<<OUTBOUND  13:27:18:004 Eventid:88113(0)

===>GPRS Mobility/Session Management Message (3 Bytes)
Protocol Discriminator : SM message
1... .... : TI Flag : (1) allocated by receiver
.101 .... : TIO : (5)
.... 1010 : Protocol Discriminator : (10)
Message Type: 0x43 (67)
Message : Activate PDP Reject
  SM Cause : (31) Activation rejected, unspecified
```

Resolution:

Issue was resolved after sessmgr task in the GGSN was restarted.

task kill facility sessmgr instance <instance number>

> Above CLI command requires CLI test-commands password configured in the chassis.
>
> Please use the command with caution! Many **TEST** commands are processor-intensive and can cause serious system problems if used too frequently. Prior to doing " task kill" it is always recommended to perform " task core" on same instance in order to be able to complete root cause analysis.

LTE

LTE


Overview

This chapter covers LTE architecture, call flows and troubleshooting commands.

LTE/SAE architecture

The below diagram displays the LTE/SAE architecture, with all the involved elements and interfaces. It also covers the interfaces towards UMTS (2g/3g) networks. This diagram is referenced later in this chapter.

Image: LTE architecture




In the sections below the focus will be on the following functionalities:

- MME: Mobility Management Entity
- SGW: Serving Gateway
- PGW: Packet Gateway

Basic LTE procedures

The following figure and the text that follows describe the message flow for a successful user-initiated subscriber attach procedure. For more information, please refer to official Cisco ASR 5000 MME/SGW/PGW Administration Guides.

Image: UE attach and activation



1. The UE initiates the Attach procedure by the transmission of an Attach Request (IMSI or old GUTI, last visited TAI (if available), UE Network Capability, PDN Address Allocation, Protocol Configuration Options, Attach Type) message together with an indication of the Selected Network to the EnodeB. IMSI is included if the UE does not have a valid GUTI available. If the UE has a valid GUTI, it is included.
2. The EnodeB derives the MME from the GUTI and from the indicated Selected Network. If that MME is not associated with the EnodeB, the EnodeB selects an MME using an “MME selection function”. The EnodeB forwards the Attach Request message to the new MME contained in a S1-MME control message (Initial UE message) together with the Selected Network and an indication of the E-UTRAN Area identity, a globally unique E-UTRAN ID of the cell from where it received the message to the new MME.
3. If the UE is unknown in the MME, the MME sends an Identity Request to the UE to request the IMSI.
4. The UE responds with Identity Response (IMSI).
5. If no UE context for the UE exists anywhere in the network, authentication is mandatory. Otherwise this step is optional. However, at least integrity checking is started and the ME Identity is retrieved from the UE at Initial Attach. The authentication functions, if performed at this step, involve AKA authentication and establishment of a NAS level security association with the UE in order to protect further NAS protocol messages.
6. The MME sends an Update Location Request (MME Identity, IMSI, ME Identity) to the HSS.
7. The HSS acknowledges the Update Location message by sending an Update Location Ack to the MME. This message also contains the Insert Subscriber Data (IMSI, Subscription Data) Request. The Subscription Data contains the list of all APNs that the UE is permitted to access, an indication about which of those APNs is the Default APN, and the 'EPS subscribed QoS profile' for each permitted APN. If the Update Location is rejected by the HSS, the MME rejects the Attach Request from the UE with an appropriate cause.
8. The MME selects an S-GW using “Serving GW selection function” and allocates an EPS Bearer Identity for the Default Bearer associated with the UE. If the PDN subscription context contains no P-GW address the MME selects a P-GW as described in clause “PDN GW selection function”. Then it sends a Create Default Bearer Request (IMSI, MME Context ID, APN, RAT type, Default Bearer QoS, PDN Address Allocation, AMBR,

EPS Bearer Identity, Protocol Configuration Options, ME Identity, User Location Information) message to the selected S-GW.

9 The S-GW creates a new entry in its EPS Bearer table and sends a Create Default Bearer Request (IMSI, APN, S-GW Address for the user plane, S-GW TEID of the user plane, S-GW TEID of the control plane, RAT type, Default Bearer QoS, PDN Address Allocation, AMBR, EPS Bearer Identity, Protocol Configuration Options, ME Identity, User Location Information) message to the P-GW.

10 If dynamic PCC is deployed, the P-GW interacts with the PCRF to get the default PCC rules for the UE. The IMSI, UE IP address, User Location Information, RAT type, AMBR are provided to the PCRF by the P-GW if received by the previous message.

11 The P-GW returns a Create Default Bearer Response (P-GW Address for the user plane, P-GW TEID of the user plane, PGW TEID of the control plane, PDN Address Information, EPS Bearer Identity, Protocol Configuration Options) message to the S-GW. PDN Address Information is included if the P-GW allocated a PDN address Based on PDN Address Allocation received in the Create Default Bearer Request. PDN Address Information contains an IPv4 address for IPv4 and/or an IPv6 prefix and an Interface Identifier for IPv6. The P-GW takes into account the UE IP version capability indicated in the PDN Address Allocation and the policies of operator when the P-GW allocates the PDN Address Information. Whether the IP address is negotiated by the UE after completion of the Attach procedure, this is indicated in the Create Default Bearer Response.

12 The Downlink (DL) Data can start flowing towards S-GW. The S-GW buffers the data.

13 The S-GW returns a Create Default Bearer Response (PDN Address Information, S-GW address for User Plane, S-GW TEID for User Plane, S-GW Context ID, EPS Bearer Identity, Protocol Configuration Options) message to the new MME. PDN Address Information is included if it was provided by the P-GW.

14 The new MME sends an Attach Accept (APN, GUTI, PDN Address Information, TAI List, EPS Bearer Identity, Session Management Configuration IE, Protocol Configuration Options) message to the EnodeB.

15 The EnodeB sends Radio Bearer Establishment Request including the EPS Radio Bearer Identity to the UE. The Attach Accept message is also sent along to the UE.

16 The UE sends the Radio Bearer Establishment Response to the EnodeB. In this message, the Attach Complete message (EPS Bearer Identity) is included.

17 The EnodeB forwards the Attach Complete (EPS Bearer Identity) message to the MME.

18 The Attach is complete and UE sends data over the default bearer. At this time the UE can send uplink packets towards the EnodeB which are then tunnelled to the S-GW and P-GW.

19 The MME sends an Update Bearer Request (EnodeB address, EnodeB TEID) message to the S-GW.

20 The S-GW acknowledges by sending Update Bearer Response (EPS Bearer Identity) message to the MME.

21 The S-GW sends its buffered downlink packets.


22 After the MME receives Update Bearer Response (EPS Bearer Identity) message, if an EPS bearer is established and the subscription data indicates that the user is allowed to perform handover to non-3GPP accesses, and if the MME selected a P-GW that is different from the P-GW address which was indicated by the HSS in the PDN subscription context, the MME sends an Update Location Request including the APN and P-GW address to the HSS for mobility with non-3GPP accesses

23 The HSS stores the APN and P-GW address pair and sends an Update Location Response to the MME

24 Bidirectional data is passed between the UE and PDN

The following figure and the text that follows describe the message flow for a user-initiated subscriber de-registration procedure. For more information, please refer to the official Cisco ASR 5000 MME/SGW/PGW Administration Guides.

Image: UE detach



1. The UE sends NAS message Detach Request (GUTI, Switch Off) to the MME. Switch Off indicates whether detach is due to a switch off situation or not.
2. The active EPS Bearers in the S-GW regarding this particular UE are deactivated by the MME sending a Delete Bearer Request (TEID) message to the S-GW.
3. The S-GW sends a Delete Bearer Request (TEID) message to the P-GW
4. The P-GW acknowledges with a Delete Bearer Response (TEID) message.
5. The P-GW may interact with the PCRF to indicate to the PCRF that EPS Bearer is released if PCRF is applied in the network.
6. The S-GW acknowledges with a Delete Bearer Response (TEID) message.
7. If Switch Off indicates that the detach is not due to a switch off situation, the MME sends a Detach Accept message to the UE.
8. The MME releases the S1-MME signalling connection for the UE by sending an S1 Release command to the EnodeB with Cause = Detach.

MME Overview

MME functionality in ASR 5000/ASR 5500 is realized in the MME-service entity. The following StarOS software processes are important:

MMEmgr: The MME Mgr tasks will be started when a MME service configuration is detected. There will be multiple instances of this task for load sharing. All MME Mgrs will have all the Active MME Services configured and will be identical in configuration and capabilities. This task will run the SCTP protocol stack. It will also handle SGSAP protocol towards MSC/VLR and some of the S1AP functionality towards EnodeB.

MMEdemux: Since there are multiple MMEmgr tasks, its the responsibility of the MMEdemux process to distribute across different MMEmgr processes.

Imsimgr: The IMSIMgr is the de-multiplexing process that selects the SessMgr instance to host a new session based on a demux algorithm logic to host a new session by handling new calls requests from the MMEMgr, the EGTPC Mgr. The new call requests or signalling procedures include Attach, Inter-MME TAU, PS Handover, and SGs, all of which go through the IMSIMgr. The IMSIMgr process also maintains the mapping of the UE identifier (e.g., IMSI/GUTI) to the SessMgr instance.

Diamproxy: MME has connection to the HSS which is run over diameter. Diamproxy process is the process responsible for maintaining the Diameter connection to the HSS.

Sessmgr: The sessmgr process is responsible for subscriber session handling. It will also establish an (internal only) diameter connection to the Diameter proxy process.

SGW Overview

The Serving Gateway routes and forwards data packets from the UE and acts as the mobility anchor during inter-EnodeB handovers. The MME selects the best SGW for a particular UE.

The following StarOS software processes are important on SGW:

egtpinmgr: Handles EGTP control plane inbound over S11 (from MME) interface.

egtpegmgr: Handles EGTP control plane outbound over S5/S8 interface

sessmgr: Subscriber specific processing.

gtpumgr: Handles GTP-U data plane traffic over S1U and S5/S8 interface

PGW Overview

The PGW is not only a node in the network path of a call setup, it is the endpoint of the call and it has the intelligence built in to do deep packet inspection (ECS), policy control (Gx), charging control (Gy), and billing (Rf), and possibly QoS. In addition, it requires three services for call control (EGTP, PGW) and user plane (GTU). The one easy part is that since it is the endpoint of the call, there is no egress call control to be concerned about, as there would be for SGW and MME which will have both ingress and egress.

The following StarOS software processes are important on PGW:

egtpinmgr: Handles EGTP control plane inbound over the S5/S8 interface and acts as demux to pass call requests to sessmgrs

sessmgr: Subscriber specific processing.

diamproxy: PGW has connections to various servers (Gx/Gy) over the Diameter protocol. Diamproxy process is the process responsible for maintaining the Diameter connection to these servers

aaamgr: Performs all AAA protocol operations and functions for subscribers

vpnmgr: Performs IP address pool and subscriber IP address management, and also context specific operations

Quick Command Reference

For more information about each command, refer to the specific troubleshooting session or the CLI Document Guide.
Always collect multiple SSDs for analysis when troubleshooting any issue.

MME Commands

> Some of the CLI commands below require CLI test-commands password configured in the chassis.
> Please use the commands with caution! Many **TEST** commands are processor-intensive and can cause serious system problems if used too frequently.

- show mme-service all
- show mme-service db statistics
- show mme-service statistics debug
- show session subsystem facility sessmgr all debug-info
- show mme-service session full <imsi/imei/msisdn>
- show mme-service db record <imsi/all/call-id>
- show mme-service enodeb-association full all
- show mme-service enodeb-association summary all
- show hss-peer-service service all
- show diameter peers full all
- show hss-peer-service statistics all
- show sgs-service all
- show sgs-service vlr-status
- show sgs-service vlr-status full
- show sgs-service statistics all
- show subscribers mme-only full
- show subscribers full imsi

monitor protocol
monitor subscriber
logging filter active facility mme-app level info

SGW Commands

> Some of the CLI commands below require CLI test-commands password configured in the chassis.
> Please use the commands with caution! Many **TEST** commands are processor-intensive and can cause serious system problems if used too frequently.

- show egtp-service all
- show gtpu-service all
- show sgw-service name <sgw_service_name>
- show sgw-service statistics all verbose

- show sgw-service statistics name <sgw_service_name>
- show egtp-service name <egtp_ingress_service_name>
- show egtpc statistics path-failure-reasons
- show egtpc statistics summary
- show egtp-service name <egtp_egress_service_name>
- show egtpc statistics egtp-service <egtp_service_name>
- show gtpu-service name <S1U_GTPU_service_name>
- monitor protocol
- monitor subscriber
- logging filter active facility sgw level info

PGW Commands

> Some of the CLI commands below require CLI test-commands password configured in the chassis.
> Please use the commands with caution! Many **TEST** commands are processor-intensive and can cause serious system problems if used too frequently.

- show egtpc-service all
- show pgw-service all
- show gtpu-service all
- show egtpc statistics
- show session disconnect-reasons
- show pgw-service statistics all verbose
- show sub full
- show sub pgw-only full
- show active-charging sessions full
- show apn statistics name <APN> query-type AAAA
- show dns-client cache client <DNS client name> query-type AAAA
- dns-client query client-name PGW-DNS query-type AAAA query-name <FQDN>
- show egtpc peers [egtp-service <service>]
- egtpc test echo gtp-version 2 src-address <service address> peer-address <peer address>

- show egtpc statistics [[[(sgw-address | pgw-address | mme-address) <address>] [demux-only]] [debug-only] [verbose] | [path-failure-reasons]
- show gtpu statistics [peer-address <peer>]
- show gtpc statistics [ggsn-service <service>] [smgr-instance <instance>]
- show demux-mgr statistics <egtpinmgr | egtpegmgr | gtpumgr> all (SGW-egress | GGSN/ PGW,/SGW ingress | GTPU)
- show egtpc statistics interface mme
- show egtpc statistics interface sgw-ingress
- show egtpc statistics interface sgw-egress
- show egtpc statistics interface pgw-ingress
- show egtpc stat path-failure-reasons
- monitor protocol
- monitor subscriber
- logging filter active facility pgw level info

Troubleshooting MME

Overview

This section focuses on MME troubleshooting techniques along with examples in ASR 5000/ASR 5500.

Basic Troubleshooting

NOTE: Always capture multiple "show support detail" instances for analysis as required.

- **show mme-service all** Check the status (should be "STARTED")

```
Service name                    : TEST-MME
Context                         : mme
Status                          : STARTED
Bind                            : Done
S1-MME IP Address               : 10.10.10.10
                                  10.10.20.0
```

- **show mme-service db statistics** Provides MME database statistics for all instances of DB, check "DB record limit reached".

Please refer to official MME Administration Guide, StarOS with corresponding software release on Cisco.com website for further details on the checks and general troubleshooting commands.

> The CLI commands below require CLI test-commands password configured in the chassis.
> Please use the command with caution! Many **TEST** commands are processor-intensive and can cause serious system problems if used too frequently.

- **show mme-service statistics debug**

This command is extremely useful for various statistics around the MME service. Including SCTP, S1AP, network procedures, handovers, etc

- **show demux-mgr statistics imsimgr full**

This is the command to audit the imsimgr process. It contains various statistics about how many new requests were coming in for various procedures, and if a sessmgr was found to handle this request, as well as MME Overload Protection and a few tables that show distribution per sessmgr.

SCTP Statistics and S1AP Statistics, transmitted, received, re-transmitted data per MMEmgr instance.

- **show mme-service session full <imsi/imei/msisdn>** - provides several details about a subscriber session.
- **show mme-service db record <imsi/all/call-id>** - provides subscriber MME database records.

Troubleshooting S1-AP interface

S1 Application Protocol (S1-AP) uses the Stream Control Transmission Protocol (SCTP) as the transport layer protocol for guaranteed delivery of signalling messages (S1AP and NAS) between MME and EnodeB. The following CLIs provide information on the status of S1-AP links between MME and EnodeB.

- **show mme-service EnodeB-association full all** - Detailed EnodeB-related info shows MME service name, MME IP addresses and EnodeB addresses for S1-AP interface.

```
MMEMgr                 : Instance
  Peerid                 : 16900006
  Global EnodeB ID       : 17000:208:01
  Assoc UpTime           : 00h03m33s
  EnodeB Name            :
  EnodeB Type            : Macro
  MME Service Name       : mme
  MME Service Address(s) : 172.16.1.1
                           172.16.2.1
  MME Service Port       : 36412
  EnodeB Port            : 36412
  EnodeB IP Address      : 172.16.3.1
    Crypto-map Name(s)   : n/a
  Paging DRX             : 0(v32)
  Supported TAI(s)       : 600:20001
```

```
  CSG ID(s)              : n/a
  S1 Paging Rate Limit   : n/a
  Path Source IP Address      : 172.16.1.1
  Path Destination IP Address : 172.16.3.1
  Path State                  : Active
  Flow Id                     : 0x1b9a063
   Path Source IP Address      : 172.16.2.1
  Path Destination IP Address : 172.16.3.1
  Path State                  : Active
Flow Id                     : 0x1b9a064a
```

- **show mme-service EnodeB-association summary all** – show summary of EnodeBs, IPs, Ports for S1-AP interface.
- Check snmp trap for affected EnodeB - MMES1PathFail and MMES1AssocFail. The MMES1AssocEstab trap indicates when the S1 links goes up. Confirm IP connectivity to the EnodeB. Collect pcap files for affected EnodeB if applicable.
- Additional logging may be required and is described below.

Troubleshooting S6a

This is the interface used by the MME to communicate with the Home Subscriber Server (HSS). The HSS is responsible for transfer of subscription and authentication data for authenticating/authorizing user access and UE context authentication. The MME communicates with the HSSs on the PLMN using Diameter protocol.

- **show hss-peer-service service all** - check the status (should be "STARTED")

```
Service name                    : hss-s6a
Context                         : hss
Status                          : STARTED
Diameter hss-endpoint           : s6a-endpoint-mme
Diameter eir-endpoint           : n/a
Diameter hss-dictionary         : Standard
Diameter eir-dictionary         : Standard
```

- **show diameter peers full all** - Run command in corresponding context. Check that Diameter sessions are in "OPEN" state. Please refer to the Diameter chapter for details.

- **show hss-peer-service statistics all** - Run command in corresponding context. Monitor failovers and Message Error stats.
- Check SNMP traps for HSS reset – SGSNHLRReset – investigate the reset on HSS side.
- Confirm IP connectivity to the HSS.

NOTE: check the Diameter section for additional information.

Troubleshooting SGs

The SGs interface connects the databases in the VLR and the MME to support circuit switch fallback scenarios.

- **show sgs-service all** Check the status (should be "STARTED")

```
Service name      : sgs
Context           : mme
Status            : STARTED
Bind              : Done
IP Address        : 172.16.1.10  172.16.1.110
SCTP port         : 29118
Num VLRs          : 3
```

- **show sgs-service vlr-status** Check associated state (should be "UP")

```
MMEMGR               : Instance 1
 MME Reset            : No
Service ID           : 6
Peer ID              : 17171000
VLR Name             : AB01.MNC01.MCC001.3GPPNETWORK.ORG
SGS Service Name     : sgs
VLR Offload          : No
SGS Service Address  : 172.17.1.25 172.20.70.26
SGS Service Port     : 29118
VLR IP Address       : 172.18.1.161 172.18.1.169
 VLR Port             : 29118
Assoc State          : UP
Assoc Uptime         : 0021d20h20m
Assoc State Up Count : 1
```

```
Assoc Path State
 172.20.72.161 172.20.70.25 UP 0x1b986db
 172.20.72.161 172.20.70.26 UP 0x1b986dc
 172.20.72.169 172.20.70.25 UP 0x1b986dd
 172.20.72.169 172.20.70.26 UP 0x1b986de
```

- **show sgs-service vlr-status full** Provides additional info on VLR status.
- **show sgs-service statistics all** Provides SCTP Statistics, search for Errors, Aborts, etc
- Check VLR reset in snmp traps - VLRAssocDown and VLRDown. The trap VLRUp indicates when the VLR links comes back UP.

Troubleshooting a subscriber connecting to MME

- **monitor subscriber** Collect and analyze a subscriber MME call with monitor subscriber from the beginning of a call till an issue with verbosity 3, options S and Y.
- **show subscribers mme-only full** Provides information on a MME subscriber session .
- **show subscribers full imsi** Provides subscriber session information.
- **monitor protocol** Select option 70 and verbosity 3 to collect DNS queries during the monitor subscriber test call. Note: Running monitor protocol may impact system performance when many subscribers are connected.
- various debugs can be activated to find issues on MME side. Activating unusual level debugs is not posing a risk to the stability of the node. Sometimes however its necessary to use debug levels of logging; increasing the debug level has to be done with caution.

  logging filter active facility mme-app level unusual
  logging filter active facility nas level unusual
  logging filter active facility s1ap level unusual
  logging filter active facility egtpc level unusual
  logging active

Troubleshooting of SPGW Selection by MME

One of the main tasks of MME is to select the SGW and PGW which will handle the subscriber session. This is usually done through DNS. Typically SGW is selected through TAC-based DNS (NAPTR) query, and PGW is selected through APN-based DNS (NAPTR) query.

Exploring all the various options on how to set this up would be outside the scope of this troubleshooting guide, but a few tips on how to troubleshoot this.

- First a manual DNS request can be issued from the MME on the correct context:

  example: TAC-based DNS query issued from MME:

```
 [gn]MME# dns-client query client-name DNS_CLIENT_NAME query-type NAPTR query-name  tac-
lbD7.tac-hb00.tac.epc.mnc001.mcc002.3gppnetwork.org

 Query Name: tac-lbd7.tac-hb00.tac.epc.mnc001.mcc002.3gppnetwork.org
 Query Type: NAPTR      TTL: 187 seconds
 Answer:
   Order: 10             Preference: 65136
   Flags: s              Service: x-3gpp-sgw:x-s5-gtp
   Regular Expression:
   Replacement: gtp.sgw-group.right.nodes.epc.mnc001.mcc002.3gppnetwork.org
```

  example: APN-based DNS query issued from MME:

```
 [gn]MME# dns-client query client-name DNS_CLIENT_NAME query-type NAPTR query-name
lte.rtc.apn.epc.mnc001.mcc002.3gppnetwork.org

 Query Name: lte.rtc.apn.epc.mnc003.mcc268.3gppnetwork.org
 Query Type: NAPTR      TTL: 300 seconds
 Answer:
   Order: 20             Preference: 65436
   Flags: s              Service: x-3gpp-pgw:x-s5-gtp:x-s8-gtp
   Regular Expression:
   Replacement: gtp.pgw-group.left.nodes.epc.mnc001.mcc002.3gppnetwork.org
```

- The following logs can be enabled on MME to find which SGW/PGW are actually selected by MME:

  # logging filter active facility mme-app level info.
  # logging active

After the collection of logs, disable logging with the following command:

no logging active

This shows selection of SGW and PGW for the duration of the log collection. Example:

```
 2015-Feb-06+09:10:53.347 [mme-app 147084 info] [7/0/12444 <sessmgr:167> mme_msg_utils.c:7847]
[callid 31977355] [context: mme_ingress, contextID: 9]  [software internal user syslog]  PGW
FQDN: topon.s5.spgw01.F.epc.mnc001.mcc001.3gppnetwork.org 2015-Feb-06+09:10:53.347 [mme-app
147084 info] [7/0/12444 <sessmgr:167> mme_msg_utils.c:6056] [callid 31977355]  [context:
mme_ingress, contextID: 9]  [software internal user syslog]  SGW FQDN:
topon.s11.spgw01.F.epc.mnc001.mcc001.3gppnetwork.org
```

For more verbose logs, the logging level can be increased to level trace, but use this with caution on a production node. Note that in below example, the PGW is selected first, after which the colocated SGW is chosen. This logic depends on configuration.

```
 2015-Feb-18+09:48:57.423 [mme-app 147070 info] [1/0/4413 <sessmgr:6> _connect_proc.c:1473]
[callid 017de361]  [context: EPC, contextID: 2]  [software internal user syslog] imsi
123456001000000, DNS NAPTR query with FQDN  ipv4.com.apn.epc.mnc456.mcc123.3gppnetwork.org and
service parameter x-3gpp-pgw:x-s5-gtp

 2015-Feb-18+09:48:57.448 [mme-app 147070 info] [1/0/4413 <sessmgr:6> _connect_proc.c:4258]
[callid 017de361]  [context: EPC, contextID: 2]  [software internal user syslog] imsi
123456001000000, DNS NAPTR query with FQDN  tac-lb29.tac-
hb09.tac.epc.mnc456.mcc123.3gppnetwork.org and service parameter x-3gpp-sgw:x-s5-gtp

 2015-Feb-18+09:48:57.550 [mme-app 147084 info] [1/0/4413 <sessmgr:6> mme_msg_utils.c:6226]
[callid 017de361]  [context: EPC, contextID: 2]  [software internal user syslog] PGW FQDN:
topon.s5.spgw01.1.epc.mnc456.mcc123.3gppnetwork.org

 2015-Feb-18+09:48:57.550 [mme-app 147084 info] [1/0/4413 <sessmgr:6> mme_msg_utils.c:6407]
[callid 017de361]  [context: EPC, contextID: 2]  [software internal user syslog] SGW FQDN:
topon.s11.spgw01.1.epc.mnc456.mcc123.3gppnetwork.org
 2015-Feb-18+09:48:57.550 [mme-app 147075 trace] [1/0/4413 <sessmgr:6> _connect_proc.c:4440]
[callid 017de361]  [context: EPC, contextID: 2]  [software external user protocol-log syslog]
imsi 123456001000000,  Selected PGW: 10.1.10.1 with S5-S8 Protocol type GTP
topon.s5.spgw01.1.epc.mnc456.mcc123.3gppnetwork.org
```

```
 2015-Feb-18+09:48:57.550 [mme-app 147076 trace] [1/0/4413 <sessmgr:6> _connect_proc.c:4444]
[callid 017de361]  [context: EPC, contextID: 2]  [software external user protocol-log syslog]
imsi 123456001000000,  New SGW selected: 10.1.17.1
topon.s11.spgw01.1.epc.mnc456.mcc123.3gppnetwork.org
```

Example Scenarios

CSFB Failure

Problem Description:

It was noted that CSFB doesn't work on phones connected to 4G intermittently. The caller gets a busy tone, and the called party doesn't receive the call.

CSFB is triggered, MME communicates with EnodeB and MSC to get subscriber on 2g/3g to receive the phone call via traditional CS network.

Logs collection:

- Collect 2 “show support detail”
- Collect monitor subscriber verbosity 5 for the subscriber, while the CSFB procedure was initiated from MSC side towards MME.
- Collect external packet capture on the relevant interfaces (S1AP, and Sgs).

Analysis:

Below is analysis of the monitor subscriber with notes and snippet of the trace. MME is behaving as expected. Please note that the CSFB specification can be found in 3GPP TS 23.272.

Inbound paging from SGS

```
INBOUND>>>>> 16:10:13:369 Eventid:173001(3)
 SGS Rx PDU, from 10.20.20.2:29118 to 10.20.30.2:29118 (68)
```

Outbound CS service notification to UE

```
<<<<OUTBOUND 16:10:13:370 Eventid:153002(3)
 NAS Tx PDU, from 10.20.40.2:36412 to 10.20.50.2:36412 (9)
 Message Type
 CS SERVICE NOTIFICATION(0x64)
```

Outbound service request to SGs

```
<<<<OUTBOUND 16:10:13:370 Eventid:173002(3)
 SGS Tx PDU, from 10.20.30.2:29118 to 10.20.20.2:29118 (51)
```

Inbound CS service notification from UE

```
INBOUND>>>>> 16:10:13:423 Eventid:153001(3)
 NAS Rx PDU, from 10.20.50.2:36412 to 10.20.40.2:36412 (20)
 Message Type
 EXTENDED SERVICE REQUEST(0x4c)
```

UE context modification

```
<<<<OUTBOUND 16:10:13:423 Eventid:155213(3)
 S1AP Tx PDU, from 10.20.40.2:36412 to 10.20.50.2:36412 (28)
 Procedure Code : UE CONTEXT MODIFICATION (21)
```

```
INBOUND>>>>> 16:10:13:458 Eventid:155212(3)
 S1AP Rx PDU, from 10.20.50.2:36412 to 10.20.40.2:36412 (23)
 Procedure Code : UE CONTEXT MODIFICATION (21)
```

Context Release

```
INBOUND>>>>> 16:10:13:458 Eventid:155212(3)
 S1AP Rx PDU, from 10.20.50.2:36412 to 10.20.40.2:36412 (29)
 Procedure Code : CONTEXT RELEASE REQUEST (18)
```

MME releases bearers to SGW

```
<<<<OUTBOUND 16:10:13:461 Eventid:155213(3)
 S1AP Tx PDU, from 10.20.40.2:36412 to 10.20.50.2:36412 (25)
 Procedure Code : UE CONTEXT RELEASE (23)
```

```
INBOUND>>>>> 16:10:13:487 Eventid:155212(3)
 S1AP Rx PDU, from 10.20.50.2:36412 to 10.20.40.2:36412 (23)
 Procedure Code : UE CONTEXT RELEASE (23)
```

In a normal call scenario it is expected that the UE will move to 2G/3G, so it can receive the call, but no activity is seen for more than 10 seconds in the monitor subscriber.

Paging from 4G network because there is downlink data

```
<<<<OUTBOUND 16:10:21:806 Eventid:141005(3)
 [SGW-S11/S4]GTPv2C Tx PDU, from 10.30.10.2:31472 to 10.40.10.2:2123 (29)
 TEID: 0x8180A05A, Message type: EGTP_DOWNLINK_DATA_NOTIFICATION (0xB0)
```

11 seconds later there is an attach request from UE

```
INBOUND>>>>>  16:10:24:810 Eventid:88112(0)
 Message : Attach Request
```

Resolution:

No issues were found on MME side. The call was not established and a new Attach was received, possibly indicating that the UE was not under any coverage. More investigation needs to be done on MSC/VLR side of network.

S1AP Failures

Problem Description:

Flaps on S1AP interface towards EnodeB(s).

Logs collection:

SNMP shows this trap:

```
 Mon Dec 08 03:53:25 2014 Internal trap notification 1167 (MMES1AssocFail) MME S1 Association
failed;  vpn s1-mme service mme-service EnodeB 123:45:12345
 Mon Dec 08 03:53:46 2014 Internal trap notification 1168 (MMES1AssocEstab) MME S1 Association
established;  vpn s1-mme service mme-service EnodeB 123:45:12345
```

Analysis:

This problem requires:

- In depth analysis of all SNMP traps
- Analysis of syslog
- Possibly external traces
- Show task resource output

First step is to evaluate the scope of the problem:

1) Does it affect 1 or more EnodeB's? if so, an external capture might be required to evaluate what happens on lower layer (IP/SCTP layer/S1AP layer) towards this EnodeB.

2) If it affects more than 1 EnodeB, does it affect EnodeB's connected to the same set of MMEMGR processes? (This can be checked in syslog). If this is the case, it could indicate some kind of overload condition on a specific MMEMGR processs.

3) If it affects all MMEMGRs, does it also affect the EnodeB's association to other MME's (if there are any)? If this is the only MME affected, it could be some overload condition on this specific MME triggered by some event, or it could be a transport issue on the S1AP interface/network.

In case (2), check if there is improper balancing of EnodeB associations by checking the 'show task resource' output:

```
[local]MME# show task resources | grep mmemgr


               cputime      memory      files       sessions
cpu facility used allc used  alloc used allc used  allc status
-------------------------------- -------------------------
2/0 mmemgr 1 85% 95%  99.18M 400.0M 216 1000 736 8100 - good
2/0 mmemgr 2 82% 95%  95.00M 400.0M 215 1000 733 8100 - good
2/0 mmemgr 3 86% 95%  96.39M 400.0M 214 1000 766 8100 - good
2/0 mmemgr 4 60% 95%  77.34M 400.0M 214 1000 435 8100 - good
2/0 mmemgr 5 62% 95%  76.93M 400.0M 214 1000 435 8100 - good
2/0 mmemgr 6 55% 95%  75.03M 400.0M 215 1000 430 8100 - good
2/0 mmemgr 7 56% 95%  75.14M 400.0M 217 1000 429 8100 - good
2/0 mmemgr 8 51% 95%  76.01M 400.0M 214 1000 430 8100 - good
```

The number of sessions is higher on the first three mmemgr's. This may need to be investigated by Cisco TAC as this is not a normal condition.

In case (3), it might be worth to check if there was a specific event that could have caused a very high load on all MMEMGR processes. Examples of such events include:

-Large EGTP path failures (which will result in massive disconnection/reconnection/paging) : verify with logs.

-crash of MMEmgr process : verify with "show crash list".

Resolution:

Several different causes can trigger such traps, so a broad investigation with the steps above is required.

Troubleshooting SGW

Overview

This section focuses on SGW troubleshooting techniques in ASR 5000/ASR 5500.

Basic Troubleshooting

The folowing section covers the troubleshooting commands for the SGW.

 # show sgw-service name *<sgw_service_name>* : this command provides the status of the SGW service, and which EGTP services are linked to it and the contexts used for ingress and egress.

```
Service name                    : SGW-SVC
 Service-Id                     : 17
 Context                        : EPC  <-- ingress EGTP context
 Accounting context             : EPC
 Accounting gtpp group          : default
 Accounting mode                : Gtpp
 Accounting stop-trigger        : Default
 Status                         : STARTED
 Egress protocol                : gtp
 Ingress EGTP service           : S11-SGW
 Egress context                 : EPC  <-- egress EGTP context
 Egress EGTP service            : S5-S8-SGW
 Egress MAG service             : n/a
 IMS auth. service              : n/a
 Peer Map                       : n/a
 Accounting policy              : n/a
 Newcall policy                 : n/a
 QCI-QOS mapping table          : n/a
 Event Reporting                : Disabled
 ...
```

 # show sgw-service statistics all verbose : this will provide total number of subscribers, handover statistics, paging statistics, packet counters.

 # show sgw-service statistics name <*sgw_service_name*> : this command shows statistics related to the SGW service. It contains info about the different kind of subscribers, handover statistics, setup counts, paging statistics, etc.

```
Subscribers Total:
  Active:                          253    Setup:                          254
  Released:                          1
    Inactivity Timeout:              0

Current Subscribers By State:
  Idle:                            253    Active:                           0

Current Subscribers By RAT-Type:
  EUTRAN:                          253    UTRAN:                            0
  GERAN:                             0    OTHER:                            0

PDNs Total:
  Active:                          253    Setup:                          254
  Released:                          1    Rejected:                      4482
  LIPA:                              0    Paused Charging:                  0

Current PDNs By RAT-Type:
    EUTRAN:                        253    UTRAN:                            0
    GERAN:                           0    OTHER:                            0

PDNs By PDN-Type:
  IPv4 PDNs:
    Active:                        253    Setup:                          254
    Released:                        1    Rejected:                      4482
  IPv6 PDNs:
    Active:                          0    Setup:                            0
    Released:                        0
    Rejected:                        0

  IPv4v6 PDNs:
    Active:                          0    Setup:                            0
```

```
    Released:                       0
    Rejected:                       0
```

Troubleshooting S11

The S11 interface is the interface between MME and SGW. It's only used for control plane traffic, and the EGTP (GTPv2) protocol is used to communicate over this interface.

- **show egtp-service name *<egtp_ingress_service_name>* :** basic settings for the EGTP service between MME and SGW

```
 Service name : S5-S8-SGW
 Service-Id                             : 13
 Context                                : EPC
 Interface Type                         : sgw-ingress
 Status                                 : STARTED
 Restart Counter                        : 9
 Message Validation Mode                : Standard
 GTPU-Context                           : EPC
 GTPC Retransmission Timeout            : 5
 GTPC Maximum Request Retransmissions   : 4
 GTPC IP QOS DSCP value                 : 10
 GTPC Echo                              : Enabled
 GTPC Echo Mode                         : Default
 GTPC Echo Retransmission Timeout       : 5
 GTPC Echo Interval                     : 60
 GTP-C Bind IPv4 Address                : 10.1.10.1
 GTP-C Bind IPv6 Address                : Not configured
```

- **show egtpc statistics path-failure-reasons** : will provide counters and reasons for failures. Related SNMP traps: EGTPCPathFail

```
Reasons for path failure at EGTPC:
 Echo Request  restart counter change:                    0
 Echo Response restart counter change:                   0
 No Echo Response received:                                    0
 Control message restart counter change at   demux:     0
```

```
Control message restart counter change at sessmgr:      0
Total path failures detected:                              0
```

 # show egtpc statistics summary

```
Control Request Messages :
 Total   TX:                        120   Total   RX:                    33921
 Initial TX:                        120   Initial RX:                    33921
 Retrans TX:                          0   Retrans RX:                        0
                                          Discarded:                         0
                                          No Rsp  RX:                        0

Control Response Messages:
 Total   TX:                      33921   Total   RX:                      120
 Initial TX:                      33921   Initial RX:                      120
   Accepted:                      24936     Accepted:                      120
     Denied:                       8985       Denied:                        0
 Retrans TX:                          0    Discarded:                        0

Echo Request:
 Total   TX:                        420   Total   RX:                        0
 Initial TX:                        420   Initial RX:                        0
 Retrans TX:                          0

Echo Response:
 Total   TX:                          0   Total   RX:                      420
```

Troubleshooting S5/S8 interfaces

The S5 interface is the interface between SGW and PGW within the same PLMN. The S8 interface is the interface used for roaming between different operators. This interface uses EGTP for control plane, and GTP-U for user-data plane.

- **show egtp-service name <*egtp_egress_service_name*>**: basic settings for the EGTP service between SGW and PGW

```
  Service name : S5-S8-SGW
  Service-Id                          : 13
```

```
 Context                                : EPC
 Interface Type                         : sgw-egress
 Status                                 : STARTED
 Restart Counter                        : 9
 Message Validation Mode                : Standard
 GTPU-Context                           : EPC
 GTPC Retransmission Timeout            : 5
 GTPC Maximum Request Retransmissions   : 4
 GTPC IP QOS DSCP value                 : 10
 GTPC Echo                              : Enabled
 GTPC Echo Mode                         : Default
 GTPC Echo Retransmission Timeout       : 5
 GTPC Echo Interval                     : 60
 GTP-C Bind IPv4 Address                : 10.1.9.1
 GTP-C Bind IPv6 Address                : Not configured
```

 # show egtpc statistics path-failure-reasons (as mentioned in S11).

 # show egtpc statistics summary (as mentioned in S11)

 # show egtpc statistics egtp-service <*egtp_service_name*>: this command will display statistics about various types of EGTP control messages. Its extremely useful to detect retransmission/failures etc. Output will contain information similar to that in the sample below:

```
Tunnel Management Messages:
Create Session Request:
 Total   TX:                          0   Total   RX:                      21513
 Initial TX:                          0   Initial RX:                      21513
 Retrans TX:                          0   Retrans RX:                          0
                                           Discarded:                           0
                                          No Rsp  RX:                           0


Create Session Response:
 Total   TX:                      21513   Total   RX:                          0
 Initial TX:                      21513   Initial RX:                          0
   Accepted:                      12528     Accepted:                          0
     Denied:                       8985       Denied:                          0
 Retrans TX:                          0    Discarded:                          0
```

```
Modify Bearer Request:
 Total   TX:                          0   Total   RX:                          0
 Initial TX:                          0   Initial RX:                          0
 Retrans TX:                          0   Retrans RX:                          0
                                           Discarded:                           0
                                          No Rsp  RX:                           0
```

- related SNMP traps: EGTPCPathFail, EGTPUPathFail
- logging facility: egtpegmgr, gtpumgr

Troubleshooting S1-U interface

The S1-U interface is the interface between SGW and EnodeB. Its used for userplane traffic only and it uses GTPU protocol for encapsulating subscriber traffic.

 # show gtpu-service name <S1U_GTPU_*service_name*>

```
  Service name:              S1U-SGW
  Context:                   EPC
  State:                     Started
  Echo Interval:             Disabled
  Sequence number:           Disabled
  Include UDP Port Ext Hdr: FALSE
  Max-retransmissions:       4
  Retransmission Timeout:    5 (secs)
  IPSEC Tunnel Idle Timeout:60 (secs)
  Allow Error-Indication:    Disabled
  Address List:
                10.1.4.1
  GTPU UDP Checksum:  Enabled - Attempt Optimize Default Mode
  Path Failure Detection
  on gtp echo msgs:          Set
  Path Failure Clear Trap : non-echo
```

 # show gtpu statistics gtpu-service <name> : will indicate statistics related to the gtpu-service.

 # show gtpu statistics peer-address <ip-address> : will indicate the number of packets transmitted, received and droppped for a particular peer.

- related SNMP traps: EGTPUPathFail. Please refer to EGTP chapter.
- logging facility: gtpumgr

Troubleshooting a subscriber SGW call

- **monitor subscriber** Collect and analyze a subscriber SGW call with monitor subscriber from the beginning of a call until an issue with verbosity 2, options S and Y.
- **show subscribers sgw-only full imsi <imsi>** Provides information on a MME subscriber session information.
- **show subscribers full imsi <imsi>** Provides information on a subscriber session information.

Troubleshooting PGW

Overview

This section's focus is PGW troubleshooting techniques along with examples in ASR 5000/ASR 5500.

Troubleshooting service status:

PGW functionality in ASR 5000/ASR 5500 is implemented in the PGW and EGTP services. Verify the service status is 'STARTED' in the following commands.

- **show egtp-service all**

```
Service name                    : TEST-GTP
Context                         : PGW
Status                          : STARTED
GTP-C Bind IPv4 Address         : <ipv4>
GTP-C Bind IPv6 Address         : <ipv6>
```

- **show pgw-service all**

```
Service name                    : TEST-PGW
  Context                         : PGW
 Status                          : STARTED
 EGTP Service                    : TEST-GTP
```

- **show gtpu-service all**

```
Service name                    : TEST-GTPU
 Context                         : PGW
State                           : Started
Address List:
              <ipv4>                          all
  <ipv6>                        all
```

Troubleshooting S5/S8 interface

S5/S8 uses EGTP for the format of messages between SGW and PGW. See a separate EGTP Checkup section that covers troubleshooting issues common to SGW and MME nodes such as EGTP path failures.

- **show egtpc statistics** - This is the primary command for examining success/failure rate of all messaging over this interface, that includes the following:
  - Create Session Request/Response
  - Modify Bearer Request/Modify Bearer Response
  - Delete Session Request/Response
  - Create Bearer Request/Response
  - Update Bearer Request/Response
  - Delete Bearer Request/Response

For any of the above, calculate the respective success/failure rates by clearing stats and taking a second sampling. The EGTP Checkup section gives an example.

- **show session disconnect-reasons** - a specific subset of failures would only apply to PGW LTE:
  - s6b-auth-failed - new calls failed due to S6b
  - gtp-user-auth-failed - handoffs failed due to S6b
  - ims-authorization-failure - Gx failure
  - failed-with-auth-charging-svc - Gy failure
- **show pgw-service statistics all verbose**
  - Breaks down PDNs/sessions by various criteria like RAT-type, IPv vs. IPv6, PLMN type, QoS and user plane packet/byte counts
  - Inter-technology handover stats.
  - Rejection and Release stat
  - Cause Code 73 No resources (verbose option):

```
PDNs Rejected By Reason:
  No Resource:                          2    Missing or unknown APN:          452
   APN sel-Mode mismatch:               0    PDN-Type not supported:            0
   APN restr violation:                 0    Subs auth failed:             526652
   static addr not allow:               0    static addr not alloc:             0
```

```
 Dynamic addr not alloc:              9    static addr not present:           1
 Invalid QCI Value:                   0
PDNs Released By Reason:
Network initiated release:   246850448    MME initiated release:    1587587634
  Admin disconnect:            863271    S4 SGSN initiated release:         0
   GTP-U error ind:                65
  SGW path failure:             20699
  Local fallback timeout:           0
Create Sess Rsp Denied - No Resource Reasons:
New Call Policy Reject:              0   Num license exceeded:                0
 Session Manager Dead:               0   No Session Manager:                  0
 Session Mgr Not Ready:              0   Congestion Policy Applied:           0
 ICSR State Invalid:               109   Input pacing queue exceeded:         0
 Charging Svc Auth Fail:         178910   ims auth failed:                339802
 no session in aaa:                  0   aaa auth req exceeded/failed:      105
 Conflict in ip address:             0   static ip not present:               1
 other reasons:                  49195   ms req invalid ip:                   0
 Session Setup Timeout:             38   DHCP IP Address Not Present:         0
```

- **show subscriber full imsi <imsi>**
  - Idle time and session time left returned in S6b exchange is reflected here
- **show subscriber pgw-only full imsi <imsi>**
  - As opposed to "show sub full", this version contains information specific to PGW subscribers and should be collected for any subscriber impacting issue.

```
[local]SPGW-1# show subscribers pgw-only full imsi 123456789012598

Username: 123456789012598@cisco.com
  Subscriber Type : Home
  Status          : Online/Active
  State           : Connected
  Connect Time    : Thu May  7 16:06:29 2015

  Idle time       : 00h26m03s
  MS TimeZone     : +0:00               Daylight Saving Time: +0 hour

  Access Type: gtp-pdn-type-ipv4         Network Type: IP
  Access Tech: eUTRAN                    pgw-service-name: pgw-svc
```

```
   Callid: 00005021                        IMSI: 123456789012598
   Protocol Username:                      MSISDN:
   Interface Type: S5S8GTP
   Emergency Bearer Type: N/A
   IMS-media Bearer: No
   S6b Auth Status: N/A
   Access Peer Profile: default
   Acct-session-id (C1): C0A8053400000102
   ThreeGPP2-correlation-id (C2): 00049649 / 002wgOB7
   Card/Cpu: 1/0                           Sessmgr Instance: 1

   Bearer Type: Default                    Bearer-Id: 5
   Bearer State: Active
   IP allocation type: local pool
   IPv6 allocation type: N/A
   IP address: 10.10.20.1
   Framed Routes: N/A                                Framed Routes Source: N/A
   ULI:
    TAI-ID:
     MCC: 123  MNC: 456
     TAC: 0x4d2
    ECGI-ID:
     MCC: 123 MNC: 456
     ECI: 0x1
   Accounting mode: None                   APN Selection Mode: Subscribed
   MEI: n/a                                Serving Nw: MCC=123, MNC=456
   charging id: 258                           charging chars: flat
   Source context: spgw                    Destination context: gi
   S5/S8/S2b/S2a-APN: cisco.com
   SGi-APN:   cisco.com
   APN-OI:    mnc456.mcc123.gprs
   traffic flow template: none
   IMS Auth Service : gx
   active input ipv4 acl: wap.vodafone.com.eg-acl.in active output ipv4 acl:
wap.vodafone.com.eg-acl.out
   active input ipv6 acl:                  active output ipv6 acl:
   ECS Rulebase: cisco

   Bearer QoS:
```

```
 QCI: 8
 ARP: 0x06c
  PCI: 1 (Disabled)
  PL : 11
  PVI: 0 (Enabled)
 MBR Uplink(bps): 0                    MBR Downlink(bps): 0
 GBR Uplink(bps): 0                    GBR Downlink(bps): 0

PCRF Authorized Bearer QoS:
 QCI: n/a
 ARP: n/a
  PCI: n/a
  PL: n/a
  PVI: n/a
 MBR uplink (bps): n/a                      MBR downlink (bps): n/a
 GBR uplink (bps): n/a                      GBR downlink (bps): n/a
 Downlink APN AMBR: n/a                  Uplink APN AMBR: n/a

P-CSCF address :
Addresses received from s6b:
  Primary IPv6  :   n/a
  Secondary IPv6:   n/a
  Tertiary IPv6 :   n/a

 Addresses received from radius or that's been configured
  Primary IPv6  :   n/a
  Secondary IPv6:   n/a
  Tertiary IPv6 :   n/a
  Primary IPv4  :   n/a
  Secondary IPv4:   n/a
  Tertiary IPv4 :   n/a

Access Point MAC Address:  N/A

 pgw c-teid: [0x80400001] 2151677953    pgw u-teid: [0x80400001] 2151677953
 sgw c-teid: [0x801fa001] 2149556225    sgw u-teid: [0x801f8001] 2149548033
 ePDG c-teid: N/A                       ePDG u-teid: N/A
 cgw c-teid: N/A                        cgw u-teid: N/A
 pgw c-addr: 192.168.5.52               pgw u-addr: 192.168.5.52
```

```
sgw c-addr: 192.168.5.51                sgw u-addr: 192.168.5.49
ePDG c-addr: N/A                        ePDG u-addr: N/A
cgw c-addr: N/A                         cgw u-addr: N/A

Downlink APN AMBR:     150000 Kbps    Uplink APN AMBR:      60000 Kbps
Mediation context: None                 Mediation no early PDUs: Disabled
Mediation No Interims: Disabled         Mediation Delay PBA: Disabled
input pkts: 0                                   output pkts: 0
input bytes: 0                                  output bytes: 0
input bytes dropped: 0                          output bytes dropped: 0
input pkts dropped: 0                           output pkts dropped: 0
                                                output pkts dropped lorc: 0
input pkts dropped due to lorc    : 0           output pkts dropped due to lorc    : 0
input bytes dropped due to lorc   : 0
in packet dropped suspended state: 0            out packet dropped suspended state: 0
in bytes dropped suspended state: 0             out bytes dropped suspended state: 0
in packet dropped overcharge protection: 0      out packet dropped overcharge protection: 0
in bytes dropped overcharge protection: 0       out bytes dropped overcharge protection: 0
in packet dropped sgw restoration state: 0      out packet dropped sgw restoration state: 0
in bytes dropped sgw restoration state: 0       out bytes dropped sgw restoration state: 0
pk rate from user(bps): 0                       pk rate to user(bps): 0
ave rate from user(bps): 0                      ave rate to user(bps): 0
sust rate from user(bps): 0                     sust rate to user(bps): 0
pk rate from user(pps): 0                       pk rate to user(pps): 0
ave rate from user(pps): 0                      ave rate to user(pps): 0
sust rate from user(pps): 0                     sust rate to user(pps): 0
```

- **show active-charging sessions full**
  - Check if the dynamic rules returned in Gx exchange are reflected here
  - Check if the charging quota returned in Gy exchange is reflected here
- **show apn statistics name <APN>** - per APN, packet/byte [dropped] counts, dedicated/default bearer, active/setup/release/reject, uplink/downlink, ipv4 vs. ipv6, statistics broken down by QCI

- **show dns-client cache client <DNS client name> query-type AAAA** - ensure that all P-CSCF FQDNs that have been returned from diameter authentication requests have a corresponding AAAA address or else the call will fail

- **dns-client query client-name <DNS client name> query-type AAAA query-name <FQDN>** - force a query for a specific FQDN that has been returned
- **monitor protocol** - Select option 70 to collect DNS queries during the monitor subscriber test call.
- **monitor subscriber**
  - Collect and analyze a subscriber PGW call with monitor subscriber from the beginning of a call till an issue with verbosity level 3, with options:
    - S = sessmgr instance #
    - Y = Multi-Call = Yes to capture all APNs for the IMSI
    - 26 = GTPU user-plane data
  - Menu option:
    - 24 Next call by APN
    - 27 Next PGW call (if other call types on node this will differentiate)
  - Reading trace
    - TEIDs at top of GTPU packet can identify which bearer the packet belongs to if more than one bearer's data is collected in the trace

Troubleshooting S6b

This is the interface used by the PGW to communicate with the Diameter authentication server for purposes of user authentication, including IP pool group, session duration and idle time-outs.

- **show diameter peers full all** - Run command in corresponding context. Check that Diameter sessions are in "OPEN" state. Please refer to the Diameter chapter for details.
- **show diameter aaa-statistics [all | group server]**

Troubleshooting Tips for "No Resource Available" Response from PGW

In the 16.0 and higher software releases, sub-causes are added for the 'No Resource Available' in "show pgw-service statistics all" to provide granularity.

show pgw-service statistics all verbose

```
 Create Sess Rsp Denied - No Resource Reasons:
  New Call Policy Reject:               0   Num license exceeded:                0
  Session Manager Dead:                 0   No Session Manager:                  0
  Session Mgr Not Ready:                0   Congestion Policy Applied:           0
  ICSR State Invalid:                   0   Input pacing queue exceeded:         0
  Charging Svc Auth Fail:            4774   ims auth failed:                209222
  no session in aaa:                    0   aaa auth req exceeded/failed:        6
  Conflict in ip address:               0   static ip not present:           22555
  other reasons:                        0   ms req invalid ip:                   0
  Session Setup Timeout:                0   DHCP IP Address Not Present:         0
  S6B/radius  IP Validation Failed:     0   mem_alloc_failed:                    0
```

Troubleshooting GTP Path Failure

Overview

This chapter provides an overview of basic troubleshooting commands for GTP Path Failure.

Basic Troubleshooting

In order to troubleshoot any kind of GTP path issues, the following commands will be useful.

> The CLI commands below with debug-info options require CLI test-commands password configured in the chassis.
> Please use the command with caution! Many **TEST** commands are processor-intensive and can cause serious system problems if used too frequently.

- show [egtp-service | gtpu-service] all
- show egtpc peers [egtp-service <service>]
- egtpc test echo gtp-version 2 src-address <service address> peer-address <peer address>
- show egtpc statistics [[[(sgw-address | pgw-address | mme-address) <address>] [demux-only]] [debug-info] [verbose] | [path-failure-reasons]
- show gtpu statistics [peer-address <peer>]
- show gtpc statistics [ggsn-service <service>] [smgr-instance <instance>]
- show demux-mgr statistics <egtpinmgr | egtpegmgr | gtpumgr> all
- SNMP traps - EGTPCPathFail[Clear], EGTPUPathFail[Clear]
- show session disconnect-reasons - gtpc-path-failure, gtpu-path-failure
- show subscriber [summary] gtpu-service <service>
- show egtpc sessions [egtp-service <service>]

* Being able to specify a peer address can be very valuable when troubleshooting specific peer issues

Statistics counter by interface:

- show egtpc statistics interface mme shows EGTPC statistics on S11 interface on MME side.
- show egtpc statistics interface sgw-ingress shows EGTPC statistics on S11 interface on SGW side.
- show egtpc statistics interface sgw-egress shows EGTPC statistics on S5/S8 interfaces on SGW side.
- show egtpc statistics interface pgw-ingress show EGTPC statistics on S5/S8 interfaces on PGW side.

For example below is a snippet of **show egtpc statistics interface mme** statistics that indicates that the MME had 39547 retransmissions of Create Session Requests out of 72120781 initial Create Session Requests (which is ~0.00005%) and 71954773 Accepted Create Session Responses out of 72118219 total Create Session Response (which is ~99.77%)

```
Tunnel Management Messages:
Create Session Request:
 Total   TX:                  72160328   Total   RX:                        0
 Initial TX:                  72120781   Initial RX:                        0
 Retrans TX:                     39547   Retrans RX:                        0
                                          Discarded:                        0
                                         No Rsp  RX:                    11628

Create Session Response:
 Total   TX:                         0   Total   RX:                 72118219
 Initial TX:                         0   Initial RX:                 72118219
   Accepted:                         0     Accepted:                 71954773
     Denied:                         0       Denied:                   163446
 Retrans TX:                         0    Discarded:                        0
```

The basic command to check the status and configuration of all EGTP services is **show egtp-service**.

```
[local]SPGW-1# show egtp-service all

  Service name                          : pgwin
  Service-Id                            : 5
```

```
  Context                                 : spgw
  Interface Type                          : pgw-ingress
  Status                                  : STARTED
  Restart Counter                         : 42
  Message Validation Mode                 : Standard
  GTPU-Context                            : spgw
  GTPC Retransmission Timeout             : 5
  GTPC Maximum Request Retransmissions    : 3
  GTPC IP QOS DSCP value                  : 10
  GTPC Echo                               : Enabled
  GTPC Echo Mode                          : Default
  GTPC Echo Retransmission Timeout        : 5
  GTPC Echo Interval                      : 60
  GTP-C Bind IPv4 Address                 : 192.168.5.52
  GTP-C Bind IPv6 Address                 : Not configured
  GTPC path failure detection policy
    Echo Timeout                          : Enabled
```

"**show egtpc peers**" is very useful in identifying all of the peers, including statuses, restart counters, and current/max subscriber counts.

```
[local]SPGW-1# show egtpc peers

+----Status:                 (I) - Inactive  (A) - Active
|
|+---GTPC Echo:              (D) - Disabled  (E) - Enabled
||
||+--Restart Counter Sent:   (S) - Sent      (N) - Not Sent
|||
|||+-Peer Restart Counter:   (K) - Known     (U) - Unknown
||||
||||+-Type of Node:          (S) - SGW       (P) - PGW
|||||                        (M) - MME       (G) - SGSN
|||||                        (L) - LGW       (E) - ePDG
|||||                        (C) - CGW
|||||                        (U) - Unknown
|||||
```

```
|||||  Service                        Restart--------+  No. of
|||||  ID                             Counter        |  restarts
|||||   |                                            |   |   Current       Max
vvvvv   v              Peer Address                  v   v   sessions    sessions
-----  --- ---------------------------------------- --- --- ----------- -----------
IDNUG   4                             10.201.251.5   0   4           0           1
AESKS   5                             192.168.5.51  42   0         253         253
AESKM   6                            192.168.5.110  10   0         253         253
AESKP   7                             192.168.5.52  42   0         253         253

Total Peers:    4
```

Since this command includes all peer types, the peer type can be filtered on via the service name.

"egtpc test echo" is used to check a specific peer to see if it is reachable or not and must be run in the context where the service is defined.

- Using ping command is not a valid test, though if it is successful, one knows that there is some level of reachability.
- The peer restart counter (Recovery) is displayed.
- Running this command will increment the Tx echo request / Rx Echo response counters in "show egtpc statistics"

```
[EGTP Context]PGW> egtpc test echo gtp-version 2 src-address <src IP> peer-address  <peer IP>
EGTPC test echo
---------------
Peer: <peer IP>                          Tx/Rx:  1/1  RTT(ms): 83   (COMPLETE) Recovery: 14
(0x0E)
```

If the test fails, then there is either a connectivity issue or the peer is down and not responding.

"show egtpc statistics" is for EGTPC (v2) and will report amongst many other things, all path management counters for Echo Request/Response Tx/Rx, and based on the timers, one can predict the growth of these counters and use them to troubleshoot if they are not incrementing as expected.

"**show gtpu statistics**" reports stats on the user-plane traffic handled by the GTP-U service(s) that are associated with EGTPC service(s). One interesting counter is Error Indication Tx/Rx which is sent when the receiving node has no record of the subscriber that should be associated with the TEID of a packet in question. That could happen for a number of reasons where the subscriber has been dropped inadvertently, and/or maybe the peer was never notified of disconnect.

The peer versions of the above stat commands are necessary when troubleshooting specific peers, which often will be the case.

Example Scenarios

EGTPC Path Failure detection

Problem Description:

EGTPC path failure was detected.

Troubleshooting steps and analysis:

General troubleshooting steps are listed below.

- Collect 2 “show support detail”
- Collect external packet capture on the relevant interfaces (S11-S5/8)
- Syslog
- Check EGTP layer with egtpc test echo.
- Check IP connectivity.

Below couple examples with SNMP traps.

Internal trap notification 1112 (**EGTPCPathFail**) context Gn, service GGSN, interface type ggsn, self address 10.10.10.10, peer address 20.20.20.20, peer old restart counter 191, peer new restart counter 59, peer session count 21, failure reason **echo-rsp-restart-counter-change**

Internal trap notification 1112 (**EGTPCPathFail**) context mme_ctx, service mme_svc_egtp, interface type mme, self address 10.10.10.10, peer address 20.20.20.20, peer old restart counter 3, peer new restart counter 20, peer session count 1994, failure reason **restart-counter-change**

The **EGTPCPathFail** trap is the key for knowing when a path failure has occurred (no response received for GTPV2 request sent from MME or SGW or PGW). Amongst some basic values, it will report the number of calls dropped, the old and new restart counters, and the reason for the failure. In addition, the session disconnect reason **gtpc-path-failure** will be incremented.

The following are path failure counts that are reported from "**show egtpc stat path-failure-reasons**" on a PGW.

```
 [local]PGW> show egtpc statistics path-failure-reasons
 Reasons for path failure at EGTPC:
  Echo Request  restart counter change:                3
    Echo Response restart counter change:                0   echo-rsp-restart-counter-change
  No Echo Response received:                           0   no-response-from-peer
  Control message restart counter change at   demux:  23   Create Session Req Restart Counter
changed or create-sess-restart-counter-change
  Control message restart counter change at sessmgr:   0   cpc-restart-counter-change or upc-
restart-counter-change
  Total path failures detected:                       26
```

It is important to understand how EGTPC/GTPC and to a lesser degree EGTPU/GTPU (as user-plane failure detection is not always configured) path failure detection is implemented to monitor the connection between EGTP nodes. A PCAP will likely be needed to confirm that the messaging is taking place as expected.

Handover Troubleshooting

Overview

This section provides overview of basic troubleshooting commands for Handover issues in LTE.

Basic Troubleshooting

The following CLIs are useful in identifying issues during handover scenarios:

- monitor subscriber - Set verbosity to 3 and select options Y and S
- packet capture
- monitor protocol - Set verbosity to 3 and option 70 for DNS
- show support details
- dns-client query client-name <dns name>
- show dns-client cache
- show mme-service statistics -Provides an overview of handover statistics, see below snippet:

```
Handover Statistics:
  Intra MME Handover:
    X2-based handover:
      Attempted:                  4867039  Success:                     4866487
      Failures:                       552
    S1-based handover:
      Attempted:                    31977  Success:                        7955
      Failures:                     24022
   EUTRAN<-> EUTRAN using S10 Interface:
    Outbound relocation using TAU procedure:
      Attempted:                        0  Success:                           0
      Failures:                         0
    Outbound relocation using S1 HO procedure:
      Attempted:                        0  Success:                           0
      Failures:                         0
    Inbound relocation using TAU procedure:
      Attempted:                      448  Success:                           0
```

```
    Failures:                       448
  Inbound relocation using S1 HO procedure:
    Attempted:                        0  Success:                          0
    Failures:                         0
EUTRAN<->UTRAN(Iu mode) SRNS Relocations using Gn/Gp Interface:
  Outbound relocation:
    Attempted:                        0  Success:                          0
    Failures:                         0
  Inbound relocation:
    Attempted:                        0  Success:                          0
    Failures:                         0
EUTRAN<->GERAN(A/Gb Mode) PS Handovers using Gn/Gp Interface:
  Outbound relocation:
    Attempted:                        0  Success:                          0
    Failures:                         0
  Inbound relocation:
    Attempted:                        0  Success:                          0
    Failures:                         0
EUTRAN<->UTRAN/GERAN(Iu or A/Gb mode) Cell Reselections using Gn/Gp Interface:
  Outbound relocation using RAU procedure:
    Attempted:                  1687207  Success:                    1593639
    Failures:                     93568
  Inbound relocation using TAU procedure:
    Attempted:                  1469349  Success:                    1414495
    Failures:                     54854
EUTRAN<->UTRAN(Iu mode) Inter-RAT Handovers using S3 Interface:
  Outbound relocation:
    Attempted:                        0  Success:                          0
    Failures:                         0
  Inbound relocation:
    Attempted:                        0  Success:                          0
    Failures:                         0
EUTRAN<->GERAN(A/Gb Mode) Inter-RAT Handovers using S3 Interface:
  Outbound relocation:
    Attempted:                        0  Success:                          0
    Failures:                         0
  Inbound relocation:
    Attempted:                        0  Success:                          0
    Failures:                         0
```

```
EUTRAN<->UTRAN/GERAN(Iu or A/Gb mode) Cell Reselections using S3 Interface:
 Outbound relocation using RAU procedure:
   Attempted:                          0  Success:                          0
   Failures:                           0
 Inbound relocation using TAU procedure:
   Attempted:                      55606  Success:                          0
   Failures:                       55606
EUTRAN-> UTRAN/GERAN using Sv Interface:
 CS only handover with no DTM support:
   Attempted:                          0  Success:                          0
   Failures:                           0
 CS only handover:
   Attempted:                          0  Success:                          0
   Failures:                           0
 CS and PS handover:
   Attempted:                          0  Success:                          0
   Failures:                           0
EUTRAN<-> Non-3GPP Unoptimized Handovers:
 Outbound relocation (Per PDN):
   Attempted:                          0  Success:                          0
   Failures:                           0
 Inbound relocation (Per PDN):
   Attempted:                          0  Success:                          0
   Failures:                           0
```

Example Scenarios:

TAU Failure examples

Problem Description:

TAU updates with IMSI attach are failing, but it fails due to MME rejecting TAU with EMM cause code 9 : UE identity cannot be derived by the network.

Logs collection:

- Collect 2 or more “show support details”
- Collect "monitor subscriber"
- Collect external packet capture
- "monitor subscriber" with verbosity 3, options Y and S
- "monitor subscriber" with verbosity 3 and option 70 for DNS
- Check dns-client query client-name dns1
- show dns-client cache

Analysis:

According to monitor subscriber and external packet capture, UE is coming back to 4G service and sending TAU request (combined TA/LA updating with IMSI attach). The MME does not have information about the subscriber, and it uses information from the "old GUTI" in the TAU request to lookup the call.

The old GUTI indicates a value mapped from a P-TMSI and RAI. The old GUTI is used by the MME mapping old SGSNs information to send Context Request Message to old SGSN.

The MME was not able to get SGSN’s IP addresses via DNS and it sent Tracking area update reject with EMM because UE identity cannot be derived by the network (9).

Snippet of the PCAP file

```
Packet #1  S1AP/NAS-EPS  Initial UE Message - Tracking area update request
NAS-PDU
EPS mobile identity - Old GUTI

.... .110 = Type of identity: GUTI (6)
Mobile Country Code (MCC): 001
Mobile Network Code (MNC): 001
MME Group ID: 11651
MME Code: 97
M-TMSI: 0xe29781c5

Packet #2 S1AP/NAS-EPS  Downlink NAS Transport - Tracking area update reject
```

```
NAS-PDU
EMM cause

Cause: UE identity cannot be derived by the network (9)

Snippet of the MME's configuration:

    mme-service  MME
            nri length 5 plmn-id mcc 001 mnc 001
```

According to 3GPP TS 23.003 V9.9.0 (2011-12) the following mappings are being used.

E?UTRAN <MCC> maps to GERAN/UTRAN <MCC>

E?UTRAN <MNC> maps to GERAN/UTRAN <MNC>

E?UTRAN <MME Group ID> maps to GERAN/UTRAN <LAC>

E?UTRAN <MME Code> maps to GERAN/UTRAN <RAC> and is also copied into the 8 most significant bits of the NRI field within the P?TMSI;

NRI length is 5. MME code = 97 = 1100001. Prepend 0 to previous value and get the result of: 01100001 where 5 most significant bits are NRI 01100 that equals C in hex.

DNS requests sent by the MME are the followings.

```
nri-sgsn000c.rac0097.lac2d83.rac.epc.mnc001.mcc001.3gppnetwork.org (NAPTR RRs)
rac0097.lac2d83.rac.epc.mnc001.mcc001.3gppnetwork.org (NAPTR RRs)
nri000c.rac0097.lac2d83.mnc001.mcc001.gprs (A/AAAA RRs)
rac0097.lac2d83.mnc001.mcc001.gprs (A/AAAA RRs)
```

The DNS queries can be checked with commands if DNS client is configured on the chassis.

Below are examples of the DNS test queries – DNS replied with "**DNS record does not exist**".

Snippet of test commands:

```
 MME> dns-client query client-name dns1 query-type NAPTR query-name  nri-
sgsn000c.rac0097.lac2d83.rac.epc.mnc001.mcc001.3gppnetwork.org
 Query Name: nri-sgsn000c.rac0097.lac2d83.rac.epc.mnc001.mcc001.3gppnetwork.org
 Query Type: NAPTR      TTL: 3 seconds
 Answer: -Negative Reply-
 Failure Reason: DNS record does not exist

 MME> dns-client query client-name dns1 query-type AAAA query-name
nri000c.rac0097.lac2d83.mnc001.mcc001.gprs
 Query Name: nri000c.rac0097.lac2d83.mnc001.mcc001.gprs
 Query Type: AAAA       TTL: 60 seconds
 Answer: -Negative Reply-
 Failure Reason: DNS record does not exist

 MME> dns-client query client-name dns1 query-type A query-name
nri000c.rac0097.lac2d83.mnc001.mcc001.gprs
 Query Name: nri000c.rac0097.lac2d83.mnc001.mcc001.gprs
 Query Type: A          TTL: 30 seconds
 Answer: -Negative Reply-
 Failure Reason: DNS record does not exist
```

Resolution:

The issue was resolved on DNS side by adding configuration for the missing instances.

Session Troubleshooting

Overview

This chapters covers the session troubleshooting commands used in ASR 5000/ASR 5500.

Monitor Subscriber Utility

Monitor subscriber provides the ability to trace control path messages and data traffic on a per subscriber basis. Operators can trace control messages of a particular subscriber using IMSI, username, callid, or next incoming call (next-call).

Here is an example of the command as it would be entered into the system using the IMSI parameter:

```
[local]RTP-ARES> monitor subscriber imsi <Mobile Station Identifier - a sequence of digits>
```

Below is a list of the most commonly used monitor subscriber options:

```
imsi                - Specific International Mobile Subscriber Identification (IMSI). Must be
                      followed by 3 digits of MCC(Mobile Country Code) 2 or 3 digits of
                      MNC(Mobile Network Code) and the rest with MSIN(Mobile Subscriber
                      Identification Number). The total should not exceed 15 digits. Ex
                      123-45-678910234 can be entered as 12345678910234
ipaddr              - Specific IP address. Must be followed by IPv4 address in dotted decimal
                      notation
msisdn              - Specific Mobile Station Integrated Services Digital Network (MSISDN)
                      Number. Must be followed by CC(Country Code) and National (significant)
                      mobile number. The total should not exceed 15 digits. Ex 91-9123412345
                      can be entered as 919123412345
next-call           - Monitors the next call established in the system
username            - Name of specific user within current context. Must be followed by user
                      name
```

For monitor subscriber, here is an example with some of the more common options (highlighted in blue):

```
C - Control Events  (ON )      11 - PPP          (ON )  21 - L2TP         (ON )
D - Data Events     (ON )      12 - A11          (ON )  22 - L2TPMGR      (OFF)
E - EventID Info    (ON )      13 - RADIUS Auth  (ON )  23 - L2TP Data    (OFF)
I - Inbound Events  (ON )      14 - RADIUS Acct  (ON )  24 - GTPC         (ON )
O - Outbound Events (ON )      15 - Mobile IPv4  (ON )  25 - TACACS  (ON )
S - Sender Info     (OFF)      16 - A11MGR       (OFF)  26 - GTPU         (OFF)
T - Timestamps      (ON )      17 - SESSMGR      (ON )  27 - GTPP         (ON )
X - PDU Hexdump     (OFF)      18 - A10          (OFF)  28 - DHCP         (ON )
A - PDU Hex/Ascii   (OFF)      19 - User L3      (OFF)  29 - CDR          (ON )
+/- Verbosity Level (  3)      31 - Radius COA   (ON )  30 - DHCPV6       (ON )
L - Limit Context   (OFF)      32 - MIP Tunnel   (ON )  53 - SCCP         (OFF)
M - Match Newcalls  (ON )      33 - L3 Tunnel    (OFF)  54 - TCAP         (OFF)
R - RADIUS Dict: (no-override) 34 - CSS Data     (OFF)  55 - MAP          (ON )
G - GTPP Dict: (no-override)   35 - CSS Signal   (OFF)  56 - RANAP        (OFF)
Y - Multi-Call Trace (OFF)     36 - EC Diameter  (ON )  57 - GMM          (ON )
H - Display ethernet (OFF)     37 - SIP (IMS)    (OFF)  58 - GPRS-NS      (OFF)
                               40 - IPSec IKEv2  (OFF)  59 - BSSGP        (OFF)
                               41 - IPSG RADIUS  (ON )  60 - CAP          (ON )
                               42 - ROHC         (OFF)  64 - LLC          (OFF)
                               43 - WiMAX R6     (ON )  65 - SNDCP        (OFF)
                               44 - WiMAX Data   (OFF)  66 - BSSAP+       (OFF)
                               45 - SRP          (OFF)  67 - SMS          (OFF)
                               46 - BCMCS SERV AUTH(OFF)68 - PHS Control(ON )
                               47 - RSVP         (ON )  69 - PHS Data     (OFF)
                               48 - Mobile IPv6  (ON )  76 - PHS EAPOL    (ON )
                               49 - ASNGWMGR     (OFF)  77 - ICAP         (ON )
                               50 - STUN (IMS)   (OFF)  78 - Micro-Tunnel(ON )
                               51 - SCTP         (OFF)
                               72 - HNBAP        (ON )  79 - ALCAP        (ON )
                               73 - RUA          (ON )  80 - SSL          (ON )
                               74 - EGTPC        (ON )
                               75 - App Specific Diameter  (OFF)
                               81 - S1-AP        (ON )  82 - NAS          (ON )
                               83 - LDAP         (ON )  84 - SGS          (ON )
                               85 - AAL2         (ON )
                               86 - PHS(Payload Header Suppression)  (OFF)
```

```
                                87 - PPPOE   (ON )
                                88 - RTP(IMS)     (OFF)  89 - RTCP(IMS)    (OFF)
                                91 - NPDB(IMS)   (OFF)
                                92 - SABP   (ON )
                                94 - SLS    (ON )
                                96 - SBc-AP   (ON )

   (Q)uit,   <ESC> Prev Menu,   <SPACE> Pause,   <ENTER> Re-Display Option
```

Sample monitor subscriber trace:

```
 *** Sender Info (ON ) ***
 *** PDU Hex+Ascii dump (ON ) ***
 *** CSS Data Decodes (ON ) ***
 *** User L3 PDU Decodes (ON ) ***
 *** GTPU PDU Decodes (ON ) ***
 *** Verbosity Level (  2) ***
 *** Verbosity Level (  3) ***

 ------------------------------------------------------------------------
 Incoming Call:
 ------------------------------------------------------------------------
  MSID/IMSI   : 506040000000002              Callid      : 017dc661
  IMEI        : n/a                          MSISDN      : 9876543210
  Username    : 9876543210                   SessionType : ggsn-pdp-type-ipv4
  Status      : Active                       Service Name: local
  Src Context : Gn
 ------------------------------------------------------------------------

 Tuesday May 05 2015
 INBOUND>>>>>  From sessmgr:6 ggsnapp_util.c:689 (Callid 77359400) 13:33:30:566
Eventid:47000(3)
 GTPC Rx PDU, from 10.1.1.3:2123 to 10.1.1.10:2123 (164)
 TEID: 0x00000000, Message type: GTP_CREATE_PDP_CONTEXT_REQ_MSG (0x10)
 Sequence Number:: 0x7FFF (32767)
 GTP HEADER FOLLOWS:
              Version number: 1
               Protocol type: 1 (GTP C/U)
```

```
       Extended header flag: Not present
       Sequence number flag: Present
           NPDU number flag: Not present
               Message Type: 0x10 (GTP_CREATE_PDP_CONTEXT_REQ_MSG)
             Message Length: 0x009C (156)
                  Tunnel ID: 0x00000000
            Sequence Number: 0x7FFF (32767)
GTP HEADER ENDS.
INFORMATION ELEMENTS FOLLOW:
                       IMSI: 50604000000002
                   Recovery: 0xD0 (208)
             Selection Mode: 0x1 (MS provided APN, subscription not verified (Sent by MS))
           Tunnel ID Data I: 0x00000400
        Tunnel ID Control I: 0x00000400
                      NSAPI: 0x05 (5)

CHARGING CHARACTERISTIC FOLLOWS:
                  Charging Chars # 1: 0x0800 (Normal)
CHARGING CHARACTERISTIC ENDS.
END USER ADDRESS FOLLOWS:
      PDP Type Organisation: IETF
            PDP Type Number: IPv4
                    Address: Empty
END USER ADDRESS ENDS.
           Access Point Name: ciscolab1.com
PROTOCOL CONFIG. OPTIONS FOLLOW:
                  IE Length: 0x39 (57)
     Configuration Protocol: (0) PPP
              Extension Bit: (1)

                Protocol id: 0xC021 (LCP)
            Protocol length: 0x0E (14)
          Protocol contents: 0103000E0506088AA1020304C023
                Protocol id: 0xC021 (LCP)
            Protocol length: 0x0E (14)
          Protocol contents: 0203000E0506088AA1020304C023
                Protocol id: 0xC023 (PAP)
            Protocol length: 0x10 (16)
          Protocol contents: 0104001004746573740673656372657 4
```

```
                Container id: 0x0005 (NCQOS BCM info)
             Container length: 0x00 (0)
           Container contents:
 PROTOCOL CONFIG. OPTIONS END.
               GSN Address I: 0x0A010103 (10.1.1.3)
              GSN Address II: 0x0A010103 (10.1.1.3)
                     MSISDN: 9876543210
                  QOS Profile: 0x0122720D7396404886074048
 COMMON FLAGS FOLLOW:
  Prohibit Payload Compression: no
             MBMS Service Type: Multicast Service
           RAN Procedures Ready: no
      MBMS Counting Information: no
            No QoS negotiation: no
                        NRSN: no
          Upgrade QoS Supported: yes
       Dual Address Bearer Flag: no
 COMMON FLAGS END.
 INFORMATION ELEMENTS END.
 PDU HEX DUMP FOLLOWS:
 0x0000   3210 009c 0000 0000 7fff 0000 0205 0604        2...............
 0x0010   0000 0020 ff0e d00f fd10 0000 0400 1100        ................
 0x0020   0004 0014 051a 0800 8000 02f1 2183 000e        ............!...
 0x0030   0963 6973 636f 6c61 6231 0363 6f6d 8400        .ciscolab1.com..
 0x0040   3980 c021 0e01 0300 0e05 0608 8aa1 0203        9..!............
 0x0050   04c0 23c0 210e 0203 000e 0506 088a a102        ..#.!...........
 0x0060   0304 c023 c023 1001 0400 1004 7465 7374        ...#.#......test
 0x0070   0673 6563 7265 7400 0500 8500 040a 0101        .secret.........
 0x0080   0385 0004 0a01 0103 8600 0691 8967 4523        .............gE#
 0x0090   0187 000c 0122 720d 7396 4048 8607 4048        ....."r.s.@H..@H
 0x00a0   9400 0140                                      ...@

 Tuesday May 05 2015
 <<<<OUTBOUND  From sessmgr:6 ggsnapp_util.c:662 (Callid 017dc661) 13:33:30:779
Eventid:47001(3)
 GTPC Tx PDU, from 10.1.1.10:2123 to 10.1.1.3:2123 (96)
 TEID: 0x00000400, Message type: GTP_CREATE_PDP_CONTEXT_RES_MSG (0x11)
 Sequence Number:: 0x7FFF (32767)
 GTP HEADER FOLLOWS:
```

```
             Version number: 1
              Protocol type: 1 (GTP C/U)
       Extended header flag: Not present
       Sequence number flag: Present
           NPDU number flag: Not present
               Message Type: 0x11 (GTP_CREATE_PDP_CONTEXT_RES_MSG)
             Message Length: 0x0058 (88)
                  Tunnel ID: 0x00000400
            Sequence Number: 0x7FFF (32767)
GTP HEADER ENDS.
INFORMATION ELEMENTS FOLLOW:
                      Cause: 0x80 (GTP_REQUEST_ACCEPTED)
           Reorder Required: 0x0 (Not present)
                   Recovery: 0x8D (141)
           Tunnel ID Data I: 0x80000006
        Tunnel ID Control I: 0x80000006
                Charging ID: 0x01AAAAAA
END USER ADDRESS FOLLOWS:
      PDP Type Organisation: IETF
            PDP Type Number: IPv4
               IPv4 Address: 172.1.1.1
END USER ADDRESS ENDS.
 PROTOCOL CONFIG. OPTIONS FOLLOW:
                  IE Length: 0x12 (18)
     Configuration Protocol: (0) PPP
              Extension Bit: (1)

                Protocol id: 0x8021 (IPCP)
            Protocol length: 0x0A (10)
          Protocol contents: 0101000A03061401010A
               Container id: 0x0005 (NCQOS BCM info)
           Container length: 0x01 (1)
         Container contents: 01
PROTOCOL CONFIG. OPTIONS END.
              GSN Address I: 0x0A01010A (10.1.1.10)
             GSN Address II: 0x0A01010A (10.1.1.10)
                QOS Profile: 0x0122520D739640488607FFFF
        Bearer Control Mode: 0x00 (UE-Only)
INFORMATION ELEMENTS END.
```

```
 PDU HEX DUMP FOLLOWS:
 0x0000   3211 0058 0000 0400 7fff 0000 0180 08fe        2..X............
 0x0010   0e8d 1080 0000 0611 8000 0006 7f01 aaaa        ................
 0x0020   aa80 0006 f121 ac01 0101 8400 1280 8021        .....!.........!
 0x0030   0a01 0100 0a03 0614 0101 0a00 0501 0185        ................
 0x0040   0004 0a01 010a 8500 040a 0101 0a87 000c        ................
 0x0050   0122 520d 7396 4048 8607 ffff b800 0100        ."R.s.@H........

 Tuesday May 05 2015
 INBOUND>>>>>  From sessmgr:6 sessmgr_med.c:17866 (Callid 017dc661) 13:33:33:849
Eventid:142004(3)
 GTPU Rx PDU, from 10.1.1.3:2152 to 10.1.1.10:2152 (69)
 TEID: 0x80000006, Message type: GTP_TPDU_MSG (0xFF)
 Sequence Number:: NA
            Payload protocol: IPv4
 PROTOCOL PAYLOAD FOLLOWS:
 172.1.1.1.1029 > 1.1.1.1.53:  [udp sum ok] 43092+ A? news.google.com. [|domain] (ttl 128, id
1217, len 61)
 PROTOCOL PAYLOAD ENDS.

 PDU HEX DUMP FOLLOWS:
 0x0000   30ff 003d 8000 0006 4500 003d 04c1 0000        0..=....E..=....
 0x0010   8011 86eb ac01 0101 0101 0101 0405 0035        ...............5
 0x0020   0029 0e10 a854 0100 0001 0000 0000 0000        .)...T..........
 0x0030   046e 6577 7306 676f 6f67 6c65 0363 6f6d        .news.google.com
 0x0040   0000 0100 01                                   .....

 Tuesday May 05 2015
 INBOUND>>>>>  From sessmgr:6 sessmgr_ipv4.c:16044 (Callid 017dc661) 13:33:33:850
Eventid:51000(0)
 IPv4 Rx PDU
 172.1.1.1.1029 > 1.1.1.1.53:  [udp sum ok] 43092+ A? news.google.com. [|domain] (ttl 128, id
1217, len 61)
 0x0000   4500 003d 04c1 0000 8011 86eb ac01 0101        E..=............
 0x0010   0101 0101 0405 0035 0029 0e10 a854 0100        .......5.)...T..
 0x0020   0001 0000 0000 0000 046e 6577 7306 676f        .........news.go
 0x0030   6f67 6c65 0363 6f6d 0000 0100 01               ogle.com.....

 Tuesday May 05 2015
```

```
 <<<<OUTBOUND  From sessmgr:6 sessmgr_ipv4.c:16235 (Callid 017dc661) 13:33:33:857
Eventid:77000(9)
 CSS Uplink Output PDU to ACS- slot:2 cpu:17 inst:4369
 172.1.1.1.1029 > 1.1.1.1.53:  [udp sum ok] 43092+ A? news.google.com. [|domain] (ttl 128, id
1217, len 61)
 0x0000   4500 003d 04c1 0000 8011 86eb ac01 0101        E..=............
 0x0010   0101 0101 0405 0035 0029 0e10 a854 0100        .......5.)...T..
 0x0020   0001 0000 0000 0000 046e 6577 7306 676f        .........news.go
 0x0030   6f67 6c65 0363 6f6d 0000 0100 01               ogle.com.....

 Tuesday May 05 2015
 ***CONTROL*** From sessmgr:6 acsmgr_rules.c:20917 (Callid 017dc661) 13:33:33:867 Eventid:77202
 Rule matched : dns-pkts for uplink packet of subscriber MSID : 50604000000002
```

Protocol Analyzer Utility

Overview

The utility displays information for all sessions that are currently being processed. This can cause a large amount of data to be displayed, depending on the number of protocols monitored, and the number of sessions in progress. Logging should be enabled on the terminal client to record all of the information that is generated. A monitor protocol on a busy interface (for example, S1AP) should be planned during a maintenance window.

Troubleshooting Command

Below are the instructions to start a monitor protocol session:

1. Run from the Exec mode by entering the "monitor protocol" command. An output listing all the currently available protocols, each with an assigned number, is displayed.
2. Select the protocol to be monitored by entering the associated number at the "**`Select:`**" prompt. A right arrow (">") appears next to the selected protocol.
3. Repeat step 2 as needed to choose multiple protocols.
4. Press B to begin the protocol monitor, and the following warning will be displayed:

```
 WARNING!!! You have selected options that can DISRUPT USER SERVICE Existing CALLS MAY BE
DROPPED and/or new CALLS MAY FAIL!!! (Under heavy call load, some debugging output may not be
displayed) Proceed? - Select (Y)es or (N)o
```

5. Enter Y to proceed with the monitor or N to go back to the previous menu. If Y is entered the following menu will appear:

```
 C - Control Events  (ON ) D - Data Events     (ON ) E - EventID Info    (ON ) H - Disply
ethernet (ON ) I - Inbound Events  (ON ) O - Outbound Event  (ON ) S - Sender Info     (OFF) T
- Timestamps       (ON ) X - PDU Hexdump     (OFF) A - PDU Hex/Ascii   (OFF) +/- Verbosity Level
(  1) L - Limit Context   (OFF) M - Match Newcalls  (ON ) R - RADIUS Dict     (no-override) G -
GTPP Dict        (no-override) Y - Multi-Call Trace ((OFF))   (Q)uit,   <ESC> Prev Menu,
<SPACE> Pause,   <ENTER> Re-Display Options
```

6 Configure the amount of information that is displayed by the monitor.

- To enable or disable options, enter the letter associated with that option (C, D, E, etc.).
- To increase or decrease the verbosity, use the plus (+) or minus (-) keys.
- The current state, ON (enabled) or OFF (disabled), is shown to the right of each option.

7 Typically for troubleshooting purposes, verbosity 3 or higher is recommended.

8 Press the **Enter** key to refresh the screen and begin monitoring. To quit the protocol monitor and return to the prompt, press **q**.

Generic session debugging commands

Overview

This chapter provides basic troubleshooting commands for subscriber related issues in ASR 5000/ASR 5500.

Troubleshooting Commands

The following commands can be used to debug sessions. Most of these commands support an option to limit the output to one subscriber (imsi/msid/username/ip/...).

Important note: "show subscriber" is context sensitive, and so if run in a particular context it will only report subscribers that are bound in that context. If different call types are bound in different contexts, then this restriction can be used to one's advantage by going into the context of the particular call type and running the command. Running the command in the local context reports all subscribers that meet the criteria specified.

"show subscriber" commands can be limited to a particular subscriber (or set of subscribers with wildcard character *) using IMSI, MSID, username, MSISDN, and callid. Interesting criteria for narrowing a set of subscribers not related to a particular call type include ip-pool, connected-time, idle-time, card-num, smgr-instance. See the online help for the complete list.

- show subscriber [summary]
- show subscriber [pgw-only | ggsn-only | mme-only | ...]
- show subscriber full
- show subscriber data-rate
- show subscriber debug-info
- show active-charging session summary
- show active-charging sessions full
- show session progress
- show session counters historical all
- show session duration
- show session disconnect-reasons

- show session setuptime
- show session subsystem
- To get a snapshot of connections (sessions) on the ASR 5000/ASR 5500, use the "show subscriber summary" command:

```
[local]ASR5x00> show subscribers summary


Total Subscribers:              1811051
Active:                         1811051       Dormant:                        0
pdsn-simple-ipv4:               0             pdsn-simple-ipv6:               0
pdsn-mobile-ip:                 0             ha-mobile-ipv6:                 0
hsgw-ipv6:                      0             hsgw-ipv4:                      0
hsgw-ipv4-ipv6:                 0             pgw-pmip-ipv6:                  45033
pgw-pmip-ipv4:                  1663          pgw-pmip-ipv4-ipv6:             48245
pgw-gtp-ipv6:                   619269        pgw-gtp-ipv4:                   38008
pgw-gtp-ipv4-ipv6:              596053        sgw-gtp-ipv6:                   0
sgw-gtp-ipv4:                   0             sgw-gtp-ipv4-ipv6:              0
sgw-pmip-ipv6:                  0             sgw-pmip-ipv4:                  0
sgw-pmip-ipv4-ipv6:             0             pgw-gtps2b-ipv4:                0
pgw-gtps2b-ipv6:                0             pgw-gtps2b-ipv4-ipv6:           0
pgw-gtps2a-ipv4:                0             pgw-gtps2a-ipv6:                0
pgw-gtps2a-ipv4-ipv6:           0
mme:                            0
henbgw-ue:                      0             henbgw-henb:                    0
ipsg-rad-snoop:                 0             ipsg-rad-server:                0
ha-mobile-ip:                   454837        ggsn-pdp-type-ppp:              0
ggsn-pdp-type-ipv4:             8668          lns-l2tp:                       0
ggsn-pdp-type-ipv6:             8             ggsn-pdp-type-ipv4v6:           77
ggsn-mbms-ue-type-ipv4:         0
```

- To look at a specific session, use the "show subscriber imsi <imsi>. Other options can be used such as username and ip-address:

```
[local]ASR5x00# show subscribers imsi 123456000000001
+-----Access  (S) - pdsn-simple-ip     (M) - pdsn-mobile-ip  (H) - ha-mobile-ip
|     Type:   (P) - ggsn-pdp-type-ppp  (h) - ha-ipsec        (N) - lns-l2tp
|             (I) - ggsn-pdp-type-ipv4 (A) - asngw-simple-ip (G) - IPSG
|             (V) - ggsn-pdp-type-ipv6 (B) - asngw-mobile-ip (C) - cscf-sip
|             (z) - ggsn-pdp-type-ipv4v6
|             (R) - sgw-gtp-ipv4       (O) - sgw-gtp-ipv6    (Q) - sgw-gtp-ipv4-ipv6
|             (W) - pgw-gtp-ipv4       (Y) - pgw-gtp-ipv6    (Z) - pgw-gtp-ipv4-ipv6
|             (@) - saegw-gtp-ipv4     (#) - saegw-gtp-ipv6  ($) - saegw-gtp-ipv4-ipv6
|             (&) - cgw-gtp-ipv4       (^) - cgw-gtp-ipv6    (*) - cgw-gtp-ipv4-ipv6
|             (p) - sgsn-pdp-type-ppp  (s) - sgsn            (4) - sgsn-pdp-type-ip
|             (6) - sgsn-pdp-type-ipv6 (2) - sgsn-pdp-type-ipv4-ipv6
|             (L) - pdif-simple-ip     (K) - pdif-mobile-ip  (o) - femto-ip
|             (F) - standalone-fa      (J) - asngw-non-anchor
|             (e) - ggsn-mbms-ue       (i) - asnpc           (U) - pdg-ipsec-ipv4
|             (E) - ha-mobile-ipv6     (T) - pdg-ssl         (v) - pdg-ipsec-ipv6
|             (f) - hnbgw-hnb          (g) - hnbgw-iu        (x) - s1-mme
|             (a) - phsgw-simple-ip    (b) - phsgw-mobile-ip (y) - asngw-auth-only
|             (j) - phsgw-non-anchor   (c) - phspc           (k) - PCC
|             (X) - HSGW               (n) - ePDG            (t) - henbgw-ue
|             (m) - henbgw-henb        (q) - wsg-simple-ip   (r) - samog-pmip
|             (D) - bng-simple-ip      (l) - pgw-pmip        (3) - GILAN
|             (u) - Unknown
|             (+) - samog-eogre
|
|+----Access  (X) - CDMA 1xRTT         (E) - GPRS GERAN      (I) - IP
||    Tech:   (D) - CDMA EV-DO         (U) - WCDMA UTRAN     (W) - Wireless LAN
||            (A) - CDMA EV-DO REVA    (G) - GPRS Other      (M) - WiMax
||            (C) - CDMA Other         (N) - GAN             (O) - Femto IPSec
||            (P) - PDIF               (S) - HSPA            (L) - eHRPD
||            (T) - eUTRAN             (B) - PPPoE           (F) - FEMTO UTRAN
||            (H) - PHS                (Q) - WSG             (.) - Other/Unknown
||
||+---Call    (C) - Connected          (c) - Connecting
|||   State:  (d) - Disconnecting      (u) - Unknown
|||           (r) - CSCF-Registering   (R) - CSCF-Registered
```

```
 |||           (U) - CSCF-Unregistered
 |||
 |||+--Access  (A) - Attached           (N) - Not Attached
 ||||  CSCF    (.) - Not Applicable
 ||||  Status:
 ||||
 ||||+-Link    (A) - Online/Active      (D) - Dormant/Idle
 ||||| Status:
 |||||
 |||||+Network (I) - IP                 (M) - Mobile-IP         (L) - L2TP
 ||||||Type:   (P) - Proxy-Mobile-IP    (i) - IP-in-IP          (G) - GRE
 ||||||        (V) - IPv6-in-IPv4       (S) - IPSEC             (C) - GTP
 ||||||        (A) - R4 (IP-GRE)        (T) - IPv6              (u) - Unknown
 ||||||        (W) - PMIPv6(IPv4)       (Y) - PMIPv6(IPv4+IPv6) (R) - IPv4+IPv6
 ||||||        (v) - PMIPv6(IPv6)       (/) - GTPv1(For SAMOG)  (+) - GTPv2(For SAMOG)
 ||||||
 ||||||
 vvvvvv CALLID   MSID            USERNAME               IP
TIME-IDLE
 ------ -------- --------------- ---------------------- ------------------------------ ---------
 xTC.DI 00004e2d 123456000000001 n/a                    192.168.41.1    00h04m18s
 RTC.AI 00004e30 123456000000001 123456792              192.168.41.1                   00h04m18s
 WTCNAI 00004e31 123456000000001 123456792@web          192.168.41.1                   00h04m18s

 Total subscribers matching specified criteria: 3
```

- In order to view the sessions for a specific access type, this can be specified as in the following examples: Use the "show subscriber pgw-only" command to view a list of subscriber sessions on the PGW. Use the "show subscriber ggsn-only" to view a list of subscriber sessions on the GGSN. Other access types can be specified as required.

```
[local]ASR5x00> show subscribers pgw-only

 Total Subscribers        : 1364684
 Total Home               : 1358837       Total Visitors            : 21
 Total Roamers            : 5826          Total S6b Assume Positive : 0
 Total Bearers            : 1251043
 Total Default Bearers    : 1250175       Total Dedicated Bearers   : 868
```

```
 Total PDNs by RAT-Type
 EUTRAN                    : 1250045       UTRAN                     : 119
 GERAN                     : 11            WLAN                      : 0
 OTHER                     : 114509

 pmip-pdn-type-ipv4        : 1677
 pmip-pdn-type-ipv6        : 55391
 pmip-pdn-type-ipv4-ipv6   : 57441
 gtp-pdn-type-ipv4         : 38069
 gtp-pdn-type-ipv6         : 618710
 gtp-pdn-type-ipv4-ipv6    : 594264
 ip-type-static            : 34980         ip-type-local-pool        : 655423
 ip-type-unknown           : 1042

 in bytes dropped          : 71162258867    out bytes dropped        : 44498468907
 in packet dropped         : 309498844     out packet dropped        : 52246423
 ipv4 ttl exceeded         : 2690922       ipv4 bad hdr              : 52359
 ipv4 frag failure         : 0             ipv4 frag sent            : 0
 ipv4 in-acl dropped       : 216740515     ipv4 out-acl dropped      : 3297
 ipv6 in-acl dropped       : 17391         ipv6 out-acl dropped      : 789
 ipv4 in-css-down dropped : 0              ipv4 out-css-down dropped : 0
 ipv4 early pdu rcvd       : 0             ipv4 icmp packets dropped : 0
```

- To show session info for a specific access type, use "show subscriber pgw-only imsi <imsi>":

```
[local]epc# show subscriber pgw-only imsi 123456000000001
+-------Access     (W) - pgw-gtp-ipv4         (Y) - pgw-gtp-ipv6
|       Type:      (Z) - pgw-gtp-ipv4-ipv6    (X) - pgw-pmip-ipv4
|                  (U) - pgw-pmip-ipv6        (V) - pgw-pmip-ipv4-ipv6
|                  (.) - Unknown
|
|+------Access     (U) - UTRAN                (G) - GERAN
||      Tech:      (W) - WLAN                 (N) - GAN
```

```
 ||                (U) - HSPA Evolution      (E) - eUTRAN
 ||                (H) - eHRPD               (.) - Unknown
 ||
 ||+-----Call      (C) - Connected           (c) - Connecting
 |||     State:    (d) - Disconnecting       (u) - Unknown
 |||
 |||+----PLMN:     (H) - Home                (V) - Visiting
 ||||              (R) - Roaming             (u) - Unknown
 ||||
 ||||+---Bearer:   (D) - Default             (E) - Dedicated
 |||||   Type
 |||||
 |||||+-Emergency: (A) - Authentic IMSI      (U) - Un-Authentic IMSI
 |||||| Bearer     (O) - Only IMEI           (N) - Non-Emergency
 |||||| Type
 ||||||
 ||||||  Addr      (L) - Local pool
 ||||||  Type:     (S) - Static (Subscriber Supplied)
 ||||||            (u) - Unknown
 ||||||  |
 ||||||  |
 ||||||  +-----------------------------+
 ||||||    EBI---------------------+   |
 ||||||                            |   |
 vvvvvv CALLID   IMSI/IMEI         v   v IP                          APN             TIME-
IDLE
 ------ -------- ----------------- --- - ------------------------------ --------------- -------
--
 WECHDN 00004e31 123456000000001   005 L 192.168.41.1                 web
00h05m02s

 Total subscribers matching specified criteria: 1
```

- To show detailed output of the session, use "show subscriber full imsi <imsi>.

```
 [local]ASR5x00# show subscriber full imsi 123451234512345

 Username: 9876543210@public              Status: Online/Active
```

```
Access Type: ggsn-pdp-type-ipv4        Network Type: IP
Access Tech: GPRS Other                Access Network Peer ID: n/a
callid: 01317b26                       imsi: 123451234512345
Card/Cpu: 3/0                          Sessmgr Instance: 5
state: Connected                       SGSN address: 192.168.2.4
connect time: Tue Dec 13 07:24:06 2011 call duration: 00h13m43s
idle time: 00h00m00s                   idle time left:  n/a
session time left:  n/a
long duration time left:  n/a          long duration action:  n/a
always on: Disabled
ip address: 10.100.133.145
ip pool name: public
ggsn-service name: ggsn-lab
source context: gn                     destination context: gi
ip header compression:
 local to remote: none
 remote to local: none
ROHC cid-mode (local/remote): na/na
ROHC max-cid  (local/remote): na/na
ROHC mrru     (local/remote): na/na
ROHC max-hdr  (local/remote): na/na
ROHC profile  (local/remote): na/na
AAA context: gi                        AAA domain: gi
AAA start count: 0                     AAA stop count: 0
AAA interim count(RADIUS+GTPP): 0      Acct-session-id: C0A802070155555A
AAA RADIUS group: default
AAA RADIUS Secondary group: n/a
RADIUS Auth Server IP: n/a             RADIUS Acct Server IP: n/a
NAS IP Address: n/a                    Nexthop IP Address: n/a
GTPP Group: default                    Acct Context: ga
Authentication Mode: None
Authentication Type: None
EAP Method: n/a
active input acl: ecs                  active output acl: ecs
active input ipv6 acl: n/a             active output ipv6 acl: n/a
ECS Rulebase: default
CBB-Policy: n/a
Bandwidth-Policy: n/a
Firewall-and-Nat Policy : n/a
```

```
   Nat Policy: Not-required
   CF Policy ID: n/a
   TPO Policy: n/a
   active input plcy grp: n/a              active output plcy grp: n/a
   Layer 3 tunneling: Disabled
   prepaid status: Off
   external inline srvr processing: Off
   IPv6 Egress address filtering: Off
   IPv6 DNS Proxy: Disabled
   Proxy DNS Intercept List: n/a
   access-link ip-frag: df-ignore
   ignore DF-bit data-tunnel: On           MIP grat-ARP mode: n/a
   Downlink traffic-policing: Disabled
   Uplink traffic-policing: Disabled
   Downlink traffic-shaping: Disabled
   Uplink traffic-shaping: Disabled
   Radius Accounting Mode: access-flow-based auxiliary-flows
   Downlink CSS Information
     Service/ACL Names: ecs/ecs
     (Active Charging Optimized Mode)
       downlink pkts to svc: 926          downlink pkts from svc: 926
   Uplink CSS Information
     Service/ACL Names: ecs/ecs
     (Active Charging Optimized Mode)
       uplink pkts to svc: 807            uplink pkts from svc: 807
   Collapsed cscf subscribers: none
   input pkts: 807                                 output pkts: 926
   input bytes: 143864                             output bytes: 657989
   input bytes dropped: 0                          output bytes dropped: 0
   input pkts dropped: 0                           output pkts dropped: 0
                                                   output pkts dropped lorc: 0
   input pkts dropped due to lorc    : 0           output pkts dropped due to lorc    :
0
   input bytes dropped due to lorc   : 0
   pk rate from user(bps): 584                     pk rate to user(bps): 398
   ave rate from user(bps): 446                    ave rate to user(bps): 293
   sust rate from user(bps): 446                   sust rate to user(bps): 294
   pk rate from user(pps): 0                       pk rate to user(pps): 0
   ave rate from user(pps): 0                      ave rate to user(pps): 0
```

```
  sust rate from user(pps): 0                    sust rate to user(pps): 0
  link online/active percent: 100
  ipv4 bad hdr: 0                                ipv4 ttl exceeded: 0
  ipv4 fragments sent: 0                         ipv4 could not fragment: 0
  ipv4 input acl drop: 0                         ipv4 output acl drop: 0
  ipv4 bad length trim: 0
  ipv6 input acl drop: 0                         ipv6 output acl drop: 0
  ipv4 input css down drop: 0                    ipv4 output css down drop: 0
  ipv4 input css down drop: 0                    ipv4 output css down drop: 0
  ipv4 output xoff pkts drop: 0                  ipv4 output xoff bytes drop: 0
  ipv6 output xoff pkts drop: 0                  ipv6 output xoff bytes drop: 0
  ipv6 input ehrpd-access drop: 0                ipv6 output ehrpd-access drop: 0
  input pkts dropped (0 mbr): 0                  output pkts dropped (0 mbr): 0
  output pkts dropped lorc  : 0
  ip source violations: 0                        ipv4 output no-flow drop: 0
  ipv6 egress filtered: 0
  ipv4 proxy-dns redirect: 0                     ipv4 proxy-dns pass-thru: 0
  ipv4 proxy-dns drop: 0
  ipv4 proxy-dns redirect tcp connection: 0
  ipv6 bad hdr: 0                                ipv6 bad length trim: 0
  ip source violations no acct: 0
  ip source violations ignored: 0
  ipv4 icmp packets dropped: 0
  APN AMBR Input Pkts Drop: 0                    APN AMBR Output Pkts Drop: 0
  APN AMBR Input Bytes Drop: 0                   APN AMBR Output Bytes Drop: 0
  Access-flows:0
  Num Auxiliary A10s:0

CAE Server Address:
Total subscribers matching specified criteria: 1
```

- To show detailed output of the session for a certain access type, use "show subscriber pgw-only full imsi <imsi>". Different access types can be specified here, but the difference with the **pgw-only** keyword versus the other call types is that the output for the "full" version of **pgw-only** is different than the standard "show sub full" command, whereas for the other call types, the output is the same as the standard "show sub full".

```
[local]epc# show sub pgw-only full imsi 123456000000001

Username: 123456792@web
  Subscriber Type : Home
  Status          : Online/Active
  State           : Connected
  Connect Time    : Tue May  5 14:38:05 2015

  Auto Delete     : No

  Idle time       : 00h39m06s
  MS TimeZone     : -4:00               Daylight Saving Time: +1 hour

  Access Type: gtp-pdn-type-ipv4         Network Type: IP
  Access Tech: eUTRAN                    pgw-service-name: PGW-SVC
  Callid: 00004e31                       IMSI: 123456000000001
  Protocol Username:                     MSISDN: 123456792
  Interface Type: S5S8GTP                Low Access Priority: N/A
  Emergency Bearer Type: N/A
  IMS-media Bearer: No
  S6b Auth Status: N/A
  Access Peer Profile: default
  Acct-session-id (C1): 0A01050100000001
  ThreeGPP2-correlation-id (C2): 0041954B / 002soycr
  Card/Cpu: 3/0                          Sessmgr Instance: 1

  Bearer Type: Default                   Bearer-Id: 5
  Bearer State: Active
  IP allocation type: local pool
  IPv6 allocation type: N/A
  IP address: 192.168.41.1
  Framed Routes: N/A                              Framed Routes Source: N/A
  ULI:
   TAI-ID:
    MCC: 123  MNC: 456
    TAC: 0x1
   ECGI-ID:
    MCC: 123 MNC: 456
    ECI: 0x1
```

```
Accounting mode: None                    APN Selection Mode: Subscribed
MEI: n/a                                 Serving Nw: MCC=123, MNC=456
charging id: 1                              charging chars: normal prepaid
Source context: src                      Destination context: dst
S5/S8/S2b/S2a-APN: web
SGi-APN:   web
APN-OI:    mnc456.mcc123.gprs
Restoration priority level: n/a
traffic flow template: none
IMS Auth Service : IMS_Gx
active input ipv4 acl: ECS               active output ipv4 acl: ECS
active input ipv6 acl:                   active output ipv6 acl:
ECS Rulebase: lab_test

Bearer QoS:
 QCI: 6
 ARP: 0x04
  PCI: 0 (Enabled)
  PL : 1
  PVI: 0 (Enabled)
 MBR Uplink(bps): 0                      MBR Downlink(bps): 0
 GBR Uplink(bps): 0                      GBR Downlink(bps): 0

PCRF Authorized Bearer QoS:
 QCI: n/a
 ARP: n/a
  PCI: n/a
 PL: n/a
  PVI: n/a
 MBR uplink (bps): n/a                        MBR downlink (bps): n/a
 GBR uplink (bps): n/a                        GBR downlink (bps): n/a
 Downlink APN AMBR: n/a                     Uplink APN AMBR: n/a


P-CSCF Address Information:
  Primary IPv6  :   n/a
  Secondary IPv6:   n/a
  Tertiary IPv6 :   n/a
```

```
    Primary IPv4  :   n/a
    Secondary IPv4:   n/a
    Tertiary IPv4 :   n/a

Access Point MAC Address:  N/A

  pgw c-teid: [0x80002001] 2147491841    pgw u-teid: [0x80002001] 2147491841
  sgw c-teid: [0x80002001] 2147491841    sgw u-teid: [0x80000001] 2147483649
  ePDG c-teid: N/A                       ePDG u-teid: N/A
  cgw c-teid: N/A                        cgw u-teid: N/A
  pgw c-addr: 10.1.5.1                   pgw u-addr: 10.1.5.1
  sgw c-addr: 10.1.5.2                   sgw u-addr: 10.1.5.2
  ePDG c-addr: N/A                       ePDG u-addr: N/A
  cgw c-addr: N/A                        cgw u-addr: N/A

  Downlink APN AMBR:      20000 bps    Uplink APN AMBR:      10000 bps
  Mediation context: None                Mediation no early PDUs: Disabled
  Mediation No Interims: Disabled        Mediation Delay PBA: Disabled
  input pkts: 0                                  output pkts: 0
  input bytes: 0                                 output bytes: 0
  input bytes dropped: 0                         output bytes dropped: 0
  input pkts dropped: 0                          output pkts dropped: 0
  input pkts dropped due to lorc    : 0          output pkts dropped due to lorc    :
0
  input bytes dropped due to lorc   : 0
  in packet dropped suspended state: 0           out packet dropped suspended state:
0
  in bytes dropped suspended state: 0            out bytes dropped suspended state: 0
  in packet dropped overcharge protection: 0     out packet dropped overcharge protection:
0
  in bytes dropped overcharge protection: 0      out bytes dropped overcharge protection:
0
  in packet dropped sgw restoration state: 0     out packet dropped sgw restoration state:
0
  in bytes dropped sgw restoration state: 0      out bytes dropped sgw restoration state:
0
  pk rate from user(bps): 0                      pk rate to user(bps): 0
  ave rate from user(bps): 0                     ave rate to user(bps): 0
  sust rate from user(bps): 0                    sust rate to user(bps): 0
```

```
  pk rate from user(pps): 0                    pk rate to user(pps): 0
  ave rate from user(pps): 0                   ave rate to user(pps): 0
  sust rate from user(pps): 0                  sust rate to user(pps): 0
  link online/active percent: 100
  ipv4 bad hdr: 0                              ipv4 ttl exceeded: 0
  ipv4 fragments sent: 0                       ipv4 could not fragment: 0
  ipv4 input acl drop: 0                       ipv4 output acl drop: 0
  ipv4 bad length trim: 0
  ipv4 input mcast drop: 0                     ipv4 input bcast drop: 0
  ipv6 input acl drop: 0                       ipv6 output acl drop: 0
  ipv4 input css down drop: 0                  ipv4 output css down drop: 0
  ipv4 input css down drop: 0                  ipv4 output css down drop: 0
  ipv4 output xoff pkts drop: 0                ipv4 output xoff bytes drop: 0
  ipv6 output xoff pkts drop: 0                ipv6 output xoff bytes drop: 0
  ipv6 input ehrpd-access drop: 0              ipv6 output ehrpd-access drop: 0
  input pkts dropped (0 mbr): 0                output pkts dropped (0 mbr): 0
  ip source violations: 0                      ipv4 output no-flow drop: 0
  ipv6 egress filtered: 0
  ipv4 proxy-dns redirect: 0                   ipv4 proxy-dns pass-thru: 0
  ipv4 proxy-dns drop: 0
  ipv4 proxy-dns redirect tcp connection: 0
  ipv6 bad hdr: 0                              ipv6 bad length trim: 0
  ip source violations no acct: 0
  ip source violations ignored: 0
  dormancy total: 0                            handoff total: 0
  ipv4 icmp packets dropped: 0
  APN AMBR Input Pkts Drop: 0                  APN AMBR Output Pkts Drop: 0
  APN AMBR Input Bytes Drop: 0                 APN AMBR Output Bytes Drop: 0

CAE Server Address:
Total subscribers matching specified criteria: 1
[local]epc#
```

- To show the session data rate, use "show subscriber data-rate". This command shows the data rate from and to the user in bytes and packets per second. As with all "show"sub commands, further qualifiers can be used to narrow to a specific IP pool, sessmgr instance #, etc.

```
[local]ASR5x00> show subscribers data-rate
Tuesday May 05 19:18:39 UTC 2015

Total Subscribers       : 1345001
Active                  : 1345001       Dormant                 : 0
peak rate from user(bps): n/a*          peak rate to user(bps)  : n/a*
ave rate from user(bps) : 864516815     ave rate to user(bps)   : 7237136108
sust rate from user(bps): 851285556     sust rate to user(bps)  : 7208140087
peak rate from user(pps): n/a*          peak rate to user(pps)  : n/a*
ave rate from user(pps) : 547608        ave rate to user(pps)   : 807570
sust rate from user(pps): 558549        sust rate to user(pps)  : 817634
```

- To show the session debug info, use "show subscriber debug-info". This command provides additional engineering level info:

```
[local]epc# show subscribers debug-info msid 123456000000001
username:      callid: 00004e2d    msid: 123456000000001
  Card/Cpu: 3/0
  Sessmgr Instance: 1
  Primary callline:
  Redundancy Status: Original Session
  Checkpoints   Attempts    Success    Last-Attempt   Last-Success
     Full:             0          0             0ms            0ms
     Micro:            0          0             0ms            0ms
  GR Checkpoints Sent
           0 Full Checkpoints
           0 Micro Checkpoints
  Current number of NAT flows checkpointed: 0

  Current state: SMGR_STATE_CONNECTED
  FSM Event trace:
    State                          Event                Num Occurances  Time
    SMGR_STATE_OPEN                SMGR_EVT_NEWCALL                (1)  2015-05-05:14:38:05
    SMGR_STATE_NEWCALL_ARRIVED     SMGR_EVT_ANSWER_CALL            (1)  2015-05-05:14:38:05
    SMGR_STATE_NEWCALL_ANSWERED    SMGR_EVT_LINE_CONNECTED         (1)  2015-05-05:14:38:05
    SMGR_STATE_LINE_CONNECTED      SMGR_EVT_LOWER_LAYER_UP         (1)  2015-05-05:14:38:05
```

```
    CLP State Trace:
             State                                                EBI's Associated
Time

   Sub Session State Trace:
           EBI ID                                 State                          TimeStamp

   Overcharge Protection Statistics:
     Downlink Packets Allowed Without Charging:          0
     Downlink Bytes Allowed Without Charging:            0


   NAT Policy NAT44: Not-required
   NAT Policy NAT64: Not-required

   Data Reorder statistics
          Total timer expiry:       0         Total flush (tmr expiry):  0
          Total no buffers:         0         Total flush (no buffers):  0
          Total flush (queue full): 0         Total flush (out of range):0
          Total flush (svc change): 0         Total out-of-seq pkt drop: 0

          Total out-of-seq arrived: 0

   IPv4 Reassembly Statistics:
          Success:                  0         In Progress:               0
          Failure (timeout):        0         Failure (no buffers):      0
          Failure (other reasons):  0

   Re-addressed Session Entries:
          Allowed:                  2000      Current:                   0
          Added:                    0         Deleted:                   0
          Revoked for use by different subscriber: 0
   TCP Proxy DNS Info entries 0
   IPv4 ACL applied:
          active input acl:                   number of rules: 0
          active output acl:                  number of rules: 0
   ACL caching statistics:
          input packets:            0         input cache hits:          0
          output packets:           0         output cache hits:         0
```

```
  IPv6 ACL applied:
         active input ipv6 acl:                    number of rules: 0
         active output ipv6 acl:                   number of rules: 0
  IPv6 ACL caching statistics:
         input cache hits:          0          output cache hits:          0
  Total number of ACL reload:         0
  Total number of ACS session deleted on ACL reload:         0

  NEMO Detail:
    Peer bond:    NO                      Peer Callid: 00000000
    Mode:         N/A                     Multi-VRF Enabled: NO

  sessmgr NPU Flow Details:
    Flow Id    Flow Type                  Nat Realm                  VPN Id

  Private IP NPU flow timeout (Seconds) : n/a
  ACS PCP Service: n/a

username:      callid: 00004e30    msid: 123456000000001
  Card/Cpu: 3/0
  Sessmgr Instance: 1
  Primary callline:
  Redundancy Status: Original Session
  Checkpoints   Attempts    Success    Last-Attempt   Last-Success
     Full:             1          0        376100ms            0ms
     Micro:            0          0              0ms           0ms
  GR Checkpoints Sent
           0 Full Checkpoints
           0 Micro Checkpoints
  Current number of NAT flows checkpointed: 0

  Current state: SMGR_STATE_CONNECTED
  FSM Event trace:
    State                           Event                Num Occurrences  Time
    SMGR_STATE_OPEN                 SMGR_EVT_NEWCALL               (1)  2015-05-05:14:38:05
    SMGR_STATE_NEWCALL_ARRIVED      SMGR_EVT_ANSWER_CALL           (1)  2015-05-05:14:38:05
    SMGR_STATE_NEWCALL_ANSWERED     SMGR_EVT_LINE_CONNECTED        (1)  2015-05-05:14:38:05
    SMGR_STATE_LINE_CONNECTED       SMGR_EVT_LOWER_LAYER_UP        (1)  2015-05-05:14:38:05
```

```
    CLP State Trace:
             State                                                EBI's Associated
Time

   Sub Session State Trace:
           EBI ID                                 State                          TimeStamp

   Overcharge Protection Statistics:
     Downlink Packets Allowed Without Charging:          0
     Downlink Bytes Allowed Without Charging:            0


   NAT Policy NAT44: Not-required
   NAT Policy NAT64: Not-required

   Data Reorder statistics
          Total timer expiry:       0         Total flush (tmr expiry):  0
          Total no buffers:         0         Total flush (no buffers):  0
          Total flush (queue full): 0         Total flush (out of range):0
          Total flush (svc change): 0         Total out-of-seq pkt drop: 0

          Total out-of-seq arrived: 0

   IPv4 Reassembly Statistics:
          Success:                  0         In Progress:               0
          Failure (timeout):        0         Failure (no buffers):      0
          Failure (other reasons):  0

   Re-addressed Session Entries:
          Allowed:                  2000      Current:                   0
          Added:                    0         Deleted:                   0
          Revoked for use by different subscriber: 0
   TCP Proxy DNS Info entries 0
   IPv4 ACL applied:
          active input acl:                   number of rules: 0
          active output acl:                  number of rules: 0
   ACL caching statistics:
          input packets:            0         input cache hits:          0
          output packets:           0         output cache hits:         0
```

```
  IPv6 ACL applied:
         active input ipv6 acl:                    number of rules: 0
         active output ipv6 acl:                   number of rules: 0
  IPv6 ACL caching statistics:
         input cache hits:          0          output cache hits:          0
  Total number of ACL reload:         0
  Total number of ACS session deleted on ACL reload:         0

  NEMO Detail:
    Peer bond:     NO                      Peer Callid: 00000000
    Mode:          N/A                     Multi-VRF Enabled: NO

  sessmgr NPU Flow Details:
    Flow Id     Flow Type                  Nat Realm                  VPN Id

  Private IP NPU flow timeout (Seconds) : n/a
  ACS PCP Service: n/a

username: 123456792@web     callid: 00004e31    msid: 123456000000001
  Card/Cpu: 3/0
  Sessmgr Instance: 1
  Primary callline:
  Redundancy Status: Original Session
  Checkpoints   Attempts    Success    Last-Attempt   Last-Success
     Full:             1          0        376100ms            0ms
     Micro:            0          0              0ms           0ms
  GR Checkpoints Sent
           0 Full Checkpoints
           0 Micro Checkpoints
  Current number of NAT flows checkpointed: 0

  Current state: SMGR_STATE_CONNECTED
  FSM Event trace:
    State                            Event                Num Occurances  Time
    SMGR_STATE_OPEN                  SMGR_EVT_NEWCALL                (1)  2015-05-05:14:38:05
    SMGR_STATE_NEWCALL_ARRIVED       SMGR_EVT_IPADDR_ALLOC_SUCCESS   (1)  2015-05-05:14:38:05
    SMGR_STATE_NEWCALL_ARRIVED       SMGR_EVT_ANSWER_CALL            (1)  2015-05-05:14:38:05
    SMGR_STATE_NEWCALL_ANSWERED      SMGR_EVT_LINE_CONNECTED         (1)  2015-05-05:14:38:05
    SMGR_STATE_LINE_CONNECTED        SMGR_EVT_LOWER_LAYER_UP         (1)  2015-05-05:14:38:05
```

```
    CLP State Trace:
             State                                          EBI's Associated
Time
     SMGR_CLP_EVT_PGW_CREATE_SESSION_REQ              5  -  -  -  -  -  -  -  -  -  -    2015-
05-05:14:38:05
     CLI_MAPPED_SMGR_SGX_BIND                         -  -  -  -  -  -  -  -  -  -  -    2015-
05-05:14:38:05
     CLI_MAPPED_SGX_EVT_SESS_SETUP_REQ                -  -  -  -  -  -  -  -  -  -  -    2015-
05-05:14:38:05
     CLI_MAPPED_SMGR_SEF_BIND                         -  -  -  -  -  -  -  -  -  -  -    2015-
05-05:14:38:05
     CLI_MAPPED_SEF_EVT_SESS_SETUP_REQ                -  -  -  -  -  -  -  -  -  -  -    2015-
05-05:14:38:05
     CLI_MAPPED_SEF_EVT_SESS_SETUP_RSP                -  -  -  -  -  -  -  -  -  -  -    2015-
05-05:14:38:05
     CLI_MAPPED_SGX_EVT_POLICY_STATUS_IND             -  -  -  -  -  -  -  -  -  -  -    2015-
05-05:14:38:05
     SMGR_CLP_EVT_PGW_CREATE_SESSION_RSP              5  -  -  -  -  -  -  -  -  -  -    2015-
05-05:14:38:05


   Sub Session State Trace:
           EBI ID                              State                        TimeStamp
           5                          SMGR_STATE_NEWCALL_ARRIVED        2015-05-05:14:38:05
           5                          SMGR_STATE_CONNECTED              2015-05-05:14:38:05

   Overcharge Protection Statistics:
     Downlink Packets Allowed Without Charging:          0
     Downlink Bytes Allowed Without Charging:            0


   NAT Policy NAT44: Not-required
   NAT Policy NAT64: Not-required

   Data Reorder statistics
          Total timer expiry:       0         Total flush (tmr expiry):  0
          Total no buffers:         0         Total flush (no buffers):  0
          Total flush (queue full): 0         Total flush (out of range):0
          Total flush (svc change): 0         Total out-of-seq pkt drop: 0
```

```
       Total out-of-seq arrived: 0

IPv4 Reassembly Statistics:
       Success:                  0          In Progress:               0
       Failure (timeout):        0          Failure (no buffers):      0
       Failure (other reasons):  0

Re-addressed Session Entries:
       Allowed:                  2000       Current:                   0
       Added:                    0          Deleted:                   0
       Revoked for use by different subscriber: 0
TCP Proxy DNS Info entries 0
IPv4 ACL applied:
       active input acl:  ECS               number of rules: 2
       active output acl: ECS               number of rules: 2
ACL caching statistics:
       input packets:            0          input cache hits:          0
       output packets:           0          output cache hits:         0
IPv6 ACL applied:
       active input ipv6 acl:                    number of rules: 0
       active output ipv6 acl:                   number of rules: 0
IPv6 ACL caching statistics:
       input cache hits:         0          output cache hits:         0
Total number of ACL reload:        0
Total number of ACS session deleted on ACL reload:        0

NEMO Detail:
  Peer bond:    NO                     Peer Callid: 00000000
  Mode:         N/A                    Multi-VRF Enabled: NO

sessmgr NPU Flow Details:
  Flow Id    Flow Type                 Nat Realm                  VPN Id
  65         IPV4_FLOW                 n/a                        0x3

Private IP NPU flow timeout (Seconds) : n/a
ACS PCP Service: n/a
```

- To show the active charging sessions on the chassis, use "show active-charging session summary":

```
[local]ASR5x00> show active-charging sessions summary

Total Active Charging Sessions: 1363079
  Uplink Bytes:             8081135415427  Downlink Bytes:         73118353480525
  Uplink Packets:             47222716272  Downlink Packets:          67987933865

  Current IP Sessions:             506031  Current ICMP Sessions:            4346
  Current IPv6 Sessions:           311123  Current ICMPv6 Sessions:         16910
  Current TCP Sessions:            530663  Current UDP Sessions:           113118
  Current HTTP Sessions:           126225  Current HTTPS Sessions:         308430
  Current FTP Sessions:                39  Current POP3 Sessions:               0
  Current SMTP Sessions:                0  Current SIP Sessions:            29842
  Current RTSP Sessions:                1  Current RTP Sessions:                1
  Current RTCP Sessions:                1  Current IMAP Sessions:               0
  Current WSP-CO Sessions:              0  Current WSP-CL Sessions:             0
  Current MMS Sessions:                 0  Current DNS Sessions:               0
  Current PPTP Sessions:               67  Current PPTP-GRE Sessions:          65
  Current P2P Sessions:                 0  Current H323 Sessions:               1
  Current TFTP Sessions:                0
  Current UNKNOWN Sessions:        529974
```

- To see the active charging session options for a specific session, use "show active-charging sessions full imsi <imsi>":

```
[local]epc# show active-charging sessions full imsi 123456000000001

  Session-ID:                      1:6  Username:             123456792@web
  Callid:                     00004e31  IMSI/MSID:          123456000000001
  MSISDN:                                                      123456792
  SessMgr Instance:                 1  SessMgr Card/Cpu:              3/0
  Client-IP:                                                192.168.41.1
  NAS-IP:                                                        0.0.0.0
  Access-NAS-IP(FA):
  NAS-PORT:                         0  NSAPI:                           5
  Acct-Session-ID:                                    0A01050100000001
```

```
NAS-ID:                                                    n/a
Access-NAS-ID(FA):                                         n/a
3GPP2-BSID:                                                n/a
Access-Correlation-ID(FA):                                 n/a
3GPP2-Correlation-ID:                                      n/a
MEID:                                                      n/a
Carrier-ID:                  123456  ESN:                  n/a
PCO:
  Value/Interface:              n/a
Uplink Bytes:                    0  Downlink Bytes:              0
Uplink Packets:                  0  Downlink Packets:            0
Injected Uplink Packets:         0  Injected Downlink Packets:   0
Buffered Uplink Packets:         0  Buffered Downlink Packets:   0
Buffered Uplink Bytes:           0  Buffered Downlink Bytes:     0
Uplink Packets in Buffer:        0  Downlink Packets in Buffer:  0
Buff Over-limit Uplink Pkts:     0  Buff Over-limit Downlink Pkts: 0
Dropped Uplink Packets:          0  Dropped Downlink Packets:    0
Uplink Out of Order Packets:     0  Downlink Out of Order Packets: 0
Dyn FUI Redirected Flows:        0  Dyn FUI Discarded Pkts:      0
ITC Terminated Flows:            0  ITC Redirected Flows:        0
ITC Dropped Packets:             0  ITC ToS Remarked Packets:    0
ITC Dropped Upl Pkts:            0  ITC Dropped Dnl Pkts:        0
Flow action Terminated Flows:                                   0
PP Flow action Terminated Flows:                                0
PP Dropped Packets:                                             0
CC Dropped Uplink Packets:       0  CC Dropped Uplink Bytes:     0
CC Dropped Downlink Packets:     0  CC Dropped Downlink Bytes:   0
NRUPC Req Made:                  0  NRUPC Req Success:           0
NRUPC Req Failed:                0  NRUPC Req Time Out:          0
Bearer Bandwidth Limiting: Enabled
Uplink MBR (bps):                0  Downlink MBR (bps):          0
Uplink GBR (bps):                0  Downlink GBR (bps):          0
Uplink Burst (bytes):            0  Downlink Burst (bytes):      0
Dropped Uplink Pkts:             0  Dropped Downlink Pkts:       0
Creation Time:                          Tuesday May 05 18:38:05 GMT 2015
Last Pkt Time:
Duration:                                                 00h:07m:19s
Rule Base name:                                              lab_test
URL-Redir First-Request-Only:                                   n/a
```

```
Tethering-detection notification:                                  Disabled
Tethering-detected notification sent:                                 n/a
Service Detection:
  Session Update:
    QOS Upgrade Triggered:          No
Bandwidth Policy:                                                     n/a
Bandwidth Policy Fallback Applied:                                     No
FW-and-NAT Policy:                                                    n/a
FW-and-NAT Policy ID:                                                 n/a
Firewall Policy IPv4:                                                 n/a
Firewall Policy IPv6:                                                 n/a
NAT Policy NAT44:                                                     n/a
NAT Policy NAT64:                                                     n/a
Bypass NAT Flow Present:                                              n/a
Congestion Mgmt Policy:                                               n/a
CF Policy ID:                                                         n/a
Old CF Policy ID:                                                     n/a
Dynamic Charging:                                                  Enabled
Dynamic Chrg Msg Received:         0  Rule Definitions Received:        0
Installs Received:                 0  Removes Received:                 0
Installs Succeeded:                0  Installs Failed:                  0
Removes Succeeded:                 0  Removes Failed:                   0
Uplink Dynamic Rule Packets:       0  Downlink Dynamic Rule Packets:    0
Dynamic Charging Packet Drop statistics:
PCC Rule BW Limit Upl Pkts:        0  PCC Rule BW Limit Dnl Pkts:       0
PCC Rule Gating Upl Pkts:          0  PCC Rule Gating Dnl Pkts:         0
RuleMatch Fail Upl Pkts:           0  RuleMatch Fail Dnl Pkts:          0
Credit-Control:                                                     Off
Event-Triggers:
QoS Renegotiate Up:                0  QoS Renegotiate Dn:               0
TCP Proxy Flows Requests:          0  TCP Proxy Flows Request Success:  0
Disable TCP Proxy Flows Requests:  0  Disable TCP Proxy Flows Success:  0
Current TCP Proxy Flows:           0  Total TCP Proxy Flows:            0
TCP-proxy reset for non-SYN flows:                                     0
Current IP Flows:                  0  Current ICMP Flows:               0
Current IPv6 Flows:                0  Current ICMPv6 Flows:             0
Current TCP Flows:                 0  Current UDP Flows:               0
Current HTTP Flows:                0  Current HTTPS Flows:              0
Current FTP Flows:                 0  Current POP3 Flows:              0
```

```
  Current SMTP Flows:                0  Current SIP Flows:                 0
  Current RTSP Flows:                0  Current RTP Flows:                 0
  Current RTCP Flows:                0  Current IMAP Flows:                0
  Current WSP-CO Flows:              0  Current WSP-CL Flows:              0
  Current MMS Flows:                 0  Current DNS Flows:                 0
  Current PPTP-GRE Flows:            0  Current PPTP Flows:                0
  Current P2P Flows:                 0  Current H323 Flows:                0
  Current TFTP Flows:                0
  Current UNKNOWN Flows:             0
  Max (L3) Flows:                    0
  Max Flows Timestamp:                                                 n/a

  TCP-Proxy Session Stats:                                             n/a

  Link Monitoring Average Throughput:                                0 kbps
  Link Monitoring Average RTT:                                       0 ms

  Charging Updates:                                                    n/a
No Charging ruledef(s) match the specified criteria
No Firewall ruledef(s) match the specified criteria

  Post-processing Rulestats : No Post-processing ruledef(s) match the specified criteria
Dynamic Charging Rule Name Statistics: n/a
Total Dynamic Rules:             0
Total Predefined Rules:          0
Total Firewall Predefined Rules: 0
Charging-Updates Statistics:         n/a
Dynamic Charging Rule Definition(s) Configured: n/a
Predefined Rules Enabled List: n/a
Predefined Firewall Rules Enabled List: n/a

Total acs sessions matching specified criteria: 1
```

- To see the status of the sessions on the chassis, use "show session progress". This command will show the total sessions and break out the various access types:

```
[local]ASR5x00> show session progress
 1367837 In-progress calls
 1367837 In-progress active calls
       0 In-progress dormant calls
       0 In-progress always-on calls
      14 In-progress calls @ ARRIVED state
       0 In-progress calls @ CSCF-CALL-ARRIVED state
       0 In-progress calls @ CSCF-REGISTERING state
       0 In-progress calls @ CSCF-REGISTERED state
       0 In-progress calls @ LCP-NEG state
       0 In-progress calls @ LCP-UP state
       0 In-progress calls @ AUTHENTICATING state
       0 In-progress calls @ BCMCS SERVICE AUTHENTICATING state
       0 In-progress calls @ AUTHENTICATED state
       0 In-progress calls @ PDG AUTHORIZING state
       0 In-progress calls @ PDG AUTHORIZED state
      10 In-progress calls @ IMS AUTHORIZING state
      13 In-progress calls @ IMS AUTHORIZED state
       0 In-progress calls @ MBMS UE AUTHORIZING state
       0 In-progress calls @ MBMS BEARER AUTHORIZING state
       0 In-progress calls @ DHCP PENDING state
       0 In-progress calls @ L2TP-LAC CONNECTING state
       0 In-progress calls @ MBMS BEARER CONNECTING state
       0 In-progress calls @ CSCF-CALL-CONNECTING state
       0 In-progress calls @ IPCP-UP state
       0 In-progress calls @ NON-ANCHOR CONNECTED state
       0 In-progress calls @ AUTH-ONLY CONNECTED state
       0 In-progress calls @ SIMPLE-IPv4 CONNECTED state
       0 In-progress calls @ SIMPLE-IPv6 CONNECTED state
       0 In-progress calls @ SIMPLE-IPv4+IPv6 CONNECTED state
       0 In-progress calls @ MOBILE-IPv4 CONNECTED state
       0 In-progress calls @ MOBILE-IPv6 CONNECTED state
       0 In-progress calls @ GTP CONNECTING state
       0 In-progress calls @ GTP CONNECTED state
       0 In-progress calls @ PROXY-MOBILE-IP CONNECTING state
       0 In-progress calls @ PROXY-MOBILE-IP CONNECTED state
```

```
       0 In-progress calls @ EPDG RE-AUTHORIZING state
       0 In-progress calls @ HA-IPSEC CONNECTED state
       0 In-progress calls @ L2TP-LAC CONNECTED state
       0 In-progress calls @ HNBGW CONNECTED state
       0 In-progress calls @ PDP-TYPE-PPP CONNECTED state
       0 In-progress calls @ IPSG CONNECTED state
       0 In-progress calls @ BCMCS CONNECTED state
       0 In-progress calls @ PCC CONNECTED state
       0 In-progress calls @ MBMS UE CONNECTED state
       0 In-progress calls @ MBMS BEARER CONNECTED state
       0 In-progress calls @ PAGING CONNECTED state
    1838 In-progress calls @ PDN-TYPE-IPv4 CONNECTED state
  785413 In-progress calls @ PDN-TYPE-IPv6 CONNECTED state
  580538 In-progress calls @ PDN-TYPE-IPv4+IPv6 CONNECTED state
       0 In-progress calls @ CSCF-CALL-CONNECTED  state
       0 In-progress calls @ MME ATTACHED state
       0 In-progress calls @ HENBGW CONNECTED state
       0 In-progress calls @ CSCF-CALL-DISCONNECTING state
      11 In-progress calls @ DISCONNECTING state
```

Please notice the "**show session subsystem data-info verbose**" command will provide visibility for **In-progress calls** on a per session manager (sessmgr) basis.

- To see the history of sessions for the last 48 hours, use "**show session counters historical all**". This command will show sessions that arrived within a 15 minute interval, including calls rejected and failed. This can be a good historical record showing where a problem occurred and the related impact. The command applies to all calls on the chassis and so if there is more than one call type, it will not distinguish between them, and so one should use other stats that are protocol specific in those scenarios.

```
 [local]AR5x00> show session counters historical all
                          ------------------- Number of Calls ------------------
                             Intv  Timestamp              Arrived   Rejected  Connected    Disconn
Failed      Handoffs      Renewals
 ----  ------------------- ---------- ---------- ---------- ---------- ---------- ------------- -------------
    1  2015:05:05:19:45:00     179446         99     117645     105080         83        166277         34121
    2  2015:05:05:19:30:00     155948         66     107183     105022         63        145068         20957
    3  2015:05:05:19:15:00     144654         97      96493     109319         81        145534         17761
    4  2015:05:05:19:00:00     141042         89      92915     108563         76        141286         18653
```

5	2015:05:05:18:45:00	145822	60	92602	113185	59	149698	20583
6	2015:05:05:18:30:00	166377	103	102026	113575	81	167989	33319
7	2015:05:05:18:15:00	183108	98	113159	112063	107	179286	38824
8	2015:05:05:18:00:00	186720	160	117990	119896	132	176960	40968
9	2015:05:05:17:45:00	188923	117	119304	120118	111	180304	44595
10	2015:05:05:17:30:00	183393	118	113965	113482	128	178033	38427

- To see the various disconnect reasons for the sessions, use "show session disconnect-reasons":

```
[local]ASR5x00> show session disconnect-reasons
Session Disconnect Statistics

Total Disconnects: 2484440

Disconnect Reason                                    Num Disc  Percentage
---------------------------------------------------  ----------  ----------
Remote-disconnect                                     1738989    69.99521
Inactivity-timeout                                     108253     4.35724
Absolute-timeout                                          194     0.00781
Invalid-source-IP-address                               21431     0.86261
MIP-remote-dereg                                       212688     8.56080
MIP-lifetime-expiry                                     10886     0.43817
MIP-auth-failure                                           21     0.00085
Gtp-unknown-pdp-addr-or-pdp-type                          346     0.01393
Local-purge                                               288     0.01159
Admin-AAA-disconnect                                   307987    12.39664
failed-auth-with-charging-svc                             844     0.03397
gtp-user-auth-failed                                       29     0.00117
ims-authorization-failed                                 1737     0.06992
Gtp-context-replacement                                   344     0.01385
ims-authorization-revoked                                1308     0.05265
No-response                                                6     0.00024
Re-Auth-failed                                             7     0.00028
disconnect-from-policy-server                          73009     2.93865
s6b-auth-failed                                           95     0.00382
gtpu-err-ind                                            5978     0.24062
```

- To see the setup time for the sessions, use "show session setuptime". This command can help determine if there are delays in the setup time for the sessions, which could be caused by problems both internal and external to the chassis:

```
[local]ASR5x00> show session setuptime

     Setup Time          Count    Setup Time          Count
     ----------          -----    ----------          -----
         <100ms         151114       1..2sec         879708
     100..200ms       58401693       2..3sec           6050
     200..300ms      123407703       3..4sec         216686
     300..400ms       77942751       4..6sec           6195
     400..500ms      142698305       6..8sec          51144
     500..600ms      109160078      8..10sec           7334
     600..700ms       36781296     10..12sec            355
     700..800ms       12257054     12..14sec              0
     800..900ms        4280789     14..16sec              0
    900..1000ms        1479314     16..18sec              0
                                      >18sec              0
```

- To see the details for the various subsystems for the sessions, use "show session subsystem [facility <sessmgr>] [instance <instance> | all]". This command provides engineering level statistics for various tasks including session manager (sessmgr), aaa manager (aaamgr), etc. and is very powerful.

```
[local]ASR5x00> show session subsystem | more
398 Session Managers
850609049 Total calls arrived          433610 Total calls rejected
572301621 Total calls connected        420010 Total calls failed
566101211 Total calls disconnected   846474152 Total handoffs
205547155 Total renewals
       0 Total active-to-idle transitions
       0 Total idle-to-active transitions
100982727 Total auth success            85652 Total auth failure
 1407997 Current aaa active sessions   28342 Current aaa deleting sessions
   56723 Current aaa acct pending
   56723/11827200 aaa acct items (used/max)
    7069/40320 aaa buffer (used in MB/max in MB)
```

```
535333746 Total aaa cancel auth
       78 Total aaa acct purged
       78 Total radius acct purged          0 Total gtpp acct purged
        0 Total LCP up                      0 Total IPCP up
        0 Total IPv6CP up
92097051 Total source violation             0 Total keepalive failure
103581566 Empty fwd pkt sessions     98466572 Empty rev pkt sessions [snip]
```

Session logging

Overview

An overview of different logging options related to all software processes and subscriber traces are covered in this chapter.

Logging Description

There are four types of logging that can be configured and viewed on the system, and a few of them are set from config mode.

Runtime logging: is enabled upon system startup for all facilities with logging level set to error by default. These logs are helpful in determining system status and capture information for all facilities currently in use. This logging is enabled / disabled via config mode, e.g.

```
config
logging filter runtime facility <facility name> level <level> [critical-info |no-critical-info]
end
```

Replace **<facility name>** with the relevant one from the available list.

```
[local]asr5000(config)# logging filter runtime facility ?
  MPLS                 - MPLS protocol logging facility
  TESTCTRL             - TESTCTRL logging facility
  TESTMGR              - TESTMGR logging facility
  a10                  - A10 interface logging facility
  a11                  - A11 interface logging facility
  a11mgr               - A11 Manager logging facility
  aaa-client           - Accounting and authentication client logging
                         facility
  :
  vpn                  - Virtual Private Network logging facility
  wimax-data           - WiMAX DATA
```

```
  wimax-r6              - WiMAX R6
[local]asr5000(config)#
```

Logging Monitor: can be enabled to record all activities associated with a particular session including the same output as captured with monitor subscriber, plus all of the chassis internal processing, which can be very extensive. This option is helpful in troubleshooting intermittent issues pertaining to a subscriber and is useful when there is a need to keep trace running for a longer time unattended. The options available are msid / username or ip address. It will not capture an existing call if enabled while the call is connected - the call must reconnect to be captured. This logging is enabled / disabled via config mode, e.g.

To enable:

```
config
logging monitor msid <Mobile Station Identifier number>
end
```

To remove:

```
config
no logging monitor msid <Mobile Station Identifier number>
end
```

Trace logging: can be used to quickly isolate issues that may arise for a specific session. Traces can be taken for a specific call identification (callid) number, IP address, mobile station identification (MSID) number, or username. Trace logging can only be enabled successfully for currently connected subscriber sessions (which is why it has the option to monitor by call id, whereas logging monitor does not).

NOTE: Trace logs impact session processing. They should be implemented for debug purposes only.

Use the following example to configure trace logs in the Exec mode:

```
[local]<hostname>#logging trace { callid call_id | ipaddr ip_address | msid ms_id | username
username }
```

Once all of the necessary information has been gathered, the trace log can be stopped by entering the following command:

```
[local]<hostname>#no logging trace { callid call_id | ipaddr ip_address | msid ms_id |
username username }
```

Active logging: can be used for troubleshooting active sessions. This can be configured on a per administrative user basis (i.e. each administrative user can have their own individual active logging sessions). Active logs configured by an administrative user in one CLI instance cannot be viewed by an administrative user in a different CLI instance. Each active log can be configured with filter and display properties that are independent of those configured globally for the system in the runtime log. Active logs are displayed in real time, on the management user's terminal display, as they are generated. The logging configured is temporary while the CLI session is active, and is lost if the session times out or the CLI window is closed. e.g. type "`logging active`" to start active logging and "`no logging active`" to stop it.

Active logging can be executed with the following command:

```
logging filter active facility <facility name> level <1-7>
```

Here is an example of the command and output:

```
[local]asr5000# logging filter active facility

  a10                   - A10 interface logging facility
  a11                   - A11 interface logging facility
  a11mgr                - A11 Manager logging facility
  :
  vpn                   - Virtual Private Network logging facility
  wimax-data            - WiMAX DATA
  wimax-r6              - WiMAX R6

[local]asr5000# logging filter active facility sessmgr level
  critical              - Level 1: Reports critical errors contained in log file
```

```
  error                - Level 2: Reports error notifications contained in log file
  warning              - Level 3: Reports warning messages contained in log file
  unusual              - Level 4: Reports unexpected errors contained in log file
  info                 - Level 5: Reports informational messages contained in log file
  trace                - Level 6: Reports trace information contained in log file
  debug                - Level 7: Reports debug information contained in log file
[local]asr5000# logging active
```

critical: logs only those events indicating a serious error has occurred and is causing the system or a system component to cease functioning. This is the highest severity level.

error: logs events that indicate an error has occurred that is causing the system or a system component to operate in a degraded state. This level also logs events with a higher severity level.

warning: logs events that may indicate a potential problem. This level also logs events with a higher severity level.

unusual: logs events that are very unusual and may need to be investigated. This level also logs events with a higher severity level.

info: logs informational events and events with a higher severity level.

trace: logs events useful for tracing and events with a higher severity level.

debug: logs all events regardless of the severity.

Warning: trace and debug level logging can be very verbose. It is recommended to run this during the scheduled maintenance hours. Please contact Cisco Support prior to running this on a production system. After any troubleshooting activity always disable logging with "no logging active"

Routing Protocol

Static Routing

Overview

This section covers static routing on ASR 5000/5500 as well as troubleshooting commands and an example scenario.

Refer to the "ARP Troubleshooting" section for layer two connectivity issues.

Configuration

ASR 5000/5500 supports static routes similar to conventional routers. The static routes configuration is per context.

ip route [network/netmask] [nexthop-address] [interface name]

```
[pgw]asr5000(config-ctx)# ip route 10.0.0.0/24 192.168.1.2 s5
```

NOTE: The interface name needs to be specified, and match an interface in the same context, when configuring the static route.

CLIs for troubleshooting

- show ip route
- show ip static-route
- show ip interface

Below is a sample output of "show ip static-route".

```
[pgw]asr5000# show ip static-route
"*" indicates the Best or Used route.
 Destination         Nexthop          Protocol   Prec Cost Interface
*10.0.0.0/24         192.168.1.2      static     1    0    s5
Total route count: 1
```

Case study

What happens if there are 2 static route entries for same route?

For example, in the following static route entries, which route will be used?

```
ip route 100.0.0.0 255.255.255.0 172.25.10.2 int1
ip route 100.0.0.0 255.255.255.0 172.25.20.2 int2
```

The routing table will look like this. Both routes are selected as the best route.

```
[PGW]asr5000# show ip route
"*" indicates the Best or Used route.  S indicates Stale.

 Destination         Nexthop          Protocol   Prec Cost Interface
*100.0.0.0/24        172.25.10.2      static     1    0    int1
*100.0.0.0/24        172.25.20.2      static     1    0    int2
```

In this case, traffic will be load-balanced across the routes, based on multiple parameters like SA, DA, Port, etc.

OSPF Routing

Overview

This section covers OSPF routing on ASR 5000 / 5500 with multiple troubleshooting commands and two scenarios.

ASR 5x00 supports two versions of the Open Shortest Path First (OSPF) protocol – OSPF Version 2 and OSPF Version 3.

Refer to the "ARP Troubleshooting" section for layer two connectivity issues.

OSPF Version 2

OSPF is a link-state routing protocol that employs an interior gateway protocol (IGP) to route IP packets using the shortest path first, based solely on the destination IP address in the IP packet header. OSPF-routed IP packets are not encapsulated in any additional protocol headers as they transit the network.

An Autonomous System (AS), or Domain, is defined as a group of networks within a common routing infrastructure. OSPF is a dynamic routing protocol that quickly detects topological changes in the Autonomous System (AS) (such as router interface failures) and calculates new loop-free routes after a period of convergence.

In a link-state routing protocol, each router maintains a database, referred to as the link-state database, that describes the Autonomous System's topology. Each participating router has an identical database. Each entry in this database is a particular router's local state and the router distributes its local state throughout the AS via multicast. All routers run the same algorithm in parallel. From the link-state database, each router constructs a tree of shortest paths with itself as root to each destination in the AS. Externally derived routing information appears on the tree as leaves. The cost of a route is described by a single dimensionless metric.

OSPF allows sets of networks to be grouped together. Such a grouping is called an area. The topology of this area is hidden from the rest of the AS, which enables a significant reduction in routing traffic. Also, routing within the area is determined only by the area‘s own topology, lending the area protection from bad routing data. An area is a generalization of an IP subnet-

ted network. OSPF enables the flexible configuration of IP subnets so that each route distributed by OSPF has a destination and mask. Two different subnets of the same IP network number may have different masks (i.e. variable-length sub-netting). A packet is routed to the best (longest or most specific) match. Externally derived routing data (for example, routes learned from an exterior protocol such as BGP) can be tagged by the advertising router, enabling the passing of additional information between routers on the boundary of the AS. OSPF uses a link-state algorithm to build and calculate the shortest path to all known destinations.

Implementing basic OSPFv2 Configuration

OSPF is enabled over specific interfaces by specifying the networks on which OSPF will run. Redistributing routes into OSPF is an optional configuration step by which any routes from another protocol that meet a specified criterion, such as route type, metric, or rule within a route-map, are redistributed using the OSPFv2 protocol to all OSPF areas.

Within one VRF or "context" configured in the ASR 5x00, only one instance of OSPF is spawned at a time.

OSPFv3

OSPFv3 is very similar to OSPF version 2. However, OSPFv3 expands on OSPF version 2 to provide support for IPv6 routing prefixes and the larger size of IPv6 addresses. OSPFv3 dynamically learns and advertises (redistributes) IPv6 routes within an OSPFv3 routing domain. Enabling OSPFv3 on an interface will cause a routing process and its associated configuration to be created.

Redistributing routes into OSPFv3 (optional configuration) means any routes from another protocol that meet a specified criterion, such as route type, metric, or rule within a route-map, are redistributed using the OSPFv3 protocol to all OSPF areas. In ASR 5500, the designer has the flexibility to configure and invoke the functionality of OSPFv2, OSPFv3, static routes – for IPv4 and IPv6, depending on the specific network design needs.

CLI for troubleshooting

- show snmp trap history |grep -i OSPFNeighborDown
- show logs | grep -i ospf

OSPF related commands can be run only from the context where OSPF is configured. Given below are some CLIs that can be used for troubleshooting on an ASR 5x00 platform followed by sample output from a lab setup.

- show ip ospf
- show ip ospf neighbor details
- show ip ospf database verbose
- show ip ospf routes
- ping <ospf neighbor ip> src <interface / loopback address>

For capturing active logs

- logging filter active facility ospf level debug
- logging active

 # show ip ospf

```
[gi]SPGW-2# show ip ospf
OSPF Routing Process 0, Router ID: 192.168.7.2
Supports only single TOS (TOS0) routes
This implementation conforms to RFC2328
Graceful-Restart:       Capability: Enabled,   Router Mode: Disabled
SPF schedule delay 5 secs, Hold time between two SPFs 10 secs
Refresh timer 10 secs
This router is an ASBR (injecting external routing information)
Number of external LSA 2
Area ID: 0.0.0.0 (Backbone)
  Number of interfaces in this area: Total: 1,   Active: 1
  Number of fully adjacent neighbors in this area: 1
  Area has no authentication
  SPF algorithm executed 579619 times
  Number of LSA 3
[gi]SPGW-2#
```

 # show ip ospf neighbor details

```
[gi]SPGW-2# show ip ospf neighbor details
```

```
Neighbor: 192.168.3.101      Interface address: 192.168.10.227
  Area:   0.0.0.0            via Interface:     gi
  Priority:                  1
  State:                     Full/Backup
  State Changes:             8
  DR:                        192.168.10.249
  BDR:                       192.168.10.227
  Dead Timer Due:            00:00:38
  Options:                   0x42 (*|O|-|-|-|E|-)
  Crypt Seq #:               0
  Uptime:                    953:51:0
  Database Summary List:     0
  LS Request List:           0
  LS Retransmit List:        0
  Inactivity Timer:          on
  DD Retransmit Timer:       off
  LS Req. Retransmit Timer:  off
  LS Upd. Retransmit Timer:  off
```

 # show ip ospf database verbose

```
[gi]SPGW-2# show ip ospf database verbose

               Router Link States (Area 0.0.0.0)
  LS age:                  1537
  Options:                 0x2 (*|-|-|-|-|E|-)
  Flags:                   0x2 : ASBR
  LS Type:                 Router Link States (1)
  Link State ID:           192.168.3.101
  Advertising Router:      192.168.3.101
  LS Seq Number:           800fe774
  Checksum:                0x8801
  Length:                  48
  Number of Links:         2

    Link connected to:                  Stub Network
    (Link ID)Network/subnet number:     192.168.3.101
    (Link Data)Network Mask:            255.255.255.255
```

```
  Number of TOS metrics:               0
  TOS 0 Metric:                        10
  Link connected to:                   a Transit Network
  (Link ID)Designated Router address:  192.168.10.249
  (Link Data)Router Interface address: 192.168.10.227
  Number of TOS metrics:               0
  TOS 0 Metric:                        10

LS age:                  1052
Options:                 0x2 (*|-|-|-|-|-|E|-)
Flags:                   0x2 : ASBR
LS Type:                 Router Link States (1)
Link State ID:           192.168.7.2
Advertising Router:      192.168.7.2
LS Seq Number:           8000100e
Checksum:                0xd694
Length:                  36
Number of Links:         1

  Link connected to:                   a Transit Network
  (Link ID)Designated Router address:  192.168.10.249
  (Link Data)Router Interface address: 192.168.10.249
  Number of TOS metrics:               0
  TOS 0 Metric:                        10


             Network Link States (Area 0.0.0.0)
LS age:                  952
Options:                 0x2 (*|-|-|-|-|-|E|-)
LS Type:                 Net Link States (2)
Link State ID:           192.168.10.249 (address of Designated Router)
Advertising Router:      192.168.7.2
LS Seq Number:           80000e46
Checksum:                0x6082
Length:                  32
Network Mask:            /24
  Attached Router:       192.168.7.2
  Attached Router:       192.168.3.101
```

```
              External Link States
  LS age:                  792
  Options:                 0x2 (*|-|-|-|-|-|E|-)
  LS Type:                 AS External Link States (5)
  Link State ID:           10.10.20.0 (External Network Number)
  Advertising Router:      192.168.7.2
  LS Seq Number:           80001000
  Checksum:                0x5cb8
  Length:                  36
  Network Mask:            /24
    Metric Type:           2 (Larger than any link state path)
    TOS:                   0
    Metric:                20
    Forward Address:       0.0.0.0
    External Route Tag:    0

  LS age:                  1482
  Options:                 0x2 (*|-|-|-|-|-|E|-)
  LS Type:                 AS External Link States (5)
  Link State ID:           192.168.7.2 (External Network Number)
  Advertising Router:      192.168.7.2
  LS Seq Number:           80001001
  Checksum:                0x1faa
  Length:                  36
  Network Mask:            /32
    Metric Type:           2 (Larger than any link state path)
    TOS:                   0
    Metric:                20
    Forward Address:       0.0.0.0
    External Route Tag:    0
```

 # show ip ospf route

```
[gi]SPGW-2# show ip ospf route
============ OSPF network routing table ============
N    192.168.3.101/32      [20] area: 0.0.0.0
                           via 192.168.10.227, gi
```

```
C    192.168.10.0/24        [10]
                            via 192.168.10.249, gi

Total routes count: 2
    Connected :     1
    Intra-area:     1
    Inter-area:     0
    External-1:     0
    External-2:     0
[gi]SPGW-2#
```

Example Scenarios

OSPF neighbor does not move to Full status

Problem Description:

OSPF neighbor does not move to Full status, but runs into a loop Init -> ExStart.

Analysis:

```
 [gn]asr5500# show ip ospf neighbor
 Neighbor ID     Pri   State           Dead Time   Address         Interface           RXmtL RqstL
DBsmL
 10.1.1.1          1   Init/DROther    00:00:38    192.168.2.1     subs                0     0     0

 [gn]asr5500# show ip ospf neighbor
 Neighbor ID     Pri   State           Dead Time   Address         Interface           RXmtL RqstL
DBsmL
 10.1.1.1          1   ExStart/Backup  00:00:37    192.168.2.1     subs                0     0     0

 [gn]asr5500# show ip ospf neighbor
 Neighbor ID     Pri   State           Dead Time   Address         Interface           RXmtL RqstL
DBsmL
 10.1.1.1          1   Init/DROther    00:00:39    192.168.2.1     subs                0     0     0
```

If the neighbor was in "Full" status before, the following snmp trap will be seen.

```
[gn]asr5500# show snmp trap history
There are 1 historical trap records (5000 maximum)

Timestamp                Trap Information
------------------------ ------------------------------------------------------------------------
--------------------------
Sun Feb 22 05:12:02 2015 Internal trap notification 1001 (OSPFNeighborDown)  vpn gn interface
subs ipaddr 192.168.2.2 ospf neighbor 10.1.1.1 transitioned from state full to down
```

Resolution:

This could be an issue of the network between OSPF neighbors. Check whether there is any issue in the intermediate network (Link/Port/MTU, etc.). In the above example, the issue was caused by MTU mismatch between OSPF neighbors.

OSPF Neighborship Down

Problem Description:

OSPF neighborship went down for OSPF neighbors and will not recover.

Analysis:

```
Wed Jun 04 21:57:13 2014 Internal trap notification 1001 (OSPFNeighborDown)  vpn ip_pool_ctx interface
ip_pool_ctx_if3 ipaddr 172.25.68.42 ospf neighbor 172.16.255.67 transitioned from state full to down
Wed Jun 04 21:57:13 2014 Internal trap notification 1001 (OSPFNeighborDown)  vpn ip_pool_ctx interface
ip_pool_ctx_if4 ipaddr 172.25.68.46 ospf neighbor 172.16.255.67 transitioned from state full to down
```

```
[aaa_ctx]ASR5000# show ip ospf neighbor
Neighbor ID     Pri   State           Dead Time   Address         Interface           RXmtL RqstL DBsmL
172.16.255.66   110   Full/DR         00:00:39    172.25.68.5     aaa_ctx_if1         0     0     0
172.16.255.66   110   Full/DR         00:00:39    172.25.68.13    aaa_ctx_if2         0     0     0
172.16.255.67   110   Init/DROther    00:00:35    172.25.68.29    aaa_ctx_if3         0     0     0
172.16.255.67   110   Init/DROther    00:00:31    172.25.68.37    aaa_ctx_if4         0     0     0
```

Check the NPU status and verify errors; in this case the lost_fails was incrementing in the Demux card.

The below CLI command requires the CLI test-commands password configured in the chassis.

```
[aaa_ctx]ASR5000# show npu stats sft
lost_fails ------------------------------------------------------------------------------+

bonus_fails ------------------------------------------------------------------------+     |
length_fails ---------------------------------------------------------------+     |     |
data_fails -----------------------------------------------------------+     |     |     |
last_valid_packet_number ---------------------------------+        |     |     |     |
valid_rcvd_pkts ------------------------------------+        |        |     |     |     |
received_pkts --------------------------+        |        |        |     |     |     |
sent_pkts ----------------------+        |        |        |        |     |     |     |
gen_pkts -------------+        |        |        |        |        |     |     |     |
cpu/inst +            |        |        |        |        |        |     |     |     |
sl       |            |        |        |        |        |        |     |     |     |
 1      0/0 ->     6076     6076      204      204     6022 ->     0     0     0  5818
 2      0/0 ->   526736   526736   526736   526736   526736 ->     0     0     0     0
 4      0/0 -> 2114170681 2114170681 2114170681 2114170681 2114170681 ->     0     0     0
0
 11      0/0 -> 2114102704 2114102704 2114102704 2114102704 2114102704 ->     0     0     0
0
 14      0/0 ->   537803   537803   537803   537803   537803 ->     0     0     0     0
 16      0/0 ->   209685   209685   209685   209685   209685 ->     0     0     0     0
```

```
[aaa_ctx]ASR5000# show npu stats sft

lost_fails ------------------------------------------------------------------------+

bonus_fails ----------------------------------------------------------------------+     |
length_fails ---------------------------------------------------------------+     |     |
data_fails -----------------------------------------------------------+     |     |     |
last_valid_packet_number ---------------------------------+        |     |     |     |
valid_rcvd_pkts ------------------------------------+        |        |     |     |     |
received_pkts --------------------------+        |        |        |     |     |     |
sent_pkts ----------------------+        |        |        |        |     |     |     |
gen_pkts -------------+        |        |        |        |        |     |     |     |
cpu/inst +            |        |        |        |        |        |     |     |     |
sl       |            |        |        |        |        |        |     |     |     |
 1      0/0 ->    12950    12950      453      453    12949 ->     0     0     0 12496
 2      0/0 ->   533610   533610   533610   533610   533610 ->     0     0     0     0
 4      0/0 -> 2114177548 2114177548 2114177548 2114177548 2114177548 ->     0     0     0
0
 11     0/0 -> 2114109578 2114109578 2114109578 2114109578 2114109578 ->     0     0     0
0
 14     0/0 ->   544677   544677   544677   544677   544677 ->     0     0     0     0
 16     0/0 ->   216552   216552   216552   216552   216552 ->     0     0     0     0
```

Resolution:

The Demux card was migrated and the SFT counter kept incrementing. This pointed to a transient issue on the card. OSPF was reestablished to Full state after the card migration.

BGP Routing

Overview


This section covers BGP routing on ASR 5000/ASR 5500 with multiple troubleshooting commands and two scenarios.

Refer to the "ARP Troubleshooting" section for layer two connectivity issues.

BGP Configuration

ASR 5000/ASR 5500 supports Border Gateway Protocol (BGP) which is an inter-AS routing protocol. BGP also may be used as a monitoring mechanism for Inter-chassis Session Recovery (ICSR). BGP-4 may trigger an active-to-standby switchover to keep subscriber services from being interrupted.

Image: Topology



Below is the basic configuration of BGP.

```
config
  context contextname
    router bgp as_number
      neighbor ip_address remote-as remote_as_number
```

CLI for troubleshooting

- show snmp trap history verbose | grep -i bgp
- show logs | grep -i bgp
- show srp monitor all (if ICSR is used)

Below are context aware CLIs. These commands will need to run from the proper context.
`context <context name>`

- show ip interface summary
- show ipv6 interface summary
- show ip bgp
- show ip bgp summary
- show ip bgp neighbors
- show ip bgp neighbors <IP Address> accepted-routes
- show ip bgp neighbors <IP Address> advertised-routes
- show ip bgp neighbors <IP Address> received-routes
- ping <BGP Neighbor IPV4> src <IPv4 Loopback>
- ping6 <BGP Neighbor IPv6> src <IPv6 Loopback>

The following commands should only be done upon recommendation from Cisco Support as increasing the logging too high may risk stress on the system and impact subscribers.

- logging filter active facility bgp level debug
- logging filter active facility iparp level debug
- logging active
- no logging active
- Wireshark traces

Below are sample CLI outputs.

```
[gn]asr5500# show ip bgp
IPv4 Routing Table:
BGP table version is 1, local router ID is 10.1.1.2
Status Codes: s  suppressed, d damped, h history, * valid, > best, i - internal, S stale, m
Multipath
Origin Codes: i - IGP, e - EGP, ? - incomplete

    Network              Next Hop             Metric LocPrf Weight Path
*>   10.1.1.2/32          0.0.0.0               0             32768  ?
*>   192.168.2.0/24       0.0.0.0               0             32768  ?
*>   192.168.100.10/32    0.0.0.0               0             32768  ?

 Total number of prefixes 3
```

```
[gn]asr5500# show ip bgp summary
BGP Address-Family : IPv4
BGP router identifier 10.1.1.2, local AS number 2
BGP table version is 1
1 BGP AS-PATH entries

Neighbor             V      AS   MsgRcvd MsgSent TblVer Up/Down  State/PfxRcd
192.168.2.1          4      1          20      22      1 00:07:38      0

BGP Address-Family : IPv6
BGP router identifier 10.1.1.2, local AS number 2
BGP table version is 1
1 BGP AS-PATH entries

Neighbor             V      AS   MsgRcvd MsgSent TblVer Up/Down  State/PfxRcd
```

```
[gn]asr5500# show ip bgp neighbors
BGP neighbor is 192.168.2.1, remote AS 1, local AS  2, external link
  BGP version 4, remote router ID 10.1.1.1
  BGP state = Established,up for 00:08:50
```

```
  Hold time is 90 seconds, keepalive interval is 30 seconds
  Configured Hold time is 90 seconds, keepalive interval is 30 seconds
  Connect Interval is 20 seconds
  Neighbor capabilities:
     Route refresh: advertised and received (old and new)
     Address family IPv4 Unicast: advertised and received
  Received 23 messages, 0 notifications, 0 in  queue
  Sent 25 messages, 0 notifications, 0 in  queue
  Route refresh request:  received 0, sent 0
  Minimum time between advertisement runs is 30 seconds

 For address family: IPv4 Unicast
  AF-dependant capabilities:
    Graceful restart: advertised
  0 accepted prefixes, maximum limit 40960
  Threshold for warning message 75(%)
  3 announced prefixes

 For address family: VPNv4 Unicast
  0 accepted prefixes
  0 announced prefixes

 For address family: IPv6 Unicast
  0 accepted prefixes
  0 announced prefixes

 For address family: VPNv6 Unicast
  0 accepted prefixes
  0 announced prefixes

 Connections established 1; dropped 0
Local host: 192.168.2.2, Local port: 38190
Foreign host: 192.168.2.1, Foreign port: 179
Next hop: 192.168.2.2
Next hop global: fe80::5:47ff:fe30:4fd8
```

Example Scenarios

Demux card switchover caused BGP peers to flap

Problem Description:

BGP peers re-established when a Demux card is switched-over/migrated.

Analysis:

This is expected behavior by design.

The BGP process runs on a Demux card as seen below.

```
[gn]asr5500# show session recovery status verbose
Session Recovery Status:
  Overall Status        : Ready For Recovery
  Last Status Update    : 4 seconds ago

              ----sessmgr---  ----aaamgr----  demux
 cpu state    active standby  active standby  active  status
---- -------  ------ -------  ------ -------  ------  -------------------------
 2/0 Active   0      0        0      0        3       Good (Demux)
 2/1 Active   0      0        0      0        3       Good (Demux)
 3/0 Active   1      1        1      1        0       Good
 3/1 Active   2      1        2      1        0       Good
 4/0 Active   2      1        2      1        0       Good
 4/1 Active   1      1        1      1        0       Good
 [gn]asr5500# show task resources facility bgp all
                   task   cputime        memory     files      sessions
 cpu facility      inst used allc   used  alloc used allc  used  allc S status
---------------------- --------- ---------- --------- ------------- ------
 2/0 bgp              3 0.0%  80%  4.38M 37.00M   13  500    --    -- -   good
 2/1 bgp              2 0.0%  80%  4.51M 37.00M   13  500    --    -- -   good
Total                 2 0.00%      8.89M        26            0
```

After the Demux card switchover event, the BGP process is restarted on the new Demux card.

```
[gn]asr5500# show session recovery status verbose
Session Recovery Status:
  Overall Status        : Ready For Recovery
  Last Status Update    : 5 seconds ago

              ----sessmgr---  ----aaamgr----  demux
 cpu state    active standby  active standby  active  status
---- -------  ------ -------  ------ -------  ------  -------------------------
 2/0 Standby  0      2        0      2        0       Good
 2/1 Standby  0      2        0      2        0       Good
 3/0 Active   1      1        1      1        0       Good
 3/1 Active   2      1        2      1        0       Good
 4/0 Active   2      1        2      1        0       Good
 4/1 Active   1      1        1      1        0       Good
 7/0 Active   0      0        0      0        3       Good (Demux)
 7/1 Active   0      0        0      0        3       Good (Demux)
 [gn]asr5500# show task resources facility bgp all
                   task   cputime        memory     files      sessions
 cpu facility      inst used allc   used  alloc used allc  used  allc S status
----------------------- --------- ------------- --------- ------------- ------
 7/0 bgp              3 0.1%  80%  4.91M 37.00M   25  500    --    -- -   good
 7/1 bgp              2 0.1%  80%  4.91M 37.00M   25  500    --    -- -   good
```

Resolution:

The new BGP process tries to re-establish the BGP session with peers. This is normal behavior.

```
 [gn]asr5500# show snmp trap history | grep BGP
 Sun Feb 22 04:39:54 2015 Internal trap notification 118 (BGPPeerSessionUp)  vpn gi ipaddr
192.168.3.1
 Sun Feb 22 04:39:54 2015 Internal trap notification 118 (BGPPeerSessionUp)  vpn gn ipaddr
192.168.2.1
```

BGP Missing path from MPLS

Problem Description:

BGP is missing path from MPLS VPN (vrf). ASR 5000 was seeing only one route from one CE. The expected behavior was two paths to the affected networks:

Logs collection:

```
[context]ASR5000# show ip bgp vpnv4 vrf test2 192.168.0.0/24
BGP routing table entry for 192.168.0.0/24
Paths: (1 available, best #1 )
Not advertised to any peer
  Local
    10.92.192.190  from 10.92.192.190 (10.96.195.190)     <<<< one path only
      Origin Incomplete, metric 50, localpref 100, weight 0, valid, internal, best
```

Analysis:

The routes were being advertised by the PEs, as seen below:

```
[context]ASR5000# show ip bgp vpnv4 all
*>i  192.168.0.0/24       10.96.195.190        50     100    0      ?
* i                       10.96.195.188        90     100    0      ?
*>i  192.168.1.0/24       10.96.195.190        50     100    0      ?
* i                       10.96.195.188        90     100    0
```

Resolution:

```
ip vrf test2
  rd 65392:700
  route-target export 65392:700
  route-target import 65392:700
```

The solution was to change the rd in one of the routers:

```
ip vrf test2
 rd 65392:706   <<<<<< different rd
 route-target export 65392:700
 route-target import 65392:700
```

Changing the rd made the route unique and load balancing can now be be achieved.
After this change the output was seen as below (two paths to the same network):

```
[corpAPN_tunnel]ASR5000# show ip bgp vpnv4 vrf patp-2 192.168.0.0/24
BGP routing table entry for 192.168.0.0/24
Paths: (2 available, best #2 )
Not advertised to any peer
  Local
    10.96.195.190  from 10.96.195.190 (10.96.195.190)
      Origin Incomplete, metric 50, localpref 100, weight 0, valid, internal

  Local
    10.96.195.188  from 10.96.195.188 (10.96.195.188)
      Origin Incomplete, metric 50, localpref 100, weight 0, valid, internal, best
```

In this case, the symptom was seen in the ASR 5k but the origin of the issue was on the up-stream routers. Because there were 2 PEs advertising the same networks, they are required to have different rd (route-distinguisher) values to make the routes unique for MP-BGP.

Interchassis Session Recovery

Inter Chassis Session Recovery

Overview

This section talks about how redundancy works in the ASR 5x00 platform using ICSR, provides troubleshooting commands, and then goes over common issues related to ICSR.

ICSR Architecture

Inter Chassis Session Recovery (ICSR) provides a solution using a pair of redundant nodes (i.e. HA and PGWs) where one node is Active, handling subscribers, and the other is Standby, ready to handle those subscribers in case the Active chassis has an issue and needs to switch over. This architecture is beneficial not only for outage scenarios but also for upgrades where the subscribers can maintain their connections while both nodes are upgraded, one after the other, and switching over in between.

Although not required, both nodes are typically geographically separated from each other. They would be configured similarly with the same services, IP pools, contexts, and hardware, and even some of the same loopback addresses used by the services running on the chassis. Each chassis will have its own specific physical addresses.

Besides the ability of being able to manually switch sessions over to the Standby, the Active chassis is also able to monitor itself for BGP, Diameter, and Radius connectivity in various contexts. If the specified protocols being monitored lose connectivity, then an unplanned switchover will occur.

ICSR relies on a special configuration section called **service-redundancy-protocol** (SRP) in which all the SRP-related configuration is done. An IP address is bound to the service and it communicates over a TCP/IP link to the other ICSR node, regularly sending and receiving SRP messages that contain the state of both sides as well as detailed information about every call on the system that has been attached longer than the configured threshold. These messages are called checkpoints and they allow the Standby to immediately re-create sessions and preserve state in the case of a switchover event.

Since both chassis are present on the network, and sharing much of the same IP information, the network must be able to know which chassis is active and be able to re-converge the trans-

port network in the event of a switchover. To do this, BGP is used, and in particular, BGP handles route modifiers. The Active chassis will always be the one that has the lower-numbered BGP route modifier, while the Standby chassis will have a route modifier value (usually one) greater than the active. This will result in more pre-pends added to BGP packet advertisements coming from the nodes, and as a result, network traffic will be pointed to the chassis sending updates that have fewer pre-pends. BGP route advertisements from the Standby are highly restricted and most of the loopbacks are in 'down' state. This further reduces the likelihood of introducing routing issues into the transport network.

If the connection between both nodes is severed, the standby node will become pseudo-active and send BGP updates. In this case both chassis in the pair will be in Active state. Due to the nature of the route modifiers in BGP, however, the newly-Active chassis should not receive any traffic since its updates have more pre-pends. If at any point the originally Active node stops sending BGP updates (ie: it gets reloaded, internal failures for BGP, chassis stops processing traffic), then that Standby chassis should start to receive traffic

More details about ICSR architecture, along with diagrams, can be found in the product documentation available on Cisco's support site.

Useful commands:

- show srp checkpoint statistics
- show srp checkpoint statistics verbose
- show srp audit-statistics all
- show srp checkpoint statistics debug-info
- show srp checkpoint statistics standby debug-info verbose
- show srp checkpoint statistics active verbose
- show srp call-loss statistics
- show srp info
- show srp statistics
- show srp audit-statistics
- show snmp trap statistics
- show snmp trap history

ICSR Troubleshooting

Overview

This chapter talks about known SRP issues and how to troubleshoot them.

Common SRP issues

1. SRP Connection down
2. SRP Configuration mismatch
3. Unplanned SRP Switchover
4. SRP Switchover takes longer than planned
5. Confirm that ICSR chassis pair is ready for an SRP Switchover
6. Verify that SRP Switchover was successful

SRP Connection Down

The SRP connection between the the Active and the Standby SRP chassis can go down for many reasons. Following are the steps to take in order to investigate why an SRP connection down occured. If at the end of the following the steps, the issue is not resolved, please open a case with Cisco in order to assist in troubleshooting.

1. Take an SSD before executing the following steps
2. Log into the normally SRP Active chassis
3. Issue the "**show srp info**" command
   - Make note of the "Peer Remote Address"
   - Verify the "Chassis State" is "Active" and the "Connection State" is "Not Connected", which would be an indication of the SRP connection down issue.
4. Access the context configured for the SRP feature:
   - `context <`SRP Context name>

5. Verify the interface configured for connectivity to the SRP mate:
   - show ip interface summary
   - Verify the interface status is in the "up" state
   - If the interface is not in the "up" state, follow steps in the the "Card and Port Troubleshooting" and "L2 Troubleshooting" chapter.
6. Obtain the default route for the SRP interface by issuing the "show ip route" command
   - Make note of the Nexthop address
7. Ping the Nexthop address of the local SRP interface:
   - `ping <`Nexthop Address>
   - `ping <`Peer Remote Address**>**
   - If the IP address is not reachable, follow the "Routing Protocol" section to address network connectivity.
8. Log into the normal SRP Standby chassis and execute steps 2-6
9. Verify that both chassis are configured with the correct Peer Remote Address
10. If all of the above has been verified, and the SRP Connection remains down, please open a case with Cisco

SRP Configuration Mismatch:

An SRP configuration mismatch can occur when the configuration that is monitored by the SRP feature is changed on either the Active or Standby chassis without ensuring the changes are also made on the mated SRP chassis. Here are the steps to take in order to identify and resolve the issue. If the issue is not cleared at the end of the steps, please open a case with Cisco:

1. Take an SSD before executing the following steps
2. Log into the normally SRP Active chassis
3. Issue the "show srp info" command
   - Make note of the "Last Peer Configuration Error field". Ensure "Invalid Checksum" is not displayed. If present, it would be an indication that there is an SRP configuration mismatch between the two chassis.
4. Issue the command "show configuration srp checksum"
   - Make note of the "Configuration checksum" that was generated

5. Display the configuration that SRP uses to generate the SRP Checksum by issuing the command "show configuration srp"
    - Save the displayed data to a text file.
6. Now log into the normally SRP Standby chassis and execute steps 2-5
7. Compare the checksum from both the SRP Active and SRP Standby chassis
    - If the checksums are the same and the "Invalid Checksum" is still displayed in the "show srp info" command, please open a case with Cisco for further troubleshooting
8. Compare the two text files containing the "show configuration srp" data line- by-line to ensure there are no differences in the configuration. Using a `diff` utility can save time and avoid missing differences.
   If no differences are found in the text files, please open a case with Cisco for further troubleshooting
9. If differences were found in the configuration, modify the configuration so that both chassis match.

Unplanned SRP Switchover occurred

SRP switchovers occur when the system identifies trigger events that cause it to transfer the SRP Active state to the normally SRP Standby chassis. These trigger events are defined in the SRP Configuration context using the "`monitor`" configuration command.

1. Take an SSD before executing the following steps
2. Log into the chassis that was formerly the SRP Active chassis
3. Issue the "show srp info" command and verify the chassis state is "Standby" and the "Connection State" is "Connected"
4. Issue the command "show srp call-loss statistics"
    - This command will display the SRP Switchovers that have occured with the most recent display first
    - Make note of the "Switchover-X started at :" field.
        - "**x**" will be the number of Switchovers that have been recorded by this chassis.
    - Make note of the "Switchover reason `:`"

5 Review system logs and SNMP Traps that occurred during the period leading up to the SRP switchover
   - show logs
   - show snmp trap history verbose
     - SRPStandy trap indicates when chassis went standby
     - Some traps to look for include BGPPeerSessionDown, DiameterIPv6PeerDown, DiameterPeerDown, SRPAAAAuthSrvUnreachable leading up to the switchover

6 If the SRP switchover cannot be explained with the data collected, please open a case with Cisco for help in identifying the trigger event.

SRP Switchover takes longer than expected

In order for the ICSR feature to checkpoint subscriber sessions from the SRP Active chassis to the SRP Standby chassis, the SRP Standby chassis will initiate a TCP SRP socket with the SRP Active chassis for each sessmgr on the system. For instance sessmgr 1 on the SRP Standby will have a connection to sessmgr 1 on the SRP Active chassis, and this will be the case for all active sessmgrs on the system. If one of these sessmgr connections is not in the proper state, the SRP Active chassis will not be able to checkpoint its subscriber sessions to the SRP Standby chassis. If an SRP switchover is performed when in this state, the system will attempt to checkpoint the subscribers for 300 seconds and at the expiration of 300 seconds, the system will force the SRP switchover. This will result in the loss of all subscribers who were not checkpointed.

To avoid this situation, always follow the steps in the section below.

Confirm ICSR chassis pair are ready for an SRP Switchover

Before executing an SRP switchover, it is important to ensure the SRP Active chassis has checkpointed all subscriber sessions and all SRP sessmgr connections are connected. This procedure will help to ensure all recommended checks are done prior to performing the SRP Switchover.

Warning:
Wait 15 minutes after any crash, task restart, card migration on the same chassis pair.
Wait 20 minutes after any previous SRP switchover on the same chassis pair.
Failure to wait the required time could have session and billing impact.

1. Perform the Health Check steps detailed in the ASR 5x00 Health Check chapter
2. Log into the Active and Standby chassis to verify their "`Chassis State:`"
   - context local
   - show srp info
     Chassis State: Active (From)
     Chassis State: Standby (To)
   - If the SRP Link has been removed, these SRP commands will give invalid results.
3. Perform these SRP switchover pre-checks on both the Active and Standby chassis.
   - show session recovery status verbose
     - Verify all are in the "`Good`" state
   - show card table
     - Verify the status of all cards (Active/Standby)
   - show task resources | grep -v good
     - Should only show the total
   - show crash list
     - Verify there was no new crash within the last 15 minutes
4. Verify Sessions are checkpointed from the Active to the Standby
   - Perform these SRP switchover pre-checks on the Active chassis
     - show subscriber summary | grep Total
     - Make note of the "Total Subscribers:" on the chassis
   - Perform these SRP switchover pre-checks on the Standby chassis
     - show srp checkpoint-statistics | grep allocated
     - Make note of the total number of "Current pre-allocated calls:"
   - Before the switchover can occur, the "Current pre-allocated calls`:`" value on the Standby chassis should be within 3% of the "`Total Subscribers:`" value on the Active chassis.

5 Verify all sessmgrs are in the standby-connected state on the Standby chassis
   - show srp checkpoint statistics | grep Sessmgrs
     - Verify the "Number of Sessmgrs:" is equal to "`Sessmgrs in Standby-Connected state:`"
       - If these values ARE NOT the same, do not proceed with an SRP switchover, and open a case with Cisco for further troubleshooting

6 Validate the Active chassis is ready for the SRP switchover
   - srp validate-configuration
   - srp validate-switchover
     - Wait at least 15 seconds
   - show srp info | grep "Last Validate Switchover Status:"
     - The "Last Validate Switchover Status:" should display "Remote Chassis - Ready for Switchover"
     - Please open a case with Cisco for further troubleshooting if "`Remote Chassis - Ready for Switchover`" is not displayed after waiting at least 10 minutes

7 The system is now ready for a SRP switchover
   - srp initiate-switchover
   - Answer "yes" when the system asks "Are you sure?"
   - After a successful SRP switchover the SRP Active chassis will now become the SRP Standby chassis

Verification SRP Switchover successful

After an SRP switchover, whether it was manual or unplanned, the system should be verified in order to make sure processing of subscriber sessions is working normally. Here are the steps to verify.

1 Log into the Active and Standby chassis to verify their "`Chassis State:`"
   - context local
   - show srp info

     Chassis State: Standby
     Chassis State: Active (Chassis that was Switched over To)
   - If the SRP Link has been removed, these SRP commands will give invalid results.

2 On the Active and Standby chassis
   - Verify Session Recovery state:
     - show session recovery status verbose
       - Verify all are in the "Good" state.

3 On the Active chassis
   - Verify Sessions are checkpointed from the Active to the Standby
     - Perform these SRP switchover pre-checks on the Active chassis
       - show subscriber summary | grep Total
       - Make note of the "Total Subscribers:" on the chassis
     - Perform these SRP switchover pre-checks on the Standby chassis
       - show srp checkpoint-statistics | grep allocated
       - Make note of the total number of "Current pre-allocated calls:"
     - After the switchover, make sure the newly Standby chassis has the "Current pre-allocated calls:" value on the Standby chassis within 3% of the "Total Subscribers:" value on the newly Active chassis.
     - Open a case with Cisco if the values are not within 3% after 10 minutes for further troubleshooting.

4 Verify all sessmgrs are in the standby-connected state on the Standby chassis
   - show srp checkpoint statistics | grep Sessmgrs
     - Verify the "Number of Sessmgrs:" is equal to "Sessmgrs in Standby-Connected state:"
       - If these values ARE NOT the same, open a case with Cisco for further troubleshooting.

5 Verify all Diameter connections have restored on the Active chassis
   - show diameter peer full all | grep -i State
     - Verify all Diameter connections show "State: OPEN [TCP]" in the output
     - Follow local procedures to troubleshoot any Diameter connection in an unexpected state
     - Open a case with Cisco for futher troubleshooting if necessary.

6 Verify the state of all SRP Monitors on the Active chassis
   - show srp monitor all
     - Verify all configured monitor statements have the state of "U" for up.
     - If any lines are not in the expected state, follow above steps to troubleshoot
       - Open a case with Cisco if further assistance is needed.

7 Perform the Health Check steps detailed in the ASR 5x00 Health Check chapter.

Radius

Overview

Radius authentication and accounting are typically components on call flows for CDMA, UMTS, and LTE. Sometimes when troubleshooting call failures, it is not immediately obvious that Radius authentication is the root cause. In this section, various commands used to determine where and if there are Radius issues will be investigated.

The section examines how Radius authentication and accounting tie into the call flow; the relevant Radius configurables; the state machine behavior – how it maintains the state of the configured servers; overload issues, recovery methods, and high-level descriptions of the types of issues one might expect to encounter, along with the information (traces, logs, counters, etc.) one might need to collect.

Authentication and Accounting Overview

"Monitor subscriber" trace will show how Radius authentication works. It is important to know when authentication and accounting take place.

For example, whether it be SIP (Simple IP) or MIP (Mobile IP), a call starts with A11 protocol message exchange followed by some PPP negotiation. For SIP, as soon as the username is received during PPP negotiation, Radius authentication can take place, followed by further PPP negotiation where compression is negotiated along with the DNS and mobile IP address being given out. For MIP (Mobile IP), unlike for SIP (Simple IP), the username is not received during PPP negotiation. Rather, the DNS information is given out, and header compression negotiation takes place. At this point PPP is finished and MIP (Mobile IP) protocol takes over, with MIP (Mobile IP) router advertisement and a MIP (Mobile IP) RRQ being received with the username, at which time Radius authentication takes place.

So the key for both SIP (Simple IP) and MIP (Mobile IP) Radius authentication is getting the username which is needed to identify the subscriber to the Radius server.

Finally Radius accounting takes place. Radius accounting also takes place at call teardown.

It is recommended to study some example traces of MIP (Mobile IP) and SIP (Simple IP) or whatever call-control protocol is being used, to understand the full call flow and to see how au-

thentication and accounting play a role. Grabbing a trace from the live network using **monitor subscriber** is an easy way to get started.

Timers, Retries, related counters

When a Radius (accounting or access) request is sent, a reply is expected. When a reply is not received within the timeout period (seconds):

```
radius (accounting) timeout 3
```

then the request is resent up to the number of times specified:

```
radius (accounting) max-retries 5
```

This means that a request can be sent a total of max-retries + 1 times until it gives up on the particular Radius server being tried. At this point, it will try the same sequence to the next Radius server in order. If each of the servers have been tried the max-retries + 1 times without response, then the call will be rejected, assuming there is no other reason for failure up to that point.

Also, there are configurables that can limit the absolute total number of transmissions of a particular request across all the configured servers, and these are disabled by default:

```
radius (accounting) max-transmissions 256
```

For example if this is set = 1, then even if there is a secondary server, it will never be attempted because only one attempt for a specific subscriber setup will ever even be attempted.

The "**show radius counters all**" command is very valuable in tracking success and failures on a server basis, and it is very important to understand the meaning of the various counters that compose this command, as it may not be obvious. In the following output, note "Access-Request Sent" = 1, while "Access-Request Retried" = 3. So, any given new request to a particular Radius server is only counted once, and all the retries are counted separately. In this case, that is a total of 3 + 1 = 4 access requests sent.

Note the counter "Access-Request Timeouts" = 1. A single timeout occurs only when ALL the retries fail, so in this case, 3 retries without a response result in 1 Timeout (not 4). This will hap-

pen across all of the configured servers until there is success, or all attempts have failed. Following is an example of this:

```
Radius max-retries 3
Radius server 192.168.50.200 encrypted key 01abd002c82b4a2c port 1812 priority 1
Radius server 192.168.50.250 encrypted key 01abd002c82b4a2c port 1812 priority 2

[destination]CSE2# show Radius counters all

   Server-specific Authentication Counters
   ---------------------------------------

   Authentication server address 192.168.50.200, port 1812:
     Access-Request Sent:                                    1
            Access-Request with DMU Attributes Sent:                 0
       Access-Request Pending:                                 0
     Access-Request Retried:                                 3
     Access-Request with DMU Attributes Retried:             0
     Access-Challenge Received:                              0
     Access-Accept Received:                                 0
     Access-Reject Received:                                 0
     Access-Reject Received with DMU Attributes:             0
     Access-Request Timeouts:                                1
     Access-Request Current Consecutive Failures in a mgr:   1
     Access-Request Response Bad Authenticator Received:     0
     Access-Request Response Malformed Received:             0
     Access-Request Response Malformed Attribute Received:   0
     Access-Request Response Unknown Type Received:          0
     Access-Request Response Dropped:                        0
     Access-Request Response Last Round Trip Time:           0.0 ms
…

  Authentication server address 192.168.50.250, port 1812:
     Access-Request Sent:                                    1
              Access-Request with DMU Attributes Sent:                0
             Access-Request Pending:                                 0
             Access-Request Retried:                                 3
             Access-Request with DMU Attributes Retried:             0
             Access-Challenge Received:                              0
```

```
 Access-Accept Received:                                    0
 Access-Reject Received:                                    0
Access-Reject Received with DMU Attributes:                0
 Access-Request Timeouts:                                   1
 Access-Request Current Consecutive Failures in a mgr:      1
Access-Request Response Bad Authenticator Received:        0
 Access-Request Response Malformed Received:                0
 Access-Request Response Malformed Attribute Received:      0
 Access-Request Response Unknown Type Received:             0
 Access-Request Response Dropped:                           0
 Access-Request Response Last Round Trip Time:              0.0 ms
```

Note also that timeouts are NOT counted as **failures**, the result being that the number of Access-Accepts received and Access-Rejects received will not add up to Access-Request Sent if there are any timeouts.

For MIP, it can be even more complicated than just described, because as the authentications are failing due to timeouts, there is no MIP RRP being sent, and the mobile may continue to initiate new MIP RRQs because it has not received a MIP RRP. Each new MIP RRQ causes the PDSN to send a new Authentication request which itself can have its own series of retries. This can be seen in the ID field at the top of a packet trace – it will be unique for each set of retries. The result is that the counters for Sent, Retried, and Timeout can be much higher than expected for the number of unique subscriber calls received. There is an option that can be enabled to minimize these extra re-tries, and it can be set in the FA (but not on the HA) service: "authentication mn-aaa <6 choices here> optimize-retries"

Note: Over an un-monitored time period, it is difficult to draw any conclusions from the counter values or the relationships amongst counters. To make accurate conclusions, the best approach is to reset the counters and monitor them over a period of time when the issue one is troubleshooting is occurring.

Whenever running Radius commands, be sure to be in the context where the aaa group that is being troubleshot is located.

show radius counters { {all | server <server IP>} [instance <aaamgr #>] | summary}

show radius {accounting | authentication} **servers detail**

A few things to note:

- instance # option (CLI test-commnds password required) is valuable when troubleshooting a particular aaamgr instance
- show support details does not contain “show radius [[accounting] [authentication]] servers detail”
- “show radius servers detail” only saves the last ten Radius state changes – so run the command multiple times to get a complete history of troubleshooting over an extended period.
- clearing the Radius counters is a good idea if monitoring the counters over a time period.
- The summary version of "show radius counters" groups together all the counters of a specific type (accounting, authentication, probe, etc.).
- Trying to look for exact correlations of various counters, even over a monitored period, can be tricky. Check for general patterns, as getting too specific may not be feasible.

State Machine Behaviors

There are two different models/algorithms/approaches to choose from to determine the status of a Radius server and when to try a different server if failures are occurring. It is important to know which one has been implemented for the system being troubleshot.

The original approach involves keeping track of the number of failures that have occurred in a row for a particular aaamgr process. An aaamgr process is responsible for all Radius message processing and exchanges with a Radius server, and many aaamgr processes will exist on all active processor cards (DPC or PSC) on a chassis. Each one paired with sessmgr processes (which are main processes responsible for call control). "**show task resources facility aaamgr all**" command can be used to view all the aaamgr processes. A particular aaamgr process will therefore be processing Radius messages for many calls, not just a single call, and this algorithm involves tracking how many times in a row a particular aaamgr process has failed to get a response to the same request it has had to resend - an "Access-Request Timeout" as described in earlier section. The respective counter "**Access-Request Current Consecutive Failures in a mgr**" is incremented when this occurs, and the "**show radius [[accounting] [authentication]] servers detail**" command will indicate the timestamps of the Radius state change from Active to Not Responding (but no SNMP trap or logs will be generated). For example:

```
[source]ASR5000> show radius accounting servers detail

+-----Type:       (A) - Authentication   (a) - Accounting
|                 (C) - Charging         (c) - Charging Accounting
|                 (M) - Mediation        (m) - Mediation Accounting
|
|+----Preference: (P) - Primary          (S) - Secondary
||
||+---State:      (A) - Active           (N) - Not Responding
|||               (D) - Down             (W) - Waiting Accounting-On
|||               (I) - Initializing     (w) - Waiting Accounting-Off
|||               (a) - Active Pending   (U) - Unknown
|||
|||+--Admin       (E) - Enabled          (D) - Disabled
||||  Status:
||||
||||+-Admin
||||| status      (O) - Overridden       (.) - Not Overridden
||||| Overridden:
|||||
vvvvv IP              PORT  GROUP
----- --------------- ----- ------------------------
aPNE. 17.2.22.5       1813  default

Event History:
2008-Nov-28+23:18:36       Active
2008-Nov-28+23:18:57       Not Responding
2008-Nov-28+23:19:12       Active
2008-Nov-28+23:19:30       Not Responding
2008-Nov-28+23:19:36       Active
2008-Nov-28+23:20:57       Not Responding
2008-Nov-28+23:21:12       Active
2008-Nov-28+23:22:31       Not Responding
2008-Nov-28+23:22:36       Active
2008-Nov-28+23:23:30       Not Responding
```

If this counter reaches the value configured (Default = 4) without ever being reset:

radius (accounting) detect-dead-server consecutive-failures 4

then this server will be marked "Down" for the period (minutes) configured:

radius (accounting) deadtime 10

An SNMP trap and logs will be triggered as well, for example, for authentication and accounting respectively:

```
 Fri Jan 30 06:17:19 2009 Internal trap notification 39 (AAAAuthSvrUnreachable) server 2 ip
address 17.2.22.1
 Fri Jan 30 06:22:19 2009 Internal trap notification 40 (AAAAuthSvrReachable) server 2 ip
address 17.2.22.1
  Fri Nov 28 21:59:12 2008 Internal trap notification 42 (AAAAccSvrUnreachable) server 6 ip
address 17.2.22.1
 Fri Nov 28 22:28:29 2008 Internal trap notification 43 (AAAAccSvrReachable) server 6 ip
address 17.2.22.1
```

```
 2008-Nov-28+21:59:12.899 [radius-acct 24006 warning] [8/0/518 <aaamgr:231>
aaamgr_config.c:1060] [context: source, contextID: 2]  [software internal security config user
critical-info] Server 17.2.22.1:1813 unreachable
  2008-Nov-28+22:28:29.280 [radius-acct 24007 info] [8/0/518 <aaamgr:231> aaamgr_config.c:1068]
[context: source, contextID: 2]  [software internal security config user critical-info] Server
17.2.22.1:1813 reachable
```

Note: Only ONE trap will be triggered regardless of how many aaamgrs get into this state at once, in order to avoid overloading the number of traps triggered. The instance # of the log version of the trap (as shown above) will be the management aaamgr instance which resides either on the SMC or the MIO and does not actually process subscriber authentication/accounting traffic.

Also, the "**show radius accounting** (or authentication) **servers detail**" command will indicate the timestamps of the state changes:

```
vvvvv IP              PORT  GROUP
----- --------------- ----- ----------------------
aSDE. 17.2.22.1  1813  default

Event History:
2008-Nov-28+21:59:12       Down
2008-Nov-28+22:28:29       Active
2008-Nov-28+22:28:57       Not Responding
2008-Nov-28+22:32:12       Down
2008-Nov-28+23:01:57       Active
2008-Nov-28+23:02:12       Not Responding
2008-Nov-28+23:05:12       Down
2008-Nov-28+23:19:29       Active
2008-Nov-28+23:19:57       Not Responding
2008-Nov-28+23:22:12       Down
```

If there is only one server configured, then it will not be marked down, as that would be critical for successful call setup.

There is another parameter that can be configured on the 'detect-dead-server' config line called "**response-timeout**". When specified, a server will be marked down only when the consecutive failures and response-timeout conditions are both met. The response-timeout specifies a period of time when NO responses are received to ALL the requests sent to a particular server. (Note that this timer would be continually reset as responses are received.) This condition would be expected when either a Radius server or the network connection is completely down, vs. partially compromised/degraded.

The use case for this would be a scenario where a burst in Radius traffic causes the consecutive failures to trigger, but marking a server down immediately as a result is not desired. Rather, the server will only be marked down after a specific period of time passes where no responses are received, effectively representing true server un-reachability.

This method just discussed, of controlling Radius state machine changes, is dependent on looking at all aaamgr processes and finding one that triggers the condition of failed retries.

Another method of detecting Radius server reachability is using dummy keepalive test messages. This involves the constant sending of fake Radius messages instead of monitoring live traffic. Another advantage of this method is that it is always active, vs. with the aaamgr ap-

proach, where there could be periods where no Radius traffic is sent, and so there is no way to know if a problem exists during those times, resulting in delayed detection when attempts do start occurring. Also when a server is marked down, these keepalives continue to be sent so that the server can be marked up as soon as possible.

Here are the various configurables relevant to this approach:

```
radius (accounting) detect-dead-server keepalive
radius (accounting) keepalive interval 30
radius (accounting) keepalive retries 3
radius (accounting) keepalive timeout 3
radius (accounting) keepalive consecutive-response 1
radius (accounting) keepalive username Test-Username
radius keepalive encrypted password 2ec59b3188f07d9b49f5ea4cc44d9586
radius (accounting) keepalive calling-station-id 000000000000000
radius keepalive valid-response access-accept
```

The command "radius (accounting) detect-dead-server keepalive" turns on the keep-alive approach instead of the consecutive failures in a aaamgr approach. In the example above, the system will send a test message with username Test-Username and password Test-Username every 30 seconds, and will retry every 3 seconds if no response is received, and will retry up to 3 times, after which it will mark the server down. Once it gets its first response, it will mark it back up again.

Here is an example authentication request/response for the above settings:

```
<<<<OUTBOUND  17:50:12:657 Eventid:23901(6)
RADIUS AUTHENTICATION Tx PDU, from 192.168.50.151:32783 to 192.168.50.200:1812 (142) PDU-dict=starent-vsa1
  Code: 1 (Access-Request)
  Id: 16
  Length: 142
  Authenticator: 51 6D B2 7D 6A C6 9A 96 0C AB 44 19 66 2C 12 0A
       User-Name = Test-Username
       User-Password = B7 23 1F D1 86 46 4D 7F 8F E0 2A EF 17 A1 F3 BF
       Calling-Station-Id = 000000000000000
```

```
      Service-Type = Framed
      Framed-Protocol = PPP
      NAS-IP-Address = 192.168.50.151
      Acct-Session-Id = 00000000
      NAS-Port-Type = HRPD
      3GPP2-MIP-HA-Address = 255.255.255.255
      3GPP2-Correlation-Id = 00000000
      NAS-Port = 4294967295
      Called-Station-ID = 00

 INBOUND>>>>>  17:50:12:676 Eventid:23900(6)
 RADIUS AUTHENTICATION Rx PDU, from 192.168.50.200:1812 to 192.168.50.151:32783 (34) PDU-
dict=starent-vsa1
  Code: 2 (Access-Accept)
  Id: 16
  Length: 34
  Authenticator: 21 99 F4 4C F8 5D F8 28 99 C6 B8 D9 F9 9F 42 70
      User-Password = testpassword
```

The same SNMP traps are used to signify the unreachable/down and reachable/up Radius states as with the original approach:

```
 Fri Feb 27 17:54:55 2009 Internal trap notification 39 (AAAAuthSvrUnreachable) server 1 ip
address 192.168.50.200
 Fri Feb 27 17:57:04 2009 Internal trap notification 40 (AAAAuthSvrReachable) server 1 ip
address 192.168.50.200
```

The “show radius counters all” has a section for keeping track of the keepalive requests for authentication and accounting as well – here are the authentication counters:

```
    Server-specific Keepalive Auth Counters
    ---------------------------------------
      Keepalive Access-Request Sent:                          33
      Keepalive Access-Request Retried:                       3
      Keepalive Access-Request Timeouts:                      4
      Keepalive Access-Accept Received:                       29
      Keepalive Access-Reject Received:                       0
      Keepalive Access-Response Bad Authenticator Received:   0
```

```
Keepalive Access-Response Malformed Received:             0
Keepalive Access-Response Malformed Attribute Received:   0
Keepalive Access-Response Unknown Type Received:          0
Keepalive Access-Response Dropped:                        0
```

Traps and Alarms for Auth/Accounting Failures

There are a number of ways alerts can be generated for Radius-related issues. The aforementioned SNMP traps for servers being marked down is one of the most obvious, and should be investigated immediately. There are also alarms and traps that can be triggered for failed authentication rates. The values for the triggers should be planned carefully, so that no unnecessary alarms are triggered.

Triggers are available for authentication and accounting. A poll interval rate is specified as the period over which the entity being monitored is monitored. The difference between aaa-auth-failure/aaa-acct-failure and aaa-auth-failure-rate/aaa-acct-failure-rate is that the former measures an absolute number of failures within the specified time, while the latter measures percentage failures out of the total attempts. Taking the percentage approach is often the most logical for measuring rates because it does not depend on traffic load which varies during the day, night, weekends and holidays, and also over time as the subscriber base grows.

Note that failures include the sum of rejections (implies failure response received) and no responses at all.

For a given metric, a poll interval is specified, threshold and clear values, and whether to enable monitoring or not. For example:

```
threshold poll aaa-auth-failure interval x
threshold poll aaa-auth-failure-rate interval x
threshold poll aaa-acct-failure interval x
threshold poll aaa-acct-failure-rate interval x
threshold poll aaa-retry-rate interval x

threshold aaa-auth-failure xclear x
threshold aaa-auth-failure-rate xclear x
threshold aaa-acct-failure x clear x
threshold aaa-acct-failure-rate x clear x
threshold aaa-retry-rate x clear x
```

```
 threshold monitoring aaa-auth-failure
 threshold monitoring aaa-acct-failure
 threshold monitoring aaa-retry-rate
```

Here are example snmp traps and logs for aaa-auth-failure for alarm trigger and clearing:

```
 Fri Jun 27 01:00:02 2008 Internal trap notification 216 (ThreshAAAAuthFail) threshold 1000
measured value 2370
 Fri Jun 27 01:10:02 2008 Internal trap notification 217 (ThreshClearAAAAuthFail) threshold 500
measured value 25
```

```
 2008-Jun-27+01:10:02.511 [alarmctrl 65200 info] [8/0/494 <evlogd:0> alarmctrl.c:273] [software
internal system critical-info] Alarm cleared: id 50020c643b920000: <23:aaa-auth-failure> has
reached or exceeded the configured threshold <1000>, the measured value is <2370>. It is
detected at <System>.
 2008-Jun-27+01:00:02.549 [alarmctrl 65201 info] [8/0/494 <evlogd:0> alarmctrl.c:180] [software
internal system critical-info] Alarm condition: id 50020c643b920000 (Minor): <23:aaa-auth-
failure> has reached or exceeded the configured threshold <1000>, the measured value is <2370>.
It is detected at <System>.
```

The alarm would look something like this:

```
 [source]ASR5000# show alarm outstanding
 Sev Object     Event
 --- ---------- -------------------------------------------------------------
 MN  Chassis    <23:aaa-auth-failure> has reached or exceeded the configured threshold <1000>,
the measured value is <2370>. It is detected at <System>.
```

Additional Data Collection

There may be circumstances where packet captures need to be done between the NAS IP address and the Radius server(s) to confirm where delays or packet drops are occurring. This information along with logs from the Radius server and Radius counters could help paint the picture of what is going on.

Logging for aaamgr, aaa-client, radius-auth, and radius-acct facilities need to be turned up beyond the default error level. Do this upon recommendation from Cisco Support, as increasing logging too high may put too much stress on the system and impact subscribers. The logging configuration command in the local context:

```
 logging filter runtime facility <aaamgr | aaa-client | radius-auth | radius-acct> level
<warning | unusual | info | trace | debug>
```

Logging monitor for a specific subscriber for which an issue is reproducible might also be useful in order to see underlying messages that would not be displayed by monitor subscriber.

Testing a specific behavior without having to set it up in the Radius server can be done by forcing local authentication via creating a subscriber template with the exact name of the subscriber – Radius authentication will not be attempted in that case. Successful authentication can be verified with the command: “show aaa local counters”.

Troubleshooting Radius Issues

Overview

This chapter discusses troubleshooting techniques for Radius-related issues to do with accounting and authentication.

Radius Overload

If the Radius server is getting overloaded, decrease the load by decreasing the value (default 256) configured for “radius (accounting) max-outstanding”, which sets a limit on the number of outstanding (unanswered) requests for any given aaamgr process. If the limit is reached, logs may indicate this: “**Failed to assign message id for radius authentication server x.x.x.x:1812**”. There is no way to specifically rate-limit authentication/accounting messages.

Radius Archiving

A feature for accounting that may be turned on is archiving, enabled with the command “radius accounting archive”. This allows for accounting packets that have failed to be responded to, to be re-queued and sent at a later time when the aaamgr processes have free cycles and are not busy processing authentication requests. The idea is that timeliness of accounting packets is not as important as authentication, though this may not be true in all situations. Note though there is no way to flush out existing archived messages. The "show radius" counter “Accounting-Request Pending” will show the number of archived accounting messages, which could increase over time if the accounting server gets bogged down. On the other hand, the “Access-Request Pending” counter for Access-Requests will decrement when it has given up trying to authenticate for a given call, which will always be a limited period of time (vs. accounting which could theoretically be tried forever).

Removing a Radius Server Temporarily

If during the troubleshooting process it has been decided to remove a Radius authentication or accounting server from the list of live servers for whatever reason, there is a (non-config) command that will take a server out of service indefinitely until it is desired to put it back in service. This is a cleaner approach than having to remove it from the configuration manually:

```
{disable | enable} radius (accounting) server x.x.x.x
```

```
[source]CSE2# show radius authentication servers detail

+-----Type:       (A) - Authentication   (a) - Accounting
|                 (C) - Charging         (c) - Charging Accounting
|                 (M) - Mediation        (m) - Mediation Accounting
|
|+----Preference: (P) - Primary          (S) - Secondary
||
||+---State:      (A) - Active           (N) - Not Responding
|||               (D) - Down             (W) - Waiting Accounting-On
|||               (I) - Initializing     (w) - Waiting Accounting-Off
|||               (a) - Active Pending   (U) - Unknown
|||
|||+--Admin       (E) - Enabled          (D) - Disabled
||||  Status:
||||
||||+-Admin
||||| status      (O) - Overridden       (.) - Not Overridden
||||| Overridden:
|||||
vvvvv IP              PORT  GROUP
----- --------------- ----- ----------------------
APNDO 192.168.50.200  1812  default
```

If one wants to change the priority of existing servers, one must first remove the server for which one wishes to change the priority, and then add it back in. When removing a server, the password/key does not need to be specified, but the port does, for example:

```
no radius server 192.168.50.200 port 1812
radius server 192.168.50.200 encrypted key 01abd002c82b4a2c port 1812 priority 3
```

Connectivity tests to Radius Server

There are a few commands that can be run to test connectivity to a Radius server.

radius test

This command (as shown below) sends a basic authentication request or accounting start and stop requests and waits for a response. For authentication, use any username and password, in which case a reject response will be received, confirming that Radius is working as designed, or use a known working username/password, in which case an accept response should be received.

```
radius test authentication server x.x.x.x port yyyy <user> <password>
radius test accoun
```

NOTE: This command uses the aaamgr process running on the SMC/MIO card to process the messages. Normal subscriber Radius traffic is handled by aaamgr processes running on the PSC/DPC cards. This applies to the aaa test command discussed in the next section also.

Here is an example output from monitor protocol and running the authentication version of the command on lab chassis:

```
[source]ASR5000# radius test authentication server 192.168.50.200 port 1812 test test

Authentication from authentication server 192.168.50.200, port 1812
Authentication Success: Access-Accept received
Round-trip time for response was 12.3 ms
<<<<OUTBOUND  14:53:49:202 Eventid:23901(6)
RADIUS AUTHENTICATION Tx PDU, from 192.168.50.151:32783 to 192.168.50.200:1812 (58) PDU-
dict=starent-vsa1
 Code: 1 (Access-Request)
 Id: 5
 Length: 58
 Authenticator: 56 97 57 9C 51 EF A4 08 20 E1 14 89 40 DE 0B 62
      User-Name = test
      User-Password = 49 B0 92 4D DC 64 49 BA B0 0E 18 36 3F B6 1B 37
      NAS-IP-Address = 192.168.50.151
      NAS-Identifier = source

INBOUND>>>>>  14:53:49:214 Eventid:23900(6)
RADIUS AUTHENTICATION Rx PDU, from 192.168.50.200:1812 to 192.168.50.151:32783 (34) PDU-
dict=starent-vsa1
```

```
  Code: 2 (Access-Accept)
  Id: 5
  Length: 34
  Authenticator: D7 94 1F 18 CA FE B4 27 17 75 5C 99 9F A8 61 78
       User-Password = testpassword
```

Failure scenario example:

```
 <<<<OUTBOUND  12:45:49:869 Eventid:23901(6)
 RADIUS AUTHENTICATION Tx PDU, from 192.168.1.1:33156 to 192.168.1.2:1645 (72) PDU-
dict=custom150
  Code: 1 (Access-Request)
  Id: 6
  Length: 72
  Authenticator: 67 C2 2B 3E 29 5E A5 28 2D FB 85 CA 0E 9F A4 17
       User-Name = test
       User-Password = 8D 95 3B 31 99 E2 6A 24 1F 81 13 00 3C 73 BC 53
       NAS-IP-Address = 192.168.1.1
       NAS-Identifier = source
       3GPP2-Session-Term-Capability = Both_Dynamic_Auth_And_Reg_Revocation_in_MIP

 INBOUND>>>>>  12:45:49:968 Eventid:23900(6)
 RADIUS AUTHENTICATION Rx PDU, from 192.168.1.2:1645 to 192.168.1.1:33156 (50) PDU-
dict=custom150
  Code: 3 (Access-Reject)
  Id: 6
  Length: 50
  Authenticator: 99 2E EC DA ED AD 18 A9 86 D4 93 52 57 4C 2F 84
       Reply-Message = Invalid username or password
```

As another example, here is a failure due to the wrong secret configured on the Radius server (or ASR 5000/ASR 5500):

```
 [source]ASR5000# radius test authentication server 192.168.50.200 port 1812 test test
 Response Failure: Bad Authenticator from RADIUS sever, probably mismatched key
 Round-trip time for response was 6.3 ms
```

Note that this would be counted as “Access-Request Response Bad Authenticator Received” in the radius counters.

Here is an example output from running the accounting version of the command. A password is not needed.

```
[source]ASR5000# radius test accounting server 192.168.50.200 port 1813 test

RADIUS Start to accounting server 192.168.50.200, port 1813
Accounting Success: response received
Round-trip time for response was 7.9 ms

RADIUS Stop to accounting server 192.168.50.200, port 1813
Accounting Success: response received
Round-trip time for response was 15.4 ms
```

```
<<<<OUTBOUND  15:23:14:974 Eventid:24901(6)
RADIUS ACCOUNTING Tx PDU, from 192.168.50.151:32783 to 192.168.50.200:1813 (62) PDU-
dict=starent-vsa1
  Code: 4 (Accounting-Request)
  Id: 8
  Length: 62
  Authenticator: DA 0F A8 11 7B FE 4B 1A 56 EB 0D 49 8C 17 BD F6
       User-Name = test
       NAS-IP-Address = 192.168.50.151
       Acct-Status-Type = Start
       Acct-Session-Id = 00000000
       NAS-Identifier = source
       Acct-Session-Time = 0

INBOUND>>>>>  15:23:14:981 Eventid:24900(6)
RADIUS ACCOUNTING Rx PDU, from 192.168.50.200:1813 to 192.168.50.151:32783 (20) PDU-
dict=starent-vsa1
  Code: 5 (Accounting-Response)
  Id: 8
  Length: 20
  Authenticator: 05 E2 82 29 45 FC BC D6 6C 48 63 AA 14 9D 47 5B
```

```
 <<<<OUTBOUND  15:23:14:983 Eventid:24901(6)
 RADIUS ACCOUNTING Tx PDU, from 192.168.50.151:32783 to 192.168.50.200:1813 (62) PDU-
dict=starent-vsa1
  Code: 4 (Accounting-Request)
  Id: 9
  Length: 62
  Authenticator: 29 DB F1 0B EC CE 68 DB C7 4D 60 E4 7F A2 D0 3A
       User-Name = test
       NAS-IP-Address = 192.168.50.151
       Acct-Status-Type = Stop
       Acct-Session-Id = 00000000
       NAS-Identifier = source
       Acct-Session-Time = 0

 INBOUND>>>>>  15:23:14:998 Eventid:24900(6)
 RADIUS ACCOUNTING Rx PDU, from 192.168.50.200:1813 to 192.168.50.151:32783 (20) PDU-
dict=starent-vsa1
  Code: 5 (Accounting-Response)
  Id: 9
  Length: 20
  Authenticator: D8 3D EF 67 EA 75 E0 31 A5 31 7F E8 7E 69 73 DC
```

In all of the above examples, the Radius test message was sent using the management aaamgr located on the SMC/MIO card. There is a more specific version of the command that can be run in tech support mode that allows specifying a specific aaamgr instance that is suspected of having an issue. For example, in the following example no response was received for instance 92 but was received for instance 93:

```
 [source]ASR5000# radius test instance 92 authentication server 192.168.1.1 port 1645 test test

 Authentication from authentication server 192.168.1.1, port 1645
 Communication Failure: No response received

 [source]CSE2# radius test instance 93 authentication server 192.168.1.1 port 1645 test test

 Authentication from authentication server 192.168.1.1, port 1645
```

```
 Authentication Failure: Access-Reject received
 Round-trip time for response was 38.0 ms
```

aaa test {authenticate <user> <password> | accounting username <user>}

These are similar commands as Radius test authentication/accounting commands, though a bit more information is included in the requests, and the port number is fixed according to the configuration.

```
 [source]ASR5000# aaa test authenticate test test

 Authentication Successful
   User level: unknown(2)
   User Privs: CLI

 <<<<OUTBOUND  15:02:59:055 Eventid:23901(6)
 RADIUS AUTHENTICATION Tx PDU, from 192.168.50.151:32783 to 192.168.50.200:1812 (76) PDU-
dict=starent-vsa1
  Code: 1 (Access-Request)
  Id: 8
  Length: 76
  Authenticator: 2E 2D 1F A9 19 FD 1A 6A 4E C0 AF 8A 04 C4 77 45
       User-Name = test
       NAS-IP-Address = 192.168.50.151
       NAS-Identifier = source
       Service-Type = Authenticate_Only
       Event-Timestamp = 1235851379
       NAS-Port = 4573834
       User-Password = D9 BF 75 9D BC 9B 45 00 F8 DB A1 6F A1 30 1D 3C

 INBOUND>>>>>  15:02:59:059 Eventid:23900(6)
 RADIUS AUTHENTICATION Rx PDU, from 192.168.50.200:1812 to 192.168.50.151:32783 (34) PDU-
dict=starent-vsa1
  Code: 2 (Access-Accept)
  Id: 8
  Length: 34
  Authenticator: EF A4 11 21 9B 59 DF 50 77 BF 66 59 F9 D7 B7 73
```

```
      User-Password = testpassword

 [source]CSE2# aaa test accounting username test

 Accounting Successful

 <<<<OUTBOUND  15:18:38:850 Eventid:24901(6)
 RADIUS ACCOUNTING Tx PDU, from 192.168.50.151:32783 to 192.168.50.200:1813 (74) PDU-
dict=starent-vsa1
  Code: 4 (Accounting-Request)
  Id: 6
  Length: 74
  Authenticator: 90 87 2F 57 14 5E 08 29 74 6A 16 0C 82 C3 CF 01
       User-Name = test
       NAS-IP-Address = 192.168.50.151
       Acct-Status-Type = Start
       Acct-Session-Id = 00000000
       NAS-Identifier = source
       Service-Type = Authenticate_Only
       Event-Timestamp = 1235852318
       NAS-Port = 4573839

 INBOUND>>>>>  15:18:38:857 Eventid:24900(6)
 RADIUS ACCOUNTING Rx PDU, from 192.168.50.200:1813 to 192.168.50.151:32783 (20) PDU-
dict=starent-vsa1
  Code: 5 (Accounting-Response)
  Id: 6
  Length: 20
  Authenticator: BC 75 DF 03 E1 BB CE 10 7B 70 85 2B 17 32 B0 8B

 <<<<OUTBOUND  15:18:38:862 Eventid:24901(6)
 RADIUS ACCOUNTING Tx PDU, from 192.168.50.151:32783 to 192.168.50.200:1813 (80) PDU-
dict=starent-vsa1
  Code: 4 (Accounting-Request)
  Id: 7
  Length: 80
  Authenticator: 76 D8 55 DC F4 16 25 D6 6C B1 5A F0 50 60 DF E1
       User-Name = test
       NAS-IP-Address = 192.168.50.151
```

```
        Acct-Status-Type = Stop
        Acct-Session-Id = 00000000
        NAS-Identifier = source
        Service-Type = Authenticate_Only
        Event-Timestamp = 1235852318
        Acct-Session-Time = 0
        NAS-Port = 4573839

 INBOUND>>>>>  15:18:38:876 Eventid:24900(6)
 RADIUS ACCOUNTING Rx PDU, from 192.168.50.200:1813 to 192.168.50.151:32783 (20) PDU-
dict=starent-vsa1
  Code: 5 (Accounting-Response)
  Id: 7
  Length: 20
  Authenticator: 47 F2 35 A5 86 07 12 EB 48 BC 49 C4 39 79 25 43
```

Problem Description:

AAAAccSvrUnreachable for a single aaamgr

This issue has been seen multiple times at multiple sites, always on a PDSN. Much troubleshooting has taken place without being able to determine root cause, and chassis reloads have fixed the issue. The issue has been seen just for accounting, and in each instance just for one aaamgr instance.

Log Collection:

- show snmp trap hist verbose | grep AAAAccSvrUnreachable
  - instance(s) causing the issue will NOT be reported here
  - should see AAAAccSrvReachable very quickly as long as any aaamgrs are receiving responses
- show context
- show config context source
- [source] show radius counters all [instance X]| grep -E "Accounting server address|Accounting-Request Sent|Accounting-Response Received|Accounting-Request Timeouts"
- show session susbsystem facility aaamgr <all | instance X>

- various fields will show much higher values for affected aaamgrs (see examples below)

- [source] radius test instance X accounting all test
  - any number of servers could fail depending on the root cause
- [source] show radius info group all instance X
  - provides the UDP port number (and ip address which one would already know) used by the aaamgr
- show npu flow ssd slot X verbose
  - check to see that all aaamgrs have the proper # of flows assigned for each card
- show npu flow record min-flowid <aaamgr min flow id> max-flowid <aaamgr max flow id> slot X verbose
  - ensure the details of suspected aaamgr flows are correct for each card
- packet capture between NAS IP address / aaamgr instance udp port # AND aaa accounting server with port #1646 (standard) taken at whatever capture points in the network are necessary to pin down where packets may be dropping. This point is critical!

Analysis:

The following messages are seen in the logs:

```
 Mon Sep 08 20:41:07 2014 Internal trap notification 52 (CLISessStart) user vendgrp privilege
level Operator ttyname /dev/pts/1
 Mon Sep 08 20:41:35 2014 Internal trap notification 53 (CLISessEnd) user vendgrp privilege
level Operator ttyname /dev/pts/1
 Mon Sep 08 20:55:49 2014 Internal trap notification 52 (CLISessStart) user vendgrp privilege
level Operator ttyname /dev/pts/1
 Mon Sep 08 20:56:17 2014 Internal trap notification 53 (CLISessEnd) user vendgrp privilege
level Operator ttyname /dev/pts/1
 Mon Sep 08 21:05:11 2014 Internal trap notification 1221 (MemoryOver) facility npumgr instance
7 card 7 cpu 1 allocated 284967 used 379040
 Mon Sep 08 21:05:21 2014 Internal trap notification 1222 (MemoryOverClear) facility npumgr
instance 7 card 7 cpu 1 allocated 284967 used 263428
 Mon Sep 08 21:10:43 2014 Internal trap notification 52 (CLISessStart) user vendgrp privilege
level Operator ttyname /dev/pts/1
 Mon Sep 08 21:11:11 2014 Internal trap notification 53 (CLISessEnd) user vendgrp privilege
level Operator ttyname /dev/pts/1

 Mon Sep 08 21:21:53 2014 Internal trap notification 42 (AAAAccSvrUnreachable) server 1 ip
```

```
address 192.168.86.10
 Mon Sep 08 21:21:55 2014 Internal trap notification 43 (AAAAccSvrReachable) server 1 ip
address 192.168.86.10

 Wed Sep 10 08:36:54 2014 Internal trap notification 42 (AAAAccSvrUnreachable) server 1 ip
address 66.168.86.10
 Wed Sep 10 08:37:00 2014 Internal trap notification 43 (AAAAccSvrReachable) server 1 ip
address 192.168.86.10
```

```
[source]5000> show snmp trap statistics | grep -i aaa

Wednesday September 10 08:38:19 UTC 2014

Trap Name                          #Gen #Disc  Disable Last Generated
---------------------------------- ----- -----  ------- --------------------
AAAAccSvrUnreachable                833     0        0  2014:09:10:08:36:54
AAAAccSvrReachable                  839     0        0  2014:09:10:08:37:00
```

The issue is occurring for **aaamgr instance 36** and further only seen with one Radius server 192.168.86.10.

Note: the output below is taken from two different instances (tickets) for this issue, where the aaamgr instance # was different for both tickets (36 in one and 114 in the other)

REFERENCE SECTION

Here are the commands that one could use to troubleshoot this issue, some of which are tech support commands. These same steps for the most part can be used for AAAAuthSrvUnreachable also.

- show snmp trap hist verbose | grep AAAAccSvrUnreachable
  - instance(s) causing the issue will NOT be reported here
  - should see AAAAccSrvReachable very quickly as long as any aaamgrs are receiving responses
- show context
- show config context source

- show radius counters all [instance X] | grep -E "Accounting server address|Accounting-Request Sent|Accounting-Response Received|Accounting-Request Timeouts"
- show session susbsystem facility aaamgr <all | instance X> (various fields will show much higher values for affected aaamgrs examples below)
- radius test instance X accounting all test (any number of servers could fail depending on the root cause)
- show radius info group all instance X (provides UDP port number and IP address used by the aaamgr)
- packet capture between NAS IP address / aaamgr instance udp port # AND aaa accounting server with port #1646 (standard) taken at whatever capture points in the network are necessary to pin down where packets may be dropping. This point is critical!

There doesn't appear to be any (major) trigger, it just starts happening:

```
 Mon Sep 08 21:05:11 2014 Internal trap notification 1221 (MemoryOver) facility npumgr instance
7 card 7 cpu 1 allocated 284967 used 379040
 Mon Sep 08 21:05:21 2014 Internal trap notification 1222 (MemoryOverClear) facility npumgr
instance 7 card 7 cpu 1 allocated 284967 used 263428
 Mon Sep 08 21:21:53 2014 Internal trap notification 42 (AAAAccSvrUnreachable) server 1 ip
address 192.168.86.10
 Mon Sep 08 21:21:55 2014 Internal trap notification 43 (AAAAccSvrReachable) server 1 ip
address 192.168.86.10
 Wed Sep 10 08:36:54 2014 Internal trap notification 42 (AAAAccSvrUnreachable) server 1 ip
address 192.168.86.10
 Wed Sep 10 08:37:00 2014 Internal trap notification 43 (AAAAccSvrReachable) server 1 ip
address 192.168.86.10
```

```
 [source]5000> show snmp trap statistics | grep -i aaa

 Wednesday September 10 08:38:19 UTC 2014

 Trap Name                          #Gen #Disc  Disable Last Generated
 ---------------------------------- ----- -----  ------- --------------------
 AAAAccSvrUnreachable                833     0        0  2014:09:10:08:36:54
 AAAAccSvrReachable                  839     0        0  2014:09:10:08:37:00
```

The issue is occurring for aaamgr instance 36 and further only seen with Radius server 192.168.86.10. The grep is very helpful for easy viewing:

```
[source]5000> show radius counters all instance 36 | grep -E "Accounting server
address|Accounting-Request Sent|Accounting-Response Received|Accounting-Request Timeouts"

Wednesday September 10 08:51:14 UTC 2014

   Accounting server address 192.168.86.10, port 1646:
     Accounting-Request Sent:                              274960760
     Accounting-Response Received:                         274020020
     Accounting-Request Timeouts:                          221140

   Accounting server address 192.168.86.13, port 1646:
     Accounting-Request Sent:                              1422570
     Accounting-Response Received:                         1422290
     Accounting-Request Timeouts:                          0
```

The above shows an increase of 2880 timeouts over 20 minutes.

Here are all the fields highlighted in the output from the session subsystem aaamgr command showing an issue for aaamgr 36, compared to the following aaamgr instance 37 which does not, just for reference. Clearing the counters could also be done, but showing the issue from inception captures the magnitude over time:

```
[source]5000> show session subsystem  facility aaamgr  instance 36
Wednesday September 10 08:51:18 UTC 2014

AAAMgr:  Instance 36
39947440 Total aaa requests              17985 Current aaa requests
24614090 Total aaa auth requests             0 Current aaa auth requests
       0 Total aaa auth probes               0 Current aaa auth probes
       0 Total aaa aggregation requests
       0 Current aaa aggregation requests
       0 Total aaa auth keepalive            0 Current aaa auth keepalive
15171628 Total aaa acct requests         17985 Current aaa acct requests
       0 Total aaa acct keepalive            0 Current aaa acct keepalive
20689536 Total aaa auth success        1322489 Total aaa auth failure
```

```
   86719 Total aaa auth purged            1016 Total aaa auth cancelled
       0 Total auth keepalive success        0 Total auth keepalive failure
       0 Total auth keepalive purged
       0 Total aaa aggregation success requests
       0 Total aaa aggregation failure requests
       0 Total aaa aggregation purged requests
   15237 Total aaa auth DMU challenged
   17985/70600 aaa request (used/max)
      14 Total diameter auth responses dropped
 6960270 Total Diameter auth requests        0 Current Diameter auth requests
   23995 Total Diameter auth requests retried
      52 Total Diameter auth requests dropped
 9306676 Total radius auth requests          0 Current radius auth requests
       0 Total radius auth requests retried
     988 Total radius auth responses dropped
      13 Total local auth requests           0 Current local auth requests
 8500275 Total pseudo auth requests          0 Current pseudo auth requests
    8578 Total null-username auth requests (rejected)
       0 Total aggregation responses dropped
15073834 Total aaa acct completed        79763 Total aaa acct purged  <<< If issue started
recently, this may not have yet started incrementing
  :
15171628 Total radius acct requests      17985 Current radius acct requests
      46 Total radius acct cancelled
   79763 Total radius acct purged
   11173 Total radius acct requests retried
      49 Total radius acct responses dropped
```

```
[source]5000> show session subsystem facility aaamgr instance 37
Wednesday September 10 08:51:28 UTC 2014

AAAMgr:  Instance 37
39571859 Total aaa requests                  0 Current aaa requests
24368622 Total aaa auth requests             0 Current aaa auth requests
       0 Total aaa auth probes               0 Current aaa auth probes
       0 Total aaa aggregation requests
       0 Current aaa aggregation requests
```

```
       0 Total aaa auth keepalive            0 Current aaa auth keepalive
15043217 Total aaa acct requests             0 Current aaa acct requests
       0 Total aaa acct keepalive            0 Current aaa acct keepalive
20482618 Total aaa auth success        1309507 Total aaa auth failure
   85331 Total aaa auth purged             968 Total aaa auth cancelled
       0 Total auth keepalive success        0 Total auth keepalive failure
       0 Total auth keepalive purged
       0 Total aaa aggregation success requests
       0 Total aaa aggregation failure requests
       0 Total aaa aggregation purged requests
   15167 Total aaa auth DMU challenged
       1/70600 aaa request (used/max)
      41 Total diameter auth responses dropped
 6883765 Total Diameter auth requests        0 Current Diameter auth requests
   23761 Total Diameter auth requests retried
      37 Total Diameter auth requests dropped
 9216203 Total radius auth requests          0 Current radius auth requests
       0 Total radius auth requests retried
     927 Total radius auth responses dropped
      15 Total local auth requests           0 Current local auth requests
 8420022 Total pseudo auth requests          0 Current pseudo auth requests
    8637 Total null-username auth requests (rejected)
       0 Total aggregation responses dropped
15043177 Total aaa acct completed            0 Total aaa acct purged
       0 Total acct keepalive success        0 Total acct keepalive timeout
  :
15043217 Total radius acct requests          0 Current radius acct requests
      40 Total radius acct cancelled
       0 Total radius acct purged
     476 Total radius acct requests retried
      37 Total radius acct responses dropped
```

Radius accounting tests fail for this aaamgr for just 192.168.86.10

```
[source]5000> radius test instance 36 accounting all test
Wednesday September 10 10:06:29 UTC 2014
```

```
RADIUS Start to accounting server 192.168.86.14, port 1646
Accounting Success: response received
Round-trip time for response was 51.2 ms

RADIUS Start to accounting server 192.168.86.10, port 1646
Communication Failure: no response received

RADIUS Stop to accounting server 192.168.86.10, port 1646
Communication Failure: no response received

RADIUS Start to accounting server 192.168.86.10, port 1646
Accounting Success: response received
Round-trip time for response was 81.6 ms

RADIUS Stop to accounting server 192.168.86.10, port 1646
Accounting Success: response received
Round-trip time for response was 77.1 ms
```

The NPU flows are clean for aaamgr 36 (flow shown only for one of the slots, it is the same for all the slots as expected). Note for "show radius info", only the aaa servers for the default group are shown with this version of the command (see more detailed version below), while in this case the issue is with ONE of the two servers in group aaa-3g.com. A single NPU flow handles all of the connections to all servers from all aaa groups using the same NAS IP address in a particular context for a particular aaamgr, and since the issue seems to only affect a specific aaa server, and just for accounting, then this would unlikely be an NPU flow issue anyway since other aaa servers ,including authentication servers, use the same flow and are not having any issues.

```
aaa group default

   radius deadtime 5
   radius accounting deadtime 3
   radius detect-dead-server consecutive-failures 4 response-timeout 10
   radius accounting detect-dead-server consecutive-failures 4 response-timeout 10
   radius max-outstanding 3
   radius accounting max-outstanding 3
   radius max-retries 0
   radius accounting max-retries 3
```

```
       radius max-transmissions 1
       radius accounting max-transmissions 3
       radius accounting timeout 10
       radius attribute nas-ip-address address x.x.x.x
       radius attribute nas-identifier xxxxxxx#10;       no radius authenticate null-username
       no radius accounting archive
       radius dictionary custom9
       radius accounting rp trigger-policy custom
       radius server 192.168.86.13 encrypted key
+A0xd66i5ta8rye21r7jg4p5goox3b7ezj2rxyi4z0dinlhx0s5r3s port 1645 priority 1
       radius server 192.168.86.13 encrypted key
+A3670dxvh3axm51mi1qi7358jze0n2bc8t7vpu2g0053fci51ay55 port 1645 priority 2
       radius accounting server 192.168.86.13 encrypted key
+A2ga9jz7lnkocq0ess8qw10boi50mv8smg45uzdr34zcucy2 port 1646 priority 1
       radius accounting server 192.168.87.13 encrypted key
+A1uk43oafg180h2z7v0s79zvdjq0sb3zxbl3hhj81p1fgiw53939n port 1646 priority 2
     #exit

    aaa group aaa-3g.com

       radius deadtime 5
       radius accounting deadtime 3
       radius detect-dead-server consecutive-failures 4 response-timeout 10
       radius accounting detect-dead-server consecutive-failures 4 response-timeout 10
       radius max-outstanding 3
       radius accounting max-outstanding 3
       radius max-retries 0
       radius accounting max-retries 3
       radius max-transmissions 1
       radius accounting max-transmissions 3
       radius accounting timeout 10
       radius attribute nas-identifier xxxxx
       no radius authenticate null-username
       radius dictionary custom9
       radius accounting rp trigger-policy custom
       radius server 192.168.86.10 encrypted key
+A3l9q6fr6vuxp71bb7r6q502xlo0a0xnk7feg6a63j0pkgtthurub port 1645 priority 1
       radius server 192.168.86.10 encrypted key
+A0l5vd78oxmn542dw0w8uzdhdm72169tkh6ingxp0uprt1sm04sao port 1645 priority 2
```

```
      radius accounting server 192.168.86.10 encrypted key
+A3pgmv2z96z5h262gheyqk02bg0c073xc8m2dlde9 port 1646 priority 1
      radius accounting server 192.168.87.10 encrypted key +A09sw0vas1o4v71i1abenbtdna9d8 port
1646 priority 2
    #exit
```

```
[source]5000> show radius info instance 36
Wednesday September 10 09:38:44 UTC 2014
Context source:
---------------------------------------------


  AAAMGR instance 36:  cb-list-en: 1 AAA Group:
  ---------------------------------------------
  socket number: 387611568
  socket state: ready
  local ip address: 172.20.148.13
  local udp port: 2456
  flow id: 20362979
  use med interface: yes
  VRF context ID: 2

    Authentication servers:
    ---------------------------------------------
    Primary  authentication server address 192.168.86.10, port 1645
      state Not Responding
      priority 1
      requests outstanding 0
      max requests outstanding 3
      consecutive failures 0
    Secondary  authentication server address 192.168.87.10, port 1645
      state Active
      priority 2
      requests outstanding 0
      max requests outstanding 3
      consecutive failures 0
```

```
    Accounting servers:
    ------------------------------------------
    Primary  accounting server address 192.168.86.10, port 1646
      state Active
      priority 1
      requests outstanding 0
      max requests outstanding 3
      consecutive failures 0
    Secondary  accounting server address 192.168.87.10, port 1646
      state Active
      priority 2
      requests outstanding 0
      max requests outstanding 3
      consecutive failures 0
```

Note: An expanded version of this command for ALL Radius groups would have shown the consecutive failures in an aaamgr. The non-specific version of the command run above only reports for the aaa group default which is not where the issue is occurring (it's occurring in aaa-3g.com group).

This example output was taken from a different ticket where the issue was on aaamgr 114:

show radius info radius group all instance X

```
[source]5000> show radius info radius group all instance 114
Wednesday October 01 11:39:15 UTC 2014

Context source:
-------------------------------------------


  AAAMGR instance 114:  cb-list-en: 1 AAA Group: aaatest.com
  -------------------------------------------
    Authentication servers:
    -------------------------------------------
    Primary  authentication server address 192.168.86.14, port 1645
      state Active
      priority 1
      requests outstanding 0
```

```
    max requests outstanding 3
    consecutive failures 0
  Secondary  authentication server address 192.168.77.14, port 1645
    state Active
    priority 2
    requests outstanding 0
    max requests outstanding 3
    consecutive failures 0

  Accounting servers:
  ------------------------------------------
  Primary  accounting server address 192.168.86.14, port 1646
    state Active
    priority 1
    requests outstanding 0
    max requests outstanding 3
    consecutive failures 0
  Secondary  accounting server address 192.168.77.14, port 1646
    state Active
    priority 2
    requests outstanding 0
    max requests outstanding 3
    consecutive failures 0

  Mediation Authentication servers:
  ------------------------------------------

  Mediation Accounting servers:
  ------------------------------------------

AAAMGR instance 114:  cb-list-en: 1 AAA Group: aaatest.com
------------------------------------------
  Authentication servers:
  ------------------------------------------
  Primary  authentication server address 192.168.86.10, port 1645
    state Active
    priority 1
    requests outstanding 0
    max requests outstanding 3
```

```
    consecutive failures 0
  Secondary  authentication server address 192.168.77.10, port 1645
    state Active
    priority 2
    requests outstanding 0
    max requests outstanding 3
    consecutive failures 0

  Accounting servers:
  ------------------------------------------
  Primary  accounting server address 192.168.86.10, port 1646
    state Down
    priority 1
    requests outstanding 3
    max requests outstanding 3
    consecutive failures 7
    dead time expires in 146 seconds
  Secondary  accounting server address 192.168.77.10, port 1646
    state Active
    priority 2
    requests outstanding 0
    max requests outstanding 3
    consecutive failures 0

  Mediation Authentication servers:
  ------------------------------------------

  Mediation Accounting servers:
  ------------------------------------------

AAAMGR instance 114:  cb-list-en: 1 AAA Group: default
------------------------------------------
socket number: 388550648
socket state: ready
local ip address: 10.210.21.234
local udp port: 25808
flow id: 20425379
use med interface: yes
VRF context ID: 2
```

```
  Authentication servers:
  -----------------------------------------
  Primary  authentication server address 192.168.86.13, port 1645
    state Active
    priority 1
    requests outstanding 0
    max requests outstanding 3
    consecutive failures 0
  Secondary  authentication server address 192.168.77.13, port 1645
    state Not Responding
    priority 2
    requests outstanding 0
    max requests outstanding 3
    consecutive failures 0

  Accounting servers:
  -----------------------------------------
  Primary  accounting server address 192.168.86.13, port 1646
    state Active
    priority 1
    requests outstanding 0
    max requests outstanding 3
    consecutive failures 0
  Secondary  accounting server address 192.168.77.13, port 1646
    state Active
    priority 2
    requests outstanding 0
    max requests outstanding 3
    consecutive failures 0
```

From an external PCAP, accounting requests between the aaamgr instance and associated bouncing server were not being responded to. In this case, aaamgr 114 was the one failing, and it was sourcing with udp port 25808, so filter "udp.port == 25808". Note that authentication packets were being responded to.

```
context source
    aaa group default
      radius attribute nas-ip-address address 10.210.21.234
```

```
   aaa group aaatest.com
      radius accounting server 192.168.86.10 encrypted key +A2ntd8tcfamm0nr179l44h06jtio port
1646 priority 1
```

```
[source]HSGW> show radius client status

RADIUS client status: UP

Active nas-ip-address: 172.21.21.234
Configured primary nas-ip-address: 10.210.21.234 UP
Configured backup nas-ip-address: NONE DOWN

[source]HSGW> show radius info radius group all instance 114
Saturday October 18 04:57:39 UTC 2014

Context source:
-------------------------------------------
  AAAMGR instance 114:  cb-list-en: 1 AAA Group: aaatest.com
    Accounting servers:
    -------------------------------------------
    Primary  accounting server address 192.168.86.10, port 1646
      state Down
      priority 1
      requests outstanding 3
      max requests outstanding 3
      consecutive failures 4
      dead time expires in 174 seconds

 AAAMGR instance 114:  cb-list-en: 1 AAA Group: default
  -------------------------------------------
  socket number: 388550648
  socket state: ready
  local ip address: 10.210.21.234
  local udp port: 25808
  flow id: 20425379
  use med interface: yes
  VRF context ID: 2
```

```
[source]HSGW> show ip int summary

Interface Name                  Address/Mask        Port                Status
============================== ================== ================== ======
19/1-RP                         10.210.21.228/29    19/1 vlan 2423     UP
19/1-RP-1x                      10.183.152.4/24     19/1 vlan 2498     UP
PDSN-RP                         10.210.21.234/32    Loopback           UP

[source]HSGW> show ip route
"*" indicates the Best or Used route.  S indicates Stale.

 Destination         Nexthop          Protocol   Prec Cost Interface
*0.0.0.0/0           172.21.21.22    static     1    0    19/1-RP

[source]HSGW> show ip arp
Flags codes:
I - Incomplete, R - Reachable, M - Permanent, S - Stale,
D - Delay,      P - Probe,     F - Failed
Address         Link Type Link Address      Flags  Mask            Interface
172.21.21.22    ether     00:00:5E:00:01:0B R                     19/1-RP
```

In a couple of hours, only 48 responses have been received, yet over 100,000 timeouts have occurred (and that doesn't include re-transmits).

```
 source]5000> show radius counters server 192.168.86.10 instance  114 | grep -E "Accounting-
Request Sent|Accounting-Response Received|Accounting-Request Timeouts"
 Wednesday October 01 18:12:24 UTC 2014
      Accounting-Request Sent:                                  14306189
      Accounting-Response Received:                             14299843
      Accounting-Request Timeouts:                              6342

 [source]5000>show radius counters server 192.168.86.10 instance 114 | grep -E "Accounting
server address|Accounting-Request Sent|Accounting-Response Received|Accounting-Request
Timeouts"
 Wednesday October 22 20:26:35 UTC 2014
    Accounting server address 192.168.86.10, port 1646:
```

```
     Accounting-Request Sent:                                  15105872
     Accounting-Response Received:                             14299891
     Accounting-Request Timeouts:                              158989


[source]5000> show radius counters server 192.168.86.10 instance 114 | grep Accounting
Wednesday October 22 20:33:09 UTC 2014
   Per-Context RADIUS Accounting Counters
   Accounting Response
   Server-specific Accounting Counters
    Accounting-Response Received:                            14299891
     Accounting-Request Current Consecutive Failures in a mgr: 11
     Current Accounting-Request Queued:                       17821


[source]5000> show radius counters server 192.168.86.10 instance 114 | grep Accounting
Wednesday October 22 20:38:57 UTC 2014
   Per-Context RADIUS Accounting Counters
   Accounting Response
   Server-specific Accounting Counters
   Accounting server address 192.168.86.10, port 1646:
     Accounting-Response Received:                 14299891  <==  NO successes in 12 minutes
```

Resolution:

Packet captures were taken between a Load Balancer and firewall that were located between the ASR 5000 and the Radius server, and these show that the firewall was dropping packets. This turned out to be a bug in the firewall and so the problem would just start occuring on the PDSN without any apparent trigger (as mentioned earlier). Restarting the failing aaamgr task or doing a PSC migration for the PSC housing the aaamgr would not resolve the issue, because the source UDP port used for Radius requests for that particular aaamgr would not change in the process of doing so.

The only resolutions for this issue are: 1) Reloading the PDSN which changes all the UDP ports used by all aaamgr instances, or 2) switching over to the redundant firewall (and rebooting the firewall with the issue), or 3) ultimately fixing the bug in the firewall

While the key to getting to the root cause of this issue was obtaining a PCAP to confirm that the PDSN was not dropping resposes, running the various CLIs on the PDSN helped in narrowing down the issue.

Diameter

Diabase

Overview

This section covers basic Diameter protocol, Diabase routing, and general troubleshooting approaches for multiple scenarios.


The Diameter base protocol was designed to provide an Authentication, Authorization and Accounting (AAA) framework for applications such as network access or IP mobility.

Diameter Base protocol handles the Diameter session establishment and control.

A Diameter session between client and server is established over TCP (or SCTP for secure interchange if required) and by exchanging capabilities and host information.

Capabilities exchange information is used between the two endpoints to allow or deny session connections and to verify both systems use the same application on top of the Diameter protocol session. Common Diameter base messages are exchanged between peers (only peer related, not subscriber related):

Sample Diabase callflow



Messages description:

- **Capabilities-Exchange-Request (CER)**: This message is sent from the client to the server to know the capabilities of the server.
- **Capabilities-Exchange-Answer (CEA)**: This message is sent from the server to the client in response to the CER message.
- **Device-Watchdog-Request (DWR)**: After the CER/CEA messages are exchanged, if there is no more traffic between peers for a while, to monitor the health of the connection, a DWR message is sent from the client. The Device Watchdog timer (Tw) is configurable in PCEF / GW and can vary from 6 through 30 seconds. A very low value will result in duplication of messages. The default value is 30 seconds. On two consecutive expiries of Tw without a DWA, the peer is taken down.
- **Device-Watchdog-Answer (DWA)**: This is the response to the DWR message from the server. This is used to monitor the connection state.
- **Disconnect-Peer-Request (DPR)**: This message is sent to the peer to confirm the shutdown of connection. PCEF / GW only receives this message.
- **Disconnect-Peer-Answer (DPA)**: This message is the response to the DPR request from the peer. On receiving the DPR, the peer sends DPA and puts the connection state to "DO NOT WANT TO TALK TO YOU" state. If a connection is stuck, there are a few options to get the connection back. One is reconfiguring (remove/re-add) the peer again and another is "**Diameter reset connection endpoint <**endpoint name**>**" at admin user mode.

Diabase Commands

- show diameter statistics
- show diameter peers full all
- show diameter message-queue counters outbound
- show diameter message-queue counters inbound
- show diameter route status
- show diameter route status full
- show diameter route table wide
- show session disconnect-reasons

Example Scenarios

Capabilities Exchange failure scenario

Problem Description:

Customer noticed DiameterPeerDown in the snmp trap logs.

Logs collection:
1. Collect trace from the wire (PCAP, Wireshark) on the particular Diameter interface.

2. If there is no way to collect this information, during non-peak hours collect "monitor protocol" with option 75 > Option 1 - Diabase

> **Monitor protocol is a service-impacting command, and it should be run on an off-loaded node or during off-peak hours.**

CLI used to troubleshoot the issue:

- show diameter statistics endpoint <endpoint name>
- show diameter peers full endpoint <endpoint name>

Analysis:

1. Collect "monitor protocol" / PCAP trace to see complete communication. In this example one CER can be seen where GGSN informs OCS what standards it supports. In CEA it is noticed that the OCS (server) in this scenario doesn't allow the GGSN (client) to establish a Diameter connection.

```
Tuesday May 05 2015
<<<<OUTBOUND  17:51:44:393 Eventid:92800(5)
Diameter message from 192.168.1.2:33861 to 192.168.1.129:3868
  Base Header Information:
   Version: 1
   Message Length: 172
   Command Flags: REQ    (128)
   Command Code: Capabilities-Exchange-Request (257)
   Application ID: Diameter-Common-Message (0)
```

```
   Hop2Hop-ID: 0x0000020c
   End2End-ID: 0x8e4b7ae0
  AVP Information:
        [M] Origin-Host: 0002-sessmgr.LAB-XT2-2
        [M] Origin-Realm: lab.realm
        [M] Host-IP-Address: IPv4 192.168.1.2
        [M] Vendor-Id: 8164
        Product-Name: SSI
        [M] Origin-State-Id: 1430845668
        [M] Supported-Vendor-Id: 10415
        [M] Auth-Application-Id: 4
        [M] Inband-Security-Id: NO_INBAND_SECURITY (0)
        Firmware-Revision: 52519

Tuesday May 05 2015
INBOUND>>>>>  17:51:44:394 Eventid:92801(5)
Diameter message from 192.168.1.129:3868 to 192.168.1.2:33861
  Base Header Information:
   Version: 1
   Message Length: 184
   Command Flags:     (0)
   Command Code: Capabilities-Exchange-Answer (257)
   Application ID: Diameter-Common-Message (0)
   Hop2Hop-ID: 0x0000020c
   End2End-ID: 0x8e4b7ae0
  AVP Information:
        [M] Result-Code: DIAMETER_UNABLE_TO_DELIVER (3002)
        [M] Origin-Host: minid-ocs
        [M] Origin-Realm: lab.realm
        [M] Host-IP-Address: IPv4 127.0.0.1
        [M] Vendor-Id: 0
        Product-Name: Dog
        [M] Origin-State-Id: 1430862704
        [M] Supported-Vendor-Id: 10415
        [M] Supported-Vendor-Id: 12645
        [M] Auth-Application-Id: 4
        [M] Inband-Security-Id: NO_INBAND_SECURITY (0)
        Firmware-Revision: 1234
```

2 Check the current state of the connection with this command. Desired state should be OPEN.

```
# show diameter peers full endpoint DCCA-OCS
--------------------------------------------------------------------------------
Context: Gi                    Endpoint: DCCA-OCS
--------------------------------------------------------------------------------
Peer Hostname: minid-ocs
  Local Hostname: 0001-sessmgr.LAB-XT2-2
  Peer Realm: lab.realm
  Local Realm: lab.realm
  Peer Address: 192.168.1.129:3868
  Local Address: 192.168.1.2:3868
  State: IDLE [TCP]
  CPU: 1/0                                Task: sessmgr-1
  Messages Out/Queued: 0/0
  Supported Vendor IDs: 10415
  Admin Status: Enable
  DPR Disconnect: N/A
  Peer Backoff Timer running:N/A
```

3 Check the current statistics regarding the connection with this command.

```
# show diameter statistics endpoint DCCA-OCS


Connection statistics:
  Connection attempts:                                    124
  Connection failures:                                    124
  Connection reads:                                         0
  Connection starts:                                      124
  Connection disconnects:                                   0
  Connection closes:                                      124
  Connection DHOST requests:                              124
  Connection DHOST removes:                               124
  Connection Timeouts:                                      0
  Tc Expire Connection Attempts:                          124
```

Resolution :

For this specific problem, The Diameter server team should be engaged to verify and allow the client to establish the connection.

Capabilities Exchange - Server does not support Vendor-Id

Problem Description:

Mobile operator noticed a problem in communication between GGSN and OCS: It seems that mandatory 3GPP AVPs are missing in CCR messages.

Logs collection:

1. Collect trace from the wire (PCAP, Wireshark trace) on Gy interface.
2. If there is no way to collect this information, during the low peak hour, collect monitor protocol with option 75 > Option 1 - Diabase & Option 2 - DIAMETER Gy.

> **Monitor protocol is a service-impacting command, and it should be run on an offloaded node or during off-peak hours.**

CLI used to troubleshoot the issue:

- show diameter statistics endpoint <endpoint name>
- show diameter peers full endpoint <endpoint name>

Analysis:

1. It can be seen that communication was established (State: OPEN [TCP]) between Client (GGSN) and server (OCS) but Supported Vendor IDs are NONE. This means currently the OCS server is only using RFC 4006-supported AVPs in this communication.

```
# show diameter peers full endpoint DCCA-OCS


--------------------------------------------------------------------------------
Context: Gi                   Endpoint: DCCA-OCS
--------------------------------------------------------------------------------
 Peer Hostname: minid-ocs
  Local Hostname: 0001-sessmgr.LAB-XT2-2
```

```
  Peer Realm: lab.realm
  Local Realm: lab.realm
  Peer Address: 192.168.1.129:3868
  Local Address: 192.168.1.2:45620
  State: OPEN [TCP]
  CPU: 1/0                                Task: sessmgr-1
  Messages Out/Queued: 0/0
  Supported Vendor IDs: None
  Admin Status: Enable
  DPR Disconnect: N/A
  Peer Backoff Timer running:N/A
```

2 If communication is reset between GGSN (Client) and OCS (Server), the CER/CEA exchange can be seen in Monitor protocol. AVP **Vendor-Id** contains the IANA "SMI Network Management Private Enterprise Codes"value assigned to the vendor of the Diameter application. In combination with the **Supported-Vendor-Id** AVP this MAY be used in order to know which vendor specific attributes may be sent to the peer.
AVP **Supported-Vendor-Id:** Is used in the CER and CEA messages in order to inform the peer that the sender supports (a subset of) the vendor-specific AVPs defined by the vendor identified in this AVP.

```
# diameter reset connection endpoint DCCA-OCS peer minid-ocs


<<<<OUTBOUND  10:33:14:299 Eventid:92800(5)
Diameter message from 192.168.1.2:43109 to 192.168.1.129:3868
  Base Header Information:
   Version: 1
   Message Length: 172
   Command Flags: REQ    (128)
   Command Code: Capabilities-Exchange-Request (257)
   Application ID: Diameter-Common-Message (0)
   Hop2Hop-ID: 0x00000013
   End2End-ID: 0xd54ae589
  AVP Information:
        [M] Origin-Host: 0004-sessmgr.LAB-XT2-2
        [M] Origin-Realm: lab.realm
        [M] Host-IP-Address: IPv4 192.168.1.2
```

```
        [M] Vendor-Id: 8164 <-- Cisco
        Product-Name: SSI
        [M] Origin-State-Id: 1430920532
        [M] Supported-Vendor-Id: 10415 <-- 3GPP TS 32.299
        [M] Auth-Application-Id: 4
        [M] Inband-Security-Id: NO_INBAND_SECURITY (0)
        Firmware-Revision: 52519


INBOUND>>>>>  10:33:14:299 Eventid:92801(5)
Diameter message from 192.168.1.129:3868 to 192.168.1.2:43109
  Base Header Information:
   Version: 1
   Message Length: 160
   Command Flags:     (0)
   Command Code: Capabilities-Exchange-Answer (257)
   Application ID: Diameter-Common-Message (0)
   Hop2Hop-ID: 0x00000013
   End2End-ID: 0xd54ae589
  AVP Information:
        [M] Result-Code: DIAMETER_SUCCESS (2001)
        [M] Origin-Host: minid-ocs
        [M] Origin-Realm: lab.realm
        [M] Host-IP-Address: IPv4 127.0.0.1
        [M] Vendor-Id: 0  <-- RFC 4006
        Product-Name: Dog
        [M] Origin-State-Id: 1430922794
        [M] Auth-Application-Id: 4
        [M] Inband-Security-Id: NO_INBAND_SECURITY (0)
        Firmware-Revision: 1234
```

3 OCS server reported to Client (GGSN) that it only supports RFC 4006, and the GGSN, as the client, must use only these AVPs. Following is an example of CCR-I with limited information. All session related information that is provided by 3GPP 32299 AVPs and Cisco-specific AVPs is missing.

```
Wednesday May 06 2015
<<<<OUTBOUND  10:33:17:165 Eventid:92810(5)
```

```
Diameter message from 192.168.1.2:49356 to 192.168.1.129:3868
  Base Header Information:
   Version: 1
   Message Length: 348
   Command Flags: REQ PXY   (192)
   Command Code: Credit-Control-Request (272)
   Application ID: Credit-Control (4)
   Hop2Hop-ID: 0x00000015
   End2End-ID: 0xd54ae58c
  AVP Information:
        [M] Session-Id: 0003-sessmgr.LAB-XT2-2;10020002;1027;554a262d-302
        [M] Origin-Host: 0003-sessmgr.LAB-XT2-2
        [M] Origin-Realm: lab.realm
        [M] Destination-Realm: lab.realm
        [M] Auth-Application-Id: 4
        [M] Service-Context-Id: 32251@3gpp.org
        [M] CC-Request-Type: INITIAL_REQUEST (1)
        [M] CC-Request-Number: 0
        [M] User-Name: testuser
        [M] Origin-State-Id: 1430920532
        [M] Event-Timestamp: Wednesday May 06 14:33:17 GMT 2015
        [M] Subscription-Id:
          [M] Subscription-Id-Type: END_USER_E164 (0)
          [M] Subscription-Id-Data: 64211234567
        [M] Subscription-Id:
          [M] Subscription-Id-Type: END_USER_IMSI (1)
          [M] Subscription-Id-Data: 450061234554321
        [M] Multiple-Services-Indicator: MULTIPLE_SERVICES_SUPPORTED (1)
```

Resolution :

On OCS server they need to enable support for 3GPP 32299 AVPs by returning in CEA:

Supported-Vendor-Id: **8164** <-- Cisco

Supported-Vendor-Id: **10415** <-- 3GPP TS 32299

Troubleshooting Diameter Peers Bouncing / not establishing

The following list of steps should be taken to determine if, and to what degree, there are Diameter peer establishment issues:

Show the current state of peer connections:

[Ingress context] show diameter peers full [endpoint <endpoint>] | grep –E "Peer Hostname|State|CPU"

Determine which Diameter interfaces are affected -- One, Some, or All? S6b, S6a, Gx, Gy, Rf, etc.

Check if the affected connections are associated with a specific diamproxy process. If the affected peers are tied to a specify diamproxy, then it may be worth looking closely at the state of the PSC / DPC on which that proxy is housed, especially if multiple Diameter interfaces are having issues also tied to that diamproxy.

Other points to investigate / questions to ask:

- Are affected connections associated with specific peer(s)?
- Are the peers down hard or are they bouncing?
- Are other nodes at the same region or site experiencing the same issue?
- Can the endpoints be continuously pinged, sourced from the appropriate loopback address? If yes, it implies potential Routing / Transport Issue
- The SNMP traps often have the answers to the above questions

Importantly, IF for every Diameter interface there is a diamproxy instance that has one peer up, then there should be no subscriber impact. Conversely if there is a Diameter interface with a diamproxy instance that has all its peers down, then there will be subscriber impact for sessmgrs that use that diamproxy instance.

Diabase Timers

Following is additional clarification for timers that can help with troubleshooting Diabase communication issues.

```
Diameter endpoint dia-cisco
      origin realm cisco.in
```

```
       use-proxy
       origin host test.cisco.in address 10.259.65.49
       watchdog-timeout 30
       device-watchdog-request max-retries 1
       vsa-support negotiated-vendor-ids
       max-outstanding 256
       response-timeout 60
       connection timeout 30
       cea-timeout 30
       load-balancing-algorithm highest-weight
       destination-host-avp session-binding
       dpa-timeout 30
       no reconnect-timeout
       connection retry-timeout 30
       route-failure threshold 16
       route-failure deadtime 60
       route-failure recovery-threshold percent 90
       dynamic-route expiry-timeout 86400
       dscp be
       peer peer1.cisco.in realm cisco.in address x.x.x.x port 3868 send-dpr-before-disconnect
disconnect-cause  1
       peer peer2.cisco.in realm cisco.in address y.y.y.y port 3868 send-dpr-before-disconnect
disconnect-cause  1
       default dynamic-peer-failure-retry-count
       no associate sctp-parameters-template
```

Connection timeout (TCP)

Command configures timer for establishment of TCP communication with server. This is the amount of time to wait for the Diameter connection to establish at the TCP/IP level (TCP SYN ack not arriving in time in response to TCP SYN) before giving up.

```
 # show diameter peers full all (State: IDLE [TCP])


 ---------------------------------------------------------------------------
 Context: aaa                   Endpoint: dia-cisco
 ---------------------------------------------------------------------------
  Peer Hostname: peer1.cisco.in
```

```
  Local Hostname: 0001-sessmgr.cisco
  Peer Realm: cisco.in                  Local Realm: cisco.in
  Peer Address: 10.240.115.58:3868
  Local Address: 10.259.65.49:47447
  State: IDLE [TCP]                       CPU: 4/0
  Messages Out/Queued: 0/0                Task: sessmgr-1
  Supported Vendor IDs: 10415,12645
  Admin Status: Enable
  DPR Disconnect: N/A

-------------------------------------------------------------------------------
```

Connection retry-timeout (TCP)

This timer is used in case when initial TCP connection was not established, after this timer is expired, client will try to establish TCP communication with the server. If **connection timeout** and **connection retry-timeout** have the same time interval, in this case the client will try to establish TCP communication with the server after he finishes waiting for server response.

Example:

If connection timer is set up for 5 seconds, and retry timer for 60 seconds, then client will send first TCP-SYN and wait for a server response for 5 seconds. If the server doesn't respond, peer state will be "IDLE", but another request will be sent 60 seconds after first request (not after 5 sec).

The effect of this can be seen in the SNMP trap history, often where a connection goes down and comes up 10 seconds later.

Note that if a connection goes down in OPEN state and is not a result of admin disconnect (CLI-based) or not a result of remote DPR, then the ASR 5000/ASR 5500 will try to establish the connection immediately to prevent unwanted session loss due to connection failure. So, one will likely find many examples in the network of connections that quickly re-establish after going down. If this retry fails, then the subsequent retry will follow the retry-timer logic:

```
 2014-Jul-10+04:37:59.925 [diamproxy 119113 unusual] [2/0/24943 <diamproxy:1>
oxy_conn_mgmt.c:3480] [software internal system syslog] somepeer3: Connection closed at state
OPEN <- Closed
```

```
 2014-Jul-10+04:38:00.925 [diamproxy 119005 debug] [2/0/24943 <diamproxy:1> diamproxy.c:6935]
[software internal system syslog] Peer 0xb70f9dec somepeer3 state BOUND -> WAIT_CONNECT <-
First Try (immediate)
 2014-Jul-10+04:38:00.926 [diamproxy 119113 unusual] [2/0/24943 <diamproxy:1>
oxy_conn_mgmt.c:5829] [software internal system syslog] somepeer3: Connection closed at state
WAIT_CONNECT <- Close
 2014-Jul-10+04:38:20.935 [diamproxy 119005 debug] [2/0/24943 <diamproxy:1> diamproxy.c:6935]
[software internal system syslog] Peer 0xb70f9dec somepeer3 state BOUND -> WAIT_CONNECT<-
second try (retry timer (20 sec in setup) has kicked in)
 2014-Jul-10+04:38:20.935 [diamproxy 119113 unusual] [2/0/24943 <diamproxy:1>
oxy_conn_mgmt.c:5829] [software internal system syslog] somepeer3: Connection closed at state
WAIT_CONNECT<-close
 2014-Jul-10+04:38:40.943 [diamproxy 119005 debug] [2/0/24943 <diamproxy:1> diamproxy.c:6935]
[software internal system syslog] Peer 0xb70f9dec somepeer3 state BOUND -> WAIT_CONNECT<-third
try
 2014-Jul-10+04:38:40.943 [diamproxy 119113 unusual] [2/0/24943 <diamproxy:1>
oxy_conn_mgmt.c:5829] [software internal system syslog] somepeer3: Connection closed at state
WAIT_CONNECT <-close
```

Capabilties Exchange Timeout

After the TCP connection is up, the amount of time to wait for a Capabilities Exchange Answer message can be seen in the chassis config, "show config" under the specific peer's configuration:

```
cea-timeout 5
```

Response-timeout (Diabase)

This is a session timer at the Diabase level. The configured value is maximum time the client waits for ANY (CCA) answer from the PEER.

The client puts all messages in a queue that are sent towards the Peer but the Peer didn't respond / answer. A different (secondary) server will be tried per the configuration if no response from the primary.

If in the defined time interval, the Peer globally doesn't respond to ANY Client requests, the client declares that this peer is not reachable, and all messages in the "queue" are discarded. Response-timeout is refreshed/reset every time when Peer responds (CCA or DWA).

- If Client doesn't receive CCA from peer, but DWA arrives in inside response-timeout time interval, in this case response-timeout is refreshed/reset.
- If Client doesn't receive DWA from Peer, but CCA arrives inside response-timeout time interval, in this case response-timeout is refreshed/restarted.
- If Client doesn't receive CCA or DWA inside response-timeout time interval, Peers is marked as unreachable.

Watchdog-timeout (Tw) (Diabase)

This is a session timer at the Diabase level. The configured interval for the periodic sending of Device-Watchdog-Request from the Client towards the Peer to check Peer availability. Every time the Client receives Device-Watchdog-Answer it refreshes/restarts response-timeout counter. This is used mostly with services that don't have active connections.

In order to determine when a Diameter connection needs to be torn down due to no responses from the peer, a watchdog (keepalive) request is sent. If after 30secs of no inbound packets, and another 30secs passes (total 1 minute), the Diameter connection is torn down (retries = 1 means just one try, not two).

```
watchdog-timeout 30
device-watchdog-request max-retries 1
```

Per the above, watchdogs are sent on connections that are not hosting any sessions. The spec (RFC 3539, Appendix A - Detailed Watchdog Algorithm) says that the message must be sent within two seconds of the timer, so for 30s, that means between 28 – 32 seconds.

Backpressure

The number of outstanding Diameter messages that have not gotten a response from a particular peer and sessmgr instance talking to each other via a diamproxy TCP/IP connection can be limited so as to prevent overloading the Diameter servers and/or network. The following can be seen in the diameter endpoint config.

```
max-outstanding 5
```


For a given peer, where the buffer is full, backpressure occurs where new potential messages that need to be created do not get created. As long as that primary peer is up, the secondary peer will NOT be tried for the buffered messages, AND backpressure will occur for new potential messages. But the queue will constantly be cleared of messages that do get a reply, or in the case of timeout, get added to the secondary peer queue. So, while the queue is continually being cleared, it has the potential of being filled faster than it is being emptied, hence backpressure.

Diabase routing


Diameter server connectivity

Diameter servers are connected to the gateway in two ways. The following pictorial representation gives the abstract and detailed view about this.

Indirectly connected Diameter server



Directly connected Diameter server



Static routes

Route entries that are constructed based on the configuration under endpoint are called static routes. For each peer under the Diameter endpoint there will be two route entries

```
Config:        peer dra1 realm cisco.com address 192.168.10.1 port 3867
```

Flag	Host	Peer	Explanation
S	dra1@cisco.com	dra1	To reach the Diameter entity dra1, Gateway should send the message to dra1
S	*@cisco.com	dra1	To reach any Diameter entity in realm “cisco.com”, Gateway can send the message to dra1.

The first route entry is called **directly connected route** as the host is directly attached.

The second route entry is called **realm based route** as the host is wild carded here. This is also called **wild carded route**.


Config:

```
route-entry host DS1 realm cisco.com peer dra1
```

Flag	Host	Peer	Explanation
S	DS1@ cisco.com	dra1	To reach the Diameter entity DS1, Gateway should send the message to dra1

Dynamic routes:

Route entries that are dynamically learnt from the response messages from the peer are called dynamic routes. Consider the following Diameter server connection.



```
config:        peer dra1 realm cisco.com address 192.168.10.1 port 3867
```

Here the gateway has no knowledge about the Diameter server (DS1) that is sitting behind the DRA (dra1). Diameter routing table after loading the config would be:

Flag	Host	Peer	Explanation
S	dra1@ cisco.com	dra1	To reach the Diameter entity dra1, Gateway should send the message to dra1
S	*@ cisco.com	dra1	To reach any Diameter entity in realm “starentnetworks.com”, Gateway can send the message to dra1.

Let’s say a Diameter session’s destination host is DS1 (Based on the config in the application).

- The second realm based route entry would be selected for routing this session’s request to DS1. Here a Path-cache entry for the second route entry would be created.
- Gateway sends the intial request to dra1.
- dra1 forwards the request to DS1. DS1 replies back to dra1.
- Now dra1 forwards the reply from DS1 to Gateway. This message will have the Origin-host as DS1. Based on this gateway adds route for the Diameter entity DS1. This route is called a **Dynamic route**. Diameter routing table after this step would be:

Flag	Host	Peer	Explanation
D	DS1@cisco.com	dra1	To reach the Diameter entity DS1, Gateway should send the message to dra1
P	*@cisco.com	dra1	To reach any Diameter entity in realm “cisco.com”, Gateway can send the message to dra1.
S	dra1@cisco.com	dra1	To reach the Diameter entity dra1, Gateway should send the message to dra1
S	*@cisco.com	dra1	To reach any Diameter entity in realm “cisco.com”, Gateway can send the message to dra1.

Alternate option to dynamic routes is available via the following CLI under Diameter endpoint.

Route-entry host <hostname> **realm** <realm name> **peer** <peer name> **weight** <w1>

For the above server connectivity, the route-entry CLI would be:

route-entry host *DS1* realm cisco.*com* peer *dra1*

The above CLI implies that Host "DS1" of realm "cisco.com" can be reached via Peer "dra1".

Diameter routing table after loading the config would be:

Flag	Host	Peer	Explanation
S	DS1@ cisco.com	dra1	To reach the Diameter entity DS1, Gateway should send the message to dra1
S	dra1@ cisco.com	dra1	To reach the Diameter entity dra1, Gateway should send the message to dra1
S	*@ cisco.com	dra1	To reach any Diameter entity in realm "starentnetworks.com", Gateway can send the message to dra1.

Let's say a Diameter session's destination host is DS1 (Based on the config in the application).

- The first route entry would be selected for routing this session's request to DS1.
- Gateway sends the initial request to dra1.
- dra1 forwards the request to DS1. DS1 replies back to dra1.
- Now dra1 forwards the reply from DS1 to Gateway. This message will have the Origin-host as DS1. Diameter routing table after this step would be

Flag	Host	Peer	Explanation
P	DS1@ cisco.com	dra1	To reach the Diameter entity DS1, Gateway should send the message to dra1
S	DS1@ cisco.com	dra1	To reach the Diameter entity DS1, Gateway should send the message to dra1
S	dra1@ cisco.com	dra1	To reach the Diameter entity dra1, Gateway should send the message to dra1
S	*@ cisco.com	dra1	To reach any Diameter entity in realm "cisco.com", Gateway can send the message to dra1.

Data collection

There may be circumstances where packet captures need to be done between the ASR 5000/ASR 5500 origin host address and the Diameter peers to confirm where delays or packet drops are occurring. This information, along with logs from the Diameter server and ASR 5000/ASR 5500 counters, could help paint the picture of what is going on.

Logging

There may be circumstances also where logging for Diameter facilities need to be turned up beyond the default error level. This should only be done upon recommendation from Cisco Support as increasing the logging too high may risk stress on the system and impact subscribers. Runtime logging is done in config mode, while active CLI session logging is done in exec mode:

logging filter <runtime | active> facility <diabase | diameter | diameter-acct | diameter-auth | diamproxy | diameter-dns | credit-control | dhost | ims-authorizatn | rf-diameter> level <warning | unusual | info | trace | debug>

For Runtime logging, when running long enough for the period in question: **show logs**

For Active logging, to start: **logging active**. To stop: **no logging active**

Monitor Subscriber

"Monitor Subscriber" will, by default, capture all Diameter packets for a session. It can all be turned off completely with option 36 - "EC Diameter". To turn off any of the individual Diameter interfaces, choose option 75 to display a sub-menu from which the various interfaces can be turned on and off:

1 - Diabase (OFF)
2 - DIAMETER Gy (OFF)
3 - DIAMETER Gx/Ty/Gxx (OFF)
4 - DIAMETER Gq/Rx/Tx (OFF)
5 - DIAMETER Cx (OFF)
6 - DIAMETER Sh (OFF)
7 - DIAMETER Rf (OFF)
8 - DIAMETER EAP/STa/S6a/S6d/S6b/S13/SWm (OFF)
9 - DIAMETER HDD (OFF)

Turning up the verbosity can be helpful in certain situations, but Verbosity 2 should suffice most of the time.

Monitor Protocol

"Monitor Protocol" using option 36 will capture all Diameter packets, or use option 75 and the submenu that follows to choose the specific Diameter interface being troubleshot. Nonetheless, this must be used with care in a live network as it will easily miss packets under load and cause undo strain.

Logging Monitor

Logging monitor for a specific subscriber for which an issue is reproducible might also be useful in order to see underlying messages that would not be displayed by monitor subscriber.

Bulkstats

The most extensive and granular way to gather statistics over a given time period is bulkstats. The following are some of the defined schemas related to Diameter, and the variable definitions can be found in the documentation: System, DCCA, Diameter Accounting, Diameter Authentication, IMSA

The System schema contains data for many areas besides Diameter. It is broken down into separate schemas in the configuration and Diameter-related variables can be found in more than one schema. Search for “diam” in the System Schema Stats chapter of the documentation for variables related to Diameter, and then search for those variables in the config to see which schema they are listed under.

Packet Captures

Packet captures may be needed for troubleshooting the TCP/IP transport packets to setup and teardown Diameter connections as this is not available in any monitoring or CLI commands. Some counters in “**show diameter stat proxy** [endpoint <endpoint>] **debug-info**” will display valuable information, but they still don’t indicate what is on the wire or what may be causing the behavior observed. Packet captures can also be helpful for analyzing when unexpected, unknown, or corrupted AVPs are received.

ASR 5000/ASR 5500 have a tcpdump facility in debug mode (will require CLI test-commands password) that can be used to capture packets according to various criteria. While user data

packets cannot be captured, certain control packets can, such as Diameter. This capability should only be used when directly requested by Cisco Support.

When analyzing PCAPs that contain packets from multiple Diameter connections, it is possible to filter on just one connection where all the packets will use the same TCP/IP layer virtual stream index. This is a function used by Wireshark to represent a unique TCP/IP connection between a pair of IP addresses and TCP/IP port numbers. It is displayed in square brackets immediately below the TCP source and destination port numbers in the packet details window. Right-click a packet that is part of the stream to be analyzed and choose the popup menu option “Follow TCP Stream”. The appropriate filter for that stream will be displayed in the filter window and applied to the trace. (Filters can be manually created based on IP addresses and port numbers to accomplish the same goal, but this is faster).

In the case of dropped connections, scroll to the bottom of the filtered stream and note which side sent the FIN (or FIN, ACK if it was acking a previous packet) packet to initiate the teardown. The other side should respond with a FIN, ACK, and the originator finally with an ACK. The other side could also just send a RST to end the connection abruptly.

Because Diameter protocol is TCP/IP based, also check for TCP-related errors.

Diamproxy feature

Diamproxy processes handle a given PSC/DPC's sessmgrs Diameter-based requests, and their instance IDs as well as memory and cpu usage can be viewed with "show task resources". Diamproxy tasks reside on each **active** PSC/DPC.

- diamproxy “proxies” all sessmgr Diameter requests – far fewer connections (and port usage) than if direction connections from all sessmgrs
- sessmgr uses diamproxy on a **different** card where aaamgrs make Diameter authentication-related requests
- sessmgr uses diamproxy on **same** card to make requests for Gx and Gy

For example:

sessmgr (PSC 3)
    S6b & Rf on diamproxy-8 (PSC 7)
    Gx & Gy on diamproxy-12 (PSC 3)

```
[PGWin]PGW# show task resources facility diamproxy all
                   task    cputime        memory     files      sessions
 cpu facility      inst used allc   used  alloc used allc  used  allc Sstatus
---------------------- --------- ------------- --------- ------------- ------
 2/0 diamproxy      11 1.8%  50%  11.3M 100.0M  258 1000    --    -- -   good
 3/0 diamproxy      12 1.7%  50%  11.3M 100.0M  255 1000    --    -- -   good
 4/0 diamproxy      5  1.8%  50%  11.1M 100.0M  288 1000    --    -- -   good
 5/0 diamproxy      1  2.0%  50%  11.2M 100.0M  248 1000    --    -- -   good
 6/0 diamproxy      9  1.9%  50%  11.3M 100.0M  260 1000    --    -- -   good
 7/0 diamproxy      8  1.9%  50%  11.2M 100.0M  255 1000    --    -- -   good
10/0 diamproxy      10 1.9%  50%  11.1M 100.0M  240 1000    --    -- -   good
11/0 diamproxy      6  2.1%  50%  11.4M 100.0M  258 1000    --    -- -   good
12/0 diamproxy      3  2.1%  50%  11.1M 100.0M  224 1000    --    -- -   good
14/0 diamproxy      2  2.0%  50%  11.2M 100.0M  242 1000    --    -- -   good
15/0 diamproxy      7  2.0%  50%  11.3M 100.0M  257 1000    --    -- -   good
16/0 diamproxy      4  2.0%  50%  11.2M 100.0M  136 1000    --    -- -   good
Total               12  23.6% -  134.6M   --     2921 -      0
```

Session Disconnect Reasons

This is the general command to see reasons for call failures (setup and teardown). This command will tell why calls disconnected or failed to setup. Following is a subset of reasons that could be related to Diameter.

```
[local]PGW# show sess disconnect-reasons
Session Disconnect Statistics

Total Disconnects: 598231358

Disconnect Reason                                      Num Disc  Percentage
-------------------------------------------------- ----------  ----------
Admin-disconnect                                       801121     0.13391
Remote-disconnect                                    236090433    39.46474
Session-setup-timeout                                  219129     0.03663
Local-purge                                          89951324    15.03621
Admin-AAA-disconnect                                   796685     0.13317
```

failed-auth-with-charging-svc	117536	0.01965
gtp-user-auth-failed	175798	0.02939
ims-authorization-failed	170688	0.02853
ims-authorization-revoked	71433	0.01194
ims-auth-decision-invalid	24	0.00000
Re-Auth-failed	20981	0.00351
disconnect-from-policy-server	2	0.00000
s6b-auth-failed	103351	0.01728
aaa-unreachable	811	0.00014

Diameter session IDs

The Diameter session ID which is a part of all Diameter protocol messages contains long sequences of digits that encapsulate the time the subscriber connected, the sessmgr instance ID, etc. This can be valuable when trying to identify which subscriber a packet is associated with, as well as troubleshooting other difficult issues. Here is an example of Diameter session id broken down:

Session-Id:0004-diamproxy.test.com;570906393;11823987;52377bbc-7303

- The first field: 0004-diamproxy.test.com is the name of the Diameter endpoint and local Diameter proxy task being used to communicate with that endpoint.
- The second field: 570906393 is a decimal notation of the hexadecimal callid. Convert 570906393 to hex and get 0x22075719
- The third field: 11823987 is an internal session number
- The fourth field: 52377bbc is the Epoch time that the session was created.
- The fifth field: 7303 is the sessmgr instance, in the first two (or 3) digits are the sessmgr instance id. The 73 has to be converted from hex, which in this case means the sessmgr instance is 115 decimal. The last two digits (03) in this case can be ignored for the purposes of this material.

Policy Control - Gx

Overview

This section covers Diameter Policy Control over Gx interface and basic troubleshooting commands with multiple examples. Policy Control is the process whereby the PCRF indicates to the PCEF/GGSN/PGW how to control the IP-CAN (connectivity access network) bearer/session.

Classifications

Policy-Control can be classified and defined as below:

- **Bearer Binding** : Association between a service data flow and the IP-CAN bearer transporting that service data flow.
- **Gating Control** : Blocking or allowing of packets, belonging to a service data flow, to pass through to the desired endpoint.
- **Event Reporting** : Notification of, and reaction to, application events to trigger new behavior in the user plane as well as the reporting of events related to the resources in the GW (PCEF),
- **QOS Control** : The authorization and enforcement of the maximum QoS that is authorized for a service data flow or an IP CAN bearer or APN, IP-CAN bearer establishment for IP-CANs that support network initiated procedures for IP CAN bearer establishment.

For session establishment and policy control over Gx, the following messages are used:

Initiated from PCEF to PCRF (PULL):

- **CCR-I :** Initialization of session from PCEF to PCRF, exchange of session information from subscriber, and all relevant information that PCRF might use to determine logic and policies that will apply. There is one Gx CCR-I per IP-CAN session (example for primary and all secondary PDP context or Default bearers plus all Dedicated bearers).
- **CCA-I :** PCRF's answer to CCR-I request. In this message PCRF includes result-code that defines if authorization is successful, or not. Also with authorization for session, PCRF provides a set of attributes that PCEF should enforce to subscriber's session.

- **Result code**: defining if PCRF accepts session or terminates it. Valid codes and expected causes are reused from 3GPP 29.212, RFC 4006 and RFC 3588.
- **QoS change**: and THP/ARP setting change for session
- **Event trigger provisioning** : setting monitoring points triggers for which PCRF wants to be notified from PCEF
- **PCC rule and/or group of PPC rules install/remove commands**: activating/deactivating pre-defined dynamic rules on PCEF, with option to set predefined future time of automatic activation and deactivation.
- **Volume monitoring and reporting**: Setting up thresholds for monitoring keys, which enables PCEF to count and report counted volume per Service Data Flow (or set of SDFs) or for entire session.


- **CCR-U :** PCEF sends update for session, based on one of the triggers that PCRF set during session initialization. Update message is sent together with trigger that caused this update message, and with attributes that are related to the change, for example new RAT TYPE, new QOS, Usage-Report due to Volume monitoring threshold exceeded, access network gateway (e.g. SGW/SGSN) change or Revalidation timer.
- **CCA-U** : PCRF answer to CCR-U request. In this message PCRF has full control to deny/modify policies on PCEF for subscriber session, by setting up result-code and provisioning any of the rules and applicable modifications with same procedure as in INIT message (Changing QoS, Setting new event-triggers, installing new rules, setting up or discarding volume monitoring).
- **CCR-T :** PCEF sends TERMINATE request when subscriber session is closed, due to any reason (UE PDP disconnection, or administrative disconnect by other entity). In termination request message, PCEF reports termination-reason, and also any outstanding information that was valid at session termination stage (Like reporting used volume or active volume-monitoring threshold).
- **CCA-T :** PCRF answer to CCR-T request which just acknowledges that the request has been processed. Failure to send a CCA-T can cause the PCEF to retransmit the CCR-T to a secondary PCRF.

Initiated from PCRF to PCEF (PUSH):

- **RAR :** PCRF can initiate change by itself using Re-Authorization-Request. Unlike Gy and Diameter Credit Control, this message does not trigger a CCR-U, but instead this is used when PCRF needs to modify session policy control during active session. With RAR, PCRF can push new policy attributes like an INIT response and UPDATE response messages, and also PCRF can request explicit volume usage-report.

- **RAA :** PCEF answer to RAR. Used to respond if PCEF accepted changes in RAR, and to provide current volume usage-report if PCRF requested it.

Session Establishment & Disconnection call-flow



Basic troubleshooting commands for Gx

- show ims-authorization policy-control statistics
- show ims-authorization service statistics
- show ims-authorization service all verbose
- show ims-authorization sessions <options>

Gx session failure-handling

Failure Handling Procedure for Gx can be invoked under the following scenarios:

1. DIABASE ERROR:
   This happens in the path of the request, mainly due to socket-based errors like link failure which happens when the server goes down.
2. 2. APPLICATION BASED TIMER:
   Default value "diameter request-timeout 10" inside ims-auth-service / policy-control
3. RESPONSE TIMEOUT:
   Default value "response-timeout 60" inside diameter endpoint configuration

The following table explains the StarOS failure-handling logic for Gx:

Event	CCR Message Type	Failure Handling Setting	Failure Handling Config	Secondary server configured and active	Secondary server not configured or its down	Secondary Server Not Responding
Session Establishment	Initial	Continue	failure-handling cc-request-type initial-request <failure_handling_action>	Retry happens to the secondary server continues with session establishment.	1. No further messaging with PCRF and no diameter session is established. 2. The imsa session is deleted but the call is not brought down.	Same behavior as in the case of server down but this is detected after the application timeout value of 10 seconds or the endpoint level response timeout value whichever happens first
		Retry-and-Terminate		Retry happens to the secondary server and continues with session establishment.	The call is brought down by initiating a delete PDP with teardown indicator which brings down all the sessions.	Same behavior as in the case of server down but this is detected after the application timeout value of 10 seconds or the endpoint level response timeout value whichever happens first
		Terminate		The call is brought down by initiating a delete PDP with teardown indicator which brings down all the sessions.	NA	NA
Session Modification	Update	Continue	failure-handling cc-request-type update-request <failure_handling_action>	Retry happens to the secondary server and continues with session modification.	1. No further messaging with PCRF and no diameter session is established. 2. The imsa session is not deleted and the call is not brought down.	Same behavior as in the case of server down but this is detected after the application timeout value of 10 seconds or the endpoint level response timeout value whichever happens first
		Retry-and-Terminate		Retry happens to the secondary server and continues with session modification.	The call is brought down by initiating a delete PDP with teardown indicator which brings down all the sessions.	Same behavior as in the case of server down but this is detected after the application timeout value of 10 seconds or the endpoint level response timeout value whichever happens first
		Terminate		The call is brought down by initiating a delete PDP with teardown indicator which brings down all the sessions.	NA	NA

Event	CCR Message Type	Failure Handling Setting	Failure Handling Config	Secondary server configured and active	Secondary server not configured or its down	Secondary Server Not Responding
Session Termination	Terminate	Continue	failure-handling cc-request-type terminate-request <failure_handling_action>	Retry happens to the secondary server continues with session termination.	1. No further messaging with PCRF and no diameter session is established. 2. The imsa session is deleted but the call is not brought down.	Same behavior as in the case of server down but this is detected after the application timeout value of 10 seconds or the endpoint level response timeout value whichever happens first
		Retry-and-Terminate		Retry happens to the secondary server continues with session termination.	The call is brought down by initiating a delete PDP with teardown indicator which brings down all the sessions.	Same behavior as in the case of server down but this is detected after the application timeout value of 10 seconds or the endpoint level response timeout value whichever happens first
		Terminate		The call is brought down by initiating a delete PDP with teardown indicator which brings down all the sessions.	NA	NA
Note: The default failure handling config is «failure-handling cc-request-type any-request retry-and-terminate» .						
Note: The above failure-handling config is applicable for all result code from 3xxx-4xxx. All Permanent result-codes (5xxx) are treated as actual failures from the PCRF and the session will be torn down						

Example Scenarios

PCRF change where some subscribers cannot establish a data call

Problem Observed:

Mobile operator noticed that after activating a new use case on the PCRF that some subscribers can't establish a data call.

Logs collection:

- monitor subscriber <imsi> *with verbosity* 3

Analysis:

1. In "monitor subscriber" the PCRF wants to install a new rulebase. After receiving this CCA-I, the GGSN disconnects the session with cause "No resources".

```
-------------------------------------------------------------------------
Incoming Call:
-------------------------------------------------------------------------
 MSID/IMSI   : 450061234554321            Callid      : 00004e22
 IMEI        : n/a                        MSISDN      : 64211234567
 Username    : 64211234567                SessionType : ggsn-pdp-type-ipv4
 Status      : Active                     Service Name: GGSN-SVC
 Src Context : Gn
-------------------------------------------------------------------------

INBOUND>>>>>  15:49:03:249 Eventid:47000(3)
GTPC Rx PDU, from 192.168.2.138:2123 to 192.168.2.1:2123 (191)
TEID: 0x00000000, Message type: GTP_CREATE_PDP_CONTEXT_REQ_MSG (0x10)
Sequence Number:: 0x7FFF (32767)
GTP HEADER FOLLOWS:
             Version number: 1
              Protocol type: 1 (GTP C/U)
       Extended header flag: Not present
       Sequence number flag: Present
```

```
            NPDU number flag: Not present
                Message Type: 0x10 (GTP_CREATE_PDP_CONTEXT_REQ_MSG)
              Message Length: 0x00B7 (183)
                   Tunnel ID: 0x00000000
             Sequence Number: 0x7FFF (32767)
GTP HEADER ENDS.
INFORMATION ELEMENTS FOLLOW:
                        IMSI: 450061234554321
                    Recovery: 0x07 (7)
              Selection Mode: 0x0 (MS or network provided APN, subscribed verified
(Subscribed))
            Tunnel ID Data I: 0x00000400
         Tunnel ID Control I: 0x00000400
                      NSAPI: 0x05 (5)

CHARGING CHARACTERISTIC FOLLOWS:
                    Charging Chars # 1: 0x0800 (Normal)
CHARGING CHARACTERISTIC ENDS.
END USER ADDRESS FOLLOWS:
       PDP Type Organisation: IETF
             PDP Type Number: IPv4
                     Address: Empty
END USER ADDRESS ENDS.
            Access Point Name: ecs-apn
PROTOCOL CONFIG. OPTIONS FOLLOW:
                    IE Length: 0x59 (89)
      Configuration Protocol: (0) PPP
                Extension Bit: (1)

                  Protocol id: 0xC021 (LCP)
              Protocol length: 0x0E (14)
           Protocol contents: 0103000E0506088AA1020304C023
                  Protocol id: 0xC021 (LCP)
              Protocol length: 0x0E (14)
           Protocol contents: 0203000E0506088AA1020304C023
                  Protocol id: 0xC023 (PAP)
              Protocol length: 0x1A (26)
           Protocol contents: 0104001A0874657374757365720C7465737470617373776F7264
                  Protocol id: 0x8021 (IPCP)
```

```
            Protocol length: 0x16 (22)
          Protocol contents: 0101001603060000000081060000000830600000000
PROTOCOL CONFIG. OPTIONS END.
              GSN Address I: 0xC0A8028A (192.168.2.138)
             GSN Address II: 0xC0A8028A (192.168.2.138)
                    MSISDN: 64211234567
               QOS Profile: 0x0122720D7396404886074048
COMMON FLAGS FOLLOW:
 Prohibit Payload Compression: no
            MBMS Service Type: Multicast Service
         RAN Procedures Ready: no
    MBMS Counting Information: no
          No QoS negotiation: no
                        NRSN: no
        Upgrade QoS Supported: yes
     Dual Address Bearer Flag: no
COMMON FLAGS END.
INFORMATION ELEMENTS END.


<<<<OUTBOUND  15:49:03:256 Eventid:81990(5)
Diameter message from 192.168.1.1:33937 to 192.168.1.128:3868
  Base Header Information:
   Version: 1
   Message Length: 732
   Command Flags: REQ PXY   (192)
   Command Code: Credit-Control-Request (272)
   Application ID: 3GPP-Gx (16777238)
   Hop2Hop-ID: 0x00000298
   End2End-ID: 0xd54aea6d
  AVP Information:
        [M] Session-Id: 0001-sessmgr.LAB-XT2;20002;513;554a702f-102
        [M] Auth-Application-Id: 16777238
        [M] Origin-Host: 0001-sessmgr.LAB-XT2
        [M] Origin-Realm: lab.realm
        [M] Destination-Realm: lab.realm
        [M] CC-Request-Type: INITIAL_REQUEST (1)
        [M] CC-Request-Number: 0
        [M] Origin-State-Id: 1430920532
```

```
        [M] Subscription-Id:
          [M] Subscription-Id-Type: END_USER_E164 (0)
          [M] Subscription-Id-Data: 64211234567
        [M] Subscription-Id:
          [M] Subscription-Id-Type: END_USER_IMSI (1)
          [M] Subscription-Id-Data: 450061234554321
        [V] [M] Supported-Features:
          [M] Vendor-Id: 10415
          [V] Feature-List-ID: 1
          [V] Feature-List: 1
        [V] [M] Bearer-Identifier: 0x00000004
        [V] [M] Bearer-Operation: ESTABLISHMENT (1)
        [M] Framed-IP-Address: IPv4 172.16.0.8
        [V] [M] IP-CAN-Type: 3GPP-GPRS (0)
        [V] [M] QoS-Information:
          [V] [M] QoS-Class-Identifier: QCI_8 (8)
          [V] [M] Max-Requested-Bandwidth-UL: 64000
          [V] [M] Max-Requested-Bandwidth-DL: 128000
          [V] [M] Bearer-Identifier: 0x00000004
          [V] [M] Allocation-Retention-Priority:
            [V] [M] Priority-Level: 1
            [V] [M] Pre-emption-Capability: PRE-EMPTION_CAPABILITY_DISABLED (1)
            [V] [M] Pre-emption-Vulnerability: PRE-EMPTION_VULNERABILITY_ENABLED (0)
        [V] [M] QoS-Upgrade: QoS_UPGRADE_SUPPORTED (1)
        [V] [M] 3GPP-SGSN-MCC-MNC: 123456
        [V] [M] 3GPP-SGSN-Address: IPv4 192.168.2.138
        [V] [M] RAI: 123456FFFEFF
        [V] [M] 3GPP-User-Location-Info: Location Type: RAI (2) Location Info (RAI): 123-456-
0xFFFE-0xFFFF
        [M] Called-Station-Id: ecs-apn
        [V] [M] Bearer-Usage: GENERAL (0)
        [V] [M] Online: DISABLE_ONLINE (0)
        [V] [M] Offline: DISABLE_OFFLINE (0)
        [V] [M] Access-Network-Charging-Address: IPv4 192.168.2.1
        [V] [M] Access-Network-Charging-Identifier-Gx:
          [V] [M] Access-Network-Charging-Identifier-Value: 0x00000002


 INBOUND>>>>>  15:49:03:257 Eventid:81991(5)
```

```
Diameter message from 192.168.1.128:3868 to 192.168.1.1:33937
  Base Header Information:
   Version: 1
   Message Length: 404
   Command Flags:  PXY   (64)
   Command Code: Credit-Control-Answer (272)
   Application ID: 3GPP-Gx (16777238)
   Hop2Hop-ID: 0x00000298
   End2End-ID: 0xd54aea6d
  AVP Information:
        [M] Session-Id: 0001-sessmgr.LAB-XT2;20002;513;554a702f-102
        [M] Auth-Application-Id: 16777238
        [M] Origin-Host: minid-pcrf
        [M] Origin-Realm: lab.realm
        [M] Result-Code: DIAMETER_SUCCESS (2001)
        [M] CC-Request-Type: INITIAL_REQUEST (1)
        [M] CC-Request-Number: 0
        [M] Route-Record: box
        [V] [M] Supported-Features:
          [M] Vendor-Id: 10415
          [V] Feature-List-ID: 1
          [V] Feature-List: 1
        [V] [M] Bearer-Control-Mode: UE_ONLY (0)
        [V] [M] Charging-Rule-Install:
          [V] [M] Charging-Rule-Base-Name: RULEBASE_1
          [V] [M] Bearer-Identifier: 0x00000004
        [V] [M] QoS-Information:
          [V] [M] QoS-Class-Identifier: QCI_4 (4)
          [V] [M] Max-Requested-Bandwidth-UL: 256000
          [V] [M] Max-Requested-Bandwidth-DL: 256000
          [V] [M] Guaranteed-Bitrate-UL: 64000
          [V] [M] Guaranteed-Bitrate-DL: 64000
          [V] [M] Bearer-Identifier: 0x00000004


<<<<OUTBOUND  15:49:03:259 Eventid:47001(3)
GTPC Tx PDU, from 192.168.2.1:2123 to 192.168.2.138:2123 (14)
TEID: 0x00000400, Message type: GTP_CREATE_PDP_CONTEXT_RES_MSG (0x11)
Sequence Number:: 0x7FFF (32767)
```

```
GTP HEADER FOLLOWS:
             Version number: 1
              Protocol type: 1 (GTP C/U)
       Extended header flag: Not present
       Sequence number flag: Present
           NPDU number flag: Not present
               Message Type: 0x11 (GTP_CREATE_PDP_CONTEXT_RES_MSG)
             Message Length: 0x0006 (6)
                  Tunnel ID: 0x00000400
            Sequence Number: 0x7FFF (32767)
GTP HEADER ENDS.
INFORMATION ELEMENTS FOLLOW:
                      Cause: 0xC7 (GTP_NO_RESOURCES_AVAILABLE)
INFORMATION ELEMENTS END.


<<<<OUTBOUND  15:49:03:279 Eventid:81990(5)
Diameter message from 192.168.1.1:33937 to 192.168.1.128:3868
  Base Header Information:
   Version: 1
   Message Length: 352
   Command Flags: REQ PXY   (192)
   Command Code: Credit-Control-Request (272)
   Application ID: 3GPP-Gx (16777238)
   Hop2Hop-ID: 0x00000299
   End2End-ID: 0xd54aea6e
  AVP Information:
        [M] Session-Id: 0001-sessmgr.LAB-XT2;20002;513;554a702f-102
        [M] Auth-Application-Id: 16777238
        [M] Origin-Host: 0001-sessmgr.LAB-XT2
        [M] Origin-Realm: lab.realm
        [M] Destination-Realm: lab.realm
        [M] CC-Request-Type: TERMINATION_REQUEST (3)
        [M] CC-Request-Number: 1
        [M] Destination-Host: minid-pcrf
        [M] Origin-State-Id: 1430920532
        [M] Subscription-Id:
          [M] Subscription-Id-Type: END_USER_E164 (0)
          [M] Subscription-Id-Data: 64211234567
```

```
        [M] Subscription-Id:
          [M] Subscription-Id-Type: END_USER_IMSI (1)
          [M] Subscription-Id-Data: 450061234554321
        [M] Framed-IP-Address: IPv4 172.16.0.8
        [M] Termination-Cause: DIAMETER_ADMINISTRATIVE (4)
        [M] Called-Station-Id: ecs-apn
        [V] [M] Access-Network-Charging-Address: IPv4 192.168.2.1


Wednesday May 06 2015
***CONTROL*** 15:49:03:279 Eventid:10285
CALL STATS: msisdn <64211234567>, apn <ecs-apn>, imsi <450061234554321>, Call-Duration(sec): 0
...   Disconnect Reason: failed-auth-with-charging-svc
  Last Progress State: IMS Authorized


INBOUND>>>>>  15:49:03:280 Eventid:81991(5)
Diameter message from 192.168.1.128:3868 to 192.168.1.1:33937
  Base Header Information:
   Version: 1
   Message Length: 172
   Command Flags:  PXY   (64)
   Command Code: Credit-Control-Answer (272)
   Application ID: 3GPP-Gx (16777238)
   Hop2Hop-ID: 0x00000299
   End2End-ID: 0xd54aea6e
  AVP Information:
        [M] Session-Id: 0001-sessmgr.LAB-XT2;20002;513;554a702f-102
        [M] Auth-Application-Id: 16777238
        [M] Origin-Host: minid-pcrf
        [M] Origin-Realm: lab.realm
        [M] Result-Code: DIAMETER_SUCCESS (2001)
        [M] CC-Request-Type: TERMINATION_REQUEST (3)
        [M] CC-Request-Number: 1
        [M] Route-Record: box
```

2 For more information additional logging can be enabled:

- config
- logging monitor msid <imsi>
- logs checkpoint (move all logs from active to standby buffer)

After reproduction of the issue, this log message can be seen: "**Gx No resources: No such group:, RULEBASE_1**".

```
 2015-May-06+15:49:03.257 [acsmgr 91746 debug] [1/0/3784 <sessmgr:1> acsmgr_gx.c:341] [callid
00004e22] [Call Trace] [context: Ga, contextID: 4]  [software internal system syslog] Gx No
resources: No such group:, RULEBASE_1, 0
 2015-May-06+15:49:03.257 [acsmgr 91431 trace] [1/0/3784 <sessmgr:1> mgr_call_mgmt.c:2347]
[callid 00004e22] [Call Trace] [software internal system syslog] ACS_SEF event: Populating the
dynamic rules list for quota request: 0,  0,  0
 2015-May-06+15:49:03.257 [acsmgr 91431 trace] [1/0/3784 <sessmgr:1> mgr_call_mgmt.c:1767]
[callid 00004e22] [Call Trace] [software internal system syslog] ACS_SEF event: Storing Policy
Received from CCM: 0,  0,  0
 2015-May-06+15:49:03.257 [acsmgr 91037 trace] [1/0/3784 <sessmgr:1> acsmgr.c:4444] [callid
00004e22] [Call Trace] [software internal user syslog] Rulebase default assigned
```

3 The rulebase seems to be properly configured:

```
 # show active-charging rulebase name RULEBASE_1

  Service Name: ECS-SVC
   Rule Base Name: RULEBASE_1
```

4 PCRF indicates the rulebase to use via the Charging-Rule-Base-Name AVP (CRBN). However, the 3GPP model of a rulebase is just a set of charging rules whereas an ECS rulebase also defines a range of other parameters such as analysers, P2P inspection, some charging parameters and various other aspects of a session. As a result, StarOS offers two ways to interpret the CRBN AVP received from PCRF controlled via CLI:

```
 # show configuration verbose | grep {policy-control | charging-rule-base-name | active-
charging-group-of-ruledefs}
```

- policy-control charging-rule-base-name active-charging-group-of-ruledefs (default)
  - Rulebase policy cannot be changed by PCRF
  - “Charging-Rule-Base-Name” Gx AVP is matched against a Group-Of-Ruledefs name
  - Ruledef name is signaled by “Charging-Rule-Name” Gx AVP
- policy-control charging-rule-base-name active-charging-rulebase
  - Rulebase policy can be changed by PCRF by “Charging-Rule-Base-Name” Gx AVP
  - Group-Of-Ruledefs is signaled by “Charging-Rule-Name” Gx AVP
  - Ruledef is signaled also by “Charging-Rule-Name” Gx AVP

Resolution :

Configure policy-control so Rulebase can be changed by PCRF:

- active-charging service <acs-name>
- policy-control charging-rule-base-name active-charging-rulebase

Subscriber Browsing is not working due to missing ruledef

Problem Observed:

Rules received from PCRF are not installed in GW

Logs collection:

- monitor subscriber imsi <imsi>
- external packet capture
- syslog
- collect 2 or more SSD


CLI used to Troubleshoot the issue:

- show ims-authorization policy statistics
- show diameter statistics
- show active-service session full imsi <imsi>

Analysis:

In a monitor subscriber trace or packet capture CCR-I is being sent from GGSN to PCRF, PCRF is replying back with pre-defined Charging rulename in CCR-A. GGSN is sending CCR-U with "PCC-Rule-Status: INACTIVE (1)". PCRF is sending CCR-U success, GGSN is removing the session from Active Charging Service.

Call Flow: Rule Failure



Trace:

```
-------------------------------------------------------------------------
Incoming Call:
-------------------------------------------------------------------------
 MSID/IMSI   : 123456000000002            Callid      : 00004e8b
 IMEI        : n/a                        MSISDN      : 9876543210
 Username    : 9876543210                 SessionType : ggsn-pdp-type-ipv4
 Status      : Active                     Service Name: ggsn
 Src Context : spgw
-------------------------------------------------------------------------

INBOUND>>>>>  15:29:57:410 Eventid:47000(3)
GTPC Rx PDU, from 10.201.251.5:2123 to 192.168.5.52:2123 (157)
TEID: 0x00000000, Message type: GTP_CREATE_PDP_CONTEXT_REQ_MSG (0x10)
Sequence Number:: 0x7FFF (32767)
GTP HEADER FOLLOWS:
```

```
             Version number: 1
              Protocol type: 1 (GTP C/U)
       Extended header flag: Not present
       Sequence number flag: Present
           NPDU number flag: Not present
              Message Type: 0x10 (GTP_CREATE_PDP_CONTEXT_REQ_MSG)
             Message Length: 0x0095 (149)
                  Tunnel ID: 0x00000000
            Sequence Number: 0x7FFF (32767)
GTP HEADER ENDS.
INFORMATION ELEMENTS FOLLOW:
                      IMSI: 123456000000002
                  Recovery: 0xFA (250)
             Selection Mode: 0x1 (MS provided APN, subscription not verified (Sent by MS))
           Tunnel ID Data I: 0x00000400
        Tunnel ID Control I: 0x00000400
                    NSAPI: 0x05 (5)

CHARGING CHARACTERISTIC FOLLOWS:
                  Charging Chars # 1: 0x0800 (Normal)
CHARGING CHARACTERISTIC ENDS.
END USER ADDRESS FOLLOWS:
      PDP Type Organisation: IETF
            PDP Type Number: IPv4
                    Address: Empty
END USER ADDRESS ENDS.
           Access Point Name: cisco.com
PROTOCOL CONFIG. OPTIONS FOLLOW:
                  IE Length: 0x36 (54)
     Configuration Protocol: (0) PPP
 INFORMATION ELEMENTS END.



Wednesday May 06 2015
<<<<OUTBOUND  15:29:57:413 Eventid:81990(5)
Diameter message from 192.168.4.200:35121 to 192.168.4.111:3868
  Base Header Information:
   Version: 1
   Message Length: 596
```

```
 Command Flags: REQ PXY   (192)
 Command Code: Credit-Control-Request (272)
 Application ID: 3GPP-Gx (16777238)
 Hop2Hop-ID: 0xadb00173
 End2End-ID: 0x006999df
AVP Information:
      [M] Session-Id: pcrf;20107;27393;554a6bb5-102
      [M] Auth-Application-Id: 16777238
      [M] Origin-Host: pcrf
      [M] Origin-Realm: cisco.com
      [M] Destination-Realm: cisco.com
      [M] CC-Request-Type: INITIAL_REQUEST (1)
      [M] CC-Request-Number: 0
      [M] Origin-State-Id: 1430935391
      [M] Subscription-Id:
        [M] Subscription-Id-Type: END_USER_E164 (0)
        [M] Subscription-Id-Data: 9876543210
      [M] Subscription-Id:
        [M] Subscription-Id-Type: END_USER_IMSI (1)
        [M] Subscription-Id-Data: 123456000000002
      [V] [M] Supported-Features:
        [M] Vendor-Id: 10415
        [V] Feature-List-ID: 1
        [V] Feature-List: 1
      [M] Framed-IP-Address: IPv4 10.10.20.101
      [V] [M] IP-CAN-Type: 3GPP-EPS (5)
      [V] [M] QoS-Information:
        [V] APN-Aggregate-Max-Bitrate-UL: 64000
        [V] APN-Aggregate-Max-Bitrate-DL: 128000
      [V] Default-EPS-Bearer-QoS:
        [V] [M] QoS-Class-Identifier: QCI_8 (8)
        [V] [M] Allocation-Retention-Priority:
          [V] [M] Priority-Level: 1
          [V] [M] Pre-emption-Capability: PRE-EMPTION_CAPABILITY_DISABLED (1)
          [V] [M] Pre-emption-Vulnerability: PRE-EMPTION_VULNERABILITY_ENABLED (0)
      [V] AN-GW-Address: IPv4 10.201.251.5
      [M] Called-Station-Id: cisco.com
      [V] [M] Bearer-Usage: GENERAL (0)
      [V] [M] Online: ENABLE_ONLINE (1)
```

```
        [V] [M] Offline: DISABLE_OFFLINE (0)
        [V] [M] Access-Network-Charging-Address: IPv4 192.168.5.52
        [V] [M] Access-Network-Charging-Identifier-Gx:
          [V] [M] Access-Network-Charging-Identifier-Value: 0x000000d0


INBOUND>>>>>  15:29:57:415 Eventid:81991(5)
Diameter message from 192.168.4.111:3868 to 192.168.4.200:35121
  Base Header Information:
   Version: 1
   Message Length: 368
   Command Flags:  PXY   (64)
   Command Code: Credit-Control-Answer (272)
   Application ID: 3GPP-Gx (16777238)
   Hop2Hop-ID: 0xadb00173
   End2End-ID: 0x006999df
  AVP Information:
        [M] Session-Id: pcrf;20107;27393;554a6bb5-102
        [M] Auth-Application-Id: 16777238
        [M] Origin-Host: pcrf
        [M] Origin-Realm: cisco.com
        [M] Result-Code: DIAMETER_SUCCESS (2001)
        [M] CC-Request-Type: INITIAL_REQUEST (1)
        [M] CC-Request-Number: 0
        [M] Route-Record: box
        [V] [M] Supported-Features:
          [M] Vendor-Id: 10415
          [V] Feature-List-ID: 1
          [V] Feature-List: 1
        [V] [M] Bearer-Control-Mode: UE_ONLY (0)
        [V] [M] Event-Trigger: QOS_CHANGE (1)
        [V] [M] Event-Trigger: RAT_CHANGE (2)
        [V] [M] Event-Trigger: IP_CAN_CHANGE (7)
        [V] [M] Event-Trigger: USER_LOCATION_CHANGE (13)
        [V] [M] Event-Trigger: AN_GW_CHANGE (21)
        [V] [M] Charging-Rule-Install:
          [V] [M] Charging-Rule-Name: my_rule
        [V] [M] Online: ENABLE_ONLINE (1)
        [V] [M] Offline: DISABLE_OFFLINE (0)
```

```
 <<<<OUTBOUND  15:29:57:417 Eventid:81990(5)
Diameter message from 192.168.4.200:35121 to 192.168.4.111:3868
  Base Header Information:
   Version: 1
   Message Length: 372
   Command Flags: REQ PXY   (192)
   Command Code: Credit-Control-Request (272)
   Application ID: 3GPP-Gx (16777238)
   Hop2Hop-ID: 0xadb00174
   End2End-ID: 0x006999e0
  AVP Information:
        [M] Session-Id: pcrf;20107;27393;554a6bb5-102
        [M] Auth-Application-Id: 16777238
        [M] Origin-Host: pcrf
        [M] Origin-Realm: cisco.com
        [M] Destination-Realm: cisco.com
        [M] CC-Request-Type: UPDATE_REQUEST (2)
        [M] CC-Request-Number: 1
        [M] Destination-Host: pcrf
        [M] Origin-State-Id: 1430935391
        [M] Subscription-Id:
          [M] Subscription-Id-Type: END_USER_E164 (0)
          [M] Subscription-Id-Data: 9876543210
        [M] Subscription-Id:
          [M] Subscription-Id-Type: END_USER_IMSI (1)
          [M] Subscription-Id-Data: 123456000000002
        [M] Framed-IP-Address: IPv4 10.10.20.101
        [M] Called-Station-Id: cisco.com
        [V] [M] Charging-Rule-Report:
          [V] [M] Charging-Rule-Name: my_rule
          [V] [M] PCC-Rule-Status: INACTIVE (1)
          [V] [M] Rule-Failure-Code: GW/PCEF_MALFUNCTION (4)
        [V] [M] Access-Network-Charging-Address: IPv4 192.168.5.52


<<<<OUTBOUND  15:29:57:418 Eventid:47001(3)
GTPC Tx PDU, from 192.168.5.52:2123 to 10.201.251.5:2123 (90)
TEID: 0x00000400, Message type: GTP_CREATE_PDP_CONTEXT_RES_MSG (0x11)
Sequence Number:: 0x7FFF (32767)
```

```
GTP HEADER FOLLOWS:
             Version number: 1
              Protocol type: 1 (GTP C/U)
       Extended header flag: Not present
       Sequence number flag: Present
           NPDU number flag: Not present
               Message Type: 0x11 (GTP_CREATE_PDP_CONTEXT_RES_MSG)
             Message Length: 0x0052 (82)
                  Tunnel ID: 0x00000400
            Sequence Number: 0x7FFF (32767)
GTP HEADER ENDS.
INFORMATION ELEMENTS FOLLOW:
                      Cause: 0x80 (GTP_REQUEST_ACCEPTED)
           Reorder Required: 0x0 (Not present)
                   Recovery: 0x27 (39)
           Tunnel ID Data I: 0x8019E001
        Tunnel ID Control I: 0x800D4001
                 Charging ID: 0x000000D0
END USER ADDRESS FOLLOWS:
      PDP Type Organisation: IETF
            PDP Type Number: IPv4
               IPv4 Address: 10.10.20.101
END USER ADDRESS ENDS.
 PROTOCOL CONFIG. OPTIONS FOLLOW:
                  IE Length: 0x05 (5)
     Configuration Protocol: (0) PPP
              Extension Bit: (1)



INBOUND>>>>>  15:29:57:418 Eventid:81991(5)
Diameter message from 192.168.4.111:3868 to 192.168.4.200:35121
  Base Header Information:
   Version: 1
   Message Length: 152
   Command Flags:  PXY   (64)
   Command Code: Credit-Control-Answer (272)
   Application ID: 3GPP-Gx (16777238)
   Hop2Hop-ID: 0xadb00174
```

```
 End2End-ID: 0x006999e0
AVP Information:
      [M] Session-Id: pcrf;20107;27393;554a6bb5-102
      [M] Auth-Application-Id: 16777238
      [M] Origin-Host: pcrf
      [M] Origin-Realm: cisco.com
      [M] Result-Code: DIAMETER_SUCCESS (2001)
      [M] CC-Request-Type: UPDATE_REQUEST (2)
      [M] CC-Request-Number: 1
      [M] Route-Record: box
```

Resolution :

Adding the **my_rule** in Active Charging Service fixed the issue. GGSN did not have the pre-defined rule in ACS and therefore the session was removed from ACS.

Online Charging - Gy

Overview

This section covers Diameter Online Charging over Gy interface and basic troubleshooting commands with multiple examples.

The Gy interface is the online charging interface between the Gateway and the Online Charging System (OCS). The Diameter protocol is used over this interface to provide online charging functionality. This is also known as the Diameter Credit Control Application (DCCA).


The Gy interface makes use of the Active Charging Service (ACS) / Enhanced Charging Service (ECS) for real-time content-based charging of data services. It is based on the 3GPP standards and relies on quota allocation. With Gy, customer traffic can be gated and billed in an online or prepaid style.

Call Flows and Troubleshooting


Depending on configuration, the Gy session shall be triggered two possible ways:

- During the session establishment (Call Flow 1)
- After the session establishment and the traffic starts (Call Flow 2)

General Call Flow 1



General Call flow 2



Failure Handling

The session failover setting determines whether the session needs to be tried and bound to another OCS in case of the primary OCS failure. The setting can be done in the credit-control configuration under active-charging service configuration as below:

```
active-charging service service-1
 credit-control group default
  diameter session failover
exit
```

Alternatively, the OCS can send the setting in the Session-Failover AVP in the CCA-I. Whatever is sent from the OCS takes precedence over what is configured in the ASR 5000/ASR 5500. If Session-Failover is not enabled through interaction with OCS, even if there is secondary OCS configured and failure-handling configured, it will not take effect and the session will be terminated.

The failure-handling setting determines what needs to be done for the session in case of failure of the OCS. Failure-handling settings can come from local configuration, or from the OCS through the Credit-Control-Failure-Handling AVP. The AVP can have any of the 3 values listed below.

• **CONTINUE** - Retry to the secondary OCS and in case that too is not reachable or not responding, then Continue the ongoing session, without any further OCS interaction. [Session goes Offline]

• **RETRY-AND-TERMINATE** - Retry to the secondary OCS and in case that too is not reachable or not responding, terminate the session.

• **TERMINATE** - Terminate the session without retrying the secondary.


Note that all the above retries are done only if the session-failover is set. If it is not set, the session is either terminated or made offline based on the failure-handling setting and the secondary is never retried.

The failure-handling setting is more comprehensive in ASR 5000/ASR 5500, where there are different options to set different failure-handling behavior for different messages (Initial/Update/Terminate).

Failure Handling Call Flow


1. If the config is CONTINUE & RETRY-AND-TERMINATE. In the Case of OCS1 down, PGW/GGSN retries the secondary server.

Scenario 1



2. If the config is CONTINUE. In the case of both OCS down. PGW/GGSN continues the session offline.
3. If the config is RETRY-AND-TERMINATE. In the Case of both OCS down. PGW/GGSN terminate the session after retrying.

Scenario 3



Basic troubleshooting commands for Gy

> Some of the below CLI commands requires CLI test-commands password configured in the chassis. Please use the command with caution!
> Many TEST commands are processor-intensive and can cause serious system problems if used too frequently.

- show active-charging sessions full imsi <>
- show active-charging credit-control statistics group <>
- show diameter statistics endpoint <>
- show diameter peers full endpoint <>
- show diameter route table endpoint <>
- show support detail

- Sniffer PCAP trace (wireshark or similar)

Capture mulitiple iterations so the delta between them can be seen.

- show active-charging sessions full <>

The following are descriptions for values of "Credit-Control:" in the output:

- **Offline Charging** - Sessions that were initially online but later moved into Offline charging due to failure handling or some Offline indication from OCS server.
- **On** - Session is online enabled and charging and currently not waiting for CCA-I, CCA-U or CCA-T.
- **Off** - The session is non-online enabled.

```
[local]SPGW-1# show active-charging sessions full imsi 123456789012410

  Session-ID:                  1:10238  Username: 112233445566843@cisco.com
  Callid:                     000063fc  IMSI/MSID:          123456789012410
  MSISDN:                                                  112233445566843
  ACSMgr Instance:                   1  ACSMgr Card/Cpu:                1/0
  SessMgr Instance:                                                      1
  Client-IP:                                                  10.10.20.7
  ...
  [snip]
  ...
  Credit-Control:                                                       On
  CC Peer:                                          minid-gy.ciscolab1.com
  CC Group:                                                           solo
  CC Mode:                                                         DIAMETER
  CC Failure Handling:                                            Terminate
  CC Session Failover:                                             Enabled
  CCR-I Server Unreachable Handling:                         Not-Configured
  CCR-U Server Unreachable Handling:                         Not-Configured
  Total CCR-U                                                            0
  Total Server Unreachable States Hit:                                   0
        Tx-Expiry:                   0   Response-TimeOut:                0
        Connection-Failure:          0   Result-Code Based:               0
  Current Server Unreachable State:                                    n/a
        Interim Volume in Bytes (used / allotted):                 na/   na
```

```
      Interim Time in Seconds (used / allotted):                 na/   na
      Server Retries (attempted / configured):                   na/   na
      Server Unreachable Reason:                                       na
  ...
```

- **show active-charging credit-control statistics group <>**

  This command will provide: Success & failure information, All error Cause-Code Information Stats, Total FH & Offline session information, and backpressure stats.

```
[local]ASR5000# show active-charging credit-control statistics group PGW-GY
Active Charging Service : ecs
  Credit Control Group  : PGW-GY

    CC Session Stats:
      Total Current Sessions:  0
      Total ECS Adds:          2334          Total CC Starts:         11
      Total Session Updates:   0             Total Terminated:        2334
      Session Switchovers:     0

    CC Message Stats:
      Total Messages Received: 24            Total Messages Sent:     24
      Total CC Requests:       24            Total CC Answers:        24
      CCR-Initial:             11            CCA-Initial:             11
      CCA-Initial Accept:      11            CCA-Initial Reject:      0
      CCA-Initial Timeouts:    0
      CCR-Update:              2             CCA-Update:              2
      CCA-Update Timeouts:     0
      CCR-Final:               11            CCA-Final:               11
      CCA-Final Timeouts:      0
      CCR-Event:               0             CCA-Event:               0
      CCA-Event Timeouts:      0             CCR-Event Retry:         0
      ASR:                     0             ASA:                     0
      RAR:                     0             RAA:                     0
      CCA Dropped:             0

    CC Message Error Stats:
      Diameter Protocol Errs:  0             Transient Failures:      0
```

```
    Permanent Failures:       0             Bad Answers:              0
    Unknown Session Reqs:     0             Unknown Command Code:     0
    Request Timeouts:         0             Parse Errors:             0
    Unknown Rating Group:     0             Unknown Rulebase:         0
    Unk Failure Handling:     0

  Backpressure Stats:
    CCR-I Messages :          0             CCR-U Messages :          0
    CCR-T Messages :          0             CCR-E Messages :          0

  CC Update Reporting Reason Stats:
    Threshold:                0             QHT:                      2
    Final:                    0             Quota Exhausted:          0
    Validity Time:            0             Other Quota:              0
    Rating Condition Change:  0             Forced Reauthorization:   0
    TITSU Time:               0

  CC Termination Cause Stats:
    Diameter Logout:          11            Service Not Provided:     0
    Bad Answer:               0             Administrative:           0
    Link Broken:              0             Auth Expired:             0
    User Moved:               0             Session Timeout:          0

  CC Bad Answer Stats:
    Auth-Application-Id:      0             Session-Id:               0
    CC-Request-Number:        0             CC-Request-Type:          0
    Origin-Host:              0             Origin-Realm:             0
    Parse-Message-Errors:     0             Parse-Mscc-Errors:        0
    Misc:                     0

  CCA Initial Message Stats:
    Result Code 2001:         11            Result Code 5003:         0
    Result Code 4011:         0             Result Code 4012:         0

  CCA Update Message Stats:
    Result Code 2001:         2             Result Code 5003:         0
    Result Code 4011:         0             Result Code 4012:         0

  CCA Event Message Stats:
```

```
    Result Code 2001:        0              Other Result Codes:      0

  Failure Handling Stats:
    Action-Terminated:       0              Action-Continue:         0
    Offline Active Sessions: 0

  CCA Result Code 2xxx Stats:
    Result Code 2xxx:        24             Result Code 2001:        24
    Result Code 2002:        0

  CCA Result Code 4xxx Stats:
    Result Code 4001:        0              Result Code 4002:        0
    Result Code 4011:        0              Result Code 4012:        0

  CCA Result Code 5xxx Stats:
    Result Code 5001:        0              Result Code 5002:        0
    Result Code 5003:        0              Result Code 5004:        0
    Result Code 5005:        0              Result Code 5006:        0
    All Other Result Codes:  0

  OCS Unreachable Stats:
    Tx-Expiry:               0              Response-TimeOut:        0
    Connection-Failure:      0              Action-Continue:         0
    Action-Terminated:       0              Server Retries:          0

  Assumed-Positive Sessions:
    Current:                 0              Cumulative:              0
```

- **show diameter statistics endpoint** <>

```
[local]ASR5000# show diameter statistics endpoint credit-control

Create Messages statistics:
  Calls:                                                    0
  Success:                                                108
  Routed:                                                   0
```

```
  Unrouted:                                  0
  Directed:                                  0
  Buffer Errors:                             0
  Peer Never Up Errors:                      0
  Window Errors:                             0
  Unsupported Application Errors:            0

Message Parse statistics:
  Message Pool Expand Attempts:              0
  Buffer Expand Attempts:                    0
  Calls:                                   108
  Too Many AVP Errors:                       0
  Header Errors:                             0
  AVP Unknown Errors:                        0
  Runt Errors:                               0
  AVP Header Errors:                         0
  Message Protocol Error:                    0
  Mand AVP Unknown Errors:                   0
  Message aborts:                            0

Send Message statistics:
  Calls:                                   108
  Truncated Errors:                          0

Read statistics:
  Read Bytes:                                0
  Read Messages Total:                       0
  Requests Read:                             0
  Requests Timed Out:                        0
  Answers Read:                            108
  Answers Timed Out:                         0
  Read Application Messages:               108
  Unexpected Answers Read:                   0

Read Parse statistics:
  Begin:                                   108
  E2E Errors:                                0
  Success:                                 108
  Application ID Errors:                     0
```

```
  Command/Flag Errors:                                0
  Diameter Protocol Errors:                           0
  Errors:                                             0
  Length Padding Errors:                              0
  H2H Errors:                                         0
  Length Too Long:                                    0
  Command Unknown:                                    0
  Length Sanity Errors:                               0
  Length-v-SCTP EOR Errors:                           0
  SCTP Missing EOR Errors:                            0

Route statistics:
  Adds:                                               0
  Expires:                                            0
  Hits:                                               0
  Misses:                                             0
  Indirects:                                          0
  Installs:                                           0

Dynamic Route statistics:
  Adds:                                               0
  Add Failures:                                       0
  Removes:                                            0
  Hits:                                               0
  Expires:                                            0

Latency statistics:
  Last Round Trip Time (ms):                         50
  Average Round Trip Time (ms):                      53

Proxy-Base Messaging statistics:
  Pin Peer Messages:                                  0
  Renegotiate Peer Messages:                          0
  Application Unregister Messages:                    0
  Redirect Indication Messages:                       0
  Data Messages Initial Attempts:                     0
  Data Messages Backpressured Attempts:               0
  Link State UP Messages:                             0
  Link State DOWN Messages:                           0
```

```
Redirect Host Usage:
  Redirected Host:                                    0
  Redirect Not Cached:                                0
  Redirect All Session:                               0
  Redirect All Realm:                                 0
  Redirect Realm and Application:                     0
  Redirect All Application:                           0
  Redirect All Host:                                  0
  Redirect All User:                                  0

Peer Backoff Timer:
  Start Count:                                        0
  Stop Count:                                         0
```

- **show diameter peers full endpoint** <>

  Status of the Diameter endpoint

```
[local]SPGW-1# show diameter peer full endpoint credit-control
--------------------------------------------------------------------------------
Context: spgw                 Endpoint: credit-control
--------------------------------------------------------------------------------
 Peer Hostname: minid-gy.ciscolab1.com
  Local Hostname: spgw-gy.ciscolab1.com
  Peer Realm: ciscolab1.com
  Local Realm: ciscolab1.com
  Peer Address: 192.168.5.195:4000
  Local Address: 192.168.5.11:52551
  State: OPEN [TCP]
  CPU: 1/0                              Task: diamproxy-1
  Messages Out/Queued: N/A
  Supported Vendor IDs: 10415
  Admin Status: Enable
  DPR Disconnect: N/A
```

```
 Peer Backoff Timer running:N/A

Peers Summary:
 Peers in OPEN state: 1
 Peers in CLOSED state: 0
 Peers in intermediate state: 0
 Total peers matching specified criteria: 1
```

- **show diameter route table endpoint** <>

  Current route entries

```
[local]asr 5000# show diameter route table endpoint dcca
-------------------------------------------------------------------------------
Context: local                Endpoint: dcca
-------------------------------------------------------------------------------
+--- Static/Redirect/Dynamic
v Origin              Host@Realm                     App Peer             Wgt Exp
D 0001-diamproxy.gy.c host2@hostrealm.com            *   dra1.drarealm.c  10 86391
S *                   dra1.drarealm.com@drarealm.com *   dra1.drarealm.c  10
S *                   *@drarealm.com                 *   dra1.drarealm.c  10
D 0002-diamproxy.gy.c host1@hostrealm.com            *   dra1.drarealm.c  10 86377
Total items matching specified criteria: 4
```

Example Scenarios

OCS reports error code 3004

Problem Description:

After some changes on OCS side, service degradation was experienced. An extremely high number of disconnects caused signaling overload on some other products. The expected behavior with OCS issues is that subscriber sessions continue, and no session disconnects should occur.

Logs Collection:

- Collect 2 or more “Show support details”

- Collect syslog
- Collect bulkstats/KPI for Diameter
- Monitor subscriber imsi <imsi> (verbosity 3)
- Monitor protocol (verbosity 3) -- Consult Cisco support before running this command in a production network.
- Collect external packet capture
- Show active-charging credit-control statistics group <credit-control group name>
- Show active-charging sessions full <imsi>
- Show session disconnect-reason
- Show support detail

Analysis:


- Based on the KPIs and show command output, it was noticed that OCS session failover occurred, and the diameter protocol Error (3xxx) started increasing.
  - **show active-charging credit-control statistics group "PGW-GY"**

    The above CLI gives a lot of information, the fields of interest are highlighted below.

```
Failure Handling Stats:
  Action-Terminated:       2000            Action-Continue: 3000
  Offline Active Sessions: 3000

CC Message Error Stats:
  Diameter Protocol Errs:  6000            Transient Failures:      0
```

- Both OCS were resonding with error 3004 (Diameter too Busy)
- Logs show both OCSs send "DIAMETER_TOO_BUSY" (3004) error to PGW.



- Because both OCSs sent 3004 result code, the Failure Handling (FH) condition is triggered, resulting in an increase in offline sessions.
- After expiry of FH timer (a timer which controls when to disconnect sessions which are offline due to FH), the PGW terminated the subscriber session which subsequently tried to reattach. This, in turn, led to an increase in the “Admin-disconnect” reason and “FH Termination” event.
- The large number of subscriber reattaches had a degrading effect which resulted in the problems.

Resolution:

1. The problem was resolved once the OCS team rolled back changes.
2. Define the DCCA high and low thresholds for the errors.

```
threshold dcca-protocol-error <value> clear<value>
threshold dcca-bad-answers <value> clear <value>
threshold dcca-unknown-rating-group <value> clear <value>
threshold dcca-rating-failed <value> clear <value>
threshold poll dcca-protocol-error interval <value>
threshold poll dcca-bad-answers interval <value>
threshold poll dcca-unknown-rating-group interval <value>
```

```
threshold poll dcca-rating-failed interval <value>
```

Low Throughput Issue due to small quota allocation

Problem Description:

Low Throughput observed for prepaid subscriber. Prepaid and postpaid subscriber should have same throughput.

Logs collection:

- Collect 2 or more “Show support details”
- Collect syslog
- Collect bulkstats/KPI for Diameter
- Monitor subscriber imsi <imsi> (verbosity 3)
- Monitor protocol (verbosity 3) -- Please check with Cisco support before running this command in a production network.
- Collect external packet capture
- Show active-charging sessions full <imsi>
- Show support detail
- Show apn statistics all

Analysis:


- The Pending traffic treatment configured is drop.
- The OCS is sending very small quota and frequency of Quota request towards OCS is more.
- From show active-charging sessions full output , it is observed that the PGW is droping the packets.

```
Dropped Uplink Pkts:              500  Dropped Downlink Pkts:            0
Dropped Uplink Bytes:             50000  Dropped Downlink Bytes:          0
```

- show apn statistics all

  The above CLI gives a lot of information, the fields of interest are highlighted below.

```
APN Name  : apn.com
  VPN Name  : gi_ctx
Gi interface statistics ('uplnk'=to PDN, 'dnlnk'=from PDN):
  uplnk bytes:                  1879718   dnlnk bytes:                482785
  uplnk pkts:                     27126   dnlnk pkts:                   5044
  uplnk bytes dropped:           166442   dnlnk bytes dropped:             0
  uplnk pkts dropped:              1212   dnlnk pkts dropped:              0
```



Resolution:

Increase the quota size to avoid frequent transaction, or configure the system to buffer packets while quota requests to OCS server are pending.

Authentication - S6a

Overview

This section covers Diameter Authentication over S6a interface and basic troubleshooting commands with an example.

The S6a interface is used to provide AAA functionality for subscriber EPS Bearer contexts between MME and HSS using Diameter protocol. The underlying transport protocol is SCTP.


The following messages are initiated by MME to HSS.

- Authentication-Information-Request(AIR)
- Update-Location-Request(ULR)
- Notify-Request(NR)
- Purge-Ue-Request(PUR)

Authentication-Information Request/Response

The Authentication Information Retrieval Procedure shall be used by the MME to request Authentication Information from the HSS.

Image - Call flow:



[MME → HSS] Authentication Information Request

The MME sends an **Authentication Information Request** message to the HSS, requesting authentication vector(s) (AV) for the UE that has an IMSI. Main parameters in the **Authentication Information Request** message are:

- IMSI: Subscriber identifier (a fixed value provisioned at HSS for a UE)
- SN ID: indicates the serving network of a subscriber, and consists of a PLMN ID (MCC+MNC)

AVP structure used by MME to ask for EPS vectors

```
Requested- EUTRAN-Authentication-Info ::= <AVP header:10415 >
   [ Number-Of-Requested-Vectors]
  [ Immediate-Response-Preferred ]
  [ Re-synchronization-Info ]
```

[MME ← HSS] Delivering Authentication Vectors

The HSS generates authentication vectors by using the LTE master key (LTE K) in the IMSI and the serving network ID (SN ID) of the UE. Authentication vectors are generated through the two steps.

First, the HSS generates SQN and RAND, and then inputs the values of {LTE K, SQN, RAND} in the crypto function to generate the values of {XRES, AUTN, CK, IK}.

Next, it inputs the values of {SQN, SN ID, CK, IK} in the key derivation function to derive KASME.

(i) (**XRES**, **AUTN**, CK, IK) = Crypto Function (LTE K, **SQN**, RAND)

(ii) **KASME** = KDF (SQN, SN ID, CK, IK)

Then HSS sends the authentication vectors, as included in the **Authentication Information Response** message to the MME.

HSS sends EUTRAN-vector in following AVP

```
E-UTRAN-Vector ::= <AVP header: 1414 10415>
                    [ Item-Number ]
                  { RAND }
                  { XRES }
                  { AUTN }&#10                  { KASME }
```


The MME then uses this information to perform mutual authentication with the UE.

Update-Location Request/Answer

Once the procedures for authentication and NAS security setup are completed, MME has to register the subscriber in the network, and find out what services the subscriber can use.

The call flow during this procedure is as in below figure.

Call flow



[MME → HSS] Notifying UE Location

The MME sends an **Update Location Request** (IMSI, MME ID) message to the HSS in order to notify of the UE's registration and obtain the subscription information of the UE.

[MME ← HSS] Delivering User Subscription Information

The HSS registers the MME ID to indicate in which MME the UE is located in. Then HSS sends the MME subscription information of the subscriber as included in an **Update Location An-**

swer message, so that the MME can create an EPS session and a default EPS bearer for the subscriber. The subscription information included in the **Update Location Answer** message is as follows:


- Subscribed APN: APN that a user is subscribed to (e.g internet service)
- Subscribed PGW-ID: an ID for P-GW through which a user can access the subscribed APN
- Subscribed QOS profile: UE-AMBR, QCI ARP, APN-AMBR

Notify Request/Response

The Notification Procedure shall be used between the MME and the HSS when an inter MME location update does not occur but the HSS needs to be notified about:

- An update of terminal information
- An assignment/change/removal of PDN GW for an APN
- The need to send a Cancel Location to the current SGSN
- The UE has become reachable again

Call flow



When receiving a Notify request the HSS shall:


- Store the new terminal information if present in the request;
- Store the new PDN GW for an APN if present in the request and the APN is present in the subscription;

- Mark the location area as "restricted" if so indicated in the request;
- Send Cancel Location to the current SGSN if so indicated in the request;
- If the UE has become reachable again, send an indication to the Service Related Entity.

Purge-UE Request/Response

The Purge UE Procedure shall be used between the MME and the HSS to indicate that the subscriber's profile has been deleted from the MME either by an Operator or automatically, e.g. because the UE has been inactive for several days.

Image - Call flow



The MME shall make use of this procedure to set the "UE Purged in the MME" flag in the HSS when the subscription profile is deleted from the MME database due to MME interaction or after long UE inactivity.

When MME sends PUR to HSS, HSS will mark that subscriber as Purged from MME. In response, HSS shall send an indication to freeze the M-TMSI (Temporary Identity) to MME for some time so that same temporary identity can be used when subscriber became active.

Basic troubleshooting commands for S6a

CLIs:

- show diameter peers full all

- show diameter route table
- show hss-peer-service service name | all
- show hss-peer-service statistics all | service | summary
- show snmp traps

Logging:

> Note:This should only be done upon recommendation from Cisco Support as increasing the logging too high may risk stress on the system and impact subscribers.

- logging filter active facility mme-app level debug
- logging filter active facility hss-peer-service level debug
- logging filter active facility diameter level debug
- logging filter active facility diabase level debug
- logging filter active facility diamproxy level debug
- logging filter active facility diameter-dns level debug
- Check for the hss-peer-service and the Status should be **Started.**

```
[local]asr5000# show hss-peer-service service all
Service name                    : S6A-MME
Context                         : SIG
Status                          : STARTED
Diameter hss-endpoint           : S6A-MME
Diameter eir-endpoint           : n/a
Diameter hss-dictionary         : Standard
Diameter eir-dictionary         : Standard
Request timeout                 : 20s
Request Auth-vectors            : 1
Notify Request Message          : Enable
```

- Check for the Diameter Peer Status and the state should be **Open**.

```
[local]asr5000# show diameter peers full
--------------------------------------------------------------------------------
```

```
Context: SIG                    Endpoint: S6A-MME
--------------------------------------------------------------------------------
Peer Hostname: megad-s6a
  Local Hostname: sim-s6a
  Peer Realm: cisco.com
  Local Realm: cisco.com
  Peer Address: XXX.XXX.XXX.X:3868
  Local Address: XXX.XXX.XXX.X:32774
  State: OPEN [SCTP]
  CPU: 1/0                                  Task: diamproxy-1
                      Messages Out/Queued: N/A
               Supported Vendor IDs: 10415
  Admin Status: Enable
  DPR Disconnect: N/A
```

- Check for any abnormal increase in failure counters

```
[local]asr5000# show hss-peer-service statistics service S6A-MME

HSS statistics for Service: S6A-MME

Session Stats:
   Total Current Sessions:    0
   Sessions Failovers:        0          Total  Starts:           0
   Total Session Updates:     0          Total Terminated:        0


Message Stats:
   UL Request:                0          UL Answer:               0
   ULR Retries:               0          ULA Timeouts:            0
   ULA Dropped:               0
   PU Request:                0          PU Answer:               0
   PUR Retries:               0          PUA Timeouts:            0
   PUA Dropped:               0
   AI Request:                0          AI Answer:               0
   AIR Retries:               0          AIA Timeouts:            0
   AIA Dropped:               0
   CL Request:                0          CL Answer:               0
```

```
   CLR Retries:                0          CLA Timeouts:               0
   CLA Dropped:                0
   ISD Request:                0          ISD Answer:                 0
   ISDR Retries:               0          ISDA Timeouts:              0
   ISDA Dropped:               0
   DSD Request:                0          DSD Answer:                 0
   DSDR Retries:               0          DSDA Timeouts:              0
   DSDA Dropped                0
   R Request:                  0          R Answer:                   0
   RR Retries:                 0          RA Timeouts:                0
   RA Dropped:                 0
   N Request:                  0          N Answer:                   0
   NR Retries:                 0          NA Timeouts:                0
   NA Dropped:                 0
   MIC Request:                0          MIC Answer:                 0
   MICR Retries:               0          MICA Timeouts:              0
   MICA Dropped                0

Message Error Stats:
   Unable To Comply:         0          Auth Data Unavailable:      0
   User Unknown:             0          Equipment Unknown:          0
   Unknown EPS Subscription:0           RAT Not Allowed:            0
   Authorization Rejected:   0          Roaming Not Allowed:        0
   Other Errors:             0
```

Example Scenarios:

Authentication issues with roaming subscribers

Problem Description:

Experiencing authentication issues with roaming subscribers in the network. S6a messages are not going out of the box for some operators and the following errors are observed with logging monitor for the subscriber:

```
 Mar 30 17:55:33 lou_cps1 evlogd: [local-60sec33.790] [mme-app 147036 error] [14/0/26859
<sessmgr:297> mme_auth_proc.c:1611] [callid 487bacae] [context: mme, contextID: 2]  [software
internal user syslog] imsi <>, procedure MME Authentication procedure , Error sending HSS-S6a
message
```

Required information for troubleshooting

- show support detail
- show diameter endpoints all
- show diameter route table [debug]
- show configuration
- monitor subscriber imsi <>

Analysis:

The current configuration indicates that static route entry is missing for the diameter end point.

According to the MME administration guide, (section: Configuring Dynamic Destination Realm Construction for Foreign Subscribers - page 89 Release 16), configuring Dynamic Destination Realm for Foreign Subscribers requires a static route entry to be added in the diameter end-point configuration for each foreign realm.

Resolution:

Adding the static route entry in Diameter endpoint configuration solved the issue:

```
context signal
 diameter endpoint hss
 route-entry realm epc.mnc001.mcc001.3gppnetwork.org peer dsr1.dea.test.net
 route-entry realm epc.mnc0o1.mcc001.3gppnetwork.org peer dsr2.dea.test.net
```

DNS

DNS Client

Overview

The infrastructure DNS-client is used by the PGW / HSGW / MME / SGSN to resolve DNS names for SGSN/MME/GGSN/PGW, P-CSCF or other servers likes accounting. In this chapter the commands used to debug and troubleshoot this feature are covered.

Troubleshooting Commands

`show context`

- This command will show the context configured on the chassis. Make note of the context which contains the dns-client configuration. This will be the context where the pgw-service is configured.

```
[local]ASR5x00> show context
Context Name    ContextID    State     Description
--------------- --------- ----------   ----------------------
local           1            Active
PGWin           2            Active
PGWout          3            Active
```

show task resources facility vpnmgr all

- This command will show the status of the vpn manager (vpnmgr) tasks, which controls the dns-client.
  Make sure the status of the task is in a good state.
- **Note:** The task instance maps to the context ID seen above, so in this example, vpnmgr instance 2 is used for context PGWin, which is where the dns-client is configured. If there is a problem on the chassis related to the dns-client, a restart of the vpnmgr task may help clear the issue.

```
[local]ASR5x00> show task resources facility vpnmgr all
                  task   cputime        memory     files      sessions
```

```
cpu facility      inst used allc   used  alloc used allc  used  allc S status
 ---------------------- --------- ------------- --------- ------------- ------
  5/0 vpnmgr           1 0.2%  30% 29.29M 48.10M   44 2000    --    -- -   good
  5/0 vpnmgr           2 3.3% 100% 548.9M  1.86G  371 2000    --    -- -   good
  5/0 vpnmgr           3 0.2% 100% 25.85M 57.20M   44 2000    --    -- -   good
```

show session recovery status verbose

- This command will show where the Demux card is located. The vpnmgr task runs on the Demux card, so make note of the location and confirm there are no problems with the card. Below are two examples showing the Demux card on ASR 5500 MIO in slot 5 and ASR 5000 PSC in slot 1.

```
[local]ASR5500> show session recovery status verbose
Session Recovery Status:
  Overall Status        : Ready For Recovery
  Last Status Update    : 4 seconds ago

              ----sessmgr---  ----aaamgr----  demux
 cpu state    active standby  active standby  active  status
---- -------  ------ -------  ------ -------  ------  -------------------------
 1/0 Active   24     1        25     1        0       Good
 1/1 Active   24     1        23     1        0       Good
 2/0 Active   24     1        24     1        0       Good
 2/1 Active   24     1        24     1        0       Good
 3/0 Active   24     1        24     1        0       Good
 3/1 Active   24     1        24     1        0       Good
 4/0 Active   24     1        24     1        0       Good
 4/1 Active   24     1        24     1        0       Good
 5/0 Active   0      0        0      0        10      Good (Demux)
 7/0 Active   24     1        24     1        0       Good
 7/1 Active   24     1        24     1        0       Good
 8/0 Active   24     1        24     1        0       Good
 8/1 Active   24     1        24     1        0       Good
 9/0 Active   24     1        24     1        0       Good
 9/1 Active   24     1        24     1        0       Good
10/0 Standby  0      24       0      25       0       Good
10/1 Standby  0      24       0      24       0       Good
```

```
 [local]ASR-5000> show session recovery status verbose
Session Recovery Status:
  Overall Status        : Ready For Recovery
  Last Status Update    : 5 seconds ago

              ----sessmgr---  ----aaamgr----  demux
 cpu state    active standby  active standby  active  status
---- -------  ------ -------  ------ -------  ------  -------------------------
 1/0 Active   0      0        0      0        26      Good (Demux)
 2/0 Active   24     1        24     1        0       Good
 3/0 Active   24     1        24     1        0       Good
 4/0 Active   24     1        24     1        0       Good
 5/0 Active   24     1        24     1        0       Good
 6/0 Active   24     1        24     1        0       Good
 7/0 Active   24     1        24     1        0       Good
10/0 Active   24     1        24     1        0       Good
11/0 Active   24     1        24     1        0       Good
12/0 Active   24     1        24     1        0       Good
13/0 Active   24     1        24     1        0       Good
14/0 Active   24     1        24     1        0       Good
15/0 Active   24     1        24     1        0       Good
16/0 Standby  0      24       0      24       0       Good
```

show dns-client statistics client <dns-client name>

- This command will show the statistics for the dns-client. In this example, a dns-client named "PGW-DNS" and the config is located in context PGWin.
- Make note of any failures and re-run the command to see if the failures are incrementing.
- If failures are seen, confirm which DNS query type has the problem.
- Check to see if the problem is related to the primary or secondary name server.
- Check for the type of failure:
  - Query Timeout
  - Domain Not Found
  - Connection Refused
  - Other Failures

- A PCAP trace may be required to determine where the problem is between the chassis and DNS servers.
- DNS NAPTR queries are used to obtain long lists of Name Authority Pointer records which are essentially FQDNs representing various nodes in the network to which an HSGW or MME desire to connect calls to. DNS AAAA queries will then ensue to obtain the actual IPv6 addresses of the FQDNs the system desires to connect to.

```
[local]ASR5x00> context PGWin
[PGWin]ASR5x00>

 [PGWin]ASR5x00> show dns-client statistics client PGW-DNS

DNS Usage Statistics:
---------------------
Query Type              Attempts       Successes        Failures
A                              0               0               0
SRV                            0               0               0
AAAA                         429             429               0
NAPTR                          0               0               0
PTR                            0               0               0
Total                        429             429               0

DNS Cache Statistics:
---------------------
                   Total   Cache Hits  Cache Hits   Not Found    Hit Ratio
                 Lookups  (Positive    (Negative     in Cache   (Percentage)
                           Response)   Response)
-------------------------------------------------------------------------------
Central Cache:         365         313            0          52         85.75%
Local Cache:           429          61            0         368         14.22%


DNS Resolver Statistics:
------------------------
Primary Name Server : 2000:4000:200:ffff:a0:e:0:1
Query Type              Attempts       Successes        Failures
A                              0               0               0
SRV                            0               0               0
AAAA                          50              50               0
```

```
NAPTR                          0               0               0
PTR                            0               0               0
Total Resolver Queries: 50
Successful Queries:     50
Query Timeouts:         0
Domain Not Found:       0
Connection Refused:     0
Other Failures:         0

Secondary Name Server : 2000:4000:200:ffff:c0:e:0:2
Query Type              Attempts        Successes       Failures
A                              0               0               0
SRV                            0               0               0
AAAA                           0               0               0
NAPTR                          0               0               0
PTR                            0               0               0
Total Resolver Queries: 0
Successful Queries:     0
Query Timeouts:         0
Domain Not Found:       0
Connection Refused:     0
Other Failures:         0
```

clear dns-client <dns-client name> statistics

- This command can be used to clear the dns-client statistics. This can be helpful to get a fresh look at the statistics during a problem. This command needs to be run from the context where dns-client is configured.

```
[PGWin]ASR5x00> clear dns-client PGW-DNS statistics

Statistics cleared for the specified criteria
```

show dns-client cache client <dns-client name>

- This command will show the dns-client cache output. This can be helpful to find specific query names, query type, TTL and DNS answer. This command needs to be run from the context where dns-client is configured.

```
[PGWin]ASR5x00> show dns-client cache client PGW-DNS

Query Name: pcscf1.aa123.xyz.com
Query Type: AAAA       TTL: 1 seconds
Answer:
  IPv6 Address: 2000:4000:1:aa01:a0:100:0:a1

Query Name: pcscf1.ab456.xyz.com
Query Type: AAAA       TTL: 1 seconds
Answer:
  IPv6 Address: 2000:4000:2:ab01:b0:100:0:b2
```

clear dns-client cache cache

- This command can be used to clear the dns-client cache. This can be helpful to perform if problems are seen related to certain entries in the cache or if additional sites/nodes have been added recently. Normally the TTL may be so low (i.e. under 60-120 seconds) that the entries will be automatically updated in the cache on a regular interval. This command needs to be run from the context where dns-client is configured.

```
[PGWin]ASR5x00> clear dns-client cache cache
```

dns query client-name <dns-client name> **query-type** <A,AAAA,NAPTR,SRV> **query-name** <name>

- This command can be used to perform a dns query to a specific query name using a specific query type. Use the "show dns-client cache client <dns-client name>" command to find a query name. Other query-type can be entered, such as "A" and "NAPTR". This command needs to be run from the context where dns-client is configured.

```
[PGWin]ASR5x00> dns query client-name PGW-DNS query-type AAAA query-name pcscf1.aa123.xyz.com

Query Name: pcscf1.aa123.xyz.com
Query Type: AAAA       TTL: 2 seconds
Answer:
  IPv6 Address: 2000:4000:1:aa01:a0:100:0:a1
```

show config context <pgw_context_name>

- This command can be used to see the configuration related to the dns-client.

show config context <pgw_context_name> verbose

- This command can be used to see any default options configured for the dns-client.

DNS Client Queries:

MME Queries

Sample query for selecting SGW and PGW selection using APN:

```
 [mme]MME2# dns-client query client-name dns1 query-type NAPTR query-name tac-lb28.tac-
hb00.tac.epc.mncxxx.mccyyy.3gppnetwork.org
 Query Name: tac-lb28.tac-hb00.tac.epc.mncxxx.mccyyy.3gppnetwork.org
 Query Type: NAPTR      TTL: 60 seconds
 Answer:
   Order: 1              Preference: 1
   Flags: a              Service: x-3gpp-sgw:x-s5-gtp
   Regular Expression:
   Replacement: sgw5.sgw.3gppnetwork.org

 Query Name: sgw5.sgw.3gppnetwork.org
 Query Type: A          TTL: 60 seconds
 Answer:
   IP Address: 192.168.50.105

 [mme]MME2#
 [mme]MME2# dns-client query client-name dns1 query-type NAPTR query-name
cisco.com.apn.epc.mncxxx.mccyyy.3gppnetwork.org
 Query Name: cisco.com.apn.epc.mncxxx.mccyyy.3gppnetwork.org
 Query Type: NAPTR      TTL: 60 seconds
 Answer:
   Order: 1              Preference: 1
   Flags: a              Service: x-3gpp-pgw:x-s5-gtp
   Regular Expression:
   Replacement: pgw5.pgw.3gppnetwork.org
```

```
Query Name: pgw5.pgw.3gppnetwork.org
Query Type: A          TTL: 60 seconds
Answer:
  IP Address: 192.168.5.52
```

Displaying the DNS cache output for verification:

```
[mme]MME2# show dns-client cache client dns1
Query Name: tac-lb28.tac-hb00.tac.epc.mncxxx.mccyyy.3gppnetwork.org
Query Type: NAPTR      TTL: 58 seconds
Answer:
  Order: 1              Preference: 1
  Flags: a              Service: x-3gpp-sgw:x-s5-gtp
  Regular Expression:
  Replacement: sgw5.sgw.3gppnetwork.org

Query Name: cisco.com.apn.epc.mncxxx.mccyyy.3gppnetwork.org
Query Type: NAPTR      TTL: 52 seconds
Answer:
  Order: 1              Preference: 1
  Flags: a              Service: x-3gpp-pgw:x-s5-gtp
  Regular Expression:
  Replacement: pgw5.pgw.3gppnetwork.org

Query Name: sgw5.sgw.3gppnetwork.org
Query Type: A          TTL: 58 seconds
Answer:
  IP Address: 192.168.50.105

Query Name: pgw5.pgw.3gppnetwork.org
Query Type: A          TTL: 52 seconds
Answer:
  IP Address: 192.168.5.52
```

SGSN Queries

DNS query for RAI for finding SGSN selection and GGSN selection using APN query.

```
[sgsn]SGSN# dns-client query client-name dns query-name cisco.com.mncxxx.mccyyy.gprs
Query Name: cisco.com.mncxxx.mccyyy.gprs
Query Type: A          TTL: 3600 seconds
Answer: IP Address: 192.168.5.52
 [sgsn]SGSN# dns-client query client-name dns query-name rac0013.lac1716.mncxxx.mccyyy.gprs
Query Name: rac0013.lac1716.mncxxx.mccyyy.gprs
Query Type: A          TTL: 3600 seconds
Answer:  IP Address: 172.16.10.12
```

Proxy DNS

Overview

This chapter talks about proxy-dns feature including configuration and troubleshooting commands.

Troubleshooting command

The following commands can be used to troubleshoot the dns-proxy intercept list:


Command	Reference
context <ingress context name>	Context that has the dns-proxy
show dns-proxy statistics	To look at dns-proxy stats
show dns-proxy intercept-list <name> statistics	To look at stats for a specific intercept list
show dns-proxy intercept-list <name> rule <rule> statistics	To look at stats for a specific intercept list and rule
show session subsystem data-info verbose | grep proxy-dns	Look for high amount of drops
show subscribers counters dns-proxy username <username>	Counters for a specific user
show sub full username <username> | grep -i dns	DNS related info for a specific session

proxy-dns intercept-list

- Use this command to define a name for a list of rules pertaining to the IP addresses associated with the foreign network's DNS. Up to 128 rules of any type can be configured per rules list. Upon entering the command, the system switches to the HA Proxy DNS Configuration Mode where the lists can be defined. Up to 64 separate rules lists can be configured in a single AAA context. This command and the commands in the HA Proxy DNS Configuration Mode provide a solution to the Mobile IP problem that occurs when a MIP subscriber, with a legacy MN or MN that does not support IS-835D, receives a DNS server address from a foreign network that is unreachable from the home network.

See the CLI Reference Guide for more details.

Image - call flow for proxy-dns



By configuring the Proxy DNS feature on the Home Agent, the foreign DNS address is intercepted and replaced with a home DNS address while the call is being handled by the home network.

Configuration

The following command creates a proxy DNS rules list named **list1** and places the CLI in the HA Proxy DNS Configuration Mode. A redirect and pass-thru rule has been configured.

```
configure
context <ingress_context>
  proxy-dns intercept-list list1
    redirect 0.0.0.0/0 primary-dns 1.1.1.1 secondary-dns 2.2.2.2
    pass-thru 5.5.0.0/16
exit
end
```

In the egress context the dns-proxy **source address** is configured. Use this command to identify the interface in this context where redirected DNS packets are sent to the home DNS. The system uses this address as the source address of the DNS packets when forwarding the intercepted DNS request to the home DNS server.

```
configure
context <egress_context>
  ip dns-proxy source-address 192.168.1.1
end
```

Active Charging Service

Active Charging Service

Overview

The Active Charging Service (ACS), also called ECS (Enhanced Charging Service) is an in-line service that provides flexible, differentiated, and detailed billing to subscribers with Layer 3 through Layer 7 packet inspection.

This chapter will cover the basic principles of ACS: the architecture, the main building blocks, advanced functionalities, and a section with troubleshooting scenarios.


Architecture

Content Service Steering: Redirects incoming traffic to the ECS subsystem.

CSS uses Access Control Lists (ACLs) to redirect selective subscriber traffic flows. ACLs control the flow of packets into and out of the system.

Protocol Analyzer: Performs inspection of incoming packets. The Protocol Analyzer is the software stack responsible for analyzing the individual protocol fields and states during packet inspection.


Image - ECS Traffic



The Protocol Analyzer performs two types of packet inspection:

- **Shallow Packet Inspection**: Inspection of the layer 3 (IP header) and layer 4 (for example, UDP or TCP header) information.
- **Deep Packet Inspection**: Inspection of layer 7 and 7+ information.

Image - Protocol Analyzer Software Stack



Rule Definitions (ruledefs): Specifies the packets to inspect or the charging actions to apply to packets based on content.

Ruledefs are of the following types:

Routing Ruledefs: Routing ruledefs are used to route packets to content analyzers. Routing ruledefs determine which content analyzer to route the packet to when the protocol fields and/or protocol-states in the ruledef expression are true.

Charging Ruledefs: Charging ruledefs are used to specify what action to take based on the analysis done by the content analyzers. Actions can include redirection, charge value, and billing record emission.

When a ruledef is created, if the rule-application is not specified, by default the system configures the ruledef as a charging ruledef. Ruledefs support a priority configuration to specify the order in which the ruledefs are examined and applied to packets. The names of the ruledefs must be unique across the service or globally. A ruledef can be used across multiple rulebases.


Ruledef priorities control the flow of the packets through the analyzers and control the order in which the charging actions are applied. The ruledef with the lowest priority number invokes first. For routing ruledefs, it is important that lower level analyzers (such as the TCP analyzer) be invoked prior to the related analyzers in the next level (such as HTTP analyzer) as the next level of analyzers may require access to resources or information from the lower level. Priorities are also important for charging ruledefs, as the action defined in the first matched charging rule apply to the packet and ECS subsystem disregards the rest of the charging rules.

Group-of-Ruledefs enable grouping ruledefs into categories. When a group-of-ruledefs is configured in a rulebase, if any of the ruledefs within the group matches, the specified charging-action is performed, any more action instances are not processed.

Rulebases: Allows grouping one or more number of rule definitions together to define the billing policies for individual subscribers or group of subscribers. A rulebase is a collection of ruledefs and their associated billing policy. The rulebase determines the action to be taken when a rule is matched.

Routing Ruledefs and Packet Inspection

Image - Routing Ruledefs and Packet Inspection




1. The packet is redirected to ECS based on the ACLs in the subscriber's APN and packets enter ECS through the Protocol Analyzer Stack.
2. Packets entering Protocol Analyzer Stack first go through a shallow inspection by passing through the following analyzers in the listed order:
   - Bearer Analyzer
   - IP Analyzer
   - ICMP, TCP, or UDP Analyzer as appropriate (traffic routes to the ICMP, TCP, and UDP analyzers by default. Therefore, defining routing ruledefs for these analyzers is not required.)
3. The fields and states found in the shallow inspection are compared to the fields and states defined in the routing ruledefs in the subscriber's rulebase. The ruledefs' priority determines the order in which the ruledefs are compared against packets.
4. When the protocol fields and states found during the shallow inspection match those defined in a routing ruledef, the packet is routed to the appropriate layer 7or 7+ analyzer for deep-packet inspection.
5. After the packet has been inspected and analyzed by the Protocol Analyzer Stack:

- The packet resumes normal flow and through the rest of the ECS subsystem.
- The output of that analysis flows into the Charging Engine, where an action can be applied. Applied actions include redirection, charge value, and billing record emission.

Charging Ruledefs and the Charging Engine

Image - Charging Ruledefs and the Charging Engine



1. In the Classification Engine, the output from the deep-packet inspection is compared to the charging ruledefs. The priority configured in each charging ruledef specifies the order in which the ruledefs are compared against the packet inspection output (Lower number = Higher priority).
2. When a field or state from the output of the deep-packet inspection matches a field or state defined in a charging ruledef, the ruledef action is applied to the packet. Actions can include redirection, charge value, or billing record emission. It is also possible that a match does not occur and no action will be applied to the packet at all.

ACS commands

Checking for proper functionality of ACS is typically found in two separate sections of the CLI, within the session subsystem and witin a separate active-charging subsystem.

- **`show subscriber full [user, imsi, msid, callid] [identifier]`**

  Description: This command will show key information about which elements in the system config this session is bound to. These include the ACL, the rulebase, the FW/NAT policy (defined below), the NAT realm, pool, and IP address, the NAT port chunks allocated to the session, and the amount of traffic sent to the ACL.

- **`show active-charging sessions full [user, imsi, msid, callid] [identifier]`**

  Description: This command will give detailed information on exactly what the session is hitting in the ACS. The rules being hit and how much traffic per rule is being recorded for this session are shown. Details on any PCRF / Gx assigned rules or purely dynamic rules can also be seen here. The output of this command will also show the current state of quota grant usage for Gy enabled rules. One key datapoint that can be pulled from this command is the "Session-id". It is at the very top of the output and is needed for some of the more detailed NAT and flow commands outlined below.

- **`show active-charging flows full session-id [value]`**

  Description: This command will give details on the specifics of the flows for the session in ACS. Keep in mind that flows come and go very quickly, so this command is only useful if something appears stuck or if some unexpected behavior with traffic or the ACS subsystem is taking place. Given the quantity of flows on a busy system, it can take a while for the output of this command to return once the command is entered.

- **`show active-charging rulebase statistics name [value]`**

  Description: Running this command will give rulebase level output. Number of packets, record quantity (EDR / UDR / GCDR). Similar commands under the "*show active-charging*" base for *ruledef* and *charging-action* also exist to further drill down on what it being hit in the config.

ACS ruledef Optimization

Overview

Ruledef is a methodology to inspect packets or apply charging actions in ASR 5000/ASR 5500. This chapter covers optimizing techniques of ruledef.

Best Practices for Optimization

Some ruledefs are more optimized for performance than others. It's important to be aware of this performance impact and consider this when building the rulebase.

Generic Rule of thumb for having optimized ruledef configuration:

- In a rulebase, keep all HTTP-based rules at higher priority than non-HTTP based rules (like RTSP/RTP etc) as HTTP traffic is significant and should get evaluated quickly.
- Keep optimized rules at a higher priority than non-optimized rules so that they get evaluated earlier.
- Remove / Re-evaluate rules which show no hits: even though rule is not hit, it still consumes CPU for evaluation.
- Find out the frequently hit rules. Keep these rules at higher priority than others.

```
#show active-charging ruledef statistics all charging

Ruledef Name        Packets-Down  Bytes-Down  Packets-Up   Bytes-Up       Hits Match-Bypassed
------------        ------------  ----------  ----------   --------       ---- --------------
Rule01                    272431   272416148      283438   38127987     481911               0
ip_any                    319352   371385357      260796   48422461     545944               0
Rule03                         0           0           0          0          0               0
ICMPv6                      1585      226584    36844017 3726219884   36845602               0
youtube                    68653    48061177       51872    9460509     115410               0
```

Ways to optimize ruledef configuration

- Every ECS config line counts: keep ECS config minimal, remove un-used rules, routes, analyzers.
- Use debug CLI command for acsmgr to check which ruledefs are optimized and need optimization.
- Check debug profiler to see if "acsmgr_rule_compare_string" is using cpu cycles. If yes, then the rulebase needs to be optimized. For more info on this command please refer to the SW troubleshooting section.

> The below CLI command requires CLI test-commands password configured in the chassis.Please use the command with caution!
> Many **TEST** commands are processor-intensive and can cause serious system problems if used too frequently.

This command can be run to perform an audit to determine if ruledef optimization is needed. In the below example, one rule needs to be optimized.

```
#debug acsmgr show rule-optimization-information

NOTE : O = Optimized, P = Partially Optimized  and U = Unoptimized. N = Empty Ruledef.
RD = Ruledef, GR = Group of Ruledefs.

                                                                                Rule Lines
 ================================================================================================
==================
 Ruledef Name                          0 0 0 0 0 0 0 0 0 1 1 1 1 1 1 1 1 1 2 2 2 2 2 2 2 2 2 3 3  Status
                                       1 2 3 4 5 6 7 8 9 0 1 2 3 4 5 6 7 8 9 0 1 2 3 4 5 6 7 8 9 0 1 2
 ================================================================================================
==================
 dns-pkts                              O O - - - - - - - - - - - - - - - - - - - - - - - - - - - -
- - - - -  O
 ip-pkts                               U - - - - - - - - - - - - - - - - - - - - - - - - - - - - -
- - - - -  U
 www-url-google                        O - - - - - - - - - - - - - - - - - - - - - - - - - - - - -
- - - - -  O
```

```
Ruledef Stats at service level :
------------------------------

Total Optimized rule lines in ruledefs :    3
Total Unoptimized rule lines in ruledefs :  1

Number of Fully Optimized Ruledefs  :      2
Number of Partially Optimized Ruledefs:    0
Number of Unoptimized Ruledefs        :    1
Number of Empty ruledefs           :       0

Total ruldefs configured at the service level:    3
```

This command will help to identify if the rulebase is the cause of high CPU utilization:

```
#show profile facility sessmgr active depth 1 head 26

 32.3%       2311  strncmp()
 22.5%       1610  acsmgr_rule_compare_string()
  4.0%        286  sn_loop_run()
  3.5%        250  syscall()
  3.4%        242  poll()
```

FW / NAT

Overview

This chapter provides an overview of the Network Address Translation (NAT) in-line service which is part of the Active Charging Service (ACS) feature-set.

The following topics are covered in this chapter:

- NAT Overview
- NAT Mappings: 1:1 and Many-to-One
- NAT Application Level Gateway
- NAT Call Flow
- Gathering NAT Statistics

NAT Basics

NAT maps non-routable RFC 6568 defined private IP addresses to routable public IP addresses. These IPs are part of IP-pool configurations which reside in the configuration of the ASR 5000/ASR 5500. There will be one or more pools in the private range(s) and separate pool(s) in the public address space.

In typical deployments, NAT is enabled to provide for the conservation of public IP addresses required to communicate with external networks. It also provides some security as the IP address scheme for the internal network is masked from external hosts. Each outgoing and incoming packet goes through the translation process.

The NAT in-line service works in conjunction with the following products:

- GGSN
- HA
- PDSN
- P-GW

NAT works by inspecting both incoming and outgoing IP datagrams, and, as needed, modifying the source IP address and port number in the IP header to reflect the configured NAT address mapping for outgoing datagrams. The reverse NAT translation is applied to incoming datagrams.

NAT can be used to perform address translation for simple IP and mobile IP. NAT can be selectively applied/denied to different flows (5-tuple connections) originating from subscribers based on the flows' L3/L4 characteristics—Source-IP, Source-Port, Destination-IP, Destination-Port, and Protocol.

Note:

- NAT works only on flows originating internally. Bi-directional NAT is not supported.
- NAT is supported only for TCP, UDP, and ICMP flows. For other flows NAT is bypassed.
- To get NATed, the private IP addresses assigned to subscribers must be from the following ranges:
  - Class A 10.0.0.0 – 10.255.255.255
  - Class B 172.16.0.0 – 172.31.255.255
  - Class C 192.168.0.0 – 192.168.255.255
  - 100.64.0.0/10 as per RFC 6598.

NAT is configured within ACS. For an overview of ACS, please see the ACS Overview section of this document. For NAT-specific config, please see below.

To configure NAT, the first thing needed is a public ip-pool and a private ip-pool:

```
 ip pool Public_01 175.200.0.0 255.255.0.0 napt-users-per-ip-address 200 group-name NAT_01 on-demand max-chunks-per-user 10 port-chunk-size 32 nat-binding-timer 1800

 ip pool Private_01 10.64.0.0 255.255.0.0 private 0 group-name TEST_Private
```

Now, within the ACS config, the mapping must be configured. Note that the "access ruledef" is identifying the private IP pool above as the traffic source (coming from the MN). Within the FW-and-NAT policy below the "nat-realm" is the same as the "group-name" defined in the public IP pool above:

```
access-ruledef Private_Pool1
      ip src-address = 10.64.0.0/16
    #exit
    fw-and-nat policy NAT_Policy_01
      access-rule priority 10 access-ruledef Private_Pool1 permit nat-realm NAT_01
    #exit
```

Once the mappings between the public and private pools are configured, the entire policy is then added to the appropriate rulebase within ACS.

```
rulebase RB1
      ~~~
      fw-and-nat default-policy NAT_Policy_01
    #exit
```

More information can be found in the NAT Administration Guide.

NAT Mappings

NAT works by inspecting both incoming and outgoing IP datagrams and, as needed, modifying the source IP address and port number in the IP header to reflect the configured NAT address mapping.

NAT supports the following mappings:


- One-to-One (Private IP to Public IP): Each private IP address is mapped to a unique public NAT IP address. The private source ports do not change.
- Many-to-One (Private IP:Port to Public IP:Port): When the number of public IP addresses available for an internal network are restricted, multiple private IP addresses are mapped to a single NAT IP address. In order to distinguish between different subscribers and different connections originating from same subscriber, internal private source ports are changed to NAT ports. This is known as Network Address Port Translation (NAPT).

NAT Application Level Gateway

Some network applications exchange IP/port information of the host endpoints as part of the packet payload. This information is used to create new flows, by server or client.

As part of NAT ALGs, the IP/port information is extracted and the flows allowed dynamically (pinholes). In case of NAT, IP and transport-level translations are done. However, the sender application may not be aware of these translations since these are transparent, so they insert the private IP or port in the payload as usual.

Image - NAT Call Flow:



Troubleshooting

The following section lists useful NAT related CLI commands that can be used to verify or troubleshoot NAT related issues.

This command shows the private IP assigned to the NAT user along with any other public IPs assigned. Also this command will show the port chunks allocated to the user if a N:1 IP is assigned to the user:

- **show sub full username** <username>

```
[local]ASR5000# show subscribers full username 5555551212@test.com

Username: 5555551212@test.com           Status: Online/Active

  ip address: 10.64.1.100
  ip pool name: Private_01

  Firewall-and-Nat Policy: NAT_Policy_01

  NAT Policy NAT44: Required
  NAT Policy NAT64: Not-required
  Nat Realm: NAT_01                      Nat ip address: 175.200.1.10   (on-demand)
(Public_01)
                                         Nexthop ip address: 1.1.1.2
  Nat port chunks allocated[start - end]: (1 chunk)
  [1344 - 1375]
  Max NAT port chunks used: 2
```

Use grep to see NAT realms and NAT ip address assigned to this user:

- **show sub full username** <username> **| grep -i nat**

```
[local]ASR5000# show sub full username 5555551212@test.com | grep -i nat

  source context: source             destination context: destination
```

```
  Firewall-and-Nat Policy: NAT_Policy_01
  NAT Policy NAT44: Required
  NAT Policy NAT64: Not-required
  Nat Realm: NAT_01                  Nat ip address: 175.200.1.10  (on-demand) (Public_01)
  Nat port chunks allocated[start - end]: (1 chunk)
  Max NAT port chunks used: 5
    Colocated COA: NO                    NAT Detected: NO
```

In order to see the NAT rules applied to a particular user and traffic flows associated with each of the flows, this CLI can be used. Also there is other flow-related details of the user available when using this command.

- **show active-charging sessions full username** <user-name>

```
 [local]ASR5000# show active-charging sessions full username
00123456789123456@nai.epc.mnc345.mcc012.3gppnetwork.org

   Session-ID:               1:24683225  Username:
00123456789123456@nai.epc.mnc345.mcc012.3gppnetwork.org
   Callid:                     0000fb5c  IMSI/MSID:          012345678912345
   MSISDN:                                                       12345678912
   ACSMgr Instance:                   1  ACSMgr Card/Cpu:                3/0
   SessMgr Instance:                                                      1
   Client-IP:                           2000:1000:a200:350a::,175.200.1.1

   FW-and-NAT Policy:                                          NAT_Policy_01
   FW-and-NAT Policy ID:                                                   3
   Firewall Policy IPv4:                                       Not-required
   Firewall Policy IPv6:                                       Not-required
   NAT Policy NAT44:                                               Required
   NAT Policy NAT64:                                           Not-required
   Bypass NAT Flow Present:                                              No


 Firewall-Ruledef Name Pkts-Down Bytes-Down    Pkts-Up   Bytes-Up       Hits
 -------------------- ---------- ---------- ---------- ---------- ---------- -------
---
 Private_Pool1           8541220  138678108    7292518 1369201894   15831834
```

Table 1. Gathering NAT Statistics

Statistics/Information	Action to perform
NAT statistics	show active-charging nat statistics
Statistics of a specific NAT IP pool	show active-charging nat statistics nat-realm *<nat_pool_name>*
Statistics of all NAT IP pools in a NAT IP pool group	show active-charging nat statistics nat-realm *<pool_group_name>*
Summary statistics of all NAT IP pools in a NAT IP pool group	show active-charging nat statistics nat-realm *<pool_group_name>* summary
Statistics for a specific ACS/Session Manager instance	show active-charging nat statistics instance *instance_number*
Statistics of NAT unsolicited packets for a specific ACS/Session Manager instance	show active-charging nat statistics unsolicited-pkts-server-list instance *instance_number*
Firewall-and-NAT Policy statistics.	show active-charging fw-and-nat policy statistics all show active-charging fw-and-nat policy statistics name *<fw_nat_policy_name>*
PCP service statistics	show active-charging pcp-service all show active-charging pcp-service name *<pcp_service_name>* show active-charging pcp-service statistics
Information on NAT bind records generated for port chunk allocation and release.	show active-charging rulebase statistics name *<rulebase_name>*
Information on NAT bind records generated.	show active-charging EDR-format statistics
Information for subscriber flows with NAT disabled.	show active-charging flows nat not-required
Information for subscriber flows with NAT enabled.	show active-charging flows nat required
Information for subscriber flows with NAT enabled, and using specific NAT IP address.	show active-charging flows nat required nat-ip *<nat_ip_address>*
Information for subscriber flows with NAT enabled, and using specific NAT IP address and NAT port number.	show active-charging flows nat required nat-ip *<nat_ip_address>* nat-port *<nat_port>*
NAT session details.	show active-charging sessions nat { not-required | required }

SIP ALG Advanced session statistics.	show active-charging analyzer statistics name sip
Information for all the active flow-mappings based on the applied filters.	show active-charging flow-mappings all
Information for the number of NATed and Bypass NATed packets.	show active-charging subsystem all
Information for all current subscribers who have either active or dormant sessions. Check IP address associated with subscriber.	show subscribers full all
Information for subscribers with NAT processing not required.	show subscribers nat not-required
Information for subscribers with NAT processing enabled and using the specified NAT IP address.	show subscribers nat required nat-ip *<nat_ip_address>*
Information for subscribers with NAT processing enabled and using the specified NAT realm.	show subscribers nat required nat-realm *<nat_pool_name>*
Information for subscribers to find out how long (in seconds) the subscriber has been using NAT-IP.	show subscribers nat required usage-time [< | > | greater-than | less-than] *value*
NAT realm IP address pool information.	show ip pool nat-realm wide
Call drop reason due to invalid NAT configuration.	show session disconnect-reasons
Pilot Packet Statistics	show apn statistics show pilot-packet statistics show session subsystem facility sessmgr

X-Header Insertion and Encryption Example

Overview

X-Header Insertion and Encryption features, collectively known as Header Enrichment, enable appending of headers to HTTP/WSP GET and POST request packets for use by end applications, such as mobile advertisement insertion (MSISDN, IMSI, IP address, user-customizable, and so on). This is a licensed feature "Header Enrichment [ASR5K-00-CS01HDRE]" and is supported only on the GGSN, IPSG and P-GW.

Troubleshooting

To check if http-x-header-analyzer rule is properly hit, and correct values for analyzed traffic are shown, the following CLIs can be used:

> Some of the below CLI commands require CLI test-commands password configured in the chassis.
> Please use the commands with caution! Many **TEST** commands are processor-intensive and can cause serious system problems if used too frequently.

- show active-charging sessions full imsi <number>
- show active-charging flows full imsi <number>
- show active-charging ruledef statistics
- show active-charging charging-action statistics name <charging-action name>
- show active-charging analyzer statistics name ip
- show active-charging analyzer statistics name tcp
- show active-charging analyzer statistics name http

Sample configuration for x-header insertion by ECS

```
xheader-format header_format_tac
     insert X-header-field-name variable bearer radius-calling-station-id
```

```
ruledef new_ruledef
       http url contains www.test.com
       wsp url contains wap.test.com

charging-action CA_xheader
       xheader-insert xheader-format header_format_tac

active-charging service ECS
rulebase test_rulebase
   action priority 1045 ruledef new_ruledef charging-action CA_xheader
```

This commands allows the user to see that XHeader information has been added to ensure the ruledef is getting hit properly:

```
[local]asr5000# show active-charging charging-action statistics name test_rulebase

 Service Name: ECS

  Charging Action Name: CA_xheader
    Uplink Pkts Retrans:              0   Downlink Pkts Retrans:             0
    Uplink Bytes Retrans:             0   Downlink Bytes Retrans:            0
    Flows Readdressed:                0   PP Flows Readdressed:              0
    Bytes Charged Yet Packet Dropped:                 0

  First-request Redirected:           0

     XHeader Information:
      XHeader Bytes Injected:             385
      XHeader Pkts Injected:               11
      XHeader Bytes Removed:                0
      XHeader Pkts Removed:                 0
      IP Frags consumed by XHeader:         0
```

This command is used to show the overall packets based on the IP protocol:

```
[local]asr5000# show active-charging analyzer statistics name ip
ACS IP Session Stats:
  Total Uplink Bytes:            1231   Total Downlink Bytes:           8378
```

```
  Total Uplink Pkts:                10   Total Downlink Pkts:                10
  Uplink Bytes Fragmented:           0   Downlink Bytes Fragmented:          0
  Uplink Pkts Fragmented:            0   Downlink Pkts Fragmented:           0
  Uplink Bytes Invalid:              0   Downlink Bytes Invalid:             0
  Uplink Pkts Invalid:               0   Downlink Pkts Invalid:              0
```

This command is used to show the overall packets based on the TCP protocol:

```
[local]asr5000# show active-charging analyzer statistics name tcp
ACS TCP Session Stats:
  Total Uplink Bytes:             1031   Total Downlink Bytes:            8178
  Total Uplink Pkts:                10   Total Downlink Pkts:               10
  Uplink Bytes Retrans:              0   Downlink Bytes Retrans:             0
  Uplink Pkts Retrans:               0   Downlink Pkts Retrans:              0
  Uplink Out of Order Pkts Successfully Analyzed:                            0
  Downlink Out of Order Pkts Successfully Analyzed:                          2
  Uplink Out of Order Pkts Failure:                                          0
  Downlink Out of Order Pkts Failure:                                        0
  Uplink Out of Order Pkts Retransmitted:                                    0
  Downlink Out of Order Pkts Retransmitted:                                  0
  Uplink Bytes Invalid:              0   Downlink Bytes Invalid:             0
  Uplink Pkts Invalid:               0   Downlink Pkts Invalid:              0
```

This command is used to show the overall packets based on the HTTP protocol:

```
[local]asr5000# active-charging analyzer statistics name http
ACS HTTP Session Stats:
  Total Uplink Bytes:              799   Total Downlink Bytes:            7970
  Total Uplink Pkts:                 8   Total Downlink Pkts:                9
  Uplink Bytes Retrans:              0   Downlink Bytes Retrans:             0
  Uplink Pkts Retrans:               0   Downlink Pkts Retrans:              0
  Total Request Succeed:             1   Total Request Failed:               0
  GET Requests:                      0   POST Requests:                      1
  CONNECT Requests:                  0
  PUT requests:                      0
  HEAD requests:                     0
  Invalid packets:                                                           0
  Wrong FSM packets:                                                         0
```

```
Big request packets:                                    0
Big response packets:                                   0
Corrupt request packets:                                0
Corrupt response packets:                               0
Unhandled request packets:                              0
Pipeline overflow packets:                              0
Unanalyzed request packets:                             0
Buffering error packets:                                0
Unhandled response packets:                             0
Unanalyzed response packets:                            0
New requests on closed connection:                      0
```

CLI for troubleshooting

> Some of the below CLI commands require CLI test-commands password configured in the chassis.
> Please use the commands with caution! Many **TEST** commands are processor-intensive and can cause serious system problems if used too frequently.

- show active-charging sessions full imsi <number>
- show active-charging flows full imsi <number>
- show active-charging ruledef statistics
- show active-charging charging-action statistics name <charging-action name>
- show active-charging analyzer statistics
- show active-charging rulebase statistics
- show active-charging charging-action statistics
- show active-charging ruledef statistics all charging

Troubleshooting ACS

Overview

This section provides some examples of troubleshooting issues arising within ACS.

Example Scenarios

HTTP Traffic is not detected

Problem description

Customer reports an issue where http traffic for certain subscribers is not detected. The target area to check in this case is the ruledef / rulebase configuration.

CLI list for troubleshooting

- show active-charging sessions full imsi <>
- monitor subscriber imsi <> with option 34, 19, A, S & verbosity 3.

Analysis

1. In the monitor subscriber output below, the traffic being received is on tcp port 80 which is HTTP.

```
[local]asr5000# monitor subscriber imsi 50604000000002
*** CSS Data Decodes (ON ) ***
*** User L3 PDU Decodes (ON ) ***
*** PDU Hex+Ascii dump (ON ) ***
*** Sender Info (ON ) ***
*** Verbosity Level (  2) ***
*** Verbosity Level (  3) ***


------------------------------------------------------------------------
Incoming Call:
------------------------------------------------------------------------
```

```
  MSID/IMSI   : 506040000000002              Callid      : 017dc661
  IMEI        : n/a                          MSISDN      : 9876543210
  Username    : 9876543210                   SessionType : ggsn-pdp-type-ipv4
  Status      : Active                       Service Name: local
  Src Context : Gn
 ------------------------------------------------------------------------
 :
 Wednesday May 06 2015
 INBOUND>>>>>  From sessmgr:6 sessmgr_ipv4.c:15903 (Callid 017dc661) 15:58:33:265
Eventid:51000(0)
 IPv4 Rx PDU
 172.1.1.1.1183 > 2.1.1.1.80: P [tcp sum ok] 1:549(548) ack 1 win 64240 (DF) (ttl 128, id 1221,
len 588)
 0x0000   4500 024c 04c5 4000 8006 43e3 ac01 0101        E..L..@...C.....
 0x0010   0201 0101 049f 0050 5e8a 8984 f87a c592        .......P^....z..
 0x0020   5018 faf0 ff50 0000 4745 5420 2f6d 2048        P....P..GET./m.H
 0x0030   5454 502f 312e 310d 0a41 6363 6570 743a        TTP/1.1..Accept:
 0x0040   2069 6d61 6765 2f67 6966 2c20 696d 6167        .image/gif,.imag
 0x0050   652f 782d 7862 6974 6d61 702c 2069 6d61        e/x-xbitmap,.ima
 0x0060   6765 2f6a 7065 672c 2069 6d61 6765 2f70        ge/jpeg,.image/p
 0x0070   6a70 6567 2c20 6170 706c 6963 6174 696f        jpeg,.applicatio
 0x0080   6e2f 782d 7368 6f63 6b77 6176 652d 666c        n/x-shockwave-fl
 0x0090   6173 682c 2061 7070 6c69 6361 7469 6f6e        ash,.application

 Wednesday May 06 2015
 <<<<OUTBOUND  From sessmgr:6 sessmgr_ipv4.c:16094 (Callid 017dc661) 15:58:33:265
Eventid:77000(9)
 CSS Uplink Output PDU to ACS- slot:2 cpu:17 inst:4369
 172.1.1.1.1183 > 2.1.1.1.80: P [tcp sum ok] 1:549(548) ack 1 win 64240 (DF) (ttl 128, id 1221,
len 588)
 0x0000   4500 024c 04c5 4000 8006 43e3 ac01 0101        E..L..@...C.....
 0x0010   0201 0101 049f 0050 5e8a 8984 f87a c592        .......P^....z..
 0x0020   5018 faf0 ff50 0000 4745 5420 2f6d 2048        P....P..GET./m.H
 0x0030   5454 502f 312e 310d 0a41 6363 6570 743a        TTP/1.1..Accept:
 0x0040   2069 6d61 6765 2f67 6966 2c20 696d 6167        .image/gif,.imag
 0x0050   652f 782d 7862 6974 6d61 702c 2069 6d61        e/x-xbitmap,.ima
 0x0060   6765 2f6a 7065 672c 2069 6d61 6765 2f70        ge/jpeg,.image/p
 0x0070   6a70 6567 2c20 6170 706c 6963 6174 696f        jpeg,.applicatio
 0x0080   6e2f 782d 7368 6f63 6b77 6176 652d 666c        n/x-shockwave-fl
```

2 The config shows the routing ruledef for http, but no charging ruledef for classifying http traffic:

```
config
  active-charging service srv1
    ruledef http-ports
      tcp either-port = 80
      rule-application routing
    #exit
    ruledef ip-pkts
      ip any-match = TRUE
    #exit
    ruledef tcp-pkts
      tcp any-match = TRUE
    #exit
    ruledef udp-pkts
      udp any-match = TRUE
    #exit

   rulebase base1
      default retransmissions-counted
      billing-records egcdr
      action priority 980 ruledef tcp-pkts charging-action standard
      action priority 990 ruledef ip-pkts charging-action standard
      route priority 80 ruledef http-ports analyzer http
      flow control-handshaking charge-to-application all-packets
      egcdr threshold interval 60
      egcdr threshold volume total 100000
      no transport-layer-checksum verify-during-packet-inspection
    #exit
```

3 In the active charging session output, the traffic is classified as TCP instead of HTTP.

```
[local]asr5000# show active-charging sessions full imsi 50604000000002

  Session-ID:                    6:2  Username:  9876543210@ciscolab1.com
  Callid:                  017dc661  IMSI/MSID:          50604000000002
  MSISDN:                                                  9876543210
```

```
  ACSMgr Instance:                    6  ACSMgr Card/Cpu:               11/0
  SessMgr Instance:                                                       6
  Client-IP:                                                    172.1.1.1
  NAS-IP:                                                         0.0.0.0
  Access-NAS-IP(FA):
  NAS-PORT:                           0  NSAPI:                          5
  Acct-Session-ID:                                          0A01010A01AAAAAA
  NAS-ID:                                                             n/a
  Access-NAS-ID(FA):                                                  n/a
  3GPP2-BSID:                                                         n/a
  Access-Correlation-ID(FA):                                          n/a
  3GPP2-Correlation-ID:                                               n/a
  MEID:                                                               n/a
  Carrier-ID:                       n/a  ESN:                         n/a
  PCO:
    Value/Interface:                n/a
  Uplink Bytes:                    2253  Downlink Bytes:             10957
  Uplink Packets:                    16  Downlink Packets:              21
  Accel Packets:                      0
  :
  Duration:                                                   00h:00m:08s
  Active Charging Service name:                                       srv1
  Rule Base name:                                                   base1
  URL-Redir First-Request-Only:                                       n/a
  :
  Charging Updates:                                                   n/a

Ruledef Name          Pkts-Down Bytes-Down    Pkts-Up   Bytes-Up       Hits Match-Bypassed
-------------------- ---------- ---------- ---------- ---------- ---------- --------------
ip-pkts                        2        518          2        122          4              0
tcp-pkts                      19      10439         14       2131         27              0

Post-processing Rulestats : Dynamic Charging Rule Definition Statistics: n/a
Charging-Updates Statistics:         n/a
Dynamic Charging Rule Definition(s) Configured: n/a
Predefined Rules Enabled List: n/a
Predefined Firewall Rules Enabled List: n/a

Total acs sessions matching specified criteria: 1
```

Resolution:

Create the ruledef to detect HTTP traffic, then add this ruledef in Rulebase with higher action priority (lower number) then ruledef to detect TCP traffic "**tcp-pkts**".

```
config
  active-charging service srv1
    !
    ruledef http
      tcp either-port = 80
    #exit
    !
   rulebase base1

    action priority 70  ruledef http charging-action standard
    #exit
```

Ruledef for detecting traffic

Problem description:

Customer reports an issue where they have a ruledef for detecting traffic for specific site (.e.g Google) but it's getting wrongly classifed as HTTP. The target area to check in this case is the ruledef / rulebase configuration.

CLI list for troubleshooting:

show active-charging sessions full imsi <>
monitor subuscriber imsi <> with option 34, 19, A, S & verbosity 3.

Analysis

1. In the monitor subscriber output below, the traffic being received is tcp port 80 which is HTTP and that subscriber is going to google.com.

```
*** CSS Data Decodes (ON ) ***
*** User L3 PDU Decodes (ON ) ***
*** Verbosity Level (  2) ***
```

```
 *** Verbosity Level (  3) ***
 *** Sender Info (ON ) ***

 ------------------------------------------------------------------------
 Incoming Call:
 ------------------------------------------------------------------------
  MSID/IMSI   : 506040000000002              Callid      : 017dc662
  IMEI        : n/a                          MSISDN      : 9876543210
  Username    : 9876543210                   SessionType : ggsn-pdp-type-ipv4
  Status      : Active                       Service Name: local
  Src Context : Gn
 ------------------------------------------------------------------------
 :
 Wednesday May 06 2015
 INBOUND>>>>>  From sessmgr:6 sessmgr_ipv4.c:16113 (Callid 017dc662) 16:27:01:842
Eventid:77001(9)
 CSS Uplink Input PDU from ACS- slot:3 cpu:34 inst:8738
 172.1.1.1.1184 > 3.1.1.1.80: P [tcp sum ok] 1:338(337) ack 1 win 64240 (DF) (ttl 128, id 1235,
len 377)
 0x0000   4500 0179 04d3 4000 8006 43a8 ac01 0101        E..y..@...C.....
 0x0010   0301 0101 04a0 0050 fad2 d78c 266a 061d        .......P....&j..
 0x0020   5018 faf0 ccc0 0000 4745 5420 2f6d 2f69        P.......GET./m/i
 0x0030   6d61 6765 732f 6c6f 676f 5f73 6d61 6c6c        mages/logo_small
 0x0040   2e67 6966 2048 5454 502f 312e 310d 0a41        .gif.HTTP/1.1..A
 0x0050   6363 6570 743a 202a 2f2a 0d0a 5265 6665        ccept:.*/*..Refe
 0x0060   7265 723a 2068 7474 703a 2f2f 6e65 7773        rer:.http://news
 0x0070   2e67 6f6f 676c 652e 636f 6d2f 6d0d 0a41        .google.com/m..A
 0x0080   6363 6570 742d 4c61 6e67 7561 6765 3a20        ccept-Language:.
```

2 The config shows that the ruledef being matched for this traffic to Google is HTTP.

```
 config
   active-charging service srv1
     ruledef http
       tcp either-port = 80
     #exit
     ruledef http-ports
       tcp either-port = 80
```

```
    rule-application routing
  #exit
  ruledef ip-pkts
    ip any-match = TRUE
  #exit
  ruledef tcp-pkts
    tcp any-match = TRUE
  #exit
  ruledef udp-pkts
    udp any-match = TRUE
  #exit
  ruledef www-url-google
    www url contains google
  #exit

  rulebase base1
    default retransmissions-counted
    billing-records egcdr
    action priority 50 ruledef http charging-action standard
    action priority 90 ruledef www-url-google charging-action test
    action priority 100 ruledef tcp-pkts charging-action standard
    action priority 200 ruledef ip-pkts charging-action standard
    route priority 80 ruledef http-ports analyzer http
    flow control-handshaking charge-to-application all-packets
    egcdr threshold interval 60
    egcdr threshold volume total 100000
    no transport-layer-checksum verify-during-packet-inspection
  #exit
```

3 In the active charging session output, the traffic is classified as HTTP, but not matching to the "Google" ruledef.

```
[local]asr5000# show active-charging sessions full imsi 50604000000002

  Session-ID:                      6:4  Username:  9876543210@ciscolab1.com
  Callid:                  017dc662  IMSI/MSID:           50604000000002
  MSISDN:                                                     9876543210
  ACSMgr Instance:                 6  ACSMgr Card/Cpu:              11/0
```

```
  SessMgr Instance:                                                  6
  Client-IP:                                                 172.1.1.1
  NAS-IP:                                                      0.0.0.0
  Access-NAS-IP(FA):
  NAS-PORT:                          0   NSAPI:                      5
  Acct-Session-ID:                                     0A01010A01AAAAAB
  :
  Duration:                                                 00h:00m:34s
  Active Charging Service name:                                  srv1
  Rule Base name:                                               base1
  :
  Charging Updates:                                              n/a

Ruledef Name          Pkts-Down Bytes-Down    Pkts-Up   Bytes-Up       Hits Match-Bypassed
-------------------- ---------- ---------- ---------- ---------- ---------- --------------
ip-pkts                        2        518          2        122          4              0
http                          19      10439         14       2131         27              0
```

Resolution:

The ruledef for catching traffic from Google needs to have higher priority then http ruledef.

```
  rulebase base1
     default retransmissions-counted
     billing-records egcdr
     action priority 90 ruledef www-url-google charging-action test
     action priority 95 ruledef http charging-action standard
     action priority 100 ruledef tcp-pkts charging-action standard
     action priority 200 ruledef ip-pkts charging-action standard
     route priority 80 ruledef http-ports analyzer http
     flow control-handshaking charge-to-application all-packets
     egcdr threshold interval 60
     egcdr threshold volume total 100000
     no transport-layer-checksum verify-during-packet-inspection
   #exit
```

GTPP (CDR's)

GTPP/CDR Overview

Overview

CDRs are Call Detail Records which are used for offline/postpaid billing purposes. They are sent from the charging data function (CDF) to the charging gateway function (CGF) over the Ga interface.

The CDF can be a network element like SGW/SGSN/PGW/SGW. The CGF is part of the actual billing system which collects the CDRs and processes them for generating bills.

Format and types

The CDRs are encoded using the ASN.1 format and are sent to the CGF using the GTPP protocol. GTPP can be run over UDP or TCP. A decoded sample CDR can be seen below, but note that contents may vary greatly depending on Product and Configuration:

```
CDR #1

------

  recordType                        SGSNPDPRECORD
  servedIMSI                        xxxxxxxxxx
  servedIMEI                        xxxxxxxxxx
  ggsnAddressUsed                   1.1.1.1
  chargingID                        932035394
  accessPointNameNI                 internet
  accessPointNameOI                 mnc001.mcc002.gprs
  pdpType                           IPV4
  servedPDPAddress                  10.0.0.1

  listOfTrafficVolumes

    dataVolumeGPRSUplink              0
    dataVolumeGPRSDownlink            0
    changeCondition                   QoS Change
```

```
  changeTime                          140715090831

  dataVolumeGPRSUplink                0
  dataVolumeGPRSDownlink              0
  changeCondition                     Record Closure
  changeTime                          140715090901
  recordOpeningTime                   140715090831
duration                            30
causeForRecClosing                  Intra SGSN Inter System Change
sgsnAddress                         2.2.2.2
msNetworkCapability                 e5 e0
rNCUnsentDownlinkVolume             2761
routingAreaCode                     11
locationAreaCode                    1f1f
 cellIdentifier                      3001
 systmeType                          IuUTRAN
recordSequenceNumber                226
nodeID                              1000GGSN01
Management Extensions follow
  Ticket Layout Version             14
  subCharacteristics                8
localSequenceNumber                 26333225
apnSelectionMode                    MS or Network Provided and Subscription Verified
servedMSISDN                        xxxxxxxxxxx
chargingCharacteristics             Normal
```

There are several types of CDRs and some are listed below.

- **Standard G-CDRs** - Generated by GGSN
- **eG-CDRs** - Enhanced CDRs generated by GGSN. They contain more granular billing info for user-defined data flows (ECS aware).
- **PGW-CDRs** - Generated on PGW. Also contains more granular billing info (ECS aware).
- **SGW-CDRs** - Generated on GW
- **S-CDRs** - Generated on SGSN

There will be differences related to contents of the CDRs, but the same transport/configuration principles apply. The below diagram has a good overview of the different account-


ing/billing functions of each product. Some products can use other billing mechanisms, or they can combine several mechanism.

Products	Radius	GTPP	ECS-aware-CDR	Diameter
GGSN	Radius/Mediation	G-CDR	eG-CDR	Gy
PGW	Mediation		PGW CDR	Rf
SGW		SGW CDR		Rf
SGSN		SCDR		
PDSN	Radius/Mediation			
PMIP-PGW				Rf
HA	Radius/Mediation			

StarOS architecture for GTPP

To understand and troubleshoot CDRs and GTPP on StarOS Platforms, it is important to understand the architecture that is used.

Image: Software Architecture



CDR Generation/transmission:

The sessmgr generates the CDRs and sends it to aaamgr. The aaamgr sends the CDRs to aaaproxy and finally aaaproxy sends the CDRs to the CGF or HDD, based on the configuration. Once the request is sent from aaamgr to aaaproxy, the request will be stored in a buffer which will be cleared once the aaaproxy sends acknowledgement mentioning that CDRs are received successfully. For recovery purposes, the CDRs are kept at sessmgr/aaamgr and in aaaproxy. The CDRs will be cleared only after getting a successful response from server/hard disk.

Role of aaamgr:

AAAMGR has two buffers:

- One holds the GTPP request outstanding with AAAproxy (AAAmgr has not yet received response from AAAproxy).
- The other buffer is to form the next GTPP request (based of max-cdr or max-pdu or wait-time configuration, AAAmgr will pack as many CDRs as possible in one GTPP request).

If the two buffers are full, AAAmgr will archive the request. The archive buffer is common for Radius and GTPP.

Role of AAAProxy

The aaaproxy process receives CDRs from each of the aaamgr and sends it across to CGF or HD. The AAAproxy is responsible for the flow control to make sure that CGFs are not over-loaded.

Configuration Guidelines:

Normally configuration is outside the scope of this guide, but there are some specifics to GTPP configuration for which it would be good to summarize here:

- PGW / GGSN Accounting

  How accounting context is selected:
  Under APN config, '**gtpp group** <> **accounting-context** <>' the context can be mentioned. If the accounting context is not configured here, it will be taken from ggsn-service. Under ggsn-service the 'accounting context <>' will select the accounting context.

If it is not configured, the context where ggsn-service is configured, will be the accounting context.

How accounting mode is selected:
Under APN, '**accounting mode radius-diameter/gtpp/none**' CLI will decide the accounting mode. The default value of accounting mode is GTPP. If only eGCDRs needs to be generated, then accounting mode should be none, and relevant egcdr configuration options should be configured under rulebase/charging-actions in the active-charging-service section).

How gtpp group is selected:
Under APN, '**gtpp group <> accounting-context <>**' will select the GTPP group. If it is not configured, 'gtpp group default' will be selected.

How secondary gtpp group is selected for load balancing:
Under APN, '**gtpp secondary-group <> accounting-context <>**' will select the gtpp group. If the accounting context is not configured here, it will be taken from ggsn-service. Under ggsn-service the '**accounting context <>**' will select the accounting context. If it is not configured, the context where ggsn-service is configured, will be the accounting context.

Sample config:

```
apn cisco.com
    gtpp group group1 accounting-context Ga
```

- SGSN Accounting

  How accounting context is selected:
  Under call-control-profile config, '**accounting context** <> **gtpp group** <>' the context can be mentioned. If the accounting context is not configured there, it will be taken from sgsn-service. Under sgsn-service the '**accounting context** <>' will select the accounting context. If it is not configured, the context where sgsn-service is configured will be the accounting context.

  How accounting mode is selected:
  Under call-control-profile config, '**accounting mode gtpp**' CLI will decide the accounting mode. Default value is '**accounting mode none**'.

How gtpp group is selected:
Under call-control-profile config, '**accounting context** <> **gtpp group** <>' the gtpp group can be mentioned. If it is not configured '**gtpp group default**' will be selected.

Sample config:

```
call-control-profile umts
  accounting context ctx gtpp group sgsn
```

- SGW Accounting

  How accounting context is selected:
  Under call-control-profile config, '**accounting context** <> **gtpp group** <>' the context can be mentioned. If the accounting context is not configured there, it will be taken from sgw-service. Under sgw-service the '**accounting context** <> **gtpp group** <>' will select the accounting context. If it is not configured, the context where sgw-service is configured, will be the accounting context.

  How accounting mode is selected:
  Under call-control-profile config, '**accounting mode gtpp**' CLI will decide the accounting mode. If its is not configured there, '**accounting mode gtpp**' from sgw-service will be selected. If it is not configured in sgw-service, default value is '**accounting mode none**'.

  How gtpp group is selected:
  Under call-control-profile config, '**accounting context** <> **gtpp group** <>' the gtpp group can be mentioned. If only '**accounting context** <>' is configured in CCP, the gtpp group will be 'default'. If nothing is configured in CCP, the value will be taken from sgw-service '**accounting context** <> **gtpp group** <>'. If it is not configured '**gtpp group default**' will be selected.

  Sample config:

```
call-control-profile lte
  accounting context ctx gtpp group sgw
```

Very important remark:
If no valid GTPP group is configured, the CDR falls back to " default" gtpp group. If this default group is not properly configured, this can lead to serious problems (see subsequent section on archiving).

GTPP troubleshooting

Overview

This section talks about CLI commands and log outputs that can be use for troubleshooting GTPP. Later in this chapter, troubleshooting GTPP archiving is also covered.

Log Collections

> Some of the below CLI commands require CLI test-commands password configured in the chassis.
> Please use the commands with caution! Many **TEST** commands are processor-intensive and can cause serious system problems if used too frequently.

- show gtpp counters all
- show gtpp accounting servers
- show gtpp statistics name gtpp_group_name verbose
- show gtpp storage-server local file statistics group name gtpp_group_name [verbose]
- show gtpp storage-server streaming file statistics group name gtpp_group_name [verbose]
- show session subsystem facility aaamgr all verbose
- show session subsystem facility aaamgr all verbose | grep -E "(archived|Mgr)"
- dir /hd-raid
- logging filter active facility gtpp level unusual
- logging filter active facility aaaproxy level unusual
- External pcap
- monitor protocol with option 27

Show Commands

- **show gtpp counters all**

  This command identifies archived and buffered CDRs for the different CDR types. If a high (more than 1000) value is observed in any of the lines, there is a possible issue that needs to be investigated.

```
show gtpp counters all
 Outstanding GCDRs:                         0
 Possibly Duplicate Outstanding GCDRs:      0
 Archived GCDRs:                            64129 <<<
 GCDRs buffered with AAAPROXY:              0
 GCDRs buffered with AAAMGR:                421 <<<<

 Outstanding MCDRs:                         0
 Possibly Duplicate Outstanding MCDRs:      0
 Archived MCDRs:                            0
 MCDRs buffered with AAAPROXY:              0
 MCDRs buffered with AAAMGR:                0

 Outstanding SCDRs:                         0
 Possibly Duplicate Outstanding SCDRs:      0
 Archived SCDRs:                            0
 SCDRs buffered with AAAPROXY:              0
 SCDRs buffered with AAAMGR:                0
```

- **show gtpp accounting servers**

  This command sumarizes the various CGF servers in a specific context.

```
show gtpp accounting servers
Context: ga
Preference IP              Port  Priority State          Group
---------- --------------- ----- -------- -------------- ----------
Primary    1.1.1.2         3387  4        Active         gtpp-serv
Secondary  1.1.1.3         3387  6        Down           gtpp-serv
Secondary  1.1.1.4         3387  8        Active         gtpp-serv
```

```
Primary    10.0.0.1        3387  1        Down          gtpp-serv-test
Primary    11.0.0.1        3387  1        Active        gtpp-serv-test2
```

- **show gtpp statistics name <**gtpp_group_name**> verbose**

  This command shows statistics about GTPP for a specific gtpp group. Interesting lines are marked in bold.

```
show gtpp statistics
Accumulated Statistics
------------------------------------------------------------------------------
  Start Collection Req:                       203
  Normal Release Req:                         142
  Management Intervention Req:                  0
  Abnormal Release Req:                        53
  Time Limit Req:                               0
  Volume Limit Req:                             0
  SGSN Change Req:                              0
  Maximum Change Condition Req:                 2
  RAT Change Req:                               0
  MS Time Zone Change Req:                      0
  List of Down Stream Node Change:              0
  Intra SGSN Intersystem Change Req:            0
  Cell Update Req:                              0
  PLMN Id Change Req (SGSN only):               0
  FOCS/ODB ACL Violation Req:                   0
  Inactivity Timeout (FOCS enabled):            0
  SGW Relocation:                               0
  Total G-CDR transmission:             228139370
  Total S-CDR transmission:                     0

  Total G-CDR retransmission:                3014
  Total S-CDR retransmission:                   0

  Total G-CDR accepted:                 228139048
  Total S-CDR accepted:                         0

  Total G-CDR transmission failures:         3044
```

```
  Total S-CDR transmission failures:           0

  G-CDR transmission failure percent:          0.00
  S-CDR transmission failure percent:          0.00

  CDRs purged by dead-server suppress-cdrs:     0
...
CGF Specific Statistics
------------------------------------------------------------------------------
Data Record Transfer Requests Sent
  Send:                         9982509    Possibly Duplicate:              20
  Cancel:                             0    Release:                          0
  Empty:                              0

Data Record Transfer Requests Retried
  Send:                             152    Possibly Duplicate:              30
  Cancel:                             0    Release:                          0
  Empty:                              0

Data Record Transfer Requests Success
  Send:                         9982497    Possibly Duplicate:              10
  Cancel:                             0    Release:                          0
  Empty:                              0

Data Record Transfer Response Cause
Accepted:                     9982507    Not Fulfilled:                    0
  Already Fulfilled:                  0    Dup Already Fulfilled:           0
  Invalid Msg Format:                32    Mandatory IE Missing:            0
  Service not supported:              0    Version not supported:           0
  Mandatory IE incorrect:             0    Optional IE incorrect:           0
  No Resources:                       0    System Failure:                  0
  CDR Decode Error:                   0    Seq No incorrect:                0
  Unknown Cause:                      0

GTPP Echo Messages
  Echo Req Sent:                  81973    Echo Req Rcvd:                   0
  Echo Rsp Rcvd:                  81973    Echo Rsp Sent:                   0

Redirection Req/Rsp Messages
```

```
  Redirection Req Rcvd:              8
  Redirection Rsp Sent:              8

Redirection Request Cause
  Trans Buffer full:                 0    Recv Buffer Full:             0
  Other Node Down:                   0    Self Node down:               8
  System Failure:                    0

Redirection Response Cause
  Accepted:                          8    Service Not Supported:        0
  System Failure:                    0    Mandatory IE Incorrect:       0
  Mandatory IE Missing:              0    Optional IE incorrect:        0
  Invalid Msg Format:                0    Version Not Supported:        0
  No Resources:                      0

Node Alive Req/Rsp Messages
  Node Alive Req Rcvd:               6    Node Alive Req Sent:          0
  Node Alive Rsp Sent:               6    Node Alive Rsp Rcvd:          0

Invalid messages received
  Invalid Sequence Number:           0
  Unknown CGF:                       0
  Unknown Msg type:                  0

Round Trip Time
  Last DRT Round Trip Time:       22.7 ms
  Average DRT Round Trip Time:     4.6 ms

 Real Oustanding Req Count:        0
Oustanding Req Count:              0

GCDR distribution in DRT Messages
  0:                                 0    41..60:                       0
  1:                               214    61..80:                       0
  2..5:                            564    81..100:                      0
  6..10:                           259    101..150:                     0
  11..15:                         2852    151..200:                     0
  16..20:                      1084357    201..254:                     0
  21..40:                      8894263    255:                          0
```

- **show gtpp storage-server local file statistics group name <**gtpp_group_name**> [verbose]**

  Displays statistics and counters for the local storage-server. This is the hard disk if **hard disk** support has been enabled with the gtpp storage-server mode command in the GTPP Group Configuration Mode

- **show gtpp storage-server streaming file statistics group name <**gtpp_group_name**> [verbose]**

  Displays the status of Charging Data Record (CDR) **stored on hard disk** while streaming mode is enabled.

- **show session subsystem facility aaamgr all verbose**
- **show session subsystem facility aaamgr all verbose | grep -E "(archived|Mgr)"**

  This command allows you to isolate counters per aaamgr process. In this example, checked the archived records (radius + GTPP) on each aaamgr instance.

```
AAAMgr:  Instance 1
       0 Total aaa acct archived             0 Current aaa acct archived
AAAMgr:  Instance 2
       0 Total aaa acct archived             0 Current aaa acct archived
AAAMgr:  Instance 3
       0 Total aaa acct archived             0 Current aaa acct archived
AAAMgr:  Instance 4
       0 Total aaa acct archived             0 Current aaa acct archived
AAAMgr:  Instance 5
       0 Total aaa acct archived             0 Current aaa acct archived
...
```

- **dir /hd-raid**

  For local streaming to HD, make sure there is enough space in the HD.

Other Useful Information To Collect:

For GTPP-related issues, here is some other useful information:

- Logging filter. This command is like a debug which can increase the granularity (by tuning the 'level' option). In general, using level unusual is not harmful to the system. Anything with deeper granularity has to be used with more caution.

  logging filter active facility gtpp level unusual
  logging filter active facility aaaproxy level unusual
  logging active

- External PCAP may be required if GTPP is streaming to a remote CGF. This could be required to identify performance related issues (slow CGF server, network issues), or transactional issues (errors/intermittent issues).
- If external capture is not possible, the 'monitor protocol' option 27 can be used, but this is typically not recommended as it it is a protocol which generates a high load.

GTPP Archiving

ASR 5000/ASR 5500 may archive CDRs for many reasons (unable to transmit files due to IP connectivity issues, remote server is unable to receive CDRs, various misconfigurations, etc.). An aaaproxy restart resolves the issue in many cases even if it is a CGF issue. For example if a CGF is unable to accept a particular type of message (e.g. cancel request) then after the aaaproxy restarts, the message is no longer being sent. Since restart of aaaproxy addresses the issue, it gives a false positive as ASR 5000/ASR 5500 being the cause. Using an external PCAP to capture traffic would help identify the cause, which in this case would be the CGF.

Example Scenarios

Too many CDRs archived in ASR 5000 / ASR 5500.

Problem Description:

- Too many CDRs archived in ASR 5000 / ASR 5500.

Analysis:

- The "**show gtpp counters**" shows the type and counters for CDRs. The counters show archived CDRs too.

In the example below, number of archived GCDRs is 144015. Multiple outputs of the "show gtpp counters" will show if the number of archived CDRs is increasing.

```
[local]StarOS# show gtpp counters all
    Archived GCDRs:                          144015
   GCDRs buffered with AAAPROXY:            0
   GCDRs buffered with AAAMGR:              22354
```

The output below shows an ongoing SCDRs archiving while GCDRs archive is stable.

```
[local]StarOS# show gtpp counters all | grep Archive
Archived GCDRs: 176703
Archived MCDRs: 0
Archived SCDRs: 2244673
Archived S-SMO-CDRs: 0
Archived S-SMT-CDRs: 0
Archived G-MB-CDRs: 0
Archived SGW CDRs: 0
Archived WLAN CDRs: 0
Archived LCS-MT CDRs: 0
 [local]StarOS# show gtpp counters all | grep Archive
Archived GCDRs: 176703
Archived MCDRs: 0
Archived SCDRs: 2244864
Archived S-SMO-CDRs: 0
Archived S-SMT-CDRs: 0
Archived G-MB-CDRs: 0
Archived SGW CDRs: 0
Archived WLAN CDRs: 0
Archived LCS-MT CDRs: 0
 [local]StarOS# show gtpp counters all | grep Archive
Archived GCDRs: 176703
Archived MCDRs: 0
Archived SCDRs: 2245281
Archived S-SMO-CDRs: 0
Archived S-SMT-CDRs: 0
Archived G-MB-CDRs: 0
Archived SGW CDRs: 0
```

```
Archived WLAN CDRs: 0
Archived LCS-MT CDRs: 0
```

- Checking syslogs for 'gtpp 52056' warning can be used to identify the context and GTPP group where archiving of CDRs is happening.

Below output shows that archiving is reported for context GTPP and gtpp group default.

```
[gtpp 52056 warning] [5/0/2399 <aaamgr:50> gr_gtpp_proxy.c:667] [context: GTPP, contextID: 6]
[software internal security system critical-info syslog] [gtpp-group default] GTPP request with
req-count 61747 retried by AAAmgr. Retry-count 3342670
```

Verification Steps:

- Wrong configuration can lead to accumulation of CDRs in the archive. If CDRs/GTPP records are generated by an unintended GTPP group, and this group has an invalid configuration, archiving will occur. Verify the configuration is present or valid for the following common issues:
  - "gtpp group default" in the APN configuration
  - "accounting context" in GGSN, SGW, SAEGW, SGSN services
  - Charging-agent IP and CGF server IP address.
- Check if CGF is up and running.
- Check if socket interface is up in corresponding context. Socket creation failure can lead to CDR archiving. To identify such issues, test the CGF connectivity using the command below. This command should be executed in the context where gtpp group is configured.

```
[context]StarOS# gtpp test accounting group name <name>
```

- Check the RTD (round trip delay) whether Charging gateway is acknowledging the CDRs. The "**show gtpp statistics verbose**" shows the RTD for CGF.
- Check the transport network to determine if it has capacity to handle the traffic by the gateway. Delay or packet drop in the network will cause CDRs to be archived in the gateway. If the packets are dropped (resulting in re-transmission of packets from ASR 5000/ASR 5500, which slows down the CDR transmission rate), this will result in

archived CDRs. This can be fixed by increasing the Transport link capacity or adding QoS in the network.

Additional Information:

> Below CLI commands requires CLI test-commands password configured in the chassis.

- "**debug aaamgr show archive-records instance** `<aaamgr_instance_id>`" on the newer software releases provides information on CDR type, context and GTPP group name for archived records on a specific aaamgr. This information helps in identifying possible misconfigurations. From below example output, it's clear that CDRs are stuck/archived in gtpp group default in context ggsn. The APN which generated these CDRs is apn wifitest. Possibly this default gtpp group in the ggsn context has an invalid configuration.

```
 ---------------------------------------------------------------------------------------
   Record Type     |  Apn Name      | Accounting Context |  Group Name    |  Timestamp
 ---------------------------------------------------------------------------------------
   EGCDR           |wifitest        |ggsn                |default         |Tuesday August 26
10:18:21
   EGCDR           |wifitest        |ggsn                |default         |Tuesday August 26
10:23:21
   EGCDR           |wifitest        |ggsn                |default         |Tuesday August 26
10:28:21
   EGCDR           |wifitest        |ggsn                |default         |Tuesday August 26
10:33:22
```

Bulkstat and KPI

Bulkstats

Overview

Bulkstat statistics are counters that are periodically generated when they are properly configured. The bulkstats are typically transferred to an external collection server where these counters may be further processed (via a pre-defined mathematical formula) or simply displayed. The bulkstats can also be locally stored in the chassis as desired for later processing.

Configuration

The bulk statistics proclet runs on the SMC card for ASR 5000 and in MIO/UMIO card for ASR 5500. At the start of a polling interval, the proclet will send queries to retrieve all of the data.

Typically, there are two steps needed for bulkstat configuration: the configuration of the communication with the collection server, and the configuration of the bulk statistic schemas.

The configuration of the communication with the collection server involves the definition of the time interval, IP address of the server, files and other options.

The bulk statistic schema configuration involves the name, format and counters.

Check the *Bulk Statistics Configuration Mode Commands* and *Bulk Statistics File Configuration Mode Commands* chapters in the *Command Line Interface Reference* for detailed configuration assistance.

After configuring support for bulk statistics on the system, verify the settings prior to saving them.

Follow the instructions in this section to verify bulk statistic settings. This command needs to be executed at the root prompt of the Exec mode.

Check for collection server communication and schema settings by entering the following command:

The following is an example command output:

```
#show bulkstats schemas
Bulk Statistics Server Configuration:
Server State:                 Enabled
File Limit:                   4000 KB
Sample Interval:              15 minutes (0D 0H 15M)
Transfer Interval:            480 minutes (0D 0H 15M)
Collection Mode:              Cumulative
Receiver Mode:                Secondary-on-failure
Local File Storage:           None
Bulk Statistics Server Statistics:
Records awaiting transmission: 232
Bytes awaiting transmission:   84423
Total records collected:       2345788
Total bytes collected:         24124545
Total records transmitted:     34233
Total bytes transmitted:       2312323
Total records discarded:       0
Total bytes discarded:         0
Last collection time required: 2 second(s)
Last transfer time required:   0 second(s)
Last successful transfer:      Tuesday November 12 10:23:44 EDT 2014
Last successful tx recs:       8754
Last successful tx bytes:      26778
Last attempted transfer:       Tuesday November 12 12:23:44 EDT 2014
File 1
Remote File Format:           /users/ems/server/data/testcity/bulkstat%date%%time%.txt
File Header:                  "testcity_test %time%"
File Footer:                  ""
Bulkstats Receivers:
Primary: 192.169.13.214 using FTP with username administrator
Records awaiting transmission: 0
Bytes awaiting transmission:   0
Total records collected:       0
Total bytes collected:         0
Total records transmitted:     0
Total bytes transmitted:       0
Total records discarded:       0
Total bytes discarded:         0
Last transfer time required:   0 second(s)
```

```
No successful data transfers
No attempted data transfe

File 2 not configured
```

Viewing Collected Bulk Statistics Data

The system provides a mechanism for viewing data that has been collected, but which has not been transferred. This data is referred to as “Records awaiting transmission”.

View pending bulk statistics data per schema by entering the following CLI:

```
# show bulkstats data
Bulk Statistics Server Statistics:
Records awaiting transmission: 2
Bytes awaiting transmission:   163687
Total records collected:       1800
Total bytes collected:         163687
Total records transmitted:     0
Total bytes transmitted:       0
Total records discarded:       0
Total bytes discarded:         0
Last collection time required: 2 second(s)
Last transfer time required:   0 second(s)
No successful data transfers
Last attempted transfer:       Monday March 17 18:23:56 EST 2014

File 1
Remote File Format:              %date%%time%
File Header:                     "Format 4.5.3.0"
File Footer:                     ""
Bulkstats Receivers:
Primary: 192.168.13.196 using FTP with username root
File Statistics:
Records awaiting transmission: 1800
Bytes awaiting transmission:   163687
Total records collected:       1800
```

```
Total bytes collected:          163687
Total records transmitted:      0
Total bytes transmitted:        0
Total records discarded:        0
Total bytes discarded:          0
Last transfer time required:    0 second(s)
No successful data transfers
Last attempted transfer:        Monday March 17 18:23:56 EST 2014

File 2 not configured
```

Bulk Statistics Event Log Messages

The stat logging facility captures several events that can be useful for diagnosing errors that could occur with either the creation or writing of a bulk statistic data set to a particular location.

The following table displays the most common event information. The range of the start events is from 31000 to 31999.

Table 1. Logging Events Pertaining to Bulk Statistics

Event	Event ID	Severity	Additional Information
Local File Open Error	31002	Warning	" Unable to open local file *filename* for storing bulkstats data"
Receiver Open Error	31018	Warning	" Unable to open url *filename* for storing bulkstats data"
Receiver Write Error	31019	Warning	" Unable to write to url *filename* while storing bulkstats data"
Receiver Close Error	31020	Warning	" Unable to close url *filename* while storing bulkstats data"

Troubleshooting Bulkstats

Overview

This section covers how to collect Bulk Statistics and provides examples of troubleshooting Bulkstats issues.

Manually Gathering and Transferring Bulk Statistics

There may be times where it is necessary to gather and transfer bulk statistics outside of the scheduled intervals. The system provides commands that can be used to manually initiate the gathering and transferring of bulk statistics.

These commands are issued from the Exec mode.

To manually initiate the gathering of bulk statistics outside of the configured sampling interval, enter the following command:

```
# bulkstats force gather
```

To manually initiate the transferring of bulk statistics prior to reaching the maximum configured storage limit, enter the following command:

```
# bulkstats force transfer
```

Clearing Bulk Statistics Counters and Information

It may be necessary to periodically clear counters pertaining to bulk statistics in order to gather new information or to remove bulk statistics information that has already been collected. The following command can be used to perform either of these functions:

```
# clear bulkstats { counters | data }
```

The **clear bulkstats data** command clears any accumulated data that has not been transferred.

This includes any "completed" files that have not been successfully transferred.

Incorrect statistics shown when a sessmgr crashes

Incorrect statistics are generated/displayed.

If there is any spike (up or down) in a particular statistic, verify if there was any sessmgr crash at around the time of spike. This can be verified with the command below:

```
# show crash list
```

Initially the Session Recovery mechanism was not designed to recover the statistics information in case of a sessmgr crash, but in newer software releases some of the service statistics are been recovered.

Example Scenarios

Bulkstat file not transfered from ASR 5000/ASR 5500

Problem Description :

If bulkstat files are not being transferred from the ASR 5000/ASR 5500 to the collection server Follow these steps to identify the issue:

With the command below, check if there are records/bytes waiting transmission.

```
# show bulkstats
 Saturday May 29 17:25:02 IST 2014
 Bulk Statistics Server Configuration:
 Server State:                  Enabled
 File Limit:                    10000 KB
 Sample Interval:               15 minutes (0D 0H 15M)
 Transfer Interval:             15 minutes (0D 0H 15M)
 Receiver Mode:                 Secondary-on-failure
 Historical Data Collection:    Enabled (15 samples stored)
 Bulk Statistics Server Statistics:
```

```
Records awaiting transmission: 34566
Bytes awaiting transmission:   3253454
Total records collected:       12312980
```

Enable the following logs:

 # logging filter active facility stats level debug

 # logging filter active facility system level debug

 # logging active

> **Note:** The above commands in production are likely to cause high CPU and memory usage. It's recommended to use these commands during a maintenance window.

And verify if there are errors; disable the logs with:

```
#no logging active
```

One possible error is described below:

```
2014-May-29+ 17:25:02.36 [stat 31018 warning] [5/0/7875 <bulkstat:0> stat_svr.c:345] [software
internal system syslog] Unable to open url ftp://root:
<password>@ipaddress/opt/ems/server/data/bulkstat20140529140000.txt for storing bulkstats data
```

Trobleshooting steps:

Event ID 31018 is a "Receiver Open Error".

- Perform a PCAP capture externally to the ASR 5000/ASR 5500 and verify the reason why the FTP connection is terminated or not established.
- Verify that the copy command works for any file (For local FTP server). This verifies that the FTP process has no issue if it passes.

- If test 1 passed, check the copy command to transfer a bulkstat file (For local FTP server). This should verify if the bulkstat process is working if it passes.
- If WEM server is available in the network, verify that the copy command works for any file to WEM Server. This verifies that the FTP is working fine for WEM.
- Check the disk space on FTP servers.
- If above test passed, try to transfer the bulkstat file manually, but this time using the bulkstat gather and force commands.
- If above test passed, check if the automatic transfer works for bulkstats or not.

If still unable to identify the issue, open a Service Request with Cisco and provide the loggings requested in step 2, the PCAP file and two SSDs (one before the PCAP and one after the PCAP).

Unable to retrieve bulkstat server information from ASR 5000/ASR 5500

Problem Description:

Bulkstat CLI shows the following failure.

```
[local]asr5500# show bulkstats

 Tuesday Aug 18 15:00:13 EST 2014

 Failure: Unable to retrieve bulkstats server information
```

Also bulkstat process disappears from name service (Normally there should be bulkstat process in the output) and notice there was no output in the above command.

```
[local]asr5500# show messenger nameservice | grep bulk

 Tuesday Aug 18 15:01:09 EST 2014

 [local]asr5500#
```

When transfering a bulkstat file to a server, there is a point in the code where bulkstat process is waiting for a response from the server. If there is a issue in the network or server side and the response is not received, bulkstat keeps waiting forever, which causes the CLI failure and the missing in namespace.

Since bulkstat is missing from namespace, "show profile" cannot be taken for bulkstat process. While taking a core of bulkstat, see below stacktrace.

```
Fatal Signal 6: Aborted
 PC: [f7eb4d10/X] libc.so.6/poll()
 Note: User-initiated state dump w/core.
 Signal from: sitmain pid=25764 uid=0
 Process: card=5 cpu=0 arch=X pid=26402 cpu=~77% argv0=bulkstat
 Crash time: 2014-Jul-04+08:43:11 UTC
 Recent errno: 9 Bad file descriptor
 Stack (15384@0xffffa000):
 [f7eb4d10/X] libc.so.6/poll() sp=0xffffaf78
 [084dc61f/X] error_readable() sp=0xffffafa8
 [084dc6d1/X] fio_errorcheck() sp=0xffffcff8
 [084db95a/X] fio_closefn() sp=0xffffd028
 [f7e57df9/X] libc.so.6/_IO_cookie_close() sp=0xffffd048
 [f7e5fd5c/X] libc.so.6/_IO_new_file_close_it() sp=0xffffd078
 [f7e5776c/X] libc.so.6/fclose@@GLIBC_2.1() sp=0xffffd0c8
 [084dd024/X] sn_mgmt_url_closesync() sp=0xffffd0f8
 [02ebfe22/X] stat_svr_transfer_receiver() sp=0xffffd558
 [02ec0586/X] stat_svr_transfer() sp=0xffffd5b8
 [02ec1852/X] stat_svr_poll() sp=0xffffd618
 [02e50bc0/X] stat_poller_cb() sp=0xffffd638
 [0a2035e6/X] sn_loop_run() sp=0xffffdbc8
 [0a02b3f4/X] main() sp=0xffffdc08
```

Solution:

Restarting bulkstat by "**task kill**" could restore the facility,

"**task core facility bulkstat all**" used before restarting bulkstat only for RCA purpose.

 # task kill facility bulkstat all

However, if the network or server side issue still exists, then the issue would happen again.


KPIs Overview

Key Performance Indicators (KPIs) provide a gauge of the state of the ASR 5000/ASR 5500 and related services. KPIs can be defined with a single counter (for example: the number of attached subscribers) or defined with a mathematical formula that takes into consideration several factors that are related to the ASR 5000/ASR 5500 behavior directly or some external factosr that are not under the control of the ASR 5000/ASR 5500 (ex: attach success-ratio KPI).

KPIs for the ASR 5000/ASR 5500 are calculated based on *bulkstats* counter variables from the ASR 5000/ASR 5500 platform.

KPIs are typically defined with the process described below:

Image: Methodology



Troubleshooting KPIs

There are a large number of KPIs and they vary from operator to operator; it is therefore not possible to cover all possible KPI scenarios in this book.

To troubleshoot a KPI that has degraded, follow this general methodology:

1. Once the degraded KPI has beein identified:
   - Verify the formula currently in use
   - Collect an SSD and store it.
2. Generate a report (with MUR or other collection server) for the previous 60 days with all the counters that are used in the formula.
   - Verify which counter(s) is mis-behaving.
3. Generate a second SSD.
4. Verify if the behavior of the logs can be linked to an error (check logs, snmp traps, crashes) seen in the SSDs.
5. If the counters are not seen in the SSD, capture outputs of "show" commands that are related to the issue in question.
6. Look for any of the following
   - Errors
   - Crashes
   - Connectivity issues
   - Links down
   - Alarms
   - Any other factors that can be associated with this degraded KPI.
7. Try to capture monitor protocol, monitor subscriber and external PCAPs where the issue can be seen or associated to.

8 If the cause of the degraded KPI is still not clear, open a Service Request with all the data collected:

- SSDs
- Logs
- Report with KPI counters
- External PCAP
- Monitor subscriber and/or monitor protocol
- A visual representation (print screen) of the KPI in question.