

Adjusting the Resistance of the EX90 Camera to Motion

Tools Required



A Torx screwdriver (size = T10) is required to perform maintenance on the EX90.

Removal of Upper Grills



To remove the upper grill, remove the screw at right and loosen the two screws at left. Note that the two screws at left cannot be removed. Repeat this process for the grill on the other side of the EX90.

Adjusting the Camera Screws



Loosen or tighten the screws indicated above until the desired resistance to motion is achieved.