



Hardware and Software Interoperability for UCSM Managed Servers in Release 2.2(8)

[Hardware and Software Interoperability Matrix](#) 2

Revised: November 29, 2016,

Hardware and Software Interoperability Matrix

This document provides interoperability matrices for Cisco Unified Computing System components and configurations that have been tested and validated by Cisco, by Cisco partners, or both. Use this document as a reference for supported hardware and software.

This document contains the following sections:

- [Document Revision Table](#)
- [Audience](#)
- [Operating System Interoperability Matrix](#)
- [VM-FEX Software Interoperability Matrix](#)
- [usNIC Software Interoperability Matrix](#)
- [Converged Network Adapter Interoperability Matrix](#)
- [Network Interface Card Interoperability Matrix](#)
- [RAID Controller on Motherboard Interoperability Matrix](#)
- [UCS Storage Accelerator Interoperability Matrix](#)
- [Storage Array Interoperability Matrix](#)
- [Enterprise Backup Interoperability Matrix](#)
- [Switch Interoperability Matrix](#)
- [Graphics Processing Unit Interoperability Matrix](#)
- [Related Documentation](#)
- [Obtaining Documentation and Submitting a Service Request](#)

For C-Series servers managed by UCSM, unless stated in this document, the supported firmware and drivers will be in the 2.0(12), 2.0(10), 2.0(9) and 1.5(9) Standalone C-Series Compatibility guide. 2.0(12) for C460 M4, 2.0(10) for C220 M4/C240 M4, 1.5(9) for C420-M3, C260-M2, C460-M2 and 2.0(9) for all other platforms. The documents are located at http://www.cisco.com/en/US/products/ps10477/prod_technical_reference_list.html .

For information regarding mixed infrastructure and host fw bundles, please refer to the Release Notes for the supported A, B and C bundle combinations .

The stated versions within this doc will always be the latest for the 2.2(8) release. FW and drivers may have been updated to resolve known issues. Please check the corresponding FW or driver footnotes for details regarding those updates. To obtain drivers, please use the latest 2.2(8) Driver ISO found at:

<http://www.cisco.com/cisco/software/type.html?mdfid=283853163&flowid=25821>

Unless stated otherwise, all mentioned drivers in this document are supported with all 2.2(8) bundle patch releases.

Document Revision Table

Table 1 lists the document revision history.

Table 1: Document Revision Table

Version	Date	Note
1	07/14/16	Intial Version
2	08/05/16	Corrected Note 46, should refer to 2.2.2 and 1.5.8 Add Note 52 for ESX VIC drivers Add MDS-9396s
3	08/19/16	Modify Note 46 Modify Note 20 Add C-Series servers based on 2.0.10c and 2.0.8 Add C-Series VIC adapters Add OL 6.8 with UEK R4 U1 Add Notes 53,54,55 Update ESX FNIC to 1.6.0.28 Add Dell Array Update Windows 2008 R2 SP FNIC to 2.1.0.34
4	09/14/16	Add InfiniDat Array Add Ubuntu 16.04.1 Add Ubuntu 14.04.5 Add Tintri Array
5	10/12/16	Add WS2016 Corrected Note 20, changed 2.0.8 to 2.0.9 Added C-Series from 2.0.9 Update WS2012 ENIC to 3.5.0.17 Add notes 56, 57
6	11/08/16	Add RHEL 7.3 Add SLES 12.2 Add OVM 3.4.2 Add UEK R4 U1 Remove the OL from UEK listings Add Note 58 Add CentOS 6.8 Add B260/B460 M4 w/E7-Series v4

Version	Date	Note
7	11/14/16	Add ESX 6.5 Add Note 59 Add UEK R4 U2 Add Netapp E2800 Series Array
8	11/29/16	Add ESX 6.5 for C-Series servers

Audience

This document is designed for use by Cisco TAC, sales, support engineers, professional service partners, and systems administrators responsible for the design and deployment of the Unified Computing System in the data center environment.

This document applies to the B Series Servers in Cisco Unified Computing System Release 2.2(8). The content of this document is updated on a regular basis. The current version was created on 2016-11-29.

Operating System Interoperability Matrix

Table 2 lists the operating systems that the Unified Computing System B Series Servers support.

Table 2: Operating System

UCS Blade Server	Vendor	Operating System Version	Notes
B200 M3 w/E5-Series	CentOS	CentOS 6.5	33, 39, 40
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B200 M4 w/E5-Series v3	CentOS	CentOS 6.5	33, 39, 40
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	CentOS	CentOS 6.6	33, 39, 40
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	CentOS	CentOS 6.6	33, 39, 40
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	CentOS	CentOS 6.7	33, 39, 40
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	CentOS	CentOS 6.7	33, 39, 40
B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	CentOS	CentOS 6.7	33, 39, 40

UCS Blade Server	Vendor	Operating System Version	Notes
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	CentOS	CentOS 6.8	33, 39, 40
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	CentOS	CentOS 6.8	33, 39, 40
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	CentOS	CentOS 6.8	33, 39, 40
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	CentOS	CentOS 7.1	33, 39, 40
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	CentOS	CentOS 7.1	33, 39, 40
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	CentOS	CentOS 7.2	33, 39, 40
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	CentOS	CentOS 7.2	33, 39, 40
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	CentOS	CentOS 7.2	33, 39, 40
B200 M2 w/E5-Series, B230 M2, B250 M2, B440 M2	Citrix	XenServer 6.1	
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/ E5-Series	Citrix	XenServer 6.1	
B200 M2 w/E5-Series, B230 M2, B250 M2, B440 M2	Citrix	XenServer 6.2	
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/ E5-Series	Citrix	XenServer 6.2	

UCS Blade Server	Vendor	Operating System Version	Notes
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	Citrix	XenServer 6.2	
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2, B200 M4 w/E5-Series v3	Citrix	XenServer 6.2	
B200 M2 w/E5-Series, B230 M2, B250 M2, B440 M2	Citrix	XenServer 6.5	
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	Citrix	XenServer 6.5	
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	Citrix	XenServer 6.5	
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	Citrix	XenServer 6.5	
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	Citrix	XenServer 6.5	
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	Citrix	XenServer 6.5	
B200 M2 w/E5-Series, B230 M2, B250 M2, B440 M2	Citrix	XenServer 7.0	
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	Citrix	XenServer 7.0	
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	Citrix	XenServer 7.0	
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	Citrix	XenServer 7.0	

UCS Blade Server	Vendor	Operating System Version	Notes
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	Citrix	XenServer 7.0	
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	Citrix	XenServer 7.0	
B200 M1 w/E5-Series, B230 M1 & M2, B250 M1 & M2, B440 M1 & M2	Microsoft	Windows Server 2008 R2 SP1	18, 33
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/ E5-Series	Microsoft	Windows Server 2008 R2 SP1	18, 33
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	Microsoft	Windows Server 2008 R2 SP1	18, 33
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	Microsoft	Windows Server 2008 R2 SP1	18, 33
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	Microsoft	Windows Server 2008 R2 SP1	18, 33
B200 M2 w/E5-Series, B230 M2, B250 M2, B440 M2	Microsoft	Windows Server 2012	18
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/ E5-Series	Microsoft	Windows Server 2012	18
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	Microsoft	Windows Server 2012	18
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	Microsoft	Windows Server 2012	18
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	Microsoft	Windows Server 2012	18

UCS Blade Server	Vendor	Operating System Version	Notes
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	Microsoft	Windows Server 2012	18
B200 M2 w/E5-Series, B230 M2, B440 M2	Microsoft	Windows Server 2012 R2	18
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/ E5-Series	Microsoft	Windows Server 2012 R2	18
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	Microsoft	Windows Server 2012 R2	18
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	Microsoft	Windows Server 2012 R2	18
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	Microsoft	Windows Server 2012 R2	18
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	Microsoft	Windows Server 2012 R2	18
B200 M2 w/E5-Series, B230 M2, B440 M2	Microsoft	Windows Server 2016	18
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/ E5-Series	Microsoft	Windows Server 2016	18
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	Microsoft	Windows Server 2016	18
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	Microsoft	Windows Server 2016	18
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	Microsoft	Windows Server 2016	18

UCS Blade Server	Vendor	Operating System Version	Notes
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	Microsoft	Windows Server 2016	18
B230 M2, B440 M2	Oracle	Solaris 11 10/12 (U1)	
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/ E5-Series	Oracle	Solaris 11 10/12 (U1)	
B200 M2 w/E5-Series, B230 M2, B440 M2	Oracle	UEK R2 U5 (2.6.39-400.x)	22, 33, 58
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/ E5-Series	Oracle	UEK R2 U5 (2.6.39-400.x)	22, 33, 58
B200 M2 w/E5-Series, B230 M2, B440 M2	Oracle	UEK R3 U1 (3.8.13-26.x)	22, 33, 58
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/ E5-Series	Oracle	UEK R3 U1 (3.8.13-26.x)	22, 33, 58
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	Oracle	UEK R3 U1 (3.8.13-26.x)	22, 33, 58
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2, B200 M4 w/E5-Series v3	Oracle	UEK R3 U1 (3.8.13-26.x)	22, 33, 58
B200 M2 w/E5-Series, B230 M2, B440 M2	Oracle	UEK R3 U3 (3.8.13-44.x)	22, 33, 58
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/ E5-Series	Oracle	UEK R3 U3 (3.8.13-44.x)	22, 33, 58
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	Oracle	UEK R3 U3 (3.8.13-44.x)	22, 33, 58
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	Oracle	UEK R3 U3 (3.8.13-44.x)	22, 33, 58

UCS Blade Server	Vendor	Operating System Version	Notes
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	Oracle	UEK R3 U3 (3.8.13-44.x)	22, 33, 58
B200 M2 w/E5-Series, B230 M2, B440 M2	Oracle	UEK R3 U5 (3.8.13-68.x)	22, 33, 58
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/ E5-Series	Oracle	UEK R3 U5 (3.8.13-68.x)	22, 33, 58
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	Oracle	UEK R3 U5 (3.8.13-68.x)	22, 33, 58
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	Oracle	UEK R3 U5 (3.8.13-68.x)	22, 33, 58
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	Oracle	UEK R3 U5 (3.8.13-68.x)	22, 33, 58
B200 M2 w/E5-Series, B230 M2, B440 M2	Oracle	UEK R3 U6 (3.8.13-98.x)	22, 33, 58
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/ E5-Series	Oracle	UEK R3 U6 (3.8.13-98.x)	22, 33, 58
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	Oracle	UEK R3 U6 (3.8.13-98.x)	22, 33, 58
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	Oracle	UEK R3 U6 (3.8.13-98.x)	22, 33, 58
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	Oracle	UEK R3 U6 (3.8.13-98.x)	22, 33, 58
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	Oracle	UEK R3 U7 (3.8.13-118.x)	22, 33, 58

UCS Blade Server	Vendor	Operating System Version	Notes
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	Oracle	UEK R3 U7 (3.8.13-118.x)	22, 33, 58
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	Oracle	UEK R3 U7 (3.8.13-118.x)	22, 33, 58
B200 M2 w/E5-Series, B230 M2, B440 M2	Oracle	UEK R4 (4.1.12-32.x)	22, 33, 58
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/ E5-Series	Oracle	UEK R4 (4.1.12-32.x)	22, 33, 58
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	Oracle	UEK R4 (4.1.12-32.x)	22, 33, 58
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	Oracle	UEK R4 (4.1.12-32.x)	22, 33, 58
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	Oracle	UEK R4 (4.1.12-32.x)	22, 33, 58
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	Oracle	UEK R4 (4.1.12-32.x)	22, 33, 58
B200 M2 w/E5-Series, B230 M2, B440 M2	Oracle	UEK R4 U1 (4.1.12-37.x)	22, 33, 58
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/ E5-Series	Oracle	UEK R4 U1 (4.1.12-37.x)	22, 33, 58
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	Oracle	UEK R4 U1 (4.1.12-37.x)	22, 33, 58
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	Oracle	UEK R4 U1 (4.1.12-37.x)	22, 33, 58

UCS Blade Server	Vendor	Operating System Version	Notes
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	Oracle	UEK R4 U1 (4.1.12-37.x)	22, 33, 58
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	Oracle	UEK R4 U1 (4.1.12-37.x)	22, 33, 58
B200 M2 w/E5-Series, B230 M2, B440 M2	Oracle	UEK R4 U2 (4.1.12-61.x)	22, 33, 58
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/ E5-Series	Oracle	UEK R4 U2 (4.1.12-61.x)	22, 33, 58
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	Oracle	UEK R4 U2 (4.1.12-61.x)	22, 33, 58
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	Oracle	UEK R4 U2 (4.1.12-61.x)	22, 33, 58
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	Oracle	UEK R4 U2 (4.1.12-61.x)	22, 33, 58
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	Oracle	UEK R4 U2 (4.1.12-61.x)	22, 33, 58
B200 M2 w/E5-Series, B230 M2, B440 M2	Oracle	OVM 3.3.1	33
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/ E5-Series	Oracle	OVM 3.3.1	33
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	Oracle	OVM 3.3.1	33
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2, B200 M4 w/E5-Series v3	Oracle	OVM 3.3.1	33

UCS Blade Server	Vendor	Operating System Version	Notes
B200 M2 w/E5-Series, B230 M2, B440 M2	Oracle	OVM 3.3.2	33
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	Oracle	OVM 3.3.2	33
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	Oracle	OVM 3.3.2	33
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	Oracle	OVM 3.3.2	33
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	Oracle	OVM 3.3.2	33
B200 M2 w/E5-Series, B230 M2, B440 M2	Oracle	OVM 3.3.3	33
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	Oracle	OVM 3.3.3	33
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	Oracle	OVM 3.3.3	33
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	Oracle	OVM 3.3.3	33
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	Oracle	OVM 3.3.3	33
B200 M2 w/E5-Series, B230 M2, B440 M2	Oracle	OVM 3.3.4	33
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	Oracle	OVM 3.3.4	33
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	Oracle	OVM 3.3.4	33

UCS Blade Server	Vendor	Operating System Version	Notes
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	Oracle	OVM 3.3.4	33
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	Oracle	OVM 3.3.4	33
B200 M2 w/E5-Series, B230 M2, B440 M2	Oracle	OVM 3.4.1	33
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/ E5-Series	Oracle	OVM 3.4.1	33
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	Oracle	OVM 3.4.1	33
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	Oracle	OVM 3.4.1	33
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	Oracle	OVM 3.4.1	33
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	Oracle	OVM 3.4.1	33
B200 M2 w/E5-Series, B230 M2, B440 M2	Oracle	OVM 3.4.2	33
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/ E5-Series	Oracle	OVM 3.4.2	33
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	Oracle	OVM 3.4.2	33
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	Oracle	OVM 3.4.2	33

UCS Blade Server	Vendor	Operating System Version	Notes
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	Oracle	OVM 3.4.2	33
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	Oracle	OVM 3.4.2	33
B200 M2 w/E5-Series, B250 M2, B230 M1 & M2, B440 M1 & M2	Red Hat	Red Hat Enterprise Linux 5.9	33
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/ E5-Series	Red Hat	Red Hat Enterprise Linux 5.9	33
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	Red Hat	Red Hat Enterprise Linux 5.9	33
B200 M2 w/E5-Series, B250 M2, B230 M1 & M2, B440 M1 & M2	Red Hat	Red Hat Enterprise Linux 5.10	33
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/ E5-Series	Red Hat	Red Hat Enterprise Linux 5.10	33
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	Red Hat	Red Hat Enterprise Linux 5.10	33
B200 M2 w/E5-Series, B250 M2, B230 M1 & M2, B440 M1 & M2	Red Hat	Red Hat Enterprise Linux 5.11	33
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/ E5-Series	Red Hat	Red Hat Enterprise Linux 5.11	33
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	Red Hat	Red Hat Enterprise Linux 5.11	33

UCS Blade Server	Vendor	Operating System Version	Notes
B200 M2 w/E5-Series, B250 M2, B230 M1 & M2, B440 M1 & M2	Red Hat	Red Hat Enterprise Linux 6.4	33
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	Red Hat	Red Hat Enterprise Linux 6.4	33
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	Red Hat	Red Hat Enterprise Linux 6.4	33
B200 M2 w/E5-Series, B250 M2, B230 M1 & M2, B440 M1 & M2	Red Hat	Red Hat Enterprise Linux 6.5	33
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	Red Hat	Red Hat Enterprise Linux 6.5	33
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	Red Hat	Red Hat Enterprise Linux 6.5	33
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2, B200 M4 w/E5-Series v3	Red Hat	Red Hat Enterprise Linux 6.5	33
B200 M2 w/E5-Series, B250 M2, B230 M1 & M2, B440 M1 & M2	Red Hat	Red Hat Enterprise Linux 6.6	33
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	Red Hat	Red Hat Enterprise Linux 6.6	33
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	Red Hat	Red Hat Enterprise Linux 6.6	33
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	Red Hat	Red Hat Enterprise Linux 6.6	33
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	Red Hat	Red Hat Enterprise Linux 6.6	33

UCS Blade Server	Vendor	Operating System Version	Notes
B200 M2 w/E5-Series, B250 M2, B230 M1 & M2, B440 M1 & M2	Red Hat	Red Hat Enterprise Linux 6.7	33
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	Red Hat	Red Hat Enterprise Linux 6.7	33
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	Red Hat	Red Hat Enterprise Linux 6.7	33
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	Red Hat	Red Hat Enterprise Linux 6.7	33
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	Red Hat	Red Hat Enterprise Linux 6.7	33
B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	Red Hat	Red Hat Enterprise Linux 6.7	33
B200 M2 w/E5-Series, B250 M2, B230 M1 & M2, B440 M1 & M2	Red Hat	Red Hat Enterprise Linux 6.8	33
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	Red Hat	Red Hat Enterprise Linux 6.8	33
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	Red Hat	Red Hat Enterprise Linux 6.8	33
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	Red Hat	Red Hat Enterprise Linux 6.8	33
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	Red Hat	Red Hat Enterprise Linux 6.8	33
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	Red Hat	Red Hat Enterprise Linux 6.8	33

UCS Blade Server	Vendor	Operating System Version	Notes
B200 M2 w/E5-Series, B230 M2, B440 M2	Red Hat	Red Hat Enterprise Linux 7.0	33
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	Red Hat	Red Hat Enterprise Linux 7.0	33
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	Red Hat	Red Hat Enterprise Linux 7.0	33
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2, B200 M4 w/E5-Series v3	Red Hat	Red Hat Enterprise Linux 7.0	33
B200 M2 w/E5-Series, B230 M2, B440 M2	Red Hat	Red Hat Enterprise Linux 7.1	33
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	Red Hat	Red Hat Enterprise Linux 7.1	33
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	Red Hat	Red Hat Enterprise Linux 7.1	33
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	Red Hat	Red Hat Enterprise Linux 7.1	33
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	Red Hat	Red Hat Enterprise Linux 7.1	33
B200 M2 w/E5-Series, B230 M2, B440 M2	Red Hat	Red Hat Enterprise Linux 7.2	33
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	Red Hat	Red Hat Enterprise Linux 7.2	33
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	Red Hat	Red Hat Enterprise Linux 7.2	33
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	Red Hat	Red Hat Enterprise Linux 7.2	33

UCS Blade Server	Vendor	Operating System Version	Notes
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	Red Hat	Red Hat Enterprise Linux 7.2	33
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	Red Hat	Red Hat Enterprise Linux 7.2	33
B200 M2 w/E5-Series, B230 M2, B440 M2	Red Hat	Red Hat Enterprise Linux 7.3	33
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/ E5-Series	Red Hat	Red Hat Enterprise Linux 7.3	33
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	Red Hat	Red Hat Enterprise Linux 7.3	33
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	Red Hat	Red Hat Enterprise Linux 7.3	33
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	Red Hat	Red Hat Enterprise Linux 7.3	33
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	Red Hat	Red Hat Enterprise Linux 7.3	33
B200 M2 w/E5-Series, B230 M2, B250 M2, B440 M2	SuSE	SUSE Linux Enterprise Server 11.2	33
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/ E5-Series	SuSE	SUSE Linux Enterprise Server 11.2	33
B200 M2 w/E5-Series, B230 M2, B250 M2, B440 M2	SuSE	SUSE Linux Enterprise Server 11.3	33
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/ E5-Series	SuSE	SUSE Linux Enterprise Server 11.3	33

UCS Blade Server	Vendor	Operating System Version	Notes
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	SuSE	SUSE Linux Enterprise Server 11.3	33
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	SuSE	SUSE Linux Enterprise Server 11.3	33
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	SuSE	SUSE Linux Enterprise Server 11.3	33
B200 M2 w/E5-Series, B230 M2, B250 M2, B440 M2	SuSE	SUSE Linux Enterprise Server 11.4	33
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	SuSE	SUSE Linux Enterprise Server 11.4	33
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	SuSE	SUSE Linux Enterprise Server 11.4	33
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	SuSE	SUSE Linux Enterprise Server 11.4	33
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	SuSE	SUSE Linux Enterprise Server 11.4	33
B200 M2 w/E5-Series, B230 M2, B440 M2	SuSE	SUSE Linux Enterprise Server 12	33
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	SuSE	SUSE Linux Enterprise Server 12	33
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	SuSE	SUSE Linux Enterprise Server 12	33
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	SuSE	SUSE Linux Enterprise Server 12	33

UCS Blade Server	Vendor	Operating System Version	Notes
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	SuSE	SUSE Linux Enterprise Server 12	33
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	SuSE	SUSE Linux Enterprise Server 12	33
B200 M2 w/E5-Series, B230 M2, B440 M2	SuSE	SUSE Linux Enterprise Server 12.1	33
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/ E5-Series	SuSE	SUSE Linux Enterprise Server 12.1	33
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	SuSE	SUSE Linux Enterprise Server 12.1	33
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	SuSE	SUSE Linux Enterprise Server 12.1	33
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	SuSE	SUSE Linux Enterprise Server 12.1	33
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	SuSE	SUSE Linux Enterprise Server 12.1	33
B200 M2 w/E5-Series, B230 M2, B440 M2	SuSE	SUSE Linux Enterprise Server 12.2	33
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/ E5-Series	SuSE	SUSE Linux Enterprise Server 12.2	33
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	SuSE	SUSE Linux Enterprise Server 12.2	33
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	SuSE	SUSE Linux Enterprise Server 12.2	33

UCS Blade Server	Vendor	Operating System Version	Notes
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	SuSE	SUSE Linux Enterprise Server 12.2	33
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	SuSE	SUSE Linux Enterprise Server 12.2	33
B200 M3 w/E5-Series	Ubuntu	Ubuntu 12.04.4	33, 36, 44
B200 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	Ubuntu	Ubuntu 12.04.4	33, 36, 44
B200 M3 w/E5-Series	Ubuntu	Ubuntu 14.04	33, 36, 44
B200 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	Ubuntu	Ubuntu 14.04	33, 36, 44
B200 M3 w/E5-Series	Ubuntu	Ubuntu 14.04.1	33, 36, 44
B200 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2, B200 M4 w/E5-Series v3	Ubuntu	Ubuntu 14.04.1	33, 36, 44
B200 M3 w/E5-Series	Ubuntu	Ubuntu 14.04.2	33, 36, 44
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	Ubuntu	Ubuntu 14.04.2	33, 36, 44
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	Ubuntu	Ubuntu 14.04.2	33, 36, 44
B200 M3 w/E5-Series	Ubuntu	Ubuntu 14.04.3	33, 36, 44
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	Ubuntu	Ubuntu 14.04.3	33, 36, 44
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	Ubuntu	Ubuntu 14.04.3	33, 36, 44

UCS Blade Server	Vendor	Operating System Version	Notes
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	Ubuntu	Ubuntu 14.04.4	33, 36, 44
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	Ubuntu	Ubuntu 14.04.4	33, 36, 44
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	Ubuntu	Ubuntu 14.04.4	33, 36, 44
B200 M4 w/E5-Series v4	Ubuntu	Ubuntu 14.04.4	33, 36, 44
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	Ubuntu	Ubuntu 14.04.5	33, 36, 44
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	Ubuntu	Ubuntu 14.04.5	33, 36, 44
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	Ubuntu	Ubuntu 14.04.5	33, 36, 44
B200 M4 w/E5-Series v4	Ubuntu	Ubuntu 14.04.5	33, 36, 44
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	Ubuntu	Ubuntu 16.04	33, 36, 44, 51
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	Ubuntu	Ubuntu 16.04	33, 36, 44, 51
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	Ubuntu	Ubuntu 16.04	33, 36, 44, 51
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	Ubuntu	Ubuntu 16.04	33, 36, 44, 51
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	Ubuntu	Ubuntu 16.04.1	33, 36, 44, 51
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	Ubuntu	Ubuntu 16.04.1	33, 36, 44, 51

UCS Blade Server	Vendor	Operating System Version	Notes
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	Ubuntu	Ubuntu 16.04.1	33, 36, 44, 51
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	Ubuntu	Ubuntu 16.04.1	33, 36, 44, 51
B200 M1 w/E5-Series, B230 M1 & M2, B250 M1 & M2, B440 M1 & M2	VMware	vSphere 5.0 U2	
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/ E5-Series	VMware	vSphere 5.0 U2	
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	VMware	vSphere 5.0 U2	
B200 M1 w/E5-Series, B230 M1 & M2, B250 M1 & M2, B440 M1 & M2	VMware	vSphere 5.0 U3	
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/ E5-Series	VMware	vSphere 5.0 U3	
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	VMware	vSphere 5.0 U3	
B200 M2 w/E5-Series, B230 M2, B250 M2, B440 M2	VMware	vSphere 5.1 U1	
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/ E5-Series	VMware	vSphere 5.1 U1	
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	VMware	vSphere 5.1 U1	
B200 M2 w/E5-Series, B230 M2, B250 M2, B440 M2	VMware	vSphere 5.1 U2	

UCS Blade Server	Vendor	Operating System Version	Notes
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	VMware	vSphere 5.1 U2	
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	VMware	vSphere 5.1 U2	
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2, B200 M4 w/E5-Series v3	VMware	vSphere 5.1 U2	19, 37
B200 M2 w/E5-Series, B230 M2, B250 M2, B440 M2	VMware	vSphere 5.1 U3	
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	VMware	vSphere 5.1 U3	
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	VMware	vSphere 5.1 U3	
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	VMware	vSphere 5.1 U3	19
B200 M2 w/E5-Series, B230 M2, B440 M2	VMware	vSphere 5.5	
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	VMware	vSphere 5.5	
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	VMware	vSphere 5.5	
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	VMware	vSphere 5.5	
B200 M2 w/E5-Series, B230 M2, B440 M2	VMware	vSphere 5.5 U1	
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	VMware	vSphere 5.5 U1	

UCS Blade Server	Vendor	Operating System Version	Notes
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	VMware	vSphere 5.5 U1	
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	VMware	vSphere 5.5 U1	
B200 M2 w/E5-Series, B230 M2, B440 M2	VMware	vSphere 5.5 U2	
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	VMware	vSphere 5.5 U2	
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	VMware	vSphere 5.5 U2	
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	VMware	vSphere 5.5 U2	
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	VMware	vSphere 5.5 U2	19
B200 M2 w/E5-Series, B230 M2, B440 M2	VMware	vSphere 5.5 U3	
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	VMware	vSphere 5.5 U3	
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	VMware	vSphere 5.5 U3	
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	VMware	vSphere 5.5 U3	
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	VMware	vSphere 5.5 U3	19

UCS Blade Server	Vendor	Operating System Version	Notes
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	VMware	vSphere 5.5 U3	19, 47, 50
B200 M2 w/E5-Series, B230 M2, B440 M2	VMware	vSphere 6.0	
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	VMware	vSphere 6.0	
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	VMware	vSphere 6.0	
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	VMware	vSphere 6.0	
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	VMware	vSphere 6.0	
B200 M2 w/E5-Series, B230 M2, B440 M2	VMware	vSphere 6.0 U1	
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	VMware	vSphere 6.0 U1	
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	VMware	vSphere 6.0 U1	
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	VMware	vSphere 6.0 U1	
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	VMware	vSphere 6.0 U1	
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	VMware	vSphere 6.0 U1	47, 50

UCS Blade Server	Vendor	Operating System Version	Notes
B200 M2 w/E5-Series, B230 M2, B440 M2	VMware	vSphere 6.0 U2	
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	VMware	vSphere 6.0 U2	
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	VMware	vSphere 6.0 U2	
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	VMware	vSphere 6.0 U2	
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	VMware	vSphere 6.0 U2	
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	VMware	vSphere 6.0 U2	
B200 M2 w/E5-Series, B230 M2, B440 M2	VMware	vSphere 6.5	
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	VMware	vSphere 6.5	
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	VMware	vSphere 6.5	
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	VMware	vSphere 6.5	
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	VMware	vSphere 6.5	
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	VMware	vSphere 6.5	

UCS Blade Server	Vendor	Operating System Version	Notes
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	CentOS	CentOS 6.6	20, 33, 39, 40
C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	CentOS	CentOS 6.6	20, 33, 39, 40
C220 M3(SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C220 M4 (SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	CentOS	CentOS 6.6	20, 33, 39, 40
C420 M3 w/E5-Series	CentOS	CentOS 6.7	20, 33, 39, 40
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C220 M4 (SFF/LFF) w/E5-Series v4, C240 M4(SFF/LFF) w/E5-Series v4	CentOS	CentOS 6.7	20, 33, 39, 40
C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3, C460 M4 w/E7-Series v4	CentOS	CentOS 6.7	20, 33, 39, 40
C220 M3(SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C220 M4 (SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	CentOS	CentOS 6.7	20, 33, 39, 40
C420 M3 w/E5-Series	CentOS	CentOS 7.1	20, 33, 39, 40
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C220 M4 (SFF/LFF) w/E5-Series v4, C240 M4(SFF/LFF) w/E5-Series v4	CentOS	CentOS 7.1	20, 33, 39, 40

UCS Blade Server	Vendor	Operating System Version	Notes
C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	CentOS	CentOS 7.1	20, 33, 39, 40
C220 M3(SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C220 M4 (SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	CentOS	CentOS 7.1	20, 33, 39, 40
C420 M3 w/E5-Series	CentOS	CentOS 7.2	20, 33, 39, 40
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C220 M4 (SFF/LFF) w/E5-Series v4, C240 M4(SFF/LFF) w/E5-Series v4	CentOS	CentOS 7.2	20, 33, 39, 40
C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3, C460 M4 w/E7-Series v4	CentOS	CentOS 7.2	20, 33, 39, 40
C220 M3(SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C220 M4 (SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	CentOS	CentOS 7.2	20, 33, 39, 40
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	Citrix	XenServer 6.2	20
C460 M4 w/E7-Series v2	Citrix	XenServer 6.2	20

UCS Blade Server	Vendor	Operating System Version	Notes
C220 M3(SFF/LFF) w/E5-Series, C240 M3(SFF/LFF) w/E5-Series, C240 M3 w/E5-Series, C22 M3(SFF/LFF) w/E5-Series, C24 M3(SFF/LFF) w/E5-Series, C220 M3(SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C22 M3(SFF/LFF) w/E5-Series v2, C24 M3(SFF/LFF) w/E5-Series v2, C220 M4 (SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2	Citrix	XenServer 6.2	20
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	Citrix	XenServer 6.5	20
C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	Citrix	XenServer 6.5	20
C220 M3(SFF/LFF) w/E5-Series, C240 M3(SFF/LFF) w/E5-Series, C240 M3 w/E5-Series, C22 M3(SFF/LFF) w/E5-Series, C24 M3(SFF/LFF) w/E5-Series, C220 M3(SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C22 M3(SFF/LFF) w/E5-Series v2, C24 M3(SFF/LFF) w/E5-Series v2, C220 M4 (SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	Citrix	XenServer 6.5	20
C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3, C460 M4 w/E7-Series v4	Citrix	XenServer 7.0	20
C260 M2 w/E7-Series, C460 M2 w/E7-Series, C420 M3 w/E5-Series	Microsoft	Windows Server 2008 R2 SP1	18, 20, 33

UCS Blade Server	Vendor	Operating System Version	Notes
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	Microsoft	Windows Server 2008 R2 SP1	18, 20, 33
C460 M4 w/E7-Series v2	Microsoft	Windows Server 2008 R2 SP1	18, 20, 33
C220 M3(SFF/LFF) w/E5-Series, C240 M3(SFF/LFF) w/E5-Series, C240 M3 w/E5-Series, C22 M3(SFF/LFF) w/E5-Series, C24 M3(SFF/LFF) w/E5-Series, C220 M3(SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C22 M3(SFF/LFF) w/E5-Series v2, C24 M3(SFF/LFF) w/E5-Series v2, C220 M4 (SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	Microsoft	Windows Server 2008 R2 SP1	18, 20, 33
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	Microsoft	Windows Server 2012	18, 20
C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3, C460 M4 w/E7-Series v4	Microsoft	Windows Server 2012	18, 20
C220 M3(SFF/LFF) w/E5-Series, C240 M3(SFF/LFF) w/E5-Series, C240 M3 w/E5-Series, C22 M3(SFF/LFF) w/E5-Series, C24 M3(SFF/LFF) w/E5-Series, C220 M3(SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C22 M3(SFF/LFF) w/E5-Series v2, C24 M3(SFF/LFF) w/E5-Series v2, C220 M4 (SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	Microsoft	Windows Server 2012	18, 20

UCS Blade Server	Vendor	Operating System Version	Notes
C260 M2 w/E7-Series, C460 M2 w/E7-Series, C420 M3 w/E5-Series	Microsoft	Windows Server 2012 R2	18, 20
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C220 M4(SFF/LFF) w/E5-Series v4, C240 M4(SFF/LFF) w/E5-Series v4	Microsoft	Windows Server 2012 R2	18, 20
C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3, C460 M4 w/E7-Series v4	Microsoft	Windows Server 2012 R2	18, 20
C220 M3(SFF/LFF) w/E5-Series, C240 M3(SFF/LFF) w/E5-Series, C240 M3 w/E5-Series, C22 M3(SFF/LFF) w/E5-Series, C24 M3(SFF/LFF) w/E5-Series, C220 M3(SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C22 M3(SFF/LFF) w/E5-Series v2, C24 M3(SFF/LFF) w/E5-Series v2, C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	Microsoft	Windows Server 2012 R2	18, 20
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	Oracle	UEK R3 U1 (3.8.13-26.x)	20, 22, 33, 58
C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	Oracle	UEK R3 U1 (3.8.13-26.x)	20, 22, 33, 58

UCS Blade Server	Vendor	Operating System Version	Notes
C220 M3(SFF/LFF) w/E5-Series, C240 M3(SFF/LFF) w/E5-Series, C240 M3 w/E5-Series, C22 M3(SFF/LFF) w/E5-Series, C24 M3(SFF/LFF) w/E5-Series, C220 M3(SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C22 M3(SFF/LFF) w/E5-Series v2, C24 M3(SFF/LFF) w/E5-Series v2, C220 M4 (SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2	Oracle	UEK R3 U1 (3.8.13-26.x)	20, 22, 33, 58
C260 M2 w/E7-Series, C460 M2 w/E7-Series, C420 M3 w/E5-Series	Oracle	UEK R3 U3 (3.8.13-44.x)	20, 22, 33, 58
C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	Oracle	UEK R3 U3 (3.8.13-44.x)	20, 22, 33, 58
C220 M3(SFF/LFF) w/E5-Series, C240 M3(SFF/LFF) w/E5-Series, C240 M3 w/E5-Series, C22 M3(SFF/LFF) w/E5-Series, C24 M3(SFF/LFF) w/E5-Series, C220 M3(SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C22 M3(SFF/LFF) w/E5-Series v2, C24 M3(SFF/LFF) w/E5-Series v2, C220 M4 (SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	Oracle	UEK R3 U3 (3.8.13-44.x)	20, 22, 33, 58
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	Oracle	UEK R3 U5 (3.8.13-68.x)	20, 22, 33, 58
C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	Oracle	UEK R3 U5 (3.8.13-68.x)	20, 22, 33, 58

UCS Blade Server	Vendor	Operating System Version	Notes
C220 M3(SFF/LFF) w/E5-Series, C240 M3(SFF/LFF) w/E5-Series, C240 M3 w/E5-Series, C22 M3(SFF/LFF) w/E5-Series, C24 M3(SFF/LFF) w/E5-Series, C220 M3(SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C22 M3(SFF/LFF) w/E5-Series v2, C24 M3(SFF/LFF) w/E5-Series v2, C220 M4 (SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	Oracle	UEK R3 U5 (3.8.13-68.x)	20, 22, 33, 58
C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	Oracle	UEK R3 U6 (3.8.13-98.x)	20, 22, 33, 58
C220 M3(SFF/LFF) w/E5-Series, C240 M3(SFF/LFF) w/E5-Series, C240 M3 w/E5-Series, C22 M3(SFF/LFF) w/E5-Series, C24 M3(SFF/LFF) w/E5-Series, C220 M3(SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C22 M3(SFF/LFF) w/E5-Series v2, C24 M3(SFF/LFF) w/E5-Series v2, C220 M4 (SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	Oracle	UEK R3 U6 (3.8.13-98.x)	20, 22, 33, 58
C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	Oracle	UEK R3 U7 (3.8.13-118.x)	20, 22, 33, 58

UCS Blade Server	Vendor	Operating System Version	Notes
C220 M3(SFF/LFF) w/E5-Series, C240 M3(SFF/LFF) w/E5-Series, C240 M3 w/E5-Series, C22 M3(SFF/LFF) w/E5-Series, C24 M3(SFF/LFF) w/E5-Series, C220 M3(SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C22 M3(SFF/LFF) w/E5-Series v2, C24 M3(SFF/LFF) w/E5-Series v2, C220 M4 (SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	Oracle	UEK R3 U7 (3.8.13-118.x)	20, 22, 33, 58
C260 M2 w/E7-Series, C460 M2 w/E7-Series, C420 M3 w/E5-Series	Oracle	UEK R4 (4.1.12-32.x)	20, 22, 58
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C220 M4 (SFF/LFF) w/E5-Series v4, C240 M4(SFF/LFF) w/E5-Series v4	Oracle	UEK R4 (4.1.12-32.x)	20, 22, 58
C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3, C460 M4 w/E7-Series v4	Oracle	UEK R4 (4.1.12-32.x)	20, 22, 33, 58
C220 M3(SFF/LFF) w/E5-Series, C240 M3(SFF/LFF) w/E5-Series, C240 M3 w/E5-Series, C22 M3(SFF/LFF) w/E5-Series, C24 M3(SFF/LFF) w/E5-Series, C220 M3(SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C22 M3(SFF/LFF) w/E5-Series v2, C24 M3(SFF/LFF) w/E5-Series v2, C220 M4 (SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	Oracle	UEK R4 (4.1.12-32.x)	20, 22, 33, 58

UCS Blade Server	Vendor	Operating System Version	Notes
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	Oracle	OVM 3.3.1	20, 33
C460 M4 w/E7-Series v2	Oracle	OVM 3.3.1	20, 33
C220 M3(SFF/LFF) w/E5-Series, C240 M3(SFF/LFF) w/E5-Series, C240 M3 w/E5-Series, C22 M3(SFF/LFF) w/E5-Series, C24 M3(SFF/LFF) w/E5-Series, C220 M3(SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C22 M3(SFF/LFF) w/E5-Series v2, C24 M3(SFF/LFF) w/E5-Series v2, C220 M4 (SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2	Oracle	OVM 3.3.1	20, 33
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	Oracle	OVM 3.3.2	20, 33
C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	Oracle	OVM 3.3.2	20, 33
C220 M3(SFF/LFF) w/E5-Series, C240 M3(SFF/LFF) w/E5-Series, C240 M3 w/E5-Series, C22 M3(SFF/LFF) w/E5-Series, C24 M3(SFF/LFF) w/E5-Series, C220 M3(SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C22 M3(SFF/LFF) w/E5-Series v2, C24 M3(SFF/LFF) w/E5-Series v2, C220 M4 (SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	Oracle	OVM 3.3.2	20, 33

UCS Blade Server	Vendor	Operating System Version	Notes
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	Oracle	OVM 3.3.3	20, 33
C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	Oracle	OVM 3.3.3	20, 33
C220 M3(SFF/LFF) w/E5-Series, C240 M3(SFF/LFF) w/E5-Series, C240 M3 w/E5-Series, C22 M3(SFF/LFF) w/E5-Series, C24 M3(SFF/LFF) w/E5-Series, C220 M3(SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C22 M3(SFF/LFF) w/E5-Series v2, C24 M3(SFF/LFF) w/E5-Series v2, C220 M4 (SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	Oracle	OVM 3.3.3	20, 33
C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3, C460 M4 w/E7-Series v4	Oracle	OVM 3.4.1	20, 33
C220 M3(SFF/LFF) w/E5-Series, C240 M3(SFF/LFF) w/E5-Series, C240 M3 w/E5-Series, C22 M3(SFF/LFF) w/E5-Series, C24 M3(SFF/LFF) w/E5-Series, C220 M3(SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C22 M3(SFF/LFF) w/E5-Series v2, C24 M3(SFF/LFF) w/E5-Series v2, C220 M4 (SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	Oracle	OVM 3.4.1	20, 33

UCS Blade Server	Vendor	Operating System Version	Notes
C220 M3(SFF/LFF) w/E5-Series, C240 M3(SFF/LFF) w/E5-Series, C240 M3 w/E5-Series, C22 M3(SFF/LFF) w/E5-Series, C24 M3(SFF/LFF) w/E5-Series, C220 M3(SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C22 M3(SFF/LFF) w/E5-Series v2, C24 M3(SFF/LFF) w/E5-Series v2	Redhat	Red Hat Enterprise Linux 6.4	20, 33
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	Redhat	Red Hat Enterprise Linux 6.5	20, 33
C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	Redhat	Red Hat Enterprise Linux 6.5	20, 33
C220 M3(SFF/LFF) w/E5-Series, C240 M3(SFF/LFF) w/E5-Series, C240 M3 w/E5-Series, C22 M3(SFF/LFF) w/E5-Series, C24 M3(SFF/LFF) w/E5-Series, C220 M3(SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C22 M3(SFF/LFF) w/E5-Series v2, C24 M3(SFF/LFF) w/E5-Series v2, C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	Redhat	Red Hat Enterprise Linux 6.5	20, 33
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	Redhat	Red Hat Enterprise Linux 6.6	20, 33
C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	Redhat	Red Hat Enterprise Linux 6.6	20, 33

UCS Blade Server	Vendor	Operating System Version	Notes
C220 M3(SFF/LFF) w/E5-Series, C240 M3(SFF/LFF) w/E5-Series, C240 M3 w/E5-Series, C22 M3(SFF/LFF) w/E5-Series, C24 M3(SFF/LFF) w/E5-Series, C220 M3(SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C22 M3(SFF/LFF) w/E5-Series v2, C24 M3(SFF/LFF) w/E5-Series v2, C220 M4 (SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	Redhat	Red Hat Enterprise Linux 6.6	20, 33
C260 M2 w/E7-Series, C460 M2 w/E7-Series, C420 M3 w/E5-Series	Redhat	Red Hat Enterprise Linux 6.7	20, 33
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C220 M4 (SFF/LFF) w/E5-Series v4, C240 M4(SFF/LFF) w/E5-Series v4	Redhat	Red Hat Enterprise Linux 6.7	20, 33
C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3, C460 M4 w/E7-Series v4	Redhat	Red Hat Enterprise Linux 6.7	20, 33
C220 M3(SFF/LFF) w/E5-Series, C240 M3(SFF/LFF) w/E5-Series, C240 M3 w/E5-Series, C22 M3(SFF/LFF) w/E5-Series, C24 M3(SFF/LFF) w/E5-Series, C220 M3(SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C22 M3(SFF/LFF) w/E5-Series v2, C24 M3(SFF/LFF) w/E5-Series v2, C220 M4 (SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	Redhat	Red Hat Enterprise Linux 6.7	20, 33

UCS Blade Server	Vendor	Operating System Version	Notes
C260 M2 w/E7-Series, C460 M2 w/E7-Series, C420 M3 w/E5-Series	Redhat	Red Hat Enterprise Linux 6.8	20, 33
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C220 M4 (SFF/LFF) w/E5-Series v4, C240 M4(SFF/LFF) w/E5-Series v4	Redhat	Red Hat Enterprise Linux 6.8	20, 33
C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3, C460 M4 w/E7-Series v4	Redhat	Red Hat Enterprise Linux 6.8	20, 33
C220 M3(SFF/LFF) w/E5-Series, C240 M3(SFF/LFF) w/E5-Series, C240 M3 w/E5-Series, C22 M3(SFF/LFF) w/E5-Series, C24 M3(SFF/LFF) w/E5-Series, C220 M3(SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C22 M3(SFF/LFF) w/E5-Series v2, C24 M3(SFF/LFF) w/E5-Series v2, C220 M4 (SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	Redhat	Red Hat Enterprise Linux 6.8	20, 33
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	Redhat	Red Hat Enterprise Linux 7.0	20, 33
C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	Redhat	Red Hat Enterprise Linux 7.0	20, 33

UCS Blade Server	Vendor	Operating System Version	Notes
C220 M3(SFF/LFF) w/E5-Series, C240 M3(SFF/LFF) w/E5-Series, C240 M3 w/E5-Series, C22 M3(SFF/LFF) w/E5-Series, C24 M3(SFF/LFF) w/E5-Series, C220 M3(SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C22 M3(SFF/LFF) w/E5-Series v2, C24 M3(SFF/LFF) w/E5-Series v2, C220 M4 (SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	Redhat	Red Hat Enterprise Linux 7.0	20, 33
C260 M2 w/E7-Series, C460 M2 w/E7-Series, C420 M3 w/E5-Series	Redhat	Red Hat Enterprise Linux 7.1	20, 33
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	Redhat	Red Hat Enterprise Linux 7.1	20, 33
C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	Redhat	Red Hat Enterprise Linux 7.1	20, 33
C220 M3(SFF/LFF) w/E5-Series, C240 M3(SFF/LFF) w/E5-Series, C240 M3 w/E5-Series, C22 M3(SFF/LFF) w/E5-Series, C24 M3(SFF/LFF) w/E5-Series, C220 M3(SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C22 M3(SFF/LFF) w/E5-Series v2, C24 M3(SFF/LFF) w/E5-Series v2, C220 M4 (SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	Redhat	Red Hat Enterprise Linux 7.1	20, 33
C260 M2 w/E7-Series, C460 M2 w/E7-Series, C420 M3 w/E5-Series	Redhat	Red Hat Enterprise Linux 7.2	20, 33

UCS Blade Server	Vendor	Operating System Version	Notes
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C220 M4 (SFF/LFF) w/E5-Series v4, C240 M4(SFF/LFF) w/E5-Series v4	Redhat	Red Hat Enterprise Linux 7.2	20, 33
C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3, C460 M4 w/E7-Series v4	Redhat	Red Hat Enterprise Linux 7.2	20, 33
C220 M3(SFF/LFF) w/E5-Series, C240 M3(SFF/LFF) w/E5-Series, C240 M3 w/E5-Series, C22 M3(SFF/LFF) w/E5-Series, C24 M3(SFF/LFF) w/E5-Series, C220 M3(SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C22 M3(SFF/LFF) w/E5-Series v2, C24 M3(SFF/LFF) w/E5-Series v2, C220 M4 (SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	Redhat	Red Hat Enterprise Linux 7.2	20, 33
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	SuSE	SUSE Linux Enterprise Server 11.3	20, 33
C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	SuSE	SUSE Linux Enterprise Server 11.3	20, 33

UCS Blade Server	Vendor	Operating System Version	Notes
C220 M3(SFF/LFF) w/E5-Series, C240 M3(SFF/LFF) w/E5-Series, C240 M3 w/E5-Series, C22 M3(SFF/LFF) w/E5-Series, C24 M3(SFF/LFF) w/E5-Series, C220 M3(SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C22 M3(SFF/LFF) w/E5-Series v2, C24 M3(SFF/LFF) w/E5-Series v2, C220 M4 (SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	SuSE	SUSE Linux Enterprise Server 11.3	20, 33
C260 M2 w/E7-Series, C460 M2 w/E7-Series, C420 M3 w/E5-Series	SuSE	SUSE Linux Enterprise Server 11.4	20, 33
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	SuSE	SUSE Linux Enterprise Server 11.4	20, 33
C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	SuSE	SUSE Linux Enterprise Server 11.4	20, 33
C220 M3(SFF/LFF) w/E5-Series, C240 M3(SFF/LFF) w/E5-Series, C240 M3 w/E5-Series, C22 M3(SFF/LFF) w/E5-Series, C24 M3(SFF/LFF) w/E5-Series, C220 M3(SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C22 M3(SFF/LFF) w/E5-Series v2, C24 M3(SFF/LFF) w/E5-Series v2, C220 M4 (SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	SuSE	SUSE Linux Enterprise Server 11.4	20, 33

UCS Blade Server	Vendor	Operating System Version	Notes
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C220 M4 (SFF/LFF) w/E5-Series v4, C240 M4(SFF/LFF) w/E5-Series v4	SuSE	SUSE Linux Enterprise Server 12	20, 33
C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3, C460 M4 w/E7-Series v4	SuSE	SUSE Linux Enterprise Server 12	20, 33
C220 M3(SFF/LFF) w/E5-Series, C240 M3(SFF/LFF) w/E5-Series, C240 M3 w/E5-Series, C22 M3(SFF/LFF) w/E5-Series, C24 M3(SFF/LFF) w/E5-Series, C220 M3(SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C22 M3(SFF/LFF) w/E5-Series v2, C24 M3(SFF/LFF) w/E5-Series v2, C220 M4 (SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	SuSE	SUSE Linux Enterprise Server 12	20, 33
C260 M2 w/E7-Series, C460 M2 w/E7-Series, C420 M3 w/E5-Series	SuSE	SUSE Linux Enterprise Server 12.1	20, 33
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C220 M4 (SFF/LFF) w/E5-Series v4, C240 M4(SFF/LFF) w/E5-Series v4	SuSE	SUSE Linux Enterprise Server 12.1	20, 33
C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3, C460 M4 w/E7-Series v4	SuSE	SUSE Linux Enterprise Server 12.1	20, 33

UCS Blade Server	Vendor	Operating System Version	Notes
C220 M3(SFF/LFF) w/E5-Series, C240 M3(SFF/LFF) w/E5-Series, C240 M3 w/E5-Series, C22 M3(SFF/LFF) w/E5-Series, C24 M3(SFF/LFF) w/E5-Series, C220 M3(SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C22 M3(SFF/LFF) w/E5-Series v2, C24 M3(SFF/LFF) w/E5-Series v2, C220 M4 (SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	SuSE	SUSE Linux Enterprise Server 12.1	20, 33
C420 M3 w/E5-Series	Ubuntu	Ubuntu 12.04.5	20, 33, 36, 44
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	Ubuntu	Ubuntu 12.04.5	20, 33, 36, 44
C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	Ubuntu	Ubuntu 12.04.5	20, 33, 36, 44
C220 M3(SFF/LFF) w/E5-Series, C240 M3(SFF/LFF) w/E5-Series, C240 M3 w/E5-Series, C220 M3(SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	Ubuntu	Ubuntu 12.04.5	20, 33, 36, 44
C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	Ubuntu	Ubuntu 14.04	20, 33, 36, 44
C220 M3(SFF/LFF) w/E5-Series, C240 M3(SFF/LFF) w/E5-Series, C240 M3 w/E5-Series, C220 M3(SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C460 M4 w/E7-Series v2	Ubuntu	Ubuntu 14.04	20, 33, 36, 44

UCS Blade Server	Vendor	Operating System Version	Notes
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	Ubuntu	Ubuntu 14.04.1	20, 36, 44
C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	Ubuntu	Ubuntu 14.04.1	20, 33, 36, 44
C220 M3(SFF/LFF) w/E5-Series, C240 M3(SFF/LFF) w/E5-Series, C240 M3 w/E5-Series, C220 M3(SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	Ubuntu	Ubuntu 14.04.1	20, 33, 36, 44
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	Ubuntu	Ubuntu 14.04.2	20, 36, 44
C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	Ubuntu	Ubuntu 14.04.2	20, 33, 36, 44
C220 M3(SFF/LFF) w/E5-Series, C240 M3(SFF/LFF) w/E5-Series, C240 M3 w/E5-Series, C220 M3(SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	Ubuntu	Ubuntu 14.04.2	20, 33, 36, 44
C420 M3 w/E5-Series	Ubuntu	Ubuntu 14.04.3	20, 36, 44
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	Ubuntu	Ubuntu 14.04.3	20, 36, 44
C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	Ubuntu	Ubuntu 14.04.3	20, 33, 36, 44

UCS Blade Server	Vendor	Operating System Version	Notes
C220 M3(SFF/LFF) w/E5-Series, C240 M3(SFF/LFF) w/E5-Series, C240 M3 w/E5-Series, C220 M3(SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	Ubuntu	Ubuntu 14.04.3	20, 33, 36, 44
C420 M3 w/E5-Series	Ubuntu	Ubuntu 14.04.4	20, 36, 44
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C220 M4 (SFF/LFF) w/E5-Series v4, C240 M4(SFF/LFF) w/E5-Series v4	Ubuntu	Ubuntu 14.04.4	20, 36, 44
C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3, C460 M4 w/E7-Series v4	Ubuntu	Ubuntu 14.04.4	20, 33, 36, 44
C220 M3(SFF/LFF) w/E5-Series, C240 M3(SFF/LFF) w/E5-Series, C240 M3 w/E5-Series, C220 M3(SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	Ubuntu	Ubuntu 14.04.4	20, 33, 36, 44
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C220 M4 (SFF/LFF) w/E5-Series v4, C240 M4(SFF/LFF) w/E5-Series v4	Ubuntu	Ubuntu 16.04	20, 33, 36, 44
C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3, C460 M4 w/E7-Series v4	Ubuntu	Ubuntu 16.04	20, 33, 36, 44

UCS Blade Server	Vendor	Operating System Version	Notes
C220 M3(SFF/LFF) w/E5-Series, C240 M3(SFF/LFF) w/E5-Series, C240 M3 w/E5-Series, C220 M3(SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	Ubuntu	Ubuntu 16.04	20, 33, 36, 44
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	VMware	vSphere 5.1 U2	20
C460 M4 w/E7-Series v2	VMware	vSphere 5.1 U2	20, 37
C220 M3(SFF/LFF) w/E5-Series, C240 M3(SFF/LFF) w/E5-Series, C240 M3 w/E5-Series, C22 M3(SFF/LFF) w/E5-Series, C24 M3(SFF/LFF) w/E5-Series, C220 M3(SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C22 M3(SFF/LFF) w/E5-Series v2, C24 M3(SFF/LFF) w/E5-Series v2, C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2	VMware	vSphere 5.1 U2	20, 37
C260 M2 w/E7-Series, C460 M2 w/E7-Series, C420 M3 w/E5-Series	VMware	vSphere 5.1 U3	20
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	VMware	vSphere 5.1 U3	20
C460 M4 w/E7-Series v2	VMware	vSphere 5.1 U3	20

UCS Blade Server	Vendor	Operating System Version	Notes
C220 M3(SFF/LFF) w/E5-Series, C240 M3(SFF/LFF) w/E5-Series, C240 M3 w/E5-Series, C22 M3(SFF/LFF) w/E5-Series, C24 M3(SFF/LFF) w/E5-Series, C220 M3(SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C22 M3(SFF/LFF) w/E5-Series v2, C24 M3(SFF/LFF) w/E5-Series v2, C220 M4 (SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2	VMware	vSphere 5.1 U3	20
C460 M4 w/E7-Series v2	VMware	vSphere 5.5	20
C220 M3(SFF/LFF) w/E5-Series, C240 M3(SFF/LFF) w/E5-Series, C240 M3 w/E5-Series, C22 M3(SFF/LFF) w/E5-Series, C24 M3(SFF/LFF) w/E5-Series, C220 M3(SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C22 M3(SFF/LFF) w/E5-Series v2, C24 M3(SFF/LFF) w/E5-Series v2, C460 M4 w/E7-Series v2	VMware	vSphere 5.5	20
C460 M4 w/E7-Series v2	VMware	vSphere 5.5 U1	20
C220 M3(SFF/LFF) w/E5-Series, C240 M3(SFF/LFF) w/E5-Series, C240 M3 w/E5-Series, C22 M3(SFF/LFF) w/E5-Series, C24 M3(SFF/LFF) w/E5-Series, C220 M3(SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C22 M3(SFF/LFF) w/E5-Series v2, C24 M3(SFF/LFF) w/E5-Series v2, C460 M4 w/E7-Series v2	VMware	vSphere 5.5 U1	20

UCS Blade Server	Vendor	Operating System Version	Notes
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	VMware	vSphere 5.5 U2	20
C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	VMware	vSphere 5.5 U2	20
C220 M3(SFF/LFF) w/E5-Series, C240 M3(SFF/LFF) w/E5-Series, C240 M3 w/E5-Series, C22 M3(SFF/LFF) w/E5-Series, C24 M3(SFF/LFF) w/E5-Series, C220 M3(SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C22 M3(SFF/LFF) w/E5-Series v2, C24 M3(SFF/LFF) w/E5-Series v2, C220 M4 (SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	VMware	vSphere 5.5 U2	20
C260 M2 w/E7-Series, C460 M2 w/E7-Series, C420 M3 w/E5-Series	VMware	vSphere 5.5 U3	20
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C220 M4 (SFF/LFF) w/E5-Series v4, C240 M4(SFF/LFF) w/E5-Series v4	VMware	vSphere 5.5 U3	20
C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	VMware	vSphere 5.5 U3	20

UCS Blade Server	Vendor	Operating System Version	Notes
C220 M3(SFF/LFF) w/E5-Series, C240 M3(SFF/LFF) w/E5-Series, C240 M3 w/E5-Series, C22 M3(SFF/LFF) w/E5-Series, C24 M3(SFF/LFF) w/E5-Series, C220 M3(SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C22 M3(SFF/LFF) w/E5-Series v2, C24 M3(SFF/LFF) w/E5-Series v2, C220 M4 (SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	VMware	vSphere 5.5 U3	20
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	VMware	vSphere 6.0	20
C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	VMware	vSphere 6.0	20
C220 M3(SFF/LFF) w/E5-Series, C240 M3(SFF/LFF) w/E5-Series, C240 M3 w/E5-Series, C22 M3(SFF/LFF) w/E5-Series, C24 M3(SFF/LFF) w/E5-Series, C220 M3(SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C22 M3(SFF/LFF) w/E5-Series v2, C24 M3(SFF/LFF) w/E5-Series v2, C220 M4 (SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	VMware	vSphere 6.0	20
C260 M2 w/E7-Series, C460 M2 w/E7-Series, C420 M3 w/E5-Series	VMware	vSphere 6.0 U1	20

UCS Blade Server	Vendor	Operating System Version	Notes
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C220 M4 (SFF/LFF) w/E5-Series v4, C240 M4(SFF/LFF) w/E5-Series v4	VMware	vSphere 6.0 U1	20
C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3, C460 M4 w/E7-Series v4	VMware	vSphere 6.0 U1	20
C220 M3(SFF/LFF) w/E5-Series, C240 M3(SFF/LFF) w/E5-Series, C240 M3 w/E5-Series, C22 M3(SFF/LFF) w/E5-Series, C24 M3(SFF/LFF) w/E5-Series, C220 M3(SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C22 M3(SFF/LFF) w/E5-Series v2, C24 M3(SFF/LFF) w/E5-Series v2, C220 M4 (SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	VMware	vSphere 6.0 U1	20
C260 M2 w/E7-Series, C460 M2 w/E7-Series, C420 M3 w/E5-Series	VMware	vSphere 6.0 U2	20
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C220 M4 (SFF/LFF) w/E5-Series v4, C240 M4(SFF/LFF) w/E5-Series v4	VMware	vSphere 6.0 U2	20
C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3, C460 M4 w/E7-Series v4	VMware	vSphere 6.0 U2	20

UCS Blade Server	Vendor	Operating System Version	Notes
C220 M3(SFF/LFF) w/E5-Series, C240 M3(SFF/LFF) w/E5-Series, C240 M3 w/E5-Series, C22 M3(SFF/LFF) w/E5-Series, C24 M3(SFF/LFF) w/E5-Series, C220 M3(SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C22 M3(SFF/LFF) w/E5-Series v2, C24 M3(SFF/LFF) w/E5-Series v2, C220 M4 (SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	VMware	vSphere 6.0 U2	20
C220 M3(SFF/LFF) w/E5-Series, C240 M3(SFF/LFF) w/E5-Series, C240 M3 w/E5-Series, C22 M3(SFF/LFF) w/E5-Series, C24 M3(SFF/LFF) w/E5-Series, C220 M3(SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C22 M3(SFF/LFF) w/E5-Series v2, C24 M3(SFF/LFF) w/E5-Series v2, C220 M4 (SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C220 M4(SFF/LFF) w/E5-Series v4, C240 M4 (SFF/LFF) w/E5-Series v4, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3, C460 M4 w/E7-Series v4	VMware	vSphere 6.5	20

VM-FEX Software Interoperability Matrix

Table 3 lists the VM-FEX Software that the Unified Computing System B Series Servers support.

Table 3: VM-FEX Software

Software Type	Software Version	Operating System	Driver	Notes
VM-FEX	VM-FEX	vSphere 5.0 U2	VEM500-20110825132140 (Zip), 132-4.2.1.1.4.1.0-3.0.4 (VIB)	42
VM-FEX	VM-FEX	vSphere 5.0 U3	VEM500-20110825132140 (Zip), 132-4.2.1.1.4.1.0-3.0.4 (VIB)	42
VM-FEX	VM-FEX	vSphere 5.1 U1	151-5.1-1.1.1.1 (Zip and VIB)	42
VM-FEX	VM-FEX	vSphere 5.1 U2	151-5.1-1.1.1.1 (Zip and VIB)	42
VM-FEX	VM-FEX	vSphere 5.1 U3	151-5.1-1.1.1.1 (Zip and VIB)	42
VM-FEX	VM-FEX	vSphere 5.5	161-5.5-1.2.7.1 (Zip and VIB)	
VM-FEX	VM-FEX	vSphere 6.0 U2	v171-6.0-1.2.10.1 (Zip and VIB)	
VM-FEX	VM-FEX	Windows Server 2012	3.5.0.17 (PF, VF enic) / 2.4.11 (vmfex_ext), 1.1.18 (UCSM provider)	21, 56, 57
VM-FEX	VM-FEX	Windows Server 2012 R2	3.5.0.17 (PF, VF enic) / 2.4.11 (vmfex_ext), 1.1.18 (UCSM provider)	21, 56, 57

usNIC Software Interoperability Matrix

Table 4 lists the usNIC Software that the Unified Computing System B Series Servers support.

Table 4: usNIC Software

Software Type	Adapter Model	Operating System	Driver	Notes
usNIC	1240/1340 and Port Expander Card, 1280/1380, 1225/1225T, 1385/1387 Virtual Interface Card	Red Hat Enterprise Linux 6.4	2.3.0.20 (ENIC), 1.1.463.6 (usnic_verbs), 2.0.39cisco1.0.463.6-1 (libdaplusnic), 1.10.2cisco1.0.463.6 (openmpi), 1.1.1.0cisco1.0.463.6 (usnic_tools), 1.3.0cisco1.1.463.6 (libfabric-cisco), 1.3.0cisco1.1.463.6 (libfabric-cisco-devel), 2.0.2.463.6 (libusnic_verbs), 1.1.463.6 (usd_tools)	21, 33
usNIC	1240/1340 and Port Expander Card, 1280/1380, 1225/1225T, 1227/1227T, 1385/1387 Virtual Interface Card	Red Hat Enterprise Linux 6.5	2.3.0.20 (ENIC), 1.1.463.6 (usnic_verbs), 2.0.39cisco1.0.463.6-1 (libdaplusnic), 1.10.2cisco1.0.463.6 (openmpi), 1.1.1.0cisco1.0.463.6 (usnic_tools), 1.3.0cisco1.1.463.6 (libfabric-cisco), 1.3.0cisco1.1.463.6 (libfabric-cisco-devel), 2.0.2.463.6 (libusnic_verbs), 1.1.463.6 (usd_tools)	21, 33
usNIC	1240/1340 and Port Expander Card, 1280/1380, 1225/1225T, 1227/1227T, 1385/1387 Virtual Interface Card	Red Hat Enterprise Linux 6.6	2.3.0.20 (ENIC), 1.1.463.6 (usnic_verbs), 2.0.39cisco1.0.463.6-1 (libdaplusnic), 1.10.2cisco1.0.463.6 (openmpi), 1.1.1.0cisco1.0.463.6 (usnic_tools), 1.3.0cisco1.1.463.6 (libfabric-cisco), 1.3.0cisco1.1.463.6 (libfabric-cisco-devel), 2.0.2.463.6 (libusnic_verbs), 1.1.463.6 (usd_tools)	21, 33

Software Type	Adapter Model	Operating System	Driver	Notes
usNIC	1240/1340 and Port Expander Card, 1280/1380, 1225/1225T, 1227/1227T, 1385/1387 Virtual Interface Card	Red Hat Enterprise Linux 6.7	2.3.0.20 (ENIC), 1.1.463.6 (usnic_verbs), 2.0.39cisco1.0.463.6-1 (libdaplusnic), 1.10.2cisco1.0.463.6 (openmpi), 1.1.1.0cisco1.0.463.6 (usnic_tools), 1.3.0cisco1.1.463.6 (libfabric-cisco), 1.3.0cisco1.1.463.6 (libfabric-cisco-devel), 2.0.2.463.6 (libusnic_verbs), 1.1.463.6 (usd_tools)	21, 33
usNIC	1240/1340 and Port Expander Card, 1280/1380, 1225/1225T, 1227/1227T, 1385/1387 Virtual Interface Card	Red Hat Enterprise Linux 6.8	2.3.0.27 (ENIC), 1.1.463.7 (usnic_verbs), 2.0.39cisco1.0.463.7-1 (libdaplusnic), 1.10.2cisco1.0.463.7 (openmpi), 1.1.1.0cisco1.0.463.7 (usnic_tools), 1.3.0cisco1.1.463.7 (libfabric-cisco), 1.3.0cisco1.1.463.7 (libfabric-cisco-devel), 2.0.2.463.7 (libusnic_verbs), 1.1.463.7 (usd_tools)	21, 33
usNIC	1240/1340 and Port Expander Card, 1280/1380, 1225/1225T, 1227/1227T, 1385/1387 Virtual Interface Card	Red Hat Enterprise Linux 7.0	2.3.0.20 (ENIC), 1.1.463.6 (usnic_verbs), 2.0.39cisco1.0.463.6-1 (libdaplusnic), 1.10.2cisco1.0.463.6 (openmpi), 1.1.1.0cisco1.0.463.6 (usnic_tools), 1.3.0cisco1.1.463.6 (libfabric-cisco), 1.3.0cisco1.1.463.6 (libfabric-cisco-devel), 2.0.2.463.6 (libusnic_verbs), 1.1.463.6 (usd_tools)	21, 33

Software Type	Adapter Model	Operating System	Driver	Notes
usNIC	1240/1340 and Port Expander Card, 1280/1380, 1225/1225T, 1227/1227T, 1385/1387 Virtual Interface Card	Red Hat Enterprise Linux 7.1	2.3.0.20 (ENIC), 1.1.463.6 (usnic_verbs), 2.0.39cisco1.0.463.6-1 (libdaplusnic), 1.10.2cisco1.0.463.6 (openmpi), 1.1.1.0cisco1.0.463.6 (usnic_tools), 1.3.0cisco1.1.463.6 (libfabric-cisco), 1.3.0cisco1.1.463.6 (libfabric-cisco-devel), 2.0.2.463.6 (libusnic_verbs), 1.1.463.6 (usd_tools)	21, 33
usNIC	1240/1340 and Port Expander Card, 1280/1380, 1225/1225T, 1227/1227T, 1385/1387 Virtual Interface Card	Red Hat Enterprise Linux 7.2	2.3.0.20 (ENIC), 1.1.463.6 (usnic_verbs), 2.0.39cisco1.0.463.6-1 (libdaplusnic), 1.10.2cisco1.0.463.6 (openmpi), 1.1.1.0cisco1.0.463.6 (usnic_tools), 1.3.0cisco1.1.463.6 (libfabric-cisco), 1.3.0cisco1.1.463.6 (libfabric-cisco-devel), 2.0.2.463.6 (libusnic_verbs), 1.1.463.6 (usd_tools)	21, 33
usNIC	1240/1340 and Port Expander Card, 1280/1380, 1225/1225T, 1227/1227T, 1385/1387 Virtual Interface Card	SUSE Linux Enterprise Server 12	2.3.0.20 (ENIC), 1.1.463.6 (usnic_verbs), 2.0.39cisco1.0.463.6-1 (libdaplusnic), 1.10.2cisco1.0.463.6 (openmpi), 1.1.1.0cisco1.0.463.6 (usnic_tools), 1.3.0cisco1.1.463.6 (libfabric-cisco), 1.3.0cisco1.1.463.6 (libfabric-cisco-devel), 2.0.2.463.6 (libusnic_verbs), 1.1.463.6 (usd_tools)	21, 33

Software Type	Adapter Model	Operating System	Driver	Notes
usNIC	1240/1340 and Port Expander Card, 1280/1380, 1225/1225T, 1227/1227T, 1385/1387 Virtual Interface Card	SUSE Linux Enterprise Server 12.1	2.3.0.20 (ENIC), 1.1.463.6 (usnic_verbs), 2.0.39cisco1.0.463.6-1 (libdaplusnic), 1.10.2cisco1.0.463.6 (openmpi), 1.1.1.0cisco1.0.463.6 (usnic_tools), 1.3.0cisco1.1.463.6 (libfabric-cisco), 1.3.0cisco1.1.463.6 (libfabric-cisco-devel), 2.0.2.463.6 (libusnic_verbs), 1.1.463.6 (usd_tools)	21, 33
usNIC	1240/1340 and Port Expander Card, 1280/1380, 1225/1225T, 1227/1227T, 1385/1387 Virtual Interface Card	Ubuntu 14.04.2	2.3.0.20 (ENIC), 1.1.463.6 (usnic_verbs), 1.10.2cisco1.0.463.6 (openmpi), 1.1.1.0cisco1.0.463.6 (usnic_tools), 1.3.0cisco1.1.463.6 (libfabric-cisco), 1.3.0cisco1.1.463.6 (libfabric-cisco-dev), 2.0.2.463.6 (libusnic_verbs), 1.1.463.6 (usd_tools)	21, 33
usNIC	1240/1340 and Port Expander Card, 1280/1380, 1225/1225T, 1227/1227T, 1385/1387 Virtual Interface Card	Ubuntu 14.04.3	2.3.0.20 (ENIC), 1.1.463.6 (usnic_verbs), 1.10.2cisco1.0.463.6 (openmpi), 1.1.1.0cisco1.0.463.6 (usnic_tools), 1.3.0cisco1.1.463.6 (libfabric-cisco), 1.3.0cisco1.1.463.6 (libfabric-cisco-dev), 2.0.2.463.6 (libusnic_verbs), 1.1.463.6 (usd_tools)	21, 33

Software Type	Adapter Model	Operating System	Driver	Notes
usNIC	1240/1340 and Port Expander Card, 1280/1380, 1225/1225T, 1227/1227T, 1385/1387 Virtual Interface Card	Ubuntu 14.04.4	2.3.0.27 (ENIC), 1.1.463.7 (usnic_verbs), 1.10.2cisco1.0.463.7 (openmpi), 1.1.1.0cisco1.0.463.7 (usnic_tools), 1.3.0cisco1.1.463.7 (libfabric-cisco), 1.3.0cisco1.1.463.7 (libfabric-cisco-dev), 2.0.2.463.7 (libusnic_verbs), 1.1.463.7 (usd_tools)	21, 33
usNIC	1240/1340 and Port Expander Card, 1280/1380, 1225/1225T, 1227/1227T, 1385/1387 Virtual Interface Card	Ubuntu 16.04	2.3.0.27 (ENIC), 1.1.463.7 (usnic_verbs), 1.10.2cisco1.0.463.7 (openmpi), 1.1.1.0cisco1.0.463.7 (usnic_tools), 1.3.0cisco1.1.463.7 (libfabric-cisco), 1.3.0cisco1.1.463.7 (libfabric-cisco-dev), 2.0.2.463.7 (libusnic_verbs), 1.1.463.7 (usd_tools)	21, 33

Converged Network Adapter Interoperability Matrix

Table 5 lists the converged network adapters that the Unified Computing System B Series Servers support.

Table 5: Converged Network Adapters

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B200 M3 w/E5-Series	UCS 1340 Virtual Interface Card and Port Expander Card	CentOS 6.5	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	21, 38, 39, 40
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B200 M4 w/E5-Series v3	UCS 1340 Virtual Interface Card and Port Expander Card	CentOS 6.5	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	21, 38, 39, 40

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS 1340 Virtual Interface Card and Port Expander Card	CentOS 6.6	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	21, 38, 39, 40
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1340 Virtual Interface Card and Port Expander Card	CentOS 6.6	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	21, 38, 39, 40
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS 1340 Virtual Interface Card and Port Expander Card	CentOS 6.7	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	21, 38, 39, 40
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1340 Virtual Interface Card and Port Expander Card	CentOS 6.7	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	21, 38, 39, 40
B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	UCS 1340 Virtual Interface Card and Port Expander Card	CentOS 6.7	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	21, 38, 39, 40
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS 1340 Virtual Interface Card and Port Expander Card	CentOS 6.8	1.6.0.27 (FNIC) / 2.3.0.30 (ENIC)	4.1(1)	21, 38, 39, 40
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1340 Virtual Interface Card and Port Expander Card	CentOS 6.8	1.6.0.27 (FNIC) / 2.3.0.30 (ENIC)	4.1(1)	21, 38, 39, 40
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	UCS 1340 Virtual Interface Card and Port Expander Card	CentOS 6.8	1.6.0.27 (FNIC) / 2.3.0.30 (ENIC)	4.1(1)	21, 38, 39, 40

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS 1340 Virtual Interface Card and Port Expander Card	CentOS 7.1	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	21, 38, 39, 40
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1340 Virtual Interface Card and Port Expander Card	CentOS 7.1	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	21, 38, 39, 40
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS 1340 Virtual Interface Card and Port Expander Card	CentOS 7.2	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	21, 38, 39, 40
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1340 Virtual Interface Card and Port Expander Card	CentOS 7.2	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	21, 38, 39, 40
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	UCS 1340 Virtual Interface Card and Port Expander Card	CentOS 7.2	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	21, 38, 39, 40
B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1340 Virtual Interface Card and Port Expander Card	UEK R2 U5 (2.6.39-400.x)	1.6.0.25 (FNIC) / 2.1.1.39 (ENIC)	4.1(1)	21, 38
B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1340 Virtual Interface Card and Port Expander Card	UEK R3 U1 (3.8.13-26.x)	1.6.0.25 (FNIC) / 2.1.1.39 (ENIC)	4.1(1)	21, 38

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2, B200 M4 w/E5-Series v3	UCS 1340 Virtual Interface Card and Port Expander Card	UEK R3 U1 (3.8.13-26.x)	1.6.0.25 (FNIC) / 2.1.1.39 (ENIC)	4.1(1)	21, 38
B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1340 Virtual Interface Card and Port Expander Card	UEK R3 U3 (3.8.13-44.x)	1.6.0.25 (FNIC) / 2.1.1.50 (ENIC)	4.1(1)	21, 38
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2, B200 M4 w/E5-Series v3	UCS 1340 Virtual Interface Card and Port Expander Card	UEK R3 U3 (3.8.13-44.x)	1.6.0.25 (FNIC) / 2.1.1.50 (ENIC)	4.1(1)	21, 38
B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1340 Virtual Interface Card and Port Expander Card	UEK R3 U5 (3.8.13-68.x)	1.6.0.25 (FNIC) / 2.1.1.67 (ENIC)	4.1(1)	21, 38
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1340 Virtual Interface Card and Port Expander Card	UEK R3 U5 (3.8.13-68.x)	1.6.0.25 (FNIC) / 2.1.1.67 (ENIC)	4.1(1)	21, 38
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1340 Virtual Interface Card and Port Expander Card	UEK R3 U5 (3.8.13-68.x)	1.6.0.25 (FNIC) / 2.1.1.67 (ENIC)	4.1(1)	21, 38
B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1340 Virtual Interface Card and Port Expander Card	UEK R3 U6 (3.8.13-98.x)	1.6.0.25 (FNIC) / 2.1.1.67 (ENIC)	4.1(1)	21, 38

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1340 Virtual Interface Card and Port Expander Card	UEK R3 U6 (3.8.13-98.x)	1.6.0.25 (FNIC) / 2.1.1.67 (ENIC)	4.1(1)	21, 38
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1340 Virtual Interface Card and Port Expander Card	UEK R3 U6 (3.8.13-98.x)	1.6.0.25 (FNIC) / 2.1.1.67 (ENIC)	4.1(1)	21, 38
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2, B200 M4 w/E5-Series v3	UCS 1340 Virtual Interface Card and Port Expander Card	UEK R3 U7 (3.8.13-118)	1.6.0.25 (FNIC) / 2.1.1.67 (ENIC)	4.1(1)	21, 38
B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1340 Virtual Interface Card and Port Expander Card	UEK R4 (4.1.12-32.x)	1.6.0.22 (FNIC) / 2.1.1.67 (ENIC)	4.1(1)	38, 43
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1340 Virtual Interface Card and Port Expander Card	UEK R4 (4.1.12-32.x)	1.6.0.22 (FNIC) / 2.1.1.67 (ENIC)	4.1(1)	38, 43
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1340 Virtual Interface Card and Port Expander Card	UEK R4 (4.1.12-32.x)	1.6.0.22 (FNIC) / 2.1.1.67 (ENIC)	4.1(1)	38, 43
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	UCS 1340 Virtual Interface Card and Port Expander Card	UEK R4 (4.1.12-32.x)	1.6.0.22 (FNIC) / 2.1.1.67 (ENIC)	4.1(1)	38, 43

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1340 Virtual Interface Card and Port Expander Card	UEK R4 U1 (4.1.12-37.x)	1.6.0.24 (FNIC) / 2.3.0.12 (ENIC)	4.1(1)	38, 43
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1340 Virtual Interface Card and Port Expander Card	UEK R4 U1 (4.1.12-37.x)	1.6.0.24 (FNIC) / 2.3.0.12 (ENIC)	4.1(1)	38, 43
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1340 Virtual Interface Card and Port Expander Card	UEK R4 U1 (4.1.12-37.x)	1.6.0.24 (FNIC) / 2.3.0.12 (ENIC)	4.1(1)	38, 43
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	UCS 1340 Virtual Interface Card and Port Expander Card	UEK R4 U1 (4.1.12-37.x)	1.6.0.24 (FNIC) / 2.3.0.12 (ENIC)	4.1(1)	38, 43
B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1340 Virtual Interface Card and Port Expander Card	UEK R4 U2 (4.1.12-61.x)	1.6.0.24 (FNIC) / 2.3.0.12 (ENIC)	4.1(1)	38, 43
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1340 Virtual Interface Card and Port Expander Card	UEK R4 U2 (4.1.12-61.x)	1.6.0.24 (FNIC) / 2.3.0.12 (ENIC)	4.1(1)	38, 43
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1340 Virtual Interface Card and Port Expander Card	UEK R4 U2 (4.1.12-61.x)	1.6.0.24 (FNIC) / 2.3.0.12 (ENIC)	4.1(1)	38, 43

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	UCS 1340 Virtual Interface Card and Port Expander Card	UEK R4 U2 (4.1.12-61.x)	1.6.0.24 (FNIC) / 2.3.0.12 (ENIC)	4.1(1)	38, 43
B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1340 Virtual Interface Card and Port Expander Card	OVM 3.3.1	1.6.0.9 (FNIC) / 2.1.1.39 (ENIC)	4.1(1)	38, 43
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2, B200 M4 w/E5-Series v3	UCS 1340 Virtual Interface Card and Port Expander Card	OVM 3.3.1	1.6.0.9 (FNIC) / 2.1.1.39 (ENIC)	4.1(1)	38, 43
B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1340 Virtual Interface Card and Port Expander Card	OVM 3.3.2	1.6.0.10 (FNIC) / 2.1.1.50 (ENIC)	4.1(1)	38, 43
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1340 Virtual Interface Card and Port Expander Card	OVM 3.3.2	1.6.0.10 (FNIC) / 2.1.1.50 (ENIC)	4.1(1)	38, 43
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1340 Virtual Interface Card and Port Expander Card	OVM 3.3.2	1.6.0.10 (FNIC) / 2.1.1.50 (ENIC)	4.1(1)	38, 43
B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1340 Virtual Interface Card and Port Expander Card	OVM 3.3.3	1.6.0.10 (FNIC) / 2.1.1.67 (ENIC)	4.1(1)	38, 43, 45

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1340 Virtual Interface Card and Port Expander Card	OVM 3.3.3	1.6.0.10 (FNIC) / 2.1.1.67 (ENIC)	4.1(1)	38, 43, 45
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1340 Virtual Interface Card and Port Expander Card	OVM 3.3.3	1.6.0.10 (FNIC) / 2.1.1.67 (ENIC)	4.1(1)	38, 43, 45
B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1340 Virtual Interface Card and Port Expander Card	OVM 3.3.4	1.6.0.18 (FNIC) / 2.1.1.67 (ENIC)	4.1(1)	38, 43, 45
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1340 Virtual Interface Card and Port Expander Card	OVM 3.3.4	1.6.0.18 (FNIC) / 2.1.1.67 (ENIC)	4.1(1)	38, 43, 45
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1340 Virtual Interface Card and Port Expander Card	OVM 3.3.4	1.6.0.18 (FNIC) / 2.1.1.67 (ENIC)	4.1(1)	38, 43, 45
B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1340 Virtual Interface Card and Port Expander Card	OVM 3.4.1	1.6.0.22 (FNIC) / 2.3.0.12 (ENIC)	4.1(1)	38, 43
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1340 Virtual Interface Card and Port Expander Card	OVM 3.4.1	1.6.0.22 (FNIC) / 2.3.0.12 (ENIC)	4.1(1)	38, 43

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1340 Virtual Interface Card and Port Expander Card	OVM 3.4.1	1.6.0.22 (FNIC) / 2.3.0.12 (ENIC)	4.1(1)	38, 43
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	UCS 1340 Virtual Interface Card and Port Expander Card	OVM 3.4.1	1.6.0.22 (FNIC) / 2.3.0.12 (ENIC)	4.1(1)	38, 43
B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1340 Virtual Interface Card and Port Expander Card	OVM 3.4.2	1.6.0.22 (FNIC) / 2.3.0.12 (ENIC)	4.1(1)	38, 43
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1340 Virtual Interface Card and Port Expander Card	OVM 3.4.2	1.6.0.22 (FNIC) / 2.3.0.12 (ENIC)	4.1(1)	38, 43
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1340 Virtual Interface Card and Port Expander Card	OVM 3.4.2	1.6.0.22 (FNIC) / 2.3.0.12 (ENIC)	4.1(1)	38, 43
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	UCS 1340 Virtual Interface Card and Port Expander Card	OVM 3.4.2	1.6.0.22 (FNIC) / 2.3.0.12 (ENIC)	4.1(1)	38, 43
B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1340 Virtual Interface Card and Port Expander Card	Red Hat Enterprise Linux 6.4	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	21, 27, 38

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS 1340 Virtual Interface Card and Port Expander Card	Red Hat Enterprise Linux 6.4	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	21, 27, 38
B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1340 Virtual Interface Card and Port Expander Card	Red Hat Enterprise Linux 6.5	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	21, 38
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2, B200 M4 w/E5-Series v3	UCS 1340 Virtual Interface Card and Port Expander Card	Red Hat Enterprise Linux 6.5	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	21, 38
B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1340 Virtual Interface Card and Port Expander Card	Red Hat Enterprise Linux 6.6	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	21, 38
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1340 Virtual Interface Card and Port Expander Card	Red Hat Enterprise Linux 6.6	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	21, 38
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1340 Virtual Interface Card and Port Expander Card	Red Hat Enterprise Linux 6.6	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	21, 38
B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1340 Virtual Interface Card and Port Expander Card	Red Hat Enterprise Linux 6.7	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	21, 38

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1340 Virtual Interface Card and Port Expander Card	Red Hat Enterprise Linux 6.7	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	21, 38
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1340 Virtual Interface Card and Port Expander Card	Red Hat Enterprise Linux 6.7	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	21, 38
B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	UCS 1340 Virtual Interface Card and Port Expander Card	Red Hat Enterprise Linux 6.7	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	21, 38
B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1340 Virtual Interface Card and Port Expander Card	Red Hat Enterprise Linux 6.8	1.6.0.27 (FNIC) / 2.3.0.27 (ENIC)	4.1(1)	21, 38
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1340 Virtual Interface Card and Port Expander Card	Red Hat Enterprise Linux 6.8	1.6.0.27 (FNIC) / 2.3.0.27 (ENIC)	4.1(1)	21, 38
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1340 Virtual Interface Card and Port Expander Card	Red Hat Enterprise Linux 6.8	1.6.0.27 (FNIC) / 2.3.0.27 (ENIC)	4.1(1)	21, 38
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	UCS 1340 Virtual Interface Card and Port Expander Card	Red Hat Enterprise Linux 6.8	1.6.0.27 (FNIC) / 2.3.0.27 (ENIC)	4.1(1)	21, 38

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1340 Virtual Interface Card and Port Expander Card	Red Hat Enterprise Linux 7.0	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	21, 38
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2, B200 M4 w/E5-Series v3	UCS 1340 Virtual Interface Card and Port Expander Card	Red Hat Enterprise Linux 7.0	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	21, 38
B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1340 Virtual Interface Card and Port Expander Card	Red Hat Enterprise Linux 7.1	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	21, 38
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1340 Virtual Interface Card and Port Expander Card	Red Hat Enterprise Linux 7.1	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	21, 38
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1340 Virtual Interface Card and Port Expander Card	Red Hat Enterprise Linux 7.1	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	21, 38
B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1340 Virtual Interface Card and Port Expander Card	Red Hat Enterprise Linux 7.2	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	21, 38
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1340 Virtual Interface Card and Port Expander Card	Red Hat Enterprise Linux 7.2	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	21, 38

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1340 Virtual Interface Card and Port Expander Card	Red Hat Enterprise Linux 7.2	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	21, 38
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	UCS 1340 Virtual Interface Card and Port Expander Card	Red Hat Enterprise Linux 7.2	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	21, 38
B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1340 Virtual Interface Card and Port Expander Card	Red Hat Enterprise Linux 7.3	1.6.0.30 (FNIC) / 2.3.0.30 (ENIC)	4.1(1)	21, 38
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1340 Virtual Interface Card and Port Expander Card	Red Hat Enterprise Linux 7.3	1.6.0.30 (FNIC) / 2.3.0.30 (ENIC)	4.1(1)	21, 38
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1340 Virtual Interface Card and Port Expander Card	Red Hat Enterprise Linux 7.3	1.6.0.30 (FNIC) / 2.3.0.30 (ENIC)	4.1(1)	21, 38
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	UCS 1340 Virtual Interface Card and Port Expander Card	Red Hat Enterprise Linux 7.3	1.6.0.30 (FNIC) / 2.3.0.30 (ENIC)	4.1(1)	21, 38
B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1340 Virtual Interface Card and Port Expander Card	SUSE Linux Enterprise Server 11.3	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	12, 21, 38

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1340 Virtual Interface Card and Port Expander Card	SUSE Linux Enterprise Server 11.3	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	12, 21, 38
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1340 Virtual Interface Card and Port Expander Card	SUSE Linux Enterprise Server 11.3	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	12, 21, 38
B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1340 Virtual Interface Card and Port Expander Card	SUSE Linux Enterprise Server 11.4	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	12, 21, 38
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1340 Virtual Interface Card and Port Expander Card	SUSE Linux Enterprise Server 11.4	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	12, 21, 38
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1340 Virtual Interface Card and Port Expander Card	SUSE Linux Enterprise Server 11.4	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	12, 21, 38
B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1340 Virtual Interface Card and Port Expander Card	SUSE Linux Enterprise Server 12	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	12, 21, 38
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1340 Virtual Interface Card and Port Expander Card	SUSE Linux Enterprise Server 12	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	12, 21, 38

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1340 Virtual Interface Card and Port Expander Card	SUSE Linux Enterprise Server 12	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	12, 21, 38
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	UCS 1340 Virtual Interface Card and Port Expander Card	SUSE Linux Enterprise Server 12	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	12, 21, 38
B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1340 Virtual Interface Card and Port Expander Card	SUSE Linux Enterprise Server 12.1	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	12, 21, 38
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1340 Virtual Interface Card and Port Expander Card	SUSE Linux Enterprise Server 12.1	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	12, 21, 38
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1340 Virtual Interface Card and Port Expander Card	SUSE Linux Enterprise Server 12.1	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	12, 21, 38
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	UCS 1340 Virtual Interface Card and Port Expander Card	SUSE Linux Enterprise Server 12.1	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	12, 21, 38
B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1340 Virtual Interface Card and Port Expander Card	SUSE Linux Enterprise Server 12.2	1.6.0.21 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	12, 38, 43

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1340 Virtual Interface Card and Port Expander Card	SUSE Linux Enterprise Server 12.2	1.6.0.21 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	12, 38, 43
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1340 Virtual Interface Card and Port Expander Card	SUSE Linux Enterprise Server 12.2	1.6.0.21 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	12, 38, 43
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	UCS 1340 Virtual Interface Card and Port Expander Card	SUSE Linux Enterprise Server 12.2	1.6.0.21 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	12, 38, 43
B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1340 Virtual Interface Card and Port Expander Card	Ubuntu 12.04.4	2.1.1.39 (ENIC)	4.1(1)	3, 38, 43
B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1340 Virtual Interface Card and Port Expander Card	Ubuntu 14.04	2.1.1.50 (ENIC)	4.1(1)	3, 38, 43
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2, B200 M4 w/E5-Series v3	UCS 1340 Virtual Interface Card and Port Expander Card	Ubuntu 14.04.1	2.1.1.50 (ENIC)	4.1(1)	3, 38, 43
B200 M3 w/E5-Series	UCS 1340 Virtual Interface Card and Port Expander Card	Ubuntu 14.04.2	2.3.0.20 (ENIC)	4.1(1)	3, 21, 38

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1340 Virtual Interface Card and Port Expander Card	Ubuntu 14.04.2	2.3.0.20 (ENIC)	4.1(1)	3, 21, 38
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1340 Virtual Interface Card and Port Expander Card	Ubuntu 14.04.2	2.3.0.20 (ENIC)	4.1(1)	3, 21, 38
B200 M3 w/E5-Series	UCS 1340 Virtual Interface Card and Port Expander Card	Ubuntu 14.04.3	2.3.0.20 (ENIC)	4.1(1)	3, 21, 38
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1340 Virtual Interface Card and Port Expander Card	Ubuntu 14.04.3	2.3.0.20 (ENIC)	4.1(1)	3, 21, 38
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1340 Virtual Interface Card and Port Expander Card	Ubuntu 14.04.3	2.3.0.20 (ENIC)	4.1(1)	3, 21, 38
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1340 Virtual Interface Card and Port Expander Card	Ubuntu 14.04.4	2.3.0.27 (ENIC)	4.1(1)	3, 21, 38
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS 1340 Virtual Interface Card and Port Expander Card	Ubuntu 14.04.4	2.3.0.27 (ENIC)	4.1(1)	3, 21, 38

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1340 Virtual Interface Card and Port Expander Card	Ubuntu 14.04.4	2.3.0.27 (ENIC)	4.1(1)	3, 21, 38
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1340 Virtual Interface Card and Port Expander Card	Ubuntu 14.04.4	2.3.0.27 (ENIC)	4.1(1)	3, 21, 38
B200 M4 w/E5-Series v4	UCS 1340 Virtual Interface Card and Port Expander Card	Ubuntu 14.04.4	2.3.0.27 (ENIC)	4.1(1)	3, 21, 38
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1340 Virtual Interface Card and Port Expander Card	Ubuntu 14.04.5	2.3.0.30 (ENIC)	4.1(1)	3, 21, 38
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS 1340 Virtual Interface Card and Port Expander Card	Ubuntu 14.04.5	2.3.0.30 (ENIC)	4.1(1)	3, 21, 38
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1340 Virtual Interface Card and Port Expander Card	Ubuntu 14.04.5	2.3.0.30 (ENIC)	4.1(1)	3, 21, 38
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1340 Virtual Interface Card and Port Expander Card	Ubuntu 14.04.5	2.3.0.30 (ENIC)	4.1(1)	3, 21, 38
B200 M4 w/E5-Series v4	UCS 1340 Virtual Interface Card and Port Expander Card	Ubuntu 14.04.5	2.3.0.30 (ENIC)	4.1(1)	3, 21, 38

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1340 Virtual Interface Card and Port Expander Card	Ubuntu 16.04	2.3.0.27 (ENIC)	4.1(1)	3, 38, 43
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS 1340 Virtual Interface Card and Port Expander Card	Ubuntu 16.04	2.3.0.27 (ENIC)	4.1(1)	3, 38, 43
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1340 Virtual Interface Card and Port Expander Card	Ubuntu 16.04	2.3.0.27 (ENIC)	4.1(1)	3, 38, 43
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1340 Virtual Interface Card and Port Expander Card	Ubuntu 16.04	2.3.0.27 (ENIC)	4.1(1)	3, 38, 43
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	UCS 1340 Virtual Interface Card and Port Expander Card	Ubuntu 16.04	2.3.0.27 (ENIC)	4.1(1)	3, 38, 43
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1340 Virtual Interface Card and Port Expander Card	Ubuntu 16.04.1	2.3.0.30 (ENIC)	4.1(1)	3, 21, 38
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS 1340 Virtual Interface Card and Port Expander Card	Ubuntu 16.04.1	2.3.0.30 (ENIC)	4.1(1)	3, 21, 38
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1340 Virtual Interface Card and Port Expander Card	Ubuntu 16.04.1	2.3.0.30 (ENIC)	4.1(1)	3, 21, 38

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1340 Virtual Interface Card and Port Expander Card	Ubuntu 16.04.1	2.3.0.30 (ENIC)	4.1(1)	3, 21, 38
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	UCS 1340 Virtual Interface Card and Port Expander Card	Ubuntu 16.04.1	2.3.0.30 (ENIC)	4.1(1)	3, 21, 38
B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1340 Virtual Interface Card and Port Expander Card	vSphere 5.0 U2	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 31, 38, 52, 53, 54
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS 1340 Virtual Interface Card and Port Expander Card	vSphere 5.0 U2	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 31, 38, 52, 53, 54
B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1340 Virtual Interface Card and Port Expander Card	vSphere 5.0 U3	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 31, 38, 52, 53, 54
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS 1340 Virtual Interface Card and Port Expander Card	vSphere 5.0 U3	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 31, 38, 52, 53, 54
B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1340 Virtual Interface Card and Port Expander Card	vSphere 5.1 U1	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 31, 38, 52, 53, 54
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS 1340 Virtual Interface Card and Port Expander Card	vSphere 5.1 U1	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 31, 38, 52, 53, 54
B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1340 Virtual Interface Card and Port Expander Card	vSphere 5.1 U2	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 31, 38, 52, 53, 54

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2, B200 M4 w/E5-Series v3	UCS 1340 Virtual Interface Card and Port Expander Card	vSphere 5.1 U2	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 31, 38, 52, 53, 54
B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1340 Virtual Interface Card and Port Expander Card	vSphere 5.1 U3	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 31, 38, 52, 53, 54
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1340 Virtual Interface Card and Port Expander Card	vSphere 5.1 U3	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 31, 38, 52, 53, 54
B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1340 Virtual Interface Card and Port Expander Card	vSphere 5.5	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 31, 38, 52, 53, 54
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1340 Virtual Interface Card and Port Expander Card	vSphere 5.5	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 31, 38, 52, 53, 54
B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1340 Virtual Interface Card and Port Expander Card	vSphere 5.5 U1	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 31, 38, 52, 53, 54
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1340 Virtual Interface Card and Port Expander Card	vSphere 5.5 U1	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 31, 38, 52, 53, 54

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1340 Virtual Interface Card and Port Expander Card	vSphere 5.5 U2	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 31, 38, 52, 53, 54
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1340 Virtual Interface Card and Port Expander Card	vSphere 5.5 U2	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 31, 38, 52, 53, 54
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1340 Virtual Interface Card and Port Expander Card	vSphere 5.5 U2	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 31, 38, 52, 53, 54
B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1340 Virtual Interface Card and Port Expander Card	vSphere 5.5 U3	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 31, 38, 52, 53, 54
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1340 Virtual Interface Card and Port Expander Card	vSphere 5.5 U3	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 31, 38, 52, 53, 54
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1340 Virtual Interface Card and Port Expander Card	vSphere 5.5 U3	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 31, 38, 52, 53, 54
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	UCS 1340 Virtual Interface Card and Port Expander Card	vSphere 5.5 U3	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 31, 38, 52, 53, 54

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1340 Virtual Interface Card and Port Expander Card	vSphere 6.0	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 31, 38, 52, 53, 54
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1340 Virtual Interface Card and Port Expander Card	vSphere 6.0	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 31, 38, 52, 53, 54
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1340 Virtual Interface Card and Port Expander Card	vSphere 6.0	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 31, 38, 52, 53, 54
B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1340 Virtual Interface Card and Port Expander Card	vSphere 6.0 U1	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 31, 38, 52, 53, 54
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1340 Virtual Interface Card and Port Expander Card	vSphere 6.0 U1	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 31, 38, 52, 53, 54
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1340 Virtual Interface Card and Port Expander Card	vSphere 6.0 U1	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 31, 38, 52, 53, 54
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	UCS 1340 Virtual Interface Card and Port Expander Card	vSphere 6.0 U1	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 31, 38, 52, 53, 54

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1340 Virtual Interface Card and Port Expander Card	vSphere 6.0 U2	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 31, 38, 52, 53, 54
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1340 Virtual Interface Card and Port Expander Card	vSphere 6.0 U2	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 31, 38, 52, 53, 54
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1340 Virtual Interface Card and Port Expander Card	vSphere 6.0 U2	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 31, 38, 52, 53, 54
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	UCS 1340 Virtual Interface Card and Port Expander Card	vSphere 6.0 U2	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 31, 38, 52, 53, 54
B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1340 Virtual Interface Card and Port Expander Card	vSphere 6.5	1.6.0.28 (FNIC) / 1.0.0.2 (NENIC)	4.1(1)	11, 12, 31, 38, 46, 59
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1340 Virtual Interface Card and Port Expander Card	vSphere 6.5	1.6.0.28 (FNIC) / 1.0.0.2 (NENIC)	4.1(1)	11, 12, 31, 38, 46, 59
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1340 Virtual Interface Card and Port Expander Card	vSphere 6.5	1.6.0.28 (FNIC) / 1.0.0.2 (NENIC)	4.1(1)	11, 12, 31, 38, 46, 59

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	UCS 1340 Virtual Interface Card and Port Expander Card	vSphere 6.5	1.6.0.28 (FNIC) / 1.0.0.2 (NENIC)	4.1(1)	11, 12, 31, 38, 46, 59
B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1340 Virtual Interface Card and Port Expander Card	Windows Server 2008 R2 SP1	2.1.0.34 (FNIC) / 2.4.0.21 (ENIC) / 2.1.0.12 (NIC Teaming Driver)	4.1(1)	12, 21, 25, 38, 53, 55
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1340 Virtual Interface Card and Port Expander Card	Windows Server 2008 R2 SP1	2.1.0.34 (FNIC) / 2.4.0.21 (ENIC) / 2.1.0.12 (NIC Teaming Driver)	4.1(1)	12, 21, 25, 38, 53, 55
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1340 Virtual Interface Card and Port Expander Card	Windows Server 2008 R2 SP1	2.1.0.34 (FNIC) / 2.4.0.21 (ENIC) / 2.1.0.12 (NIC Teaming Driver)	4.1(1)	12, 21, 25, 38, 53, 55
B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1340 Virtual Interface Card and Port Expander Card	Windows Server 2008 R2 SP1	2.4.0.19 (FNIC) / 3.5.0.17 (ENIC)	4.1(1)	12, 21, 35, 38, 56, 57
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1340 Virtual Interface Card and Port Expander Card	Windows Server 2012	2.4.0.19 (FNIC) / 3.5.0.17 (ENIC)	4.1(1)	12, 21, 35, 38, 56, 57
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1340 Virtual Interface Card and Port Expander Card	Windows Server 2012	2.4.0.19 (FNIC) / 3.5.0.17 (ENIC)	4.1(1)	12, 21, 35, 38, 56, 57

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	UCS 1340 Virtual Interface Card and Port Expander Card	Windows Server 2012	2.4.0.19 (FNIC) / 3.5.0.17 (ENIC)	4.1(1)	12, 21, 35, 38, 56, 57
B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1340 Virtual Interface Card and Port Expander Card	Windows Server 2012 R2	2.4.0.19 (FNIC) / 3.5.0.17 (ENIC)	4.1(1)	10, 12, 21, 35, 38, 56, 57
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1340 Virtual Interface Card and Port Expander Card	Windows Server 2012 R2	2.4.0.19 (FNIC) / 3.5.0.17 (ENIC)	4.1(1)	10, 12, 21, 35, 38, 56, 57
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1340 Virtual Interface Card and Port Expander Card	Windows Server 2012 R2	2.4.0.19 (FNIC) / 3.5.0.17 (ENIC)	4.1(1)	10, 12, 21, 35, 38, 56, 57
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	UCS 1340 Virtual Interface Card and Port Expander Card	Windows Server 2012 R2	2.4.0.19 (FNIC) / 3.5.0.17 (ENIC)	4.1(1)	10, 12, 21, 35, 38, 56, 57
B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1340 Virtual Interface Card and Port Expander Card	Windows Server 2016	3.0.0.7 (FNIC) / 4.0.0.2 (ENIC)	4.1(2)	10, 12, 21, 38, 46
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1340 Virtual Interface Card and Port Expander Card	Windows Server 2016	3.0.0.7 (FNIC) / 4.0.0.2 (ENIC)	4.1(2)	10, 12, 21, 38, 46

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1340 Virtual Interface Card and Port Expander Card	Windows Server 2016	3.0.0.7 (FNIC) / 4.0.0.2 (ENIC)	4.1(2)	10, 12, 21, 38, 46
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	UCS 1340 Virtual Interface Card and Port Expander Card	Windows Server 2016	3.0.0.7 (FNIC) / 4.0.0.2 (ENIC)	4.1(2)	10, 12, 21, 38, 46
B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1340 Virtual Interface Card and Port Expander Card	XenServer 6.1	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	4, 21, 29, 38
B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1340 Virtual Interface Card and Port Expander Card	XenServer 6.2	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	21, 38
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2, B200 M4 w/E5-Series v3	UCS 1340 Virtual Interface Card and Port Expander Card	XenServer 6.2	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	21, 38
B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1340 Virtual Interface Card and Port Expander Card	XenServer 6.5	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	21, 38, 41
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1340 Virtual Interface Card and Port Expander Card	XenServer 6.5	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	21, 38, 41

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1340 Virtual Interface Card and Port Expander Card	XenServer 6.5	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	21, 38, 41
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	UCS 1340 Virtual Interface Card and Port Expander Card	XenServer 6.5	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	21, 38, 41
B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1340 Virtual Interface Card and Port Expander Card	XenServer 7.0	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	38, 43
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1340 Virtual Interface Card and Port Expander Card	XenServer 7.0	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	38, 43
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1340 Virtual Interface Card and Port Expander Card	XenServer 7.0	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	38, 43
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	UCS 1340 Virtual Interface Card and Port Expander Card	XenServer 7.0	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	38, 43
B200 M3 w/E5-Series	UCS 1380 Virtual Interface Card	CentOS 6.5	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	21, 38, 39, 40
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B200 M4 w/E5-Series v3	UCS 1380 Virtual Interface Card	CentOS 6.5	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	21, 38, 39, 40

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS 1380 Virtual Interface Card	CentOS 6.6	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	21, 38, 39, 40
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1380 Virtual Interface Card	CentOS 6.6	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	21, 38, 39, 40
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS 1380 Virtual Interface Card	CentOS 6.7	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	21, 38, 39, 40
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1380 Virtual Interface Card	CentOS 6.7	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	21, 38, 39, 40
B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	UCS 1380 Virtual Interface Card	CentOS 6.7	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	21, 38, 39, 40
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS 1380 Virtual Interface Card	CentOS 6.8	1.6.0.27 (FNIC) / 2.3.0.30 (ENIC)	4.1(1)	21, 38, 39, 40
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1380 Virtual Interface Card	CentOS 6.8	1.6.0.27 (FNIC) / 2.3.0.30 (ENIC)	4.1(1)	21, 38, 39, 40
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	UCS 1380 Virtual Interface Card	CentOS 6.8	1.6.0.27 (FNIC) / 2.3.0.30 (ENIC)	4.1(1)	21, 38, 39, 40
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS 1380 Virtual Interface Card	CentOS 7.1	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	21, 38, 39, 40

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1380 Virtual Interface Card	CentOS 7.1	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	21, 38, 39, 40
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS 1380 Virtual Interface Card	CentOS 7.2	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	21, 38, 39, 40
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1380 Virtual Interface Card	CentOS 7.2	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	21, 38, 39, 40
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	UCS 1380 Virtual Interface Card	CentOS 7.2	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	21, 38, 39, 40
B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1380 Virtual Interface Card	UEK R2 U5 (2.6.39-400.x)	1.6.0.25 (FNIC) / 2.1.1.39 (ENIC)	4.1(1)	21, 38
B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1380 Virtual Interface Card	UEK R3 U1 (3.8.13-26.x)	1.6.0.25 (FNIC) / 2.1.1.39 (ENIC)	4.1(1)	21, 38
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2, B200 M4 w/E5-Series v3	UCS 1380 Virtual Interface Card	UEK R3 U1 (3.8.13-26.x)	1.6.0.25 (FNIC) / 2.1.1.39 (ENIC)	4.1(1)	21, 38
B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1380 Virtual Interface Card	UEK R3 U3 (3.8.13-44.x)	1.6.0.25 (FNIC) / 2.1.1.50 (ENIC)	4.1(1)	21, 38

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2, B200 M4 w/E5-Series v3	UCS 1380 Virtual Interface Card	UEK R3 U3 (3.8.13-44.x)	1.6.0.25 (FNIC) / 2.1.1.50 (ENIC)	4.1(1)	21, 38
B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1380 Virtual Interface Card	UEK R3 U5 (3.8.13-68.x)	1.6.0.25 (FNIC) / 2.1.1.67 (ENIC)	4.1(1)	21, 38
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1380 Virtual Interface Card	UEK R3 U5 (3.8.13-68.x)	1.6.0.25 (FNIC) / 2.1.1.67 (ENIC)	4.1(1)	21, 38
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1380 Virtual Interface Card	UEK R3 U5 (3.8.13-68.x)	1.6.0.25 (FNIC) / 2.1.1.67 (ENIC)	4.1(1)	21, 38
B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1380 Virtual Interface Card	UEK R3 U6 (3.8.13-98.x)	1.6.0.25 (FNIC) / 2.1.1.67 (ENIC)	4.1(1)	21, 38
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1380 Virtual Interface Card	UEK R3 U6 (3.8.13-98.x)	1.6.0.25 (FNIC) / 2.1.1.67 (ENIC)	4.1(1)	21, 38
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1380 Virtual Interface Card	UEK R3 U6 (3.8.13-98.x)	1.6.0.25 (FNIC) / 2.1.1.67 (ENIC)	4.1(1)	21, 38

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2, B200 M4 w/E5-Series v3	UCS 1380 Virtual Interface Card	UEK R3 U7 (3.8.13-118)	1.6.0.25 (FNIC) / 2.1.1.67 (ENIC)	4.1(1)	21, 38
B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1380 Virtual Interface Card	UEK R4 (4.1.12-32.x)	1.6.0.22 (FNIC) / 2.1.1.67 (ENIC)	4.1(1)	38, 43
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1380 Virtual Interface Card	UEK R4 (4.1.12-32.x)	1.6.0.22 (FNIC) / 2.1.1.67 (ENIC)	4.1(1)	38, 43
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1380 Virtual Interface Card	UEK R4 (4.1.12-32.x)	1.6.0.22 (FNIC) / 2.1.1.67 (ENIC)	4.1(1)	38, 43
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	UCS 1380 Virtual Interface Card	UEK R4 (4.1.12-32.x)	1.6.0.22 (FNIC) / 2.1.1.67 (ENIC)	4.1(1)	38, 43
B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1380 Virtual Interface Card	UEK R4 U1 (4.1.12-37.x)	1.6.0.24 (FNIC) / 2.3.0.12 (ENIC)	4.1(1)	38, 43
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1380 Virtual Interface Card	UEK R4 U1 (4.1.12-37.x)	1.6.0.24 (FNIC) / 2.3.0.12 (ENIC)	4.1(1)	38, 43

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1380 Virtual Interface Card	UEK R4 U1 (4.1.12-37.x)	1.6.0.24 (FNIC) / 2.3.0.12 (ENIC)	4.1(1)	38, 43
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	UCS 1380 Virtual Interface Card	UEK R4 U1 (4.1.12-37.x)	1.6.0.24 (FNIC) / 2.3.0.12 (ENIC)	4.1(1)	38, 43
B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1380 Virtual Interface Card	UEK R4 U2 (4.1.12-61.x)	1.6.0.24 (FNIC) / 2.3.0.12 (ENIC)	4.1(1)	38, 43
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1380 Virtual Interface Card	UEK R4 U2 (4.1.12-61.x)	1.6.0.24 (FNIC) / 2.3.0.12 (ENIC)	4.1(1)	38, 43
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1380 Virtual Interface Card	UEK R4 U2 (4.1.12-61.x)	1.6.0.24 (FNIC) / 2.3.0.12 (ENIC)	4.1(1)	38, 43
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	UCS 1380 Virtual Interface Card	UEK R4 U2 (4.1.12-61.x)	1.6.0.24 (FNIC) / 2.3.0.12 (ENIC)	4.1(1)	38, 43
B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1380 Virtual Interface Card	OVM 3.3.1	1.6.0.9 (FNIC) / 2.1.1.39 (ENIC)	4.1(1)	38, 43

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2, B200 M4 w/E5-Series v3	UCS 1380 Virtual Interface Card	OVM 3.3.1	1.6.0.9 (FNIC) / 2.1.1.39 (ENIC)	4.1(1)	38, 43
B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1380 Virtual Interface Card	OVM 3.3.2	1.6.0.10 (FNIC) / 2.1.1.50 (ENIC)	4.1(1)	38, 43
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1380 Virtual Interface Card	OVM 3.3.2	1.6.0.10 (FNIC) / 2.1.1.50 (ENIC)	4.1(1)	38, 43
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1380 Virtual Interface Card	OVM 3.3.2	1.6.0.10 (FNIC) / 2.1.1.50 (ENIC)	4.1(1)	38, 43
B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1380 Virtual Interface Card	OVM 3.3.3	1.6.0.10 (FNIC) / 2.1.1.67 (ENIC)	4.1(1)	38, 43, 45
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1380 Virtual Interface Card	OVM 3.3.3	1.6.0.10 (FNIC) / 2.1.1.67 (ENIC)	4.1(1)	38, 43, 45
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1380 Virtual Interface Card	OVM 3.3.3	1.6.0.10 (FNIC) / 2.1.1.67 (ENIC)	4.1(1)	38, 43, 45
B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1380 Virtual Interface Card	OVM 3.3.4	1.6.0.18 (FNIC) / 2.1.1.67 (ENIC)	4.1(1)	38, 43, 45

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1380 Virtual Interface Card	OVM 3.3.4	1.6.0.18 (FNIC) / 2.1.1.67 (ENIC)	4.1(1)	38, 43, 45
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1380 Virtual Interface Card	OVM 3.3.4	1.6.0.18 (FNIC) / 2.1.1.67 (ENIC)	4.1(1)	38, 43, 45
B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1380 Virtual Interface Card	OVM 3.4.1	1.6.0.22 (FNIC) / 2.3.0.12 (ENIC)	4.1(1)	38, 43
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1380 Virtual Interface Card	OVM 3.4.1	1.6.0.22 (FNIC) / 2.3.0.12 (ENIC)	4.1(1)	38, 43
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1380 Virtual Interface Card	OVM 3.4.1	1.6.0.22 (FNIC) / 2.3.0.12 (ENIC)	4.1(1)	38, 43
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	UCS 1380 Virtual Interface Card	OVM 3.4.1	1.6.0.22 (FNIC) / 2.3.0.12 (ENIC)	4.1(1)	38, 43
B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1380 Virtual Interface Card	OVM 3.4.2	1.6.0.22 (FNIC) / 2.3.0.12 (ENIC)	4.1(1)	38, 43

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1380 Virtual Interface Card	OVM 3.4.2	1.6.0.22 (FNIC) / 2.3.0.12 (ENIC)	4.1(1)	38, 43
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1380 Virtual Interface Card	OVM 3.4.2	1.6.0.22 (FNIC) / 2.3.0.12 (ENIC)	4.1(1)	38, 43
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	UCS 1380 Virtual Interface Card	OVM 3.4.2	1.6.0.22 (FNIC) / 2.3.0.12 (ENIC)	4.1(1)	38, 43
B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1380 Virtual Interface Card	Red Hat Enterprise Linux 6.4	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	21, 27, 38
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS 1380 Virtual Interface Card	Red Hat Enterprise Linux 6.4	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	21, 27, 38
B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1380 Virtual Interface Card	Red Hat Enterprise Linux 6.5	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	21, 38
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2, B200 M4 w/E5-Series v3	UCS 1380 Virtual Interface Card	Red Hat Enterprise Linux 6.5	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	21, 38
B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1380 Virtual Interface Card	Red Hat Enterprise Linux 6.6	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	21, 38

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1380 Virtual Interface Card	Red Hat Enterprise Linux 6.6	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	21, 38
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1380 Virtual Interface Card	Red Hat Enterprise Linux 6.6	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	21, 38
B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1380 Virtual Interface Card	Red Hat Enterprise Linux 6.7	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	21, 38
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1380 Virtual Interface Card	Red Hat Enterprise Linux 6.7	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	21, 38
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1380 Virtual Interface Card	Red Hat Enterprise Linux 6.7	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	21, 38
B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	UCS 1380 Virtual Interface Card	Red Hat Enterprise Linux 6.7	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	21, 38
B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1380 Virtual Interface Card	Red Hat Enterprise Linux 6.8	1.6.0.27 (FNIC) / 2.3.0.27 (ENIC)	4.1(1)	21, 38
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1380 Virtual Interface Card	Red Hat Enterprise Linux 6.8	1.6.0.27 (FNIC) / 2.3.0.27 (ENIC)	4.1(1)	21, 38

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1380 Virtual Interface Card	Red Hat Enterprise Linux 6.8	1.6.0.27 (FNIC) / 2.3.0.27 (ENIC)	4.1(1)	21, 38
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	UCS 1380 Virtual Interface Card	Red Hat Enterprise Linux 6.8	1.6.0.27 (FNIC) / 2.3.0.27 (ENIC)	4.1(1)	21, 38
B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1380 Virtual Interface Card	Red Hat Enterprise Linux 7.0	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	21, 38
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2, B200 M4 w/E5-Series v3	UCS 1380 Virtual Interface Card	Red Hat Enterprise Linux 7.0	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	21, 38
B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1380 Virtual Interface Card	Red Hat Enterprise Linux 7.1	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	21, 38
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1380 Virtual Interface Card	Red Hat Enterprise Linux 7.1	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	21, 38
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1380 Virtual Interface Card	Red Hat Enterprise Linux 7.1	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	21, 38
B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1380 Virtual Interface Card	Red Hat Enterprise Linux 7.2	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	21, 38

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1380 Virtual Interface Card	Red Hat Enterprise Linux 7.2	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	21, 38
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1380 Virtual Interface Card	Red Hat Enterprise Linux 7.2	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	21, 38
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	UCS 1380 Virtual Interface Card	Red Hat Enterprise Linux 7.2	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	21, 38
B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1380 Virtual Interface Card	Red Hat Enterprise Linux 7.3	1.6.0.30 (FNIC) / 2.3.0.30 (ENIC)	4.1(1)	21, 38
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1380 Virtual Interface Card	Red Hat Enterprise Linux 7.3	1.6.0.30 (FNIC) / 2.3.0.30 (ENIC)	4.1(1)	21, 38
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1380 Virtual Interface Card	Red Hat Enterprise Linux 7.3	1.6.0.30 (FNIC) / 2.3.0.30 (ENIC)	4.1(1)	21, 38
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	UCS 1380 Virtual Interface Card	Red Hat Enterprise Linux 7.3	1.6.0.30 (FNIC) / 2.3.0.30 (ENIC)	4.1(1)	21, 38

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1380 Virtual Interface Card	SUSE Linux Enterprise Server 11.3	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	12, 21, 38
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1380 Virtual Interface Card	SUSE Linux Enterprise Server 11.3	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	12, 21, 38
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1380 Virtual Interface Card	SUSE Linux Enterprise Server 11.3	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	12, 21, 38
B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1380 Virtual Interface Card	SUSE Linux Enterprise Server 11.4	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	12, 21, 38
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1380 Virtual Interface Card	SUSE Linux Enterprise Server 11.4	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	12, 21, 38
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1380 Virtual Interface Card	SUSE Linux Enterprise Server 11.4	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	12, 21, 38
B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1380 Virtual Interface Card	SUSE Linux Enterprise Server 12	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	12, 21, 38
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1380 Virtual Interface Card	SUSE Linux Enterprise Server 12	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	12, 21, 38

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1380 Virtual Interface Card	SUSE Linux Enterprise Server 12	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	12, 21, 38
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	UCS 1380 Virtual Interface Card	SUSE Linux Enterprise Server 12	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	12, 21, 38
B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1380 Virtual Interface Card	SUSE Linux Enterprise Server 12.1	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	12, 21, 38
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1380 Virtual Interface Card	SUSE Linux Enterprise Server 12.1	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	12, 21, 38
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1380 Virtual Interface Card	SUSE Linux Enterprise Server 12.1	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	12, 21, 38
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	UCS 1380 Virtual Interface Card	SUSE Linux Enterprise Server 12.1	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	12, 21, 38
B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1380 Virtual Interface Card	SUSE Linux Enterprise Server 12.2	1.6.0.21 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	12, 38, 43

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1380 Virtual Interface Card	SUSE Linux Enterprise Server 12.2	1.6.0.21 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	12, 38, 43
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1380 Virtual Interface Card	SUSE Linux Enterprise Server 12.2	1.6.0.21 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	12, 38, 43
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	UCS 1380 Virtual Interface Card	SUSE Linux Enterprise Server 12.2	1.6.0.21 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	12, 38, 43
B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1380 Virtual Interface Card	Ubuntu 12.04.4	2.1.1.39 (ENIC)	4.1(1)	3, 38, 43
B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1380 Virtual Interface Card	Ubuntu 14.04	2.1.1.50 (ENIC)	4.1(1)	3, 38, 43
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2, B200 M4 w/E5-Series v3	UCS 1380 Virtual Interface Card	Ubuntu 14.04.1	2.1.1.50 (ENIC)	4.1(1)	3, 38, 43
B200 M3 w/E5-Series	UCS 1380 Virtual Interface Card	Ubuntu 14.04.2	2.3.0.20 (ENIC)	4.1(1)	3, 21, 38
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1380 Virtual Interface Card	Ubuntu 14.04.2	2.3.0.20 (ENIC)	4.1(1)	3, 21, 38

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1380 Virtual Interface Card	Ubuntu 14.04.2	2.3.0.20 (ENIC)	4.1(1)	3, 21, 38
B200 M3 w/E5-Series	UCS 1380 Virtual Interface Card	Ubuntu 14.04.3	2.3.0.20 (ENIC)	4.1(1)	3, 21, 38
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1380 Virtual Interface Card	Ubuntu 14.04.3	2.3.0.20 (ENIC)	4.1(1)	3, 21, 38
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1380 Virtual Interface Card	Ubuntu 14.04.3	2.3.0.20 (ENIC)	4.1(1)	3, 21, 38
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1380 Virtual Interface Card	Ubuntu 14.04.4	2.3.0.27 (ENIC)	4.1(1)	3, 21, 38
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS 1380 Virtual Interface Card	Ubuntu 14.04.4	2.3.0.27 (ENIC)	4.1(1)	3, 21, 38
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1380 Virtual Interface Card	Ubuntu 14.04.4	2.3.0.27 (ENIC)	4.1(1)	3, 21, 38
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1380 Virtual Interface Card	Ubuntu 14.04.4	2.3.0.27 (ENIC)	4.1(1)	3, 21, 38
B200 M4 w/E5-Series v4	UCS 1380 Virtual Interface Card	Ubuntu 14.04.4	2.3.0.27 (ENIC)	4.1(1)	3, 21, 38

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1380 Virtual Interface Card	Ubuntu 14.04.5	2.3.0.30 (ENIC)	4.1(1)	3, 21, 38
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS 1380 Virtual Interface Card	Ubuntu 14.04.5	2.3.0.30 (ENIC)	4.1(1)	3, 21, 38
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1380 Virtual Interface Card	Ubuntu 14.04.5	2.3.0.30 (ENIC)	4.1(1)	3, 21, 38
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1380 Virtual Interface Card	Ubuntu 14.04.5	2.3.0.30 (ENIC)	4.1(1)	3, 21, 38
B200 M4 w/E5-Series v4	UCS 1380 Virtual Interface Card	Ubuntu 14.04.5	2.3.0.30 (ENIC)	4.1(1)	3, 21, 38
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1380 Virtual Interface Card	Ubuntu 16.04	2.3.0.27 (ENIC)	4.1(1)	3, 38, 43
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS 1380 Virtual Interface Card	Ubuntu 16.04	2.3.0.27 (ENIC)	4.1(1)	3, 38, 43
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1380 Virtual Interface Card	Ubuntu 16.04	2.3.0.27 (ENIC)	4.1(1)	3, 38, 43
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1380 Virtual Interface Card	Ubuntu 16.04	2.3.0.27 (ENIC)	4.1(1)	3, 38, 43

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	UCS 1380 Virtual Interface Card	Ubuntu 16.04	2.3.0.27 (ENIC)	4.1(1)	3, 38, 43
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1380 Virtual Interface Card	Ubuntu 16.04.1	2.3.0.30 (ENIC)	4.1(1)	3, 21, 38
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS 1380 Virtual Interface Card	Ubuntu 16.04.1	2.3.0.30 (ENIC)	4.1(1)	3, 21, 38
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1380 Virtual Interface Card	Ubuntu 16.04.1	2.3.0.30 (ENIC)	4.1(1)	3, 21, 38
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1380 Virtual Interface Card	Ubuntu 16.04.1	2.3.0.30 (ENIC)	4.1(1)	3, 21, 38
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	UCS 1380 Virtual Interface Card	Ubuntu 16.04.1	2.3.0.30 (ENIC)	4.1(1)	3, 21, 38
B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1380 Virtual Interface Card	vSphere 5.0 U2	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 31, 38, 52, 53, 54
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS 1380 Virtual Interface Card	vSphere 5.0 U2	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 31, 38, 52, 53, 54
B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1380 Virtual Interface Card	vSphere 5.0 U3	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 31, 38, 52, 53, 54

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS 1380 Virtual Interface Card	vSphere 5.0 U3	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 31, 38, 52, 53, 54
B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1380 Virtual Interface Card	vSphere 5.1 U1	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 31, 38, 52, 53, 54
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS 1380 Virtual Interface Card	vSphere 5.1 U1	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 31, 38, 52, 53, 54
B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1380 Virtual Interface Card	vSphere 5.1 U2	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 31, 38, 52, 53, 54
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2, B200 M4 w/E5-Series v3	UCS 1380 Virtual Interface Card	vSphere 5.1 U2	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 31, 38, 52, 53, 54
B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1380 Virtual Interface Card	vSphere 5.1 U3	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 31, 38, 52, 53, 54
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1380 Virtual Interface Card	vSphere 5.1 U3	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 31, 38, 52, 53, 54
B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1380 Virtual Interface Card	vSphere 5.5	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 31, 38, 52, 53, 54

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1380 Virtual Interface Card	vSphere 5.5	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 31, 38, 52, 53, 54
B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1380 Virtual Interface Card	vSphere 5.5 U1	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 31, 38, 52, 53, 54
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1380 Virtual Interface Card	vSphere 5.5 U1	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 31, 38, 52, 53, 54
B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1380 Virtual Interface Card	vSphere 5.5 U2	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 31, 38, 52, 53, 54
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1380 Virtual Interface Card	vSphere 5.5 U2	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 31, 38, 52, 53, 54
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1380 Virtual Interface Card	vSphere 5.5 U2	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 31, 38, 52, 53, 54
B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1380 Virtual Interface Card	vSphere 5.5 U3	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 31, 38, 52, 53, 54
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1380 Virtual Interface Card	vSphere 5.5 U3	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 31, 38, 52, 53, 54

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1380 Virtual Interface Card	vSphere 5.5 U3	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 31, 38, 52, 53, 54
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	UCS 1380 Virtual Interface Card	vSphere 5.5 U3	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 31, 38, 52, 53, 54
B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1380 Virtual Interface Card	vSphere 6.0	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 31, 38, 52, 53, 54
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1380 Virtual Interface Card	vSphere 6.0	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 31, 38, 52, 53, 54
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1380 Virtual Interface Card	vSphere 6.0	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 31, 38, 52, 53, 54
B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1380 Virtual Interface Card	vSphere 6.0 U1	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 31, 38, 52, 53, 54
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1380 Virtual Interface Card	vSphere 6.0 U1	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 31, 38, 52, 53, 54

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1380 Virtual Interface Card	vSphere 6.0 U1	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 31, 38, 52, 53, 54
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	UCS 1380 Virtual Interface Card	vSphere 6.0 U1	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 31, 38, 52, 53, 54
B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1380 Virtual Interface Card	vSphere 6.0 U2	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 31, 38, 52, 53, 54
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1380 Virtual Interface Card	vSphere 6.0 U2	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 31, 38, 52, 53, 54
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1380 Virtual Interface Card	vSphere 6.0 U2	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 31, 38, 52, 53, 54
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	UCS 1380 Virtual Interface Card	vSphere 6.0 U2	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 31, 38, 52, 53, 54
B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1380 Virtual Interface Card	vSphere 6.5	1.6.0.28 (FNIC) / 1.0.0.2 (NENIC)	4.1(1)	11, 12, 31, 38, 46, 59

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1380 Virtual Interface Card	vSphere 6.5	1.6.0.28 (FNIC) / 1.0.0.2 (NENIC)	4.1(1)	11, 12, 31, 38, 46, 59
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1380 Virtual Interface Card	vSphere 6.5	1.6.0.28 (FNIC) / 1.0.0.2 (NENIC)	4.1(1)	11, 12, 31, 38, 46, 59
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	UCS 1380 Virtual Interface Card	vSphere 6.5	1.6.0.28 (FNIC) / 1.0.0.2 (NENIC)	4.1(1)	11, 12, 31, 38, 46, 59
B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1380 Virtual Interface Card	Windows Server 2008 R2 SP1	2.1.0.34 (FNIC) / 2.4.0.21 (ENIC) / 2.1.0.12 (NIC Teaming Driver)	4.1(1)	12, 21, 25, 38, 53, 55
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1380 Virtual Interface Card	Windows Server 2008 R2 SP1	2.1.0.34 (FNIC) / 2.4.0.21 (ENIC) / 2.1.0.12 (NIC Teaming Driver)	4.1(1)	12, 21, 25, 38, 53, 55
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1380 Virtual Interface Card	Windows Server 2008 R2 SP1	2.1.0.34 (FNIC) / 2.4.0.21 (ENIC) / 2.1.0.12 (NIC Teaming Driver)	4.1(1)	12, 21, 25, 38, 53, 55
B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1380 Virtual Interface Card	Windows Server 2012	2.4.0.19 (FNIC) / 3.5.0.17 (ENIC)	4.1(1)	12, 21, 35, 38, 56, 57

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1380 Virtual Interface Card	Windows Server 2012	2.4.0.19 (FNIC) / 3.5.0.17 (ENIC)	4.1(1)	12, 21, 35, 38, 56, 57
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1380 Virtual Interface Card	Windows Server 2012	2.4.0.19 (FNIC) / 3.5.0.17 (ENIC)	4.1(1)	12, 21, 35, 38, 56, 57
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	UCS 1380 Virtual Interface Card	Windows Server 2012	2.4.0.19 (FNIC) / 3.5.0.17 (ENIC)	4.1(1)	12, 21, 35, 38, 56, 57
B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1380 Virtual Interface Card	Windows Server 2012 R2	2.4.0.19 (FNIC) / 3.5.0.17 (ENIC)	4.1(1)	10, 12, 21, 35, 38, 56, 57
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1380 Virtual Interface Card	Windows Server 2012 R2	2.4.0.19 (FNIC) / 3.5.0.17 (ENIC)	4.1(1)	10, 12, 21, 35, 38, 56, 57
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1380 Virtual Interface Card	Windows Server 2012 R2	2.4.0.19 (FNIC) / 3.5.0.17 (ENIC)	4.1(1)	10, 12, 21, 35, 38, 56, 57
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	UCS 1380 Virtual Interface Card	Windows Server 2012 R2	2.4.0.19 (FNIC) / 3.5.0.17 (ENIC)	4.1(1)	10, 12, 21, 35, 38, 56, 57

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1380 Virtual Interface Card	Windows Server 2016	3.0.0.7 (FNIC) / 4.0.0.2 (ENIC)	4.1(2)	10, 12, 21, 38, 46
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1380 Virtual Interface Card	Windows Server 2016	3.0.0.7 (FNIC) / 4.0.0.2 (ENIC)	4.1(2)	10, 12, 21, 38, 46
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1380 Virtual Interface Card	Windows Server 2016	3.0.0.7 (FNIC) / 4.0.0.2 (ENIC)	4.1(2)	10, 12, 21, 38, 46
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	UCS 1380 Virtual Interface Card	Windows Server 2016	3.0.0.7 (FNIC) / 4.0.0.2 (ENIC)	4.1(2)	10, 12, 21, 38, 46
B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1380 Virtual Interface Card	XenServer 6.1	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	4, 21, 29, 38
B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1380 Virtual Interface Card	XenServer 6.2	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	21, 38
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2, B200 M4 w/E5-Series v3	UCS 1380 Virtual Interface Card	XenServer 6.2	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	21, 38
B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1380 Virtual Interface Card	XenServer 6.5	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	21, 38, 41

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1380 Virtual Interface Card	XenServer 6.5	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	21, 38, 41
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1380 Virtual Interface Card	XenServer 6.5	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	21, 38, 41
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	UCS 1380 Virtual Interface Card	XenServer 6.5	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	21, 38, 41
B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1380 Virtual Interface Card	XenServer 7.0	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	38, 43
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1380 Virtual Interface Card	XenServer 7.0	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	38, 43
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1380 Virtual Interface Card	XenServer 7.0	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	38, 43
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	UCS 1380 Virtual Interface Card	XenServer 7.0	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	38, 43

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B200 M3 w/E5-Series	UCS 1240 Virtual Interface Card and Port Expander Card	CentOS 6.5	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	14, 21, 39, 40
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B200 M4 w/E5-Series v3	UCS 1240 Virtual Interface Card and Port Expander Card	CentOS 6.5	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	14, 21, 39, 40
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS 1240 Virtual Interface Card and Port Expander Card	CentOS 6.6	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	14, 21, 39, 40
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1240 Virtual Interface Card and Port Expander Card	CentOS 6.6	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	14, 21, 39, 40
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS 1240 Virtual Interface Card and Port Expander Card	CentOS 6.7	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	14, 21, 39, 40
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1240 Virtual Interface Card and Port Expander Card	CentOS 6.7	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	14, 21, 39, 40
B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	UCS 1240 Virtual Interface Card and Port Expander Card	CentOS 6.7	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	14, 21, 39, 40
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS 1240 Virtual Interface Card and Port Expander Card	CentOS 6.8	1.6.0.27 (FNIC) / 2.3.0.30 (ENIC)	4.1(1)	14, 21, 39, 40

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1240 Virtual Interface Card and Port Expander Card	CentOS 6.8	1.6.0.27 (FNIC) / 2.3.0.30 (ENIC)	4.1(1)	14, 21, 39, 40
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	UCS 1240 Virtual Interface Card and Port Expander Card	CentOS 6.8	1.6.0.27 (FNIC) / 2.3.0.30 (ENIC)	4.1(1)	14, 21, 39, 40
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS 1240 Virtual Interface Card and Port Expander Card	CentOS 7.1	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	14, 21, 39, 40
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1240 Virtual Interface Card and Port Expander Card	CentOS 7.1	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	14, 21, 39, 40
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS 1240 Virtual Interface Card and Port Expander Card	CentOS 7.2	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	14, 21, 39, 40
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1240 Virtual Interface Card and Port Expander Card	CentOS 7.2	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	14, 21, 39, 40
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	UCS 1240 Virtual Interface Card and Port Expander Card	CentOS 7.2	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	14, 21, 39, 40

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1240 Virtual Interface Card and Port Expander Card	UEK R2 U5 (2.6.39-400.x)	1.6.0.25 (FNIC) / 2.1.1.39 (ENIC)	4.1(1)	14, 21
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1240 Virtual Interface Card and Port Expander Card	UEK R3 U1 (3.8.13-26.x)	1.6.0.25 (FNIC) / 2.1.1.39 (ENIC)	4.1(1)	14, 21
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2, B200 M4 w/E5-Series v3	UCS 1240 Virtual Interface Card and Port Expander Card	UEK R3 U1 (3.8.13-26.x)	1.6.0.25 (FNIC) / 2.1.1.39 (ENIC)	4.1(1)	14, 21
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1240 Virtual Interface Card and Port Expander Card	UEK R3 U3 (3.8.13-44.x)	1.6.0.25 (FNIC) / 2.1.1.50 (ENIC)	4.1(1)	14, 21
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2, B200 M4 w/E5-Series v3	UCS 1240 Virtual Interface Card and Port Expander Card	UEK R3 U3 (3.8.13-44.x)	1.6.0.25 (FNIC) / 2.1.1.50 (ENIC)	4.1(1)	14, 21
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1240 Virtual Interface Card and Port Expander Card	UEK R3 U5 (3.8.13-68.x)	1.6.0.25 (FNIC) / 2.1.1.67 (ENIC)	4.1(1)	14, 21
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1240 Virtual Interface Card and Port Expander Card	UEK R3 U5 (3.8.13-68.x)	1.6.0.25 (FNIC) / 2.1.1.67 (ENIC)	4.1(1)	14, 21

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1240 Virtual Interface Card and Port Expander Card	UEK R3 U5 (3.8.13-68.x)	1.6.0.25 (FNIC) / 2.1.1.67 (ENIC)	4.1(1)	14, 21
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1240 Virtual Interface Card and Port Expander Card	UEK R3 U6 (3.8.13-98.x)	1.6.0.25 (FNIC) / 2.1.1.67 (ENIC)	4.1(1)	14, 21
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1240 Virtual Interface Card and Port Expander Card	UEK R3 U6 (3.8.13-98.x)	1.6.0.25 (FNIC) / 2.1.1.67 (ENIC)	4.1(1)	14, 21
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1240 Virtual Interface Card and Port Expander Card	UEK R3 U6 (3.8.13-98.x)	1.6.0.25 (FNIC) / 2.1.1.67 (ENIC)	4.1(1)	14, 21
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2, B200 M4 w/E5-Series v3	UCS 1240 Virtual Interface Card and Port Expander Card	UEK R3 U7 (3.8.13-118)	1.6.0.25 (FNIC) / 2.1.1.67 (ENIC)	4.1(1)	14, 21
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1240 Virtual Interface Card and Port Expander Card	UEK R4 (4.1.12-32.x)	1.6.0.22 (FNIC) / 2.1.1.67 (ENIC)	4.1(1)	14, 43
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS 1240 Virtual Interface Card and Port Expander Card	UEK R4 (4.1.12-32.x)	1.6.0.22 (FNIC) / 2.1.1.67 (ENIC)	4.1(1)	14, 43

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1240 Virtual Interface Card and Port Expander Card	UEK R4 (4.1.12-32.x)	1.6.0.22 (FNIC) / 2.1.1.67 (ENIC)	4.1(1)	14, 43
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1240 Virtual Interface Card and Port Expander Card	UEK R4 (4.1.12-32.x)	1.6.0.22 (FNIC) / 2.1.1.67 (ENIC)	4.1(1)	14, 43
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	UCS 1240 Virtual Interface Card and Port Expander Card	UEK R4 (4.1.12-32.x)	1.6.0.22 (FNIC) / 2.1.1.67 (ENIC)	4.1(1)	14, 43
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1240 Virtual Interface Card and Port Expander Card	UEK R4 U1 (4.1.12-37.x)	1.6.0.24 (FNIC) / 2.3.0.12 (ENIC)	4.1(1)	14, 43
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS 1240 Virtual Interface Card and Port Expander Card	UEK R4 U1 (4.1.12-37.x)	1.6.0.24 (FNIC) / 2.3.0.12 (ENIC)	4.1(1)	14, 43
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1240 Virtual Interface Card and Port Expander Card	UEK R4 U1 (4.1.12-37.x)	1.6.0.24 (FNIC) / 2.3.0.12 (ENIC)	4.1(1)	14, 43
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1240 Virtual Interface Card and Port Expander Card	UEK R4 U1 (4.1.12-37.x)	1.6.0.24 (FNIC) / 2.3.0.12 (ENIC)	4.1(1)	14, 43
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	UCS 1240 Virtual Interface Card and Port Expander Card	UEK R4 U1 (4.1.12-37.x)	1.6.0.24 (FNIC) / 2.3.0.12 (ENIC)	4.1(1)	14, 43

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1240 Virtual Interface Card and Port Expander Card	UEK R4 U2 (4.1.12-61.x)	1.6.0.24 (FNIC) / 2.3.0.12 (ENIC)	4.1(1)	14, 43
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS 1240 Virtual Interface Card and Port Expander Card	UEK R4 U2 (4.1.12-61.x)	1.6.0.24 (FNIC) / 2.3.0.12 (ENIC)	4.1(1)	14, 43
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1240 Virtual Interface Card and Port Expander Card	UEK R4 U2 (4.1.12-61.x)	1.6.0.24 (FNIC) / 2.3.0.12 (ENIC)	4.1(1)	14, 43
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1240 Virtual Interface Card and Port Expander Card	UEK R4 U2 (4.1.12-61.x)	1.6.0.24 (FNIC) / 2.3.0.12 (ENIC)	4.1(1)	14, 43
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	UCS 1240 Virtual Interface Card and Port Expander Card	UEK R4 U2 (4.1.12-61.x)	1.6.0.24 (FNIC) / 2.3.0.12 (ENIC)	4.1(1)	14, 43
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1240 Virtual Interface Card and Port Expander Card	OVM 3.3.1	1.6.0.9 (FNIC) / 2.1.1.39 (ENIC)	4.1(1)	14, 43
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2, B200 M4 w/E5-Series v3	UCS 1240 Virtual Interface Card and Port Expander Card	OVM 3.3.1	1.6.0.9 (FNIC) / 2.1.1.39 (ENIC)	4.1(1)	14, 43

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1240 Virtual Interface Card and Port Expander Card	OVM 3.3.2	1.6.0.10 (FNIC) / 2.1.1.50 (ENIC)	4.1(1)	14, 43
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1240 Virtual Interface Card and Port Expander Card	OVM 3.3.2	1.6.0.10 (FNIC) / 2.1.1.50 (ENIC)	4.1(1)	14, 43
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1240 Virtual Interface Card and Port Expander Card	OVM 3.3.2	1.6.0.10 (FNIC) / 2.1.1.50 (ENIC)	4.1(1)	14, 43
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1240 Virtual Interface Card and Port Expander Card	OVM 3.3.3	1.6.0.10 (FNIC) / 2.1.1.67 (ENIC)	4.1(1)	14, 43, 45
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1240 Virtual Interface Card and Port Expander Card	OVM 3.3.3	1.6.0.10 (FNIC) / 2.1.1.67 (ENIC)	4.1(1)	14, 43, 45
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1240 Virtual Interface Card and Port Expander Card	OVM 3.3.3	1.6.0.10 (FNIC) / 2.1.1.67 (ENIC)	4.1(1)	14, 43, 45
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1240 Virtual Interface Card and Port Expander Card	OVM 3.3.4	1.6.0.18 (FNIC) / 2.1.1.67 (ENIC)	4.1(1)	14, 43, 45

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1240 Virtual Interface Card and Port Expander Card	OVM 3.3.4	1.6.0.18 (FNIC) / 2.1.1.67 (ENIC)	4.1(1)	14, 43, 45
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1240 Virtual Interface Card and Port Expander Card	OVM 3.3.4	1.6.0.18 (FNIC) / 2.1.1.67 (ENIC)	4.1(1)	14, 43, 45
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1240 Virtual Interface Card and Port Expander Card	OVM 3.4.1	1.6.0.22 (FNIC) / 2.3.0.12 (ENIC)	4.1(1)	38, 43
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1240 Virtual Interface Card and Port Expander Card	OVM 3.4.1	1.6.0.22 (FNIC) / 2.3.0.12 (ENIC)	4.1(1)	38, 43
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1240 Virtual Interface Card and Port Expander Card	OVM 3.4.1	1.6.0.22 (FNIC) / 2.3.0.12 (ENIC)	4.1(1)	38, 43
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	UCS 1240 Virtual Interface Card and Port Expander Card	OVM 3.4.1	1.6.0.22 (FNIC) / 2.3.0.12 (ENIC)	4.1(1)	38, 43
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1240 Virtual Interface Card and Port Expander Card	OVM 3.4.2	1.6.0.22 (FNIC) / 2.3.0.12 (ENIC)	4.1(1)	38, 43

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1240 Virtual Interface Card and Port Expander Card	OVM 3.4.2	1.6.0.22 (FNIC) / 2.3.0.12 (ENIC)	4.1(1)	38, 43
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1240 Virtual Interface Card and Port Expander Card	OVM 3.4.2	1.6.0.22 (FNIC) / 2.3.0.12 (ENIC)	4.1(1)	38, 43
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	UCS 1240 Virtual Interface Card and Port Expander Card	OVM 3.4.2	1.6.0.22 (FNIC) / 2.3.0.12 (ENIC)	4.1(1)	38, 43
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1240 Virtual Interface Card and Port Expander Card	Red Hat Enterprise Linux 5.9	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	12, 14, 21, 27
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS 1240 Virtual Interface Card and Port Expander Card	Red Hat Enterprise Linux 5.9	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	12, 14, 21, 27
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1240 Virtual Interface Card and Port Expander Card	Red Hat Enterprise Linux 5.10	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	12, 14, 21
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS 1240 Virtual Interface Card and Port Expander Card	Red Hat Enterprise Linux 5.10	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	12, 14, 21

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1240 Virtual Interface Card and Port Expander Card	Red Hat Enterprise Linux 5.11	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	12, 14, 21
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS 1240 Virtual Interface Card and Port Expander Card	Red Hat Enterprise Linux 5.11	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	12, 14, 21
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1240 Virtual Interface Card and Port Expander Card	Red Hat Enterprise Linux 6.4	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	12, 14, 21, 27
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS 1240 Virtual Interface Card and Port Expander Card	Red Hat Enterprise Linux 6.4	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	12, 14, 21, 27
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1240 Virtual Interface Card and Port Expander Card	Red Hat Enterprise Linux 6.5	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	14, 21
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2, B200 M4 w/E5-Series v3	UCS 1240 Virtual Interface Card and Port Expander Card	Red Hat Enterprise Linux 6.5	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	14, 21
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1240 Virtual Interface Card and Port Expander Card	Red Hat Enterprise Linux 6.6	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	14, 21

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1240 Virtual Interface Card and Port Expander Card	Red Hat Enterprise Linux 6.6	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	14, 21
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1240 Virtual Interface Card and Port Expander Card	Red Hat Enterprise Linux 6.6	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	14, 21
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1240 Virtual Interface Card and Port Expander Card	Red Hat Enterprise Linux 6.7	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	14, 21
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1240 Virtual Interface Card and Port Expander Card	Red Hat Enterprise Linux 6.7	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	14, 21
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1240 Virtual Interface Card and Port Expander Card	Red Hat Enterprise Linux 6.7	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	14, 21
B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	UCS 1240 Virtual Interface Card and Port Expander Card	Red Hat Enterprise Linux 6.7	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	14, 21
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1240 Virtual Interface Card and Port Expander Card	Red Hat Enterprise Linux 6.8	1.6.0.27 (FNIC) / 2.3.0.27 (ENIC)	4.1(1)	14, 21

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1240 Virtual Interface Card and Port Expander Card	Red Hat Enterprise Linux 6.8	1.6.0.27 (FNIC) / 2.3.0.27 (ENIC)	4.1(1)	14, 21
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1240 Virtual Interface Card and Port Expander Card	Red Hat Enterprise Linux 6.8	1.6.0.27 (FNIC) / 2.3.0.27 (ENIC)	4.1(1)	14, 21
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	UCS 1240 Virtual Interface Card and Port Expander Card	Red Hat Enterprise Linux 6.8	1.6.0.27 (FNIC) / 2.3.0.27 (ENIC)	4.1(1)	14, 21
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1240 Virtual Interface Card and Port Expander Card	Red Hat Enterprise Linux 7.0	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	14, 21
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2, B200 M4 w/E5-Series v3	UCS 1240 Virtual Interface Card and Port Expander Card	Red Hat Enterprise Linux 7.0	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	14, 21
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1240 Virtual Interface Card and Port Expander Card	Red Hat Enterprise Linux 7.1	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	14, 21

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1240 Virtual Interface Card and Port Expander Card	Red Hat Enterprise Linux 7.1	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	14, 21
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1240 Virtual Interface Card and Port Expander Card	Red Hat Enterprise Linux 7.1	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	14, 21
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1240 Virtual Interface Card and Port Expander Card	Red Hat Enterprise Linux 7.2	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	14, 21
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1240 Virtual Interface Card and Port Expander Card	Red Hat Enterprise Linux 7.2	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	14, 21
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1240 Virtual Interface Card and Port Expander Card	Red Hat Enterprise Linux 7.2	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	14, 21
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	UCS 1240 Virtual Interface Card and Port Expander Card	Red Hat Enterprise Linux 7.2	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	14, 21
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1240 Virtual Interface Card and Port Expander Card	Red Hat Enterprise Linux 7.3	1.6.0.30 (FNIC) / 2.3.0.30 (ENIC)	4.1(1)	14, 21

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1240 Virtual Interface Card and Port Expander Card	Red Hat Enterprise Linux 7.3	1.6.0.30 (FNIC) / 2.3.0.30 (ENIC)	4.1(1)	14, 21
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1240 Virtual Interface Card and Port Expander Card	Red Hat Enterprise Linux 7.3	1.6.0.30 (FNIC) / 2.3.0.30 (ENIC)	4.1(1)	14, 21
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	UCS 1240 Virtual Interface Card and Port Expander Card	Red Hat Enterprise Linux 7.3	1.6.0.30 (FNIC) / 2.3.0.30 (ENIC)	4.1(1)	14, 21
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1240 Virtual Interface Card and Port Expander Card	SUSE Linux Enterprise Server 11.2	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	14, 21
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1240 Virtual Interface Card and Port Expander Card	SUSE Linux Enterprise Server 11.3	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	12, 14, 21
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1240 Virtual Interface Card and Port Expander Card	SUSE Linux Enterprise Server 11.3	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	12, 14, 21
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1240 Virtual Interface Card and Port Expander Card	SUSE Linux Enterprise Server 11.3	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	12, 14, 21

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1240 Virtual Interface Card and Port Expander Card	SUSE Linux Enterprise Server 11.4	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	12, 14, 21
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1240 Virtual Interface Card and Port Expander Card	SUSE Linux Enterprise Server 11.4	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	12, 14, 21
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1240 Virtual Interface Card and Port Expander Card	SUSE Linux Enterprise Server 11.4	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	12, 14, 21
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1240 Virtual Interface Card and Port Expander Card	SUSE Linux Enterprise Server 12	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	12, 14, 21
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1240 Virtual Interface Card and Port Expander Card	SUSE Linux Enterprise Server 12	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	12, 14, 21
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1240 Virtual Interface Card and Port Expander Card	SUSE Linux Enterprise Server 12	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	12, 14, 21
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	UCS 1240 Virtual Interface Card and Port Expander Card	SUSE Linux Enterprise Server 12	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	12, 14, 21

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1240 Virtual Interface Card and Port Expander Card	SUSE Linux Enterprise Server 12.1	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	12, 14, 21
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1240 Virtual Interface Card and Port Expander Card	SUSE Linux Enterprise Server 12.1	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	12, 14, 21
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1240 Virtual Interface Card and Port Expander Card	SUSE Linux Enterprise Server 12.1	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	12, 14, 21
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	UCS 1240 Virtual Interface Card and Port Expander Card	SUSE Linux Enterprise Server 12.1	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	12, 14, 21
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1240 Virtual Interface Card and Port Expander Card	SUSE Linux Enterprise Server 12.2	1.6.0.21 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	12, 14, 43
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1240 Virtual Interface Card and Port Expander Card	SUSE Linux Enterprise Server 12.2	1.6.0.21 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	12, 14, 43
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1240 Virtual Interface Card and Port Expander Card	SUSE Linux Enterprise Server 12.2	1.6.0.21 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	12, 14, 43

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	UCS 1240 Virtual Interface Card and Port Expander Card	SUSE Linux Enterprise Server 12.2	1.6.0.21 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	12, 14, 43
B200 M3 w/E5-Series	UCS 1240 Virtual Interface Card and Port Expander Card	Ubuntu 12.04.4	2.1.1.39 (ENIC)	4.1(1)	3, 14, 43
B200 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1240 Virtual Interface Card and Port Expander Card	Ubuntu 12.04.4	2.1.1.39 (ENIC)	4.1(1)	3, 14, 43
B200 M3 w/E5-Series	UCS 1240 Virtual Interface Card and Port Expander Card	Ubuntu 14.04	2.1.1.50 (ENIC)	4.1(1)	3, 14, 43
B200 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1240 Virtual Interface Card and Port Expander Card	Ubuntu 14.04	2.1.1.50 (ENIC)	4.1(1)	3, 14, 43
B200 M3 w/E5-Series	UCS 1240 Virtual Interface Card and Port Expander Card	Ubuntu 14.04.1	2.1.1.50 (ENIC)	4.1(1)	3, 14, 43
B200 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2, B200 M4 w/E5-Series v3	UCS 1240 Virtual Interface Card and Port Expander Card	Ubuntu 14.04.1	2.1.1.50 (ENIC)	4.1(1)	3, 14, 43
B200 M3 w/E5-Series	UCS 1240 Virtual Interface Card and Port Expander Card	Ubuntu 14.04.2	2.3.0.20 (ENIC)	4.1(1)	3, 14, 21

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B200 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1240 Virtual Interface Card and Port Expander Card	Ubuntu 14.04.2	2.3.0.20 (ENIC)	4.1(1)	3, 14, 21
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1240 Virtual Interface Card and Port Expander Card	Ubuntu 14.04.2	2.3.0.20 (ENIC)	4.1(1)	3, 14, 21
B200 M3 w/E5-Series	UCS 1240 Virtual Interface Card and Port Expander Card	Ubuntu 14.04.3	2.3.0.20 (ENIC)	4.1(1)	3, 14, 21
B200 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1240 Virtual Interface Card and Port Expander Card	Ubuntu 14.04.3	2.3.0.20 (ENIC)	4.1(1)	3, 14, 21
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1240 Virtual Interface Card and Port Expander Card	Ubuntu 14.04.3	2.3.0.20 (ENIC)	4.1(1)	3, 14, 21
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1240 Virtual Interface Card and Port Expander Card	Ubuntu 14.04.4	2.3.0.27 (ENIC)	4.1(1)	3, 14, 21
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS 1240 Virtual Interface Card and Port Expander Card	Ubuntu 14.04.4	2.3.0.27 (ENIC)	4.1(1)	3, 14, 21
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1240 Virtual Interface Card and Port Expander Card	Ubuntu 14.04.4	2.3.0.27 (ENIC)	4.1(1)	3, 14, 21

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1240 Virtual Interface Card and Port Expander Card	Ubuntu 14.04.4	2.3.0.27 (ENIC)	4.1(1)	3, 14, 21
B200 M4 w/E5-Series v4	UCS 1240 Virtual Interface Card and Port Expander Card	Ubuntu 14.04.4	2.3.0.27 (ENIC)	4.1(1)	3, 14, 21
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1240 Virtual Interface Card and Port Expander Card	Ubuntu 14.04.5	2.3.0.30 (ENIC)	4.1(1)	3, 14, 21
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS 1240 Virtual Interface Card and Port Expander Card	Ubuntu 14.04.5	2.3.0.30 (ENIC)	4.1(1)	3, 14, 21
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1240 Virtual Interface Card and Port Expander Card	Ubuntu 14.04.5	2.3.0.30 (ENIC)	4.1(1)	3, 14, 21
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1240 Virtual Interface Card and Port Expander Card	Ubuntu 14.04.5	2.3.0.30 (ENIC)	4.1(1)	3, 14, 21
B200 M4 w/E5-Series v4	UCS 1240 Virtual Interface Card and Port Expander Card	Ubuntu 14.04.5	2.3.0.30 (ENIC)	4.1(1)	3, 14, 21
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1240 Virtual Interface Card and Port Expander Card	Ubuntu 16.04	2.3.0.27 (ENIC)	4.1(1)	3, 14, 43

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS 1240 Virtual Interface Card and Port Expander Card	Ubuntu 16.04	2.3.0.27 (ENIC)	4.1(1)	3, 14, 43
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1240 Virtual Interface Card and Port Expander Card	Ubuntu 16.04	2.3.0.27 (ENIC)	4.1(1)	3, 14, 43
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1240 Virtual Interface Card and Port Expander Card	Ubuntu 16.04	2.3.0.27 (ENIC)	4.1(1)	3, 14, 43
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	UCS 1240 Virtual Interface Card and Port Expander Card	Ubuntu 16.04	2.3.0.27 (ENIC)	4.1(1)	3, 14, 43
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1240 Virtual Interface Card and Port Expander Card	Ubuntu 16.04.1	2.3.0.30 (ENIC)	4.1(1)	3, 14, 21
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS 1240 Virtual Interface Card and Port Expander Card	Ubuntu 16.04.1	2.3.0.30 (ENIC)	4.1(1)	3, 14, 21
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1240 Virtual Interface Card and Port Expander Card	Ubuntu 16.04.1	2.3.0.30 (ENIC)	4.1(1)	3, 14, 21
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1240 Virtual Interface Card and Port Expander Card	Ubuntu 16.04.1	2.3.0.30 (ENIC)	4.1(1)	3, 14, 21

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	UCS 1240 Virtual Interface Card and Port Expander Card	Ubuntu 16.04.1	2.3.0.30 (ENIC)	4.1(1)	3, 14, 21
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1240 Virtual Interface Card and Port Expander Card	vSphere 5.0 U2	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 14, 31, 52, 53, 54
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS 1240 Virtual Interface Card and Port Expander Card	vSphere 5.0 U2	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 14, 31, 52, 53, 54
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1240 Virtual Interface Card and Port Expander Card	vSphere 5.0 U3	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 14, 31, 52, 53, 54
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS 1240 Virtual Interface Card and Port Expander Card	vSphere 5.0 U3	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 14, 31, 52, 53, 54
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1240 Virtual Interface Card and Port Expander Card	vSphere 5.1 U1	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 14, 31, 52, 53, 54
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS 1240 Virtual Interface Card and Port Expander Card	vSphere 5.1 U1	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 14, 31, 52, 53, 54
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1240 Virtual Interface Card and Port Expander Card	vSphere 5.1 U2	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 14, 31, 52, 53, 54

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2, B200 M4 w/E5-Series v3	UCS 1240 Virtual Interface Card and Port Expander Card	vSphere 5.1 U2	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 14, 31, 52, 53, 54
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1240 Virtual Interface Card and Port Expander Card	vSphere 5.1 U3	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 14, 31, 52, 53, 54
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1240 Virtual Interface Card and Port Expander Card	vSphere 5.1 U3	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 14, 31, 52, 53, 54
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1240 Virtual Interface Card and Port Expander Card	vSphere 5.5	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 14, 31, 52, 53, 54
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1240 Virtual Interface Card and Port Expander Card	vSphere 5.5	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 14, 31, 52, 53, 54
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1240 Virtual Interface Card and Port Expander Card	vSphere 5.5 U1	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 14, 31, 52, 53, 54

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1240 Virtual Interface Card and Port Expander Card	vSphere 5.5 U1	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 14, 31, 52, 53, 54
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1240 Virtual Interface Card and Port Expander Card	vSphere 5.5 U2	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 14, 31, 52, 53, 54
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1240 Virtual Interface Card and Port Expander Card	vSphere 5.5 U2	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 14, 31, 52, 53, 54
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1240 Virtual Interface Card and Port Expander Card	vSphere 5.5 U2	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 14, 31, 52, 53, 54
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1240 Virtual Interface Card and Port Expander Card	vSphere 5.5 U3	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 14, 31, 52, 53, 54
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1240 Virtual Interface Card and Port Expander Card	vSphere 5.5 U3	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 14, 31, 52, 53, 54

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1240 Virtual Interface Card and Port Expander Card	vSphere 5.5 U3	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 14, 31, 52, 53, 54
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	UCS 1240 Virtual Interface Card and Port Expander Card	vSphere 5.5 U3	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 14, 31, 52, 53, 54
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1240 Virtual Interface Card and Port Expander Card	vSphere 6.0	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 14, 31, 52, 53, 54
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1240 Virtual Interface Card and Port Expander Card	vSphere 6.0	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 14, 31, 52, 53, 54
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1240 Virtual Interface Card and Port Expander Card	vSphere 6.0	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 14, 31, 52, 53, 54
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1240 Virtual Interface Card and Port Expander Card	vSphere 6.0 U1	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 14, 31, 52, 53, 54
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1240 Virtual Interface Card and Port Expander Card	vSphere 6.0 U1	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 14, 31, 52, 53, 54

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1240 Virtual Interface Card and Port Expander Card	vSphere 6.0 U1	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 14, 31, 52, 53, 54
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	UCS 1240 Virtual Interface Card and Port Expander Card	vSphere 6.0 U1	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 14, 31, 52, 53, 54
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1240 Virtual Interface Card and Port Expander Card	vSphere 6.0 U2	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 14, 31, 52, 53, 54
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1240 Virtual Interface Card and Port Expander Card	vSphere 6.0 U2	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 14, 31, 52, 53, 54
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1240 Virtual Interface Card and Port Expander Card	vSphere 6.0 U2	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 14, 31, 52, 53, 54
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	UCS 1240 Virtual Interface Card and Port Expander Card	vSphere 6.0 U2	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 14, 31, 52, 53, 54
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1240 Virtual Interface Card and Port Expander Card	vSphere 6.5	1.6.0.28 (FNIC) / 1.0.0.2 (NENIC)	4.1(1)	11, 12, 14, 31, 46, 59

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1240 Virtual Interface Card and Port Expander Card	vSphere 6.5	1.6.0.28 (FNIC) / 1.0.0.2 (NENIC)	4.1(1)	11, 12, 14, 31, 46, 59
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1240 Virtual Interface Card and Port Expander Card	vSphere 6.5	1.6.0.28 (FNIC) / 1.0.0.2 (NENIC)	4.1(1)	11, 12, 14, 31, 46, 59
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	UCS 1240 Virtual Interface Card and Port Expander Card	vSphere 6.5	1.6.0.28 (FNIC) / 1.0.0.2 (NENIC)	4.1(1)	11, 12, 14, 31, 46, 59
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1240 Virtual Interface Card and Port Expander Card	Windows Server 2008 R2 SP1	2.1.0.34 (FNIC) / 2.4.0.21 (ENIC) / 2.1.0.12 (NIC Teaming Driver)	4.1(1)	12, 14, 21, 25, 53, 55
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1240 Virtual Interface Card and Port Expander Card	Windows Server 2008 R2 SP1	2.1.0.34 (FNIC) / 2.4.0.21 (ENIC) / 2.1.0.12 (NIC Teaming Driver)	4.1(1)	12, 14, 21, 25, 53, 55
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1240 Virtual Interface Card and Port Expander Card	Windows Server 2008 R2 SP1	2.1.0.34 (FNIC) / 2.4.0.21 (ENIC) / 2.1.0.12 (NIC Teaming Driver)	4.1(1)	12, 14, 21, 25, 53, 55
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1240 Virtual Interface Card and Port Expander Card	Windows Server 2012	2.4.0.19 (FNIC) / 3.5.0.17 (ENIC)	4.1(1)	12, 14, 21, 35, 56, 57

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1240 Virtual Interface Card and Port Expander Card	Windows Server 2012	2.4.0.19 (FNIC) / 3.5.0.17 (ENIC)	4.1(1)	12, 14, 21, 35, 56, 57
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1240 Virtual Interface Card and Port Expander Card	Windows Server 2012	2.4.0.19 (FNIC) / 3.5.0.17 (ENIC)	4.1(1)	12, 14, 21, 35, 56, 57
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	UCS 1240 Virtual Interface Card and Port Expander Card	Windows Server 2012	2.4.0.19 (FNIC) / 3.5.0.17 (ENIC)	4.1(1)	12, 14, 21, 35, 56, 57
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1240 Virtual Interface Card and Port Expander Card	Windows Server 2012 R2	2.4.0.19 (FNIC) / 3.5.0.17 (ENIC)	4.1(1)	10, 12, 14, 21, 35, 56, 57
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1240 Virtual Interface Card and Port Expander Card	Windows Server 2012 R2	2.4.0.19 (FNIC) / 3.5.0.17 (ENIC)	4.1(1)	10, 12, 14, 21, 35, 56, 57
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1240 Virtual Interface Card and Port Expander Card	Windows Server 2012 R2	2.4.0.19 (FNIC) / 3.5.0.17 (ENIC)	4.1(1)	10, 12, 14, 21, 35, 56, 57

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	UCS 1240 Virtual Interface Card and Port Expander Card	Windows Server 2012 R2	2.4.0.19 (FNIC) / 3.5.0.17 (ENIC)	4.1(1)	10, 12, 14, 21, 35, 56, 57
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1240 Virtual Interface Card and Port Expander Card	Windows Server 2016	3.0.0.7 (FNIC) / 4.0.0.2 (ENIC)	4.1(2)	10, 12, 14, 21, 46
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1240 Virtual Interface Card and Port Expander Card	Windows Server 2016	3.0.0.7 (FNIC) / 4.0.0.2 (ENIC)	4.1(2)	10, 12, 14, 21, 46
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1240 Virtual Interface Card and Port Expander Card	Windows Server 2016	3.0.0.7 (FNIC) / 4.0.0.2 (ENIC)	4.1(2)	10, 12, 14, 21, 46
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	UCS 1240 Virtual Interface Card and Port Expander Card	Windows Server 2016	3.0.0.7 (FNIC) / 4.0.0.2 (ENIC)	4.1(2)	10, 12, 14, 21, 46
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1240 Virtual Interface Card and Port Expander Card	XenServer 6.1	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	4, 14, 21, 29
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1240 Virtual Interface Card and Port Expander Card	XenServer 6.2	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	14, 21

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2, B200 M4 w/E5-Series v3	UCS 1240 Virtual Interface Card and Port Expander Card	XenServer 6.2	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	14, 21
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1240 Virtual Interface Card and Port Expander Card	XenServer 6.5	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	21, 38, 41
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1240 Virtual Interface Card and Port Expander Card	XenServer 6.5	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	21, 38, 41
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1240 Virtual Interface Card and Port Expander Card	XenServer 6.5	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	21, 38, 41
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	UCS 1240 Virtual Interface Card and Port Expander Card	XenServer 6.5	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	21, 38, 41
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1240 Virtual Interface Card and Port Expander Card	XenServer 7.0	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	38, 43

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1240 Virtual Interface Card and Port Expander Card	XenServer 7.0	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	38, 43
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1240 Virtual Interface Card and Port Expander Card	XenServer 7.0	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	38, 43
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	UCS 1240 Virtual Interface Card and Port Expander Card	XenServer 7.0	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	38, 43
B200 M3 w/E5-Series	UCS 1280 Virtual Interface Card	CentOS 6.5	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	14, 21, 39, 40
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B200 M4 w/E5-Series v3	UCS 1280 Virtual Interface Card	CentOS 6.5	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	14, 21, 39, 40
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS 1280 Virtual Interface Card	CentOS 6.6	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	14, 21, 39, 40
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1280 Virtual Interface Card	CentOS 6.6	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	14, 21, 39, 40
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS 1280 Virtual Interface Card	CentOS 6.7	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	14, 21, 39, 40

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1280 Virtual Interface Card	CentOS 6.7	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	14, 21, 39, 40
B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	UCS 1280 Virtual Interface Card	CentOS 6.7	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	14, 21, 39, 40
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS 1280 Virtual Interface Card	CentOS 6.8	1.6.0.27 (FNIC) / 2.3.0.30 (ENIC)	4.1(1)	14, 21, 39, 40
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1280 Virtual Interface Card	CentOS 6.8	1.6.0.27 (FNIC) / 2.3.0.30 (ENIC)	4.1(1)	14, 21, 39, 40
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	UCS 1280 Virtual Interface Card	CentOS 6.8	1.6.0.27 (FNIC) / 2.3.0.30 (ENIC)	4.1(1)	14, 21, 39, 40
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS 1280 Virtual Interface Card	CentOS 7.1	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	14, 21, 39, 40
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1280 Virtual Interface Card	CentOS 7.1	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	14, 21, 39, 40
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS 1280 Virtual Interface Card	CentOS 7.2	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	14, 21, 39, 40

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1280 Virtual Interface Card	CentOS 7.2	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	14, 21, 39, 40
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	UCS 1280 Virtual Interface Card	CentOS 7.2	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	14, 21, 39, 40
B200 M2 w/E5-Series, B230 M2, B440 M2	UCS 1280 Virtual Interface Card	UEK R2 U5 (2.6.39-400.x)	1.6.0.25 (FNIC) / 2.1.1.39 (ENIC)	4.1(1)	14, 21
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1280 Virtual Interface Card	UEK R2 U5 (2.6.39-400.x)	1.6.0.25 (FNIC) / 2.1.1.39 (ENIC)	4.1(1)	14, 21
B200 M2 w/E5-Series, B230 M2, B440 M2	UCS 1280 Virtual Interface Card	UEK R3 U1 (3.8.13-26.x)	1.6.0.25 (FNIC) / 2.1.1.39 (ENIC)	4.1(1)	14, 21
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1280 Virtual Interface Card	UEK R3 U1 (3.8.13-26.x)	1.6.0.25 (FNIC) / 2.1.1.39 (ENIC)	4.1(1)	14, 21
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2, B200 M4 w/E5-Series v3	UCS 1280 Virtual Interface Card	UEK R3 U1 (3.8.13-26.x)	1.6.0.25 (FNIC) / 2.1.1.39 (ENIC)	4.1(1)	14, 21
B200 M2 w/E5-Series, B230 M2, B440 M2	UCS 1280 Virtual Interface Card	UEK R3 U3 (3.8.13-44.x)	1.6.0.25 (FNIC) / 2.1.1.50 (ENIC)	4.1(1)	14, 21

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1280 Virtual Interface Card	UEK R3 U3 (3.8.13-44.x)	1.6.0.25 (FNIC) / 2.1.1.50 (ENIC)	4.1(1)	14, 21
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2, B200 M4 w/E5-Series v3	UCS 1280 Virtual Interface Card	UEK R3 U3 (3.8.13-44.x)	1.6.0.25 (FNIC) / 2.1.1.50 (ENIC)	4.1(1)	14, 21
B200 M2 w/E5-Series, B230 M2, B440 M2	UCS 1280 Virtual Interface Card	UEK R3 U5 (3.8.13-68.x)	1.6.0.25 (FNIC) / 2.1.1.67 (ENIC)	4.1(1)	14, 21
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1280 Virtual Interface Card	UEK R3 U5 (3.8.13-68.x)	1.6.0.25 (FNIC) / 2.1.1.67 (ENIC)	4.1(1)	14, 21
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1280 Virtual Interface Card	UEK R3 U5 (3.8.13-68.x)	1.6.0.25 (FNIC) / 2.1.1.67 (ENIC)	4.1(1)	14, 21
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1280 Virtual Interface Card	UEK R3 U5 (3.8.13-68.x)	1.6.0.25 (FNIC) / 2.1.1.67 (ENIC)	4.1(1)	14, 21
B200 M2 w/E5-Series, B230 M2, B440 M2	UCS 1280 Virtual Interface Card	UEK R3 U6 (3.8.13-98.x)	1.6.0.25 (FNIC) / 2.1.1.67 (ENIC)	4.1(1)	14, 21
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1280 Virtual Interface Card	UEK R3 U6 (3.8.13-98.x)	1.6.0.25 (FNIC) / 2.1.1.67 (ENIC)	4.1(1)	14, 21

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1280 Virtual Interface Card	UEK R3 U6 (3.8.13-98.x)	1.6.0.25 (FNIC) / 2.1.1.67 (ENIC)	4.1(1)	14, 21
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1280 Virtual Interface Card	UEK R3 U6 (3.8.13-98.x)	1.6.0.25 (FNIC) / 2.1.1.67 (ENIC)	4.1(1)	14, 21
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2, B200 M4 w/E5-Series v3	UCS 1280 Virtual Interface Card	UEK R3 U7 (3.8.13-118)	1.6.0.25 (FNIC) / 2.1.1.67 (ENIC)	4.1(1)	14, 21
B200 M2 w/E5-Series, B230 M2, B440 M2	UCS 1280 Virtual Interface Card	UEK R4 (4.1.12-32.x)	1.6.0.22 (FNIC) / 2.1.1.67 (ENIC)	4.1(1)	14, 43
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1280 Virtual Interface Card	UEK R4 (4.1.12-32.x)	1.6.0.22 (FNIC) / 2.1.1.67 (ENIC)	4.1(1)	14, 43
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS 1280 Virtual Interface Card	UEK R4 (4.1.12-32.x)	1.6.0.22 (FNIC) / 2.1.1.67 (ENIC)	4.1(1)	14, 43
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1280 Virtual Interface Card	UEK R4 (4.1.12-32.x)	1.6.0.22 (FNIC) / 2.1.1.67 (ENIC)	4.1(1)	14, 43

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1280 Virtual Interface Card	UEK R4 (4.1.12-32.x)	1.6.0.22 (FNIC) / 2.1.1.67 (ENIC)	4.1(1)	14, 43
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	UCS 1280 Virtual Interface Card	UEK R4 (4.1.12-32.x)	1.6.0.22 (FNIC) / 2.1.1.67 (ENIC)	4.1(1)	14, 43
B200 M2 w/E5-Series, B230 M2, B440 M2	UCS 1280 Virtual Interface Card	UEK R4 U1 (4.1.12-37.x)	1.6.0.24 (FNIC) / 2.3.0.12 (ENIC)	4.1(1)	14, 43
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1280 Virtual Interface Card	UEK R4 U1 (4.1.12-37.x)	1.6.0.24 (FNIC) / 2.3.0.12 (ENIC)	4.1(1)	14, 43
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS 1280 Virtual Interface Card	UEK R4 U1 (4.1.12-37.x)	1.6.0.24 (FNIC) / 2.3.0.12 (ENIC)	4.1(1)	14, 43
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1280 Virtual Interface Card	UEK R4 U1 (4.1.12-37.x)	1.6.0.24 (FNIC) / 2.3.0.12 (ENIC)	4.1(1)	14, 43
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1280 Virtual Interface Card	UEK R4 U1 (4.1.12-37.x)	1.6.0.24 (FNIC) / 2.3.0.12 (ENIC)	4.1(1)	14, 43
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	UCS 1280 Virtual Interface Card	UEK R4 U1 (4.1.12-37.x)	1.6.0.24 (FNIC) / 2.3.0.12 (ENIC)	4.1(1)	14, 43

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B200 M2 w/E5-Series, B230 M2, B440 M2	UCS 1280 Virtual Interface Card	UEK R4 U2 (4.1.12-61.x)	1.6.0.24 (FNIC) / 2.3.0.12 (ENIC)	4.1(1)	14, 43
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1280 Virtual Interface Card	UEK R4 U2 (4.1.12-61.x)	1.6.0.24 (FNIC) / 2.3.0.12 (ENIC)	4.1(1)	14, 43
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS 1280 Virtual Interface Card	UEK R4 U2 (4.1.12-61.x)	1.6.0.24 (FNIC) / 2.3.0.12 (ENIC)	4.1(1)	14, 43
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1280 Virtual Interface Card	UEK R4 U2 (4.1.12-61.x)	1.6.0.24 (FNIC) / 2.3.0.12 (ENIC)	4.1(1)	14, 43
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1280 Virtual Interface Card	UEK R4 U2 (4.1.12-61.x)	1.6.0.24 (FNIC) / 2.3.0.12 (ENIC)	4.1(1)	14, 43
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	UCS 1280 Virtual Interface Card	UEK R4 U2 (4.1.12-61.x)	1.6.0.24 (FNIC) / 2.3.0.12 (ENIC)	4.1(1)	14, 43
B200 M2 w/E5-Series, B230 M2, B440 M2	UCS 1280 Virtual Interface Card	OVM 3.3.1	1.6.0.9 (FNIC) / 2.1.1.39 (ENIC)	4.1(1)	14, 43
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1280 Virtual Interface Card	OVM 3.3.1	1.6.0.9 (FNIC) / 2.1.1.39 (ENIC)	4.1(1)	14, 43

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2, B200 M4 w/E5-Series v3	UCS 1280 Virtual Interface Card	OVM 3.3.1	1.6.0.9 (FNIC) / 2.1.1.39 (ENIC)	4.1(1)	14, 43
B200 M2 w/E5-Series, B230 M2, B440 M2	UCS 1280 Virtual Interface Card	OVM 3.3.2	1.6.0.10 (FNIC) / 2.1.1.50 (ENIC)	4.1(1)	14, 43
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1280 Virtual Interface Card	OVM 3.3.2	1.6.0.10 (FNIC) / 2.1.1.50 (ENIC)	4.1(1)	14, 43
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1280 Virtual Interface Card	OVM 3.3.2	1.6.0.10 (FNIC) / 2.1.1.50 (ENIC)	4.1(1)	14, 43
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1280 Virtual Interface Card	OVM 3.3.2	1.6.0.10 (FNIC) / 2.1.1.50 (ENIC)	4.1(1)	14, 43
B200 M2 w/E5-Series, B230 M2, B440 M2	UCS 1280 Virtual Interface Card	OVM 3.3.3	1.6.0.10 (FNIC) / 2.1.1.67 (ENIC)	4.1(1)	14, 43, 45
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1280 Virtual Interface Card	OVM 3.3.3	1.6.0.10 (FNIC) / 2.1.1.67 (ENIC)	4.1(1)	14, 43, 45

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1280 Virtual Interface Card	OVM 3.3.3	1.6.0.10 (FNIC) / 2.1.1.67 (ENIC)	4.1(1)	14, 43, 45
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1280 Virtual Interface Card	OVM 3.3.3	1.6.0.10 (FNIC) / 2.1.1.67 (ENIC)	4.1(1)	14, 43, 45
B200 M2 w/E5-Series, B230 M2, B440 M2	UCS 1280 Virtual Interface Card	OVM 3.3.4	1.6.0.18 (FNIC) / 2.1.1.67 (ENIC)	4.1(1)	14, 43, 45
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1280 Virtual Interface Card	OVM 3.3.4	1.6.0.18 (FNIC) / 2.1.1.67 (ENIC)	4.1(1)	14, 43, 45
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1280 Virtual Interface Card	OVM 3.3.4	1.6.0.18 (FNIC) / 2.1.1.67 (ENIC)	4.1(1)	14, 43, 45
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1280 Virtual Interface Card	OVM 3.3.4	1.6.0.18 (FNIC) / 2.1.1.67 (ENIC)	4.1(1)	14, 43, 45
B200 M2 w/E5-Series, B230 M2, B440 M2	UCS 1280 Virtual Interface Card	OVM 3.4.1	1.6.0.22 (FNIC) / 2.3.0.12 (ENIC)	4.1(1)	38, 43

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1280 Virtual Interface Card	OVM 3.4.1	1.6.0.22 (FNIC) / 2.3.0.12 (ENIC)	4.1(1)	38, 43
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1280 Virtual Interface Card	OVM 3.4.1	1.6.0.22 (FNIC) / 2.3.0.12 (ENIC)	4.1(1)	38, 43
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1280 Virtual Interface Card	OVM 3.4.1	1.6.0.22 (FNIC) / 2.3.0.12 (ENIC)	4.1(1)	38, 43
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	UCS 1280 Virtual Interface Card	OVM 3.4.1	1.6.0.22 (FNIC) / 2.3.0.12 (ENIC)	4.1(1)	38, 43
B200 M2 w/E5-Series, B230 M2, B440 M2	UCS 1280 Virtual Interface Card	OVM 3.4.2	1.6.0.22 (FNIC) / 2.3.0.12 (ENIC)	4.1(1)	38, 43
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1280 Virtual Interface Card	OVM 3.4.2	1.6.0.22 (FNIC) / 2.3.0.12 (ENIC)	4.1(1)	38, 43
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1280 Virtual Interface Card	OVM 3.4.2	1.6.0.22 (FNIC) / 2.3.0.12 (ENIC)	4.1(1)	38, 43

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1280 Virtual Interface Card	OVM 3.4.2	1.6.0.22 (FNIC) / 2.3.0.12 (ENIC)	4.1(1)	38, 43
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	UCS 1280 Virtual Interface Card	OVM 3.4.2	1.6.0.22 (FNIC) / 2.3.0.12 (ENIC)	4.1(1)	38, 43
B200 M2 w/E5-Series, B230 M2, B440 M2	UCS 1280 Virtual Interface Card	Red Hat Enterprise Linux 5.9	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	12, 14, 21, 27
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1280 Virtual Interface Card	Red Hat Enterprise Linux 5.9	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	12, 14, 21, 27
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS 1280 Virtual Interface Card	Red Hat Enterprise Linux 5.9	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	12, 14, 21, 27
B200 M2 w/E5-Series, B230 M2, B440 M2	UCS 1280 Virtual Interface Card	Red Hat Enterprise Linux 5.10	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	12, 14, 21
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1280 Virtual Interface Card	Red Hat Enterprise Linux 5.10	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	12, 14, 21
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS 1280 Virtual Interface Card	Red Hat Enterprise Linux 5.10	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	12, 14, 21
B200 M2 w/E5-Series, B230 M2, B440 M2	UCS 1280 Virtual Interface Card	Red Hat Enterprise Linux 5.11	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	12, 14, 21

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1280 Virtual Interface Card	Red Hat Enterprise Linux 5.11	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	12, 14, 21
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS 1280 Virtual Interface Card	Red Hat Enterprise Linux 5.11	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	12, 14, 21
B200 M2 w/E5-Series, B230 M2, B440 M2	UCS 1280 Virtual Interface Card	Red Hat Enterprise Linux 6.4	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	12, 14, 21, 27
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1280 Virtual Interface Card	Red Hat Enterprise Linux 6.4	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	12, 14, 21, 27
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS 1280 Virtual Interface Card	Red Hat Enterprise Linux 6.4	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	12, 14, 21, 27
B200 M2 w/E5-Series, B230 M2, B440 M2	UCS 1280 Virtual Interface Card	Red Hat Enterprise Linux 6.5	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	14, 21
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1280 Virtual Interface Card	Red Hat Enterprise Linux 6.5	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	14, 21
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2, B200 M4 w/E5-Series v3	UCS 1280 Virtual Interface Card	Red Hat Enterprise Linux 6.5	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	14, 21
B200 M2 w/E5-Series, B230 M2, B440 M2	UCS 1280 Virtual Interface Card	Red Hat Enterprise Linux 6.6	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	14, 21

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1280 Virtual Interface Card	Red Hat Enterprise Linux 6.6	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	14, 21
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1280 Virtual Interface Card	Red Hat Enterprise Linux 6.6	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	14, 21
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1280 Virtual Interface Card	Red Hat Enterprise Linux 6.6	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	14, 21
B200 M2 w/E5-Series, B230 M2, B440 M2	UCS 1280 Virtual Interface Card	Red Hat Enterprise Linux 6.7	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	14, 21
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1280 Virtual Interface Card	Red Hat Enterprise Linux 6.7	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	14, 21
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1280 Virtual Interface Card	Red Hat Enterprise Linux 6.7	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	14, 21
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1280 Virtual Interface Card	Red Hat Enterprise Linux 6.7	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	14, 21

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	UCS 1280 Virtual Interface Card	Red Hat Enterprise Linux 6.7	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	14, 21
B200 M2 w/E5-Series, B230 M2, B440 M2	UCS 1280 Virtual Interface Card	Red Hat Enterprise Linux 6.8	1.6.0.27 (FNIC) / 2.3.0.27 (ENIC)	4.1(1)	14, 21
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1280 Virtual Interface Card	Red Hat Enterprise Linux 6.8	1.6.0.27 (FNIC) / 2.3.0.27 (ENIC)	4.1(1)	14, 21
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1280 Virtual Interface Card	Red Hat Enterprise Linux 6.8	1.6.0.27 (FNIC) / 2.3.0.27 (ENIC)	4.1(1)	14, 21
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1280 Virtual Interface Card	Red Hat Enterprise Linux 6.8	1.6.0.27 (FNIC) / 2.3.0.27 (ENIC)	4.1(1)	14, 21
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	UCS 1280 Virtual Interface Card	Red Hat Enterprise Linux 6.8	1.6.0.27 (FNIC) / 2.3.0.27 (ENIC)	4.1(1)	14, 21
B200 M2 w/E5-Series, B230 M2, B440 M2	UCS 1280 Virtual Interface Card	Red Hat Enterprise Linux 7.0	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	14, 21
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1280 Virtual Interface Card	Red Hat Enterprise Linux 7.0	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	14, 21

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2, B200 M4 w/E5-Series v3	UCS 1280 Virtual Interface Card	Red Hat Enterprise Linux 7.0	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	14, 21
B200 M2 w/E5-Series, B230 M2, B440 M2	UCS 1280 Virtual Interface Card	Red Hat Enterprise Linux 7.1	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	14, 21
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1280 Virtual Interface Card	Red Hat Enterprise Linux 7.1	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	14, 21
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1280 Virtual Interface Card	Red Hat Enterprise Linux 7.1	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	14, 21
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1280 Virtual Interface Card	Red Hat Enterprise Linux 7.1	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	14, 21
B200 M2 w/E5-Series, B230 M2, B440 M2	UCS 1280 Virtual Interface Card	Red Hat Enterprise Linux 7.2	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	14, 21
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1280 Virtual Interface Card	Red Hat Enterprise Linux 7.2	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	14, 21

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1280 Virtual Interface Card	Red Hat Enterprise Linux 7.2	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	14, 21
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1280 Virtual Interface Card	Red Hat Enterprise Linux 7.2	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	14, 21
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	UCS 1280 Virtual Interface Card	Red Hat Enterprise Linux 7.2	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	14, 21
B200 M2 w/E5-Series, B230 M2, B440 M2	UCS 1280 Virtual Interface Card	Red Hat Enterprise Linux 7.3	1.6.0.30 (FNIC) / 2.3.0.30 (ENIC)	4.1(1)	14, 21
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1280 Virtual Interface Card	Red Hat Enterprise Linux 7.3	1.6.0.30 (FNIC) / 2.3.0.30 (ENIC)	4.1(1)	14, 21
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1280 Virtual Interface Card	Red Hat Enterprise Linux 7.3	1.6.0.30 (FNIC) / 2.3.0.30 (ENIC)	4.1(1)	14, 21
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1280 Virtual Interface Card	Red Hat Enterprise Linux 7.3	1.6.0.30 (FNIC) / 2.3.0.30 (ENIC)	4.1(1)	14, 21

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	UCS 1280 Virtual Interface Card	Red Hat Enterprise Linux 7.3	1.6.0.30 (FNIC) / 2.3.0.30 (ENIC)	4.1(1)	14, 21
B200 M2 w/E5-Series, B230 M2, B440 M2	UCS 1280 Virtual Interface Card	SUSE Linux Enterprise Server 11.2	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	14, 21
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1280 Virtual Interface Card	SUSE Linux Enterprise Server 11.2	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	14, 21
B200 M2 w/E5-Series, B230 M2, B440 M2	UCS 1280 Virtual Interface Card	SUSE Linux Enterprise Server 11.3	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	12, 14, 21
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1280 Virtual Interface Card	SUSE Linux Enterprise Server 11.3	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	12, 14, 21
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1280 Virtual Interface Card	SUSE Linux Enterprise Server 11.3	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	12, 14, 21
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1280 Virtual Interface Card	SUSE Linux Enterprise Server 11.3	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	12, 14, 21
B200 M2 w/E5-Series, B230 M2, B440 M2	UCS 1280 Virtual Interface Card	SUSE Linux Enterprise Server 11.4	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	12, 14, 21

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1280 Virtual Interface Card	SUSE Linux Enterprise Server 11.4	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	12, 14, 21
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1280 Virtual Interface Card	SUSE Linux Enterprise Server 11.4	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	12, 14, 21
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1280 Virtual Interface Card	SUSE Linux Enterprise Server 11.4	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	12, 14, 21
B200 M2 w/E5-Series, B230 M2, B440 M2	UCS 1280 Virtual Interface Card	SUSE Linux Enterprise Server 12	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	12, 14, 21
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1280 Virtual Interface Card	SUSE Linux Enterprise Server 12	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	12, 14, 21
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1280 Virtual Interface Card	SUSE Linux Enterprise Server 12	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	12, 14, 21
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1280 Virtual Interface Card	SUSE Linux Enterprise Server 12	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	12, 14, 21

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	UCS 1280 Virtual Interface Card	SUSE Linux Enterprise Server 12	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	12, 14, 21
B200 M2 w/E5-Series, B230 M2, B440 M2	UCS 1280 Virtual Interface Card	SUSE Linux Enterprise Server 12.1	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	12, 14, 21
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1280 Virtual Interface Card	SUSE Linux Enterprise Server 12.1	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	12, 14, 21
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1280 Virtual Interface Card	SUSE Linux Enterprise Server 12.1	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	12, 14, 21
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1280 Virtual Interface Card	SUSE Linux Enterprise Server 12.1	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	12, 14, 21
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	UCS 1280 Virtual Interface Card	SUSE Linux Enterprise Server 12.1	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	12, 14, 21
B200 M2 w/E5-Series, B230 M2, B440 M2	UCS 1280 Virtual Interface Card	SUSE Linux Enterprise Server 12.2	1.6.0.21 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	12, 14, 43
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1280 Virtual Interface Card	SUSE Linux Enterprise Server 12.2	1.6.0.21 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	12, 14, 43

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1280 Virtual Interface Card	SUSE Linux Enterprise Server 12.2	1.6.0.21 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	12, 14, 43
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1280 Virtual Interface Card	SUSE Linux Enterprise Server 12.2	1.6.0.21 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	12, 14, 43
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	UCS 1280 Virtual Interface Card	SUSE Linux Enterprise Server 12.2	1.6.0.21 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	12, 14, 43
B200 M3 w/E5-Series	UCS 1280 Virtual Interface Card	Ubuntu 12.04.4	2.1.1.39 (ENIC)	4.1(1)	3, 14, 43
B200 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1280 Virtual Interface Card	Ubuntu 12.04.4	2.1.1.39 (ENIC)	4.1(1)	3, 14, 43
B200 M3 w/E5-Series	UCS 1280 Virtual Interface Card	Ubuntu 14.04	2.1.1.50 (ENIC)	4.1(1)	3, 14, 43
B200 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1280 Virtual Interface Card	Ubuntu 14.04	2.1.1.50 (ENIC)	4.1(1)	3, 14, 43
B200 M3 w/E5-Series	UCS 1280 Virtual Interface Card	Ubuntu 14.04.1	2.1.1.50 (ENIC)	4.1(1)	3, 14, 43

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B200 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2, B200 M4 w/E5-Series v3	UCS 1280 Virtual Interface Card	Ubuntu 14.04.1	2.1.1.50 (ENIC)	4.1(1)	3, 14, 43
B200 M3 w/E5-Series	UCS 1280 Virtual Interface Card	Ubuntu 14.04.2	2.3.0.20 (ENIC)	4.1(1)	3, 14, 21
B200 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1280 Virtual Interface Card	Ubuntu 14.04.2	2.3.0.20 (ENIC)	4.1(1)	3, 14, 21
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1280 Virtual Interface Card	Ubuntu 14.04.2	2.3.0.20 (ENIC)	4.1(1)	3, 14, 21
B200 M3 w/E5-Series	UCS 1280 Virtual Interface Card	Ubuntu 14.04.3	2.3.0.20 (ENIC)	4.1(1)	3, 14, 21
B200 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1280 Virtual Interface Card	Ubuntu 14.04.3	2.3.0.20 (ENIC)	4.1(1)	3, 14, 21
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1280 Virtual Interface Card	Ubuntu 14.04.3	2.3.0.20 (ENIC)	4.1(1)	3, 14, 21
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1280 Virtual Interface Card	Ubuntu 14.04.4	2.3.0.27 (ENIC)	4.1(1)	3, 14, 21

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS 1280 Virtual Interface Card	Ubuntu 14.04.4	2.3.0.27 (ENIC)	4.1(1)	3, 14, 21
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1280 Virtual Interface Card	Ubuntu 14.04.4	2.3.0.27 (ENIC)	4.1(1)	3, 14, 21
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1280 Virtual Interface Card	Ubuntu 14.04.4	2.3.0.27 (ENIC)	4.1(1)	3, 14, 21
B200 M4 w/E5-Series v4	UCS 1280 Virtual Interface Card	Ubuntu 14.04.4	2.3.0.27 (ENIC)	4.1(1)	3, 14, 21
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1280 Virtual Interface Card	Ubuntu 14.04.5	2.3.0.30 (ENIC)	4.1(1)	3, 14, 21
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS 1280 Virtual Interface Card	Ubuntu 14.04.5	2.3.0.30 (ENIC)	4.1(1)	3, 14, 21
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1280 Virtual Interface Card	Ubuntu 14.04.5	2.3.0.30 (ENIC)	4.1(1)	3, 14, 21
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1280 Virtual Interface Card	Ubuntu 14.04.5	2.3.0.30 (ENIC)	4.1(1)	3, 14, 21
B200 M4 w/E5-Series v4	UCS 1280 Virtual Interface Card	Ubuntu 14.04.5	2.3.0.30 (ENIC)	4.1(1)	3, 14, 21

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1280 Virtual Interface Card	Ubuntu 16.04	2.3.0.27 (ENIC)	4.1(1)	3, 14, 43
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS 1280 Virtual Interface Card	Ubuntu 16.04	2.3.0.27 (ENIC)	4.1(1)	3, 14, 43
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1280 Virtual Interface Card	Ubuntu 16.04	2.3.0.27 (ENIC)	4.1(1)	3, 14, 43
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1280 Virtual Interface Card	Ubuntu 16.04	2.3.0.27 (ENIC)	4.1(1)	3, 14, 43
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	UCS 1280 Virtual Interface Card	Ubuntu 16.04	2.3.0.27 (ENIC)	4.1(1)	3, 14, 43
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1280 Virtual Interface Card	Ubuntu 16.04.1	2.3.0.30 (ENIC)	4.1(1)	3, 14, 21
B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS 1280 Virtual Interface Card	Ubuntu 16.04.1	2.3.0.30 (ENIC)	4.1(1)	3, 14, 21
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1280 Virtual Interface Card	Ubuntu 16.04.1	2.3.0.30 (ENIC)	4.1(1)	3, 14, 21

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1280 Virtual Interface Card	Ubuntu 16.04.1	2.3.0.30 (ENIC)	4.1(1)	3, 14, 21
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	UCS 1280 Virtual Interface Card	Ubuntu 16.04.1	2.3.0.30 (ENIC)	4.1(1)	3, 14, 21
B200 M2 w/E5-Series, B230 M2, B440 M2	UCS 1280 Virtual Interface Card	vSphere 5.0 U2	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 14, 31, 52, 53, 54
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1280 Virtual Interface Card	vSphere 5.0 U2	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 14, 31, 52, 53, 54
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS 1280 Virtual Interface Card	vSphere 5.0 U2	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 14, 31, 52, 53, 54
B200 M2 w/E5-Series, B230 M2, B440 M2	UCS 1280 Virtual Interface Card	vSphere 5.0 U3	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 14, 31, 52, 53, 54
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1280 Virtual Interface Card	vSphere 5.0 U3	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 14, 31, 52, 53, 54
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS 1280 Virtual Interface Card	vSphere 5.0 U3	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 14, 31, 52, 53, 54
B200 M2 w/E5-Series, B230 M2, B440 M2	UCS 1280 Virtual Interface Card	vSphere 5.1 U1	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 14, 31, 52, 53, 54

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1280 Virtual Interface Card	vSphere 5.1 U1	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 14, 31, 52, 53, 54
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS 1280 Virtual Interface Card	vSphere 5.1 U1	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 14, 31, 52, 53, 54
B200 M2 w/E5-Series, B230 M2, B440 M2	UCS 1280 Virtual Interface Card	vSphere 5.1 U2	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 14, 31, 52, 53, 54
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1280 Virtual Interface Card	vSphere 5.1 U2	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 14, 31, 52, 53, 54
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2, B200 M4 w/E5-Series v3	UCS 1280 Virtual Interface Card	vSphere 5.1 U2	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 14, 31, 52, 53, 54
B200 M2 w/E5-Series, B230 M2, B440 M2	UCS 1280 Virtual Interface Card	vSphere 5.1 U3	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 14, 31, 52, 53, 54
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1280 Virtual Interface Card	vSphere 5.1 U3	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 14, 31, 52, 53, 54

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1280 Virtual Interface Card	vSphere 5.1 U3	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 14, 31, 52, 53, 54
B200 M2 w/E5-Series, B230 M2, B440 M2	UCS 1280 Virtual Interface Card	vSphere 5.5	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 14, 31, 52, 53, 54
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1280 Virtual Interface Card	vSphere 5.5	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 14, 31, 52, 53, 54
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1280 Virtual Interface Card	vSphere 5.5	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 14, 31, 52, 53, 54
B200 M2 w/E5-Series, B230 M2, B440 M2	UCS 1280 Virtual Interface Card	vSphere 5.5 U1	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 14, 31, 52, 53, 54
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1280 Virtual Interface Card	vSphere 5.5 U1	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 14, 31, 52, 53, 54
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1280 Virtual Interface Card	vSphere 5.5 U1	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 14, 31, 52, 53, 54

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B200 M2 w/E5-Series, B230 M2, B440 M2	UCS 1280 Virtual Interface Card	vSphere 5.5 U2	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 14, 31, 52, 53, 54
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1280 Virtual Interface Card	vSphere 5.5 U2	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 14, 31, 52, 53, 54
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1280 Virtual Interface Card	vSphere 5.5 U2	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 14, 31, 52, 53, 54
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1280 Virtual Interface Card	vSphere 5.5 U2	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 14, 31, 52, 53, 54
B200 M2 w/E5-Series, B230 M2, B440 M2	UCS 1280 Virtual Interface Card	vSphere 5.5 U3	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 14, 31, 52, 53, 54
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1280 Virtual Interface Card	vSphere 5.5 U3	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 14, 31, 52, 53, 54
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1280 Virtual Interface Card	vSphere 5.5 U3	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 14, 31, 52, 53, 54

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1280 Virtual Interface Card	vSphere 5.5 U3	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 14, 31, 52, 53, 54
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	UCS 1280 Virtual Interface Card	vSphere 5.5 U3	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 14, 31, 52, 53, 54
B200 M2 w/E5-Series, B230 M2, B440 M2	UCS 1280 Virtual Interface Card	vSphere 6.0	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 14, 31, 52, 53, 54
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1280 Virtual Interface Card	vSphere 6.0	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 14, 31, 52, 53, 54
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1280 Virtual Interface Card	vSphere 6.0	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 14, 31, 52, 53, 54
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1280 Virtual Interface Card	vSphere 6.0	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 14, 31, 52, 53, 54
B200 M2 w/E5-Series, B230 M2, B440 M2	UCS 1280 Virtual Interface Card	vSphere 6.0 U1	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 14, 31, 52, 53, 54
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1280 Virtual Interface Card	vSphere 6.0 U1	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 14, 31, 52, 53, 54

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1280 Virtual Interface Card	vSphere 6.0 U1	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 14, 31, 52, 53, 54
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1280 Virtual Interface Card	vSphere 6.0 U1	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 14, 31, 52, 53, 54
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	UCS 1280 Virtual Interface Card	vSphere 6.0 U1	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 14, 31, 52, 53, 54
B200 M2 w/E5-Series, B230 M2, B440 M2	UCS 1280 Virtual Interface Card	vSphere 6.0 U2	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 14, 31, 52, 53, 54
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1280 Virtual Interface Card	vSphere 6.0 U2	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 14, 31, 52, 53, 54
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1280 Virtual Interface Card	vSphere 6.0 U2	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 14, 31, 52, 53, 54
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1280 Virtual Interface Card	vSphere 6.0 U2	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 14, 31, 52, 53, 54

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	UCS 1280 Virtual Interface Card	vSphere 6.0 U2	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 14, 31, 52, 53, 54
B200 M2 w/E5-Series, B230 M2, B440 M2	UCS 1280 Virtual Interface Card	vSphere 6.5	1.6.0.28 (FNIC) / 1.0.0.2 (NENIC)	4.1(1)	11, 12, 14, 31, 46, 59
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1280 Virtual Interface Card	vSphere 6.5	1.6.0.28 (FNIC) / 1.0.0.2 (NENIC)	4.1(1)	11, 12, 14, 31, 46, 59
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1280 Virtual Interface Card	vSphere 6.5	1.6.0.28 (FNIC) / 1.0.0.2 (NENIC)	4.1(1)	11, 12, 14, 31, 46, 59
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1280 Virtual Interface Card	vSphere 6.5	1.6.0.28 (FNIC) / 1.0.0.2 (NENIC)	4.1(1)	11, 12, 14, 31, 46, 59
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	UCS 1280 Virtual Interface Card	vSphere 6.5	1.6.0.28 (FNIC) / 1.0.0.2 (NENIC)	4.1(1)	11, 12, 14, 31, 46, 59
B200 M2 w/E5-Series, B230 M2, B440 M2	UCS 1280 Virtual Interface Card	Windows Server 2008 R2 SP1	2.1.0.34 (FNIC) / 2.4.0.21 (ENIC) / 2.1.0.12 (NIC Teaming Driver)	4.1(1)	12, 14, 21, 25, 53, 55
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1280 Virtual Interface Card	Windows Server 2008 R2 SP1	2.1.0.34 (FNIC) / 2.4.0.21 (ENIC) / 2.1.0.12 (NIC Teaming Driver)	4.1(1)	12, 14, 21, 25, 53, 55

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1280 Virtual Interface Card	Windows Server 2008 R2 SP1	2.1.0.34 (FNIC) / 2.4.0.21 (ENIC) / 2.1.0.12 (NIC Teaming Driver)	4.1(1)	12, 14, 21, 25, 53, 55
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1280 Virtual Interface Card	Windows Server 2008 R2 SP1	2.1.0.34 (FNIC) / 2.4.0.21 (ENIC) / 2.1.0.12 (NIC Teaming Driver)	4.1(1)	12, 14, 21, 25, 53, 55
B200 M2 w/E5-Series, B230 M2, B440 M2	UCS 1280 Virtual Interface Card	Windows Server 2012	2.4.0.19 (FNIC) / 3.5.0.17 (ENIC)	4.1(1)	12, 14, 21, 35, 56, 57
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1280 Virtual Interface Card	Windows Server 2012	2.4.0.19 (FNIC) / 3.5.0.17 (ENIC)	4.1(1)	12, 14, 21, 35, 56, 57
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1280 Virtual Interface Card	Windows Server 2012	2.4.0.19 (FNIC) / 3.5.0.17 (ENIC)	4.1(1)	12, 14, 21, 35, 56, 57
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1280 Virtual Interface Card	Windows Server 2012	2.4.0.19 (FNIC) / 3.5.0.17 (ENIC)	4.1(1)	12, 14, 21, 35, 56, 57
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	UCS 1280 Virtual Interface Card	Windows Server 2012	2.4.0.19 (FNIC) / 3.5.0.17 (ENIC)	4.1(1)	12, 14, 21, 35, 56, 57

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B200 M2 w/E5-Series, B230 M2, B440 M2	UCS 1280 Virtual Interface Card	Windows Server 2012 R2	2.4.0.19 (FNIC) / 3.5.0.17 (ENIC)	4.1(1)	10, 12, 14, 21, 35, 56, 57
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1280 Virtual Interface Card	Windows Server 2012 R2	2.4.0.19 (FNIC) / 3.5.0.17 (ENIC)	4.1(1)	10, 12, 14, 21, 35, 56, 57
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1280 Virtual Interface Card	Windows Server 2012 R2	2.4.0.19 (FNIC) / 3.5.0.17 (ENIC)	4.1(1)	10, 12, 14, 21, 35, 56, 57
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1280 Virtual Interface Card	Windows Server 2012 R2	2.4.0.19 (FNIC) / 3.5.0.17 (ENIC)	4.1(1)	10, 12, 14, 21, 35, 56, 57
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	UCS 1280 Virtual Interface Card	Windows Server 2012 R2	2.4.0.19 (FNIC) / 3.5.0.17 (ENIC)	4.1(1)	10, 12, 14, 21, 35, 56, 57
B200 M2 w/E5-Series, B230 M2, B440 M2	UCS 1280 Virtual Interface Card	Windows Server 2016	3.0.0.7 (FNIC) / 4.0.0.2 (ENIC)	4.1(2)	10, 12, 14, 21, 46
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1280 Virtual Interface Card	Windows Server 2016	3.0.0.7 (FNIC) / 4.0.0.2 (ENIC)	4.1(2)	10, 12, 14, 21, 46

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1280 Virtual Interface Card	Windows Server 2016	3.0.0.7 (FNIC) / 4.0.0.2 (ENIC)	4.1(2)	10, 12, 14, 21, 46
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1280 Virtual Interface Card	Windows Server 2016	3.0.0.7 (FNIC) / 4.0.0.2 (ENIC)	4.1(2)	10, 12, 14, 21, 46
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	UCS 1280 Virtual Interface Card	Windows Server 2016	3.0.0.7 (FNIC) / 4.0.0.2 (ENIC)	4.1(2)	10, 12, 14, 21, 46
B200 M2 w/E5-Series, B230 M2, B440 M2	UCS 1280 Virtual Interface Card	XenServer 6.1	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	4, 14, 21, 29
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1280 Virtual Interface Card	XenServer 6.1	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	4, 14, 21, 29
B200 M2 w/E5-Series, B230 M2, B440 M2	UCS 1280 Virtual Interface Card	XenServer 6.2	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	4, 14, 21
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1280 Virtual Interface Card	XenServer 6.2	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	14, 21

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2, B200 M4 w/E5-Series v3	UCS 1280 Virtual Interface Card	XenServer 6.2	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	14, 21
B200 M2 w/E5-Series, B230 M2, B440 M2	UCS 1280 Virtual Interface Card	XenServer 6.5	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	21, 38, 41
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1280 Virtual Interface Card	XenServer 6.5	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	21, 38, 41
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1280 Virtual Interface Card	XenServer 6.5	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	21, 38, 41
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1280 Virtual Interface Card	XenServer 6.5	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	21, 38, 41
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	UCS 1280 Virtual Interface Card	XenServer 6.5	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	21, 38, 41
B200 M2 w/E5-Series, B230 M2, B440 M2	UCS 1280 Virtual Interface Card	XenServer 7.0	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	38, 43

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1280 Virtual Interface Card	XenServer 7.0	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	38, 43
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1280 Virtual Interface Card	XenServer 7.0	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	38, 43
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1280 Virtual Interface Card	XenServer 7.0	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	38, 43
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	UCS 1280 Virtual Interface Card	XenServer 7.0	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	38, 43
B200 M2 w/E5-Series, B250 M2, B230 M1 & M2, B440 M1 & M2	UCS M81KR Virtual Interface Card	Red Hat Enterprise Linux 5.9	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	2.2(3)	12, 21, 27
B200 M2 w/E5-Series, B250 M2, B230 M1 & M2, B440 M1 & M2	UCS M81KR Virtual Interface Card	Red Hat Enterprise Linux 5.10	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	2.2(3)	12, 21
B200 M2 w/E5-Series, B250 M2, B230 M1 & M2, B440 M1 & M2	UCS M81KR Virtual Interface Card	Red Hat Enterprise Linux 5.11	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	2.2(3)	12, 21
B200 M2 w/E5-Series, B250 M2, B230 M1 & M2, B440 M1 & M2	UCS M81KR Virtual Interface Card	Red Hat Enterprise Linux 6.4	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	2.2(3)	12, 21, 27

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B200 M2 w/E5-Series, B250 M2, B230 M1 & M2, B440 M1 & M2	UCS M81KR Virtual Interface Card	Red Hat Enterprise Linux 6.5	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	2.2(3)	12, 21
B200 M2 w/E5-Series, B250 M2, B230 M1 & M2, B440 M1 & M2	UCS M81KR Virtual Interface Card	Red Hat Enterprise Linux 6.6	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	2.2(3)	12, 21
B200 M2 w/E5-Series, B250 M2, B230 M1 & M2, B440 M1 & M2	UCS M81KR Virtual Interface Card	Red Hat Enterprise Linux 6.7	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	2.2(3)	12, 21
B200 M2 w/E5-Series, B250 M2, B230 M1 & M2, B440 M1 & M2	UCS M81KR Virtual Interface Card	Red Hat Enterprise Linux 6.8	1.6.0.27 (FNIC) / 2.3.0.27 (ENIC)	2.2(3)	12, 21
B200 M2 w/E5-Series, B230 M2, B250 M2, B440 M2	UCS M81KR Virtual Interface Card	SUSE Linux Enterprise Server 11.2	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	2.2(3)	12, 21
B200 M2 w/E5-Series, B230 M2, B250 M2, B440 M2	UCS M81KR Virtual Interface Card	SUSE Linux Enterprise Server 11.3	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	2.2(3)	12, 21
B200 M2 w/E5-Series, B230 M2, B250 M2, B440 M2	UCS M81KR Virtual Interface Card	SUSE Linux Enterprise Server 11.4	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	2.2(3)	12, 21
B200 M1 w/E5-Series, B230 M1 & M2, B250 M1 & M2, B440 M1 & M2	UCS M81KR Virtual Interface Card	vSphere 5.0 U2	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	2.2(3)	11, 12, 31, 52, 53, 54
B200 M1 w/E5-Series, B230 M1 & M2, B250 M1 & M2, B440 M1 & M2	UCS M81KR Virtual Interface Card	vSphere 5.0 U3	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	2.2(3)	11, 12, 31, 52, 53, 54

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B200 M2 w/E5-Series, B230 M2, B250 M2, B440 M2	UCS M81KR Virtual Interface Card	vSphere 5.1 U1	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	2.2(3)	11, 12, 31, 52, 53, 54
B200 M2 w/E5-Series, B230 M2, B250 M2, B440 M2	UCS M81KR Virtual Interface Card	vSphere 5.1 U2	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	2.2(3)	11, 12, 31, 52, 53, 54
B200 M2 w/E5-Series, B230 M2, B250 M2, B440 M2	UCS M81KR Virtual Interface Card	vSphere 5.1 U3	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	2.2(3)	11, 12, 31, 52, 53, 54
B200 M1 w/E5-Series, B230 M1 & M2, B250 M1 & M2, B440 M1 & M2	UCS M81KR Virtual Interface Card	Windows Server 2008 R2 SP1	2.1.0.34 (FNIC) / 2.4.0.21 (ENIC) / 2.1.0.12 (NIC Teaming Driver)	2.2(3)	12, 21, 25, 53, 55
B200 M2 w/E5-Series, B230 M2, B250 M2, B440 M2	UCS M81KR Virtual Interface Card	Windows Server 2012	2.4.0.19 (FNIC) / 3.5.0.17 (ENIC)	2.2(3)	12, 21, 35, 56, 57
B200 M2 w/E5-Series, B230 M2, B440 M2	UCS M81KR Virtual Interface Card	Windows Server 2012 R2	2.4.0.19 (FNIC) / 3.5.0.17 (ENIC)	2.2(3)	10, 12, 21, 35, 56, 57
B200 M2 w/E5-Series, B230 M2, B250 M2, B440 M2	UCS M81KR Virtual Interface Card	XenServer 6.1	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	2.2(3)	4, 21, 29
B200 M2 w/E5-Series, B230 M2, B250 M2, B440 M2	UCS M81KR Virtual Interface Card	XenServer 6.2	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	2.2(3)	4, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1227 10Gbps 2 port CNA SFP+	vSphere 5.1 U2	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 20, 31, 52, 53, 54

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1227 10Gbps 2 port CNA SFP+	vSphere 5.1 U2	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 20, 31, 52, 53, 54
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1227 10Gbps 2 port CNA SFP+	vSphere 5.1 U3	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 20, 31, 52, 53, 54
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1227 10Gbps 2 port CNA SFP+	vSphere 5.1 U3	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 20, 31, 52, 53, 54
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1227 10Gbps 2 port CNA SFP+	vSphere 5.5 U2	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 20, 31, 52, 53, 54
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1227 10Gbps 2 port CNA SFP+	vSphere 5.5 U2	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 20, 31, 52, 53, 54
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C220 M4(SFF/LFF) w/E5-Series v4, C240 M4(SFF/LFF) w/E5-Series v4	UCS VIC 1227 10Gbps 2 port CNA SFP+	vSphere 5.5 U3	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 20, 31, 52, 53, 54
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1227 10Gbps 2 port CNA SFP+	vSphere 5.5 U3	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 20, 31, 52, 53, 54

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1227 10Gbps 2 port CNA SFP+	vSphere 6.0	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 20, 31, 52, 53, 54
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1227 10Gbps 2 port CNA SFP+	vSphere 6.0	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 20, 31, 52, 53, 54
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C220 M4(SFF/LFF) w/E5-Series v4, C240 M4(SFF/LFF) w/E5-Series v4	UCS VIC 1227 10Gbps 2 port CNA SFP+	vSphere 6.0 U1	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 20, 31, 52, 53, 54
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1227 10Gbps 2 port CNA SFP+	vSphere 6.0 U1	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 20, 31, 52, 53, 54
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C220 M4(SFF/LFF) w/E5-Series v4, C240 M4(SFF/LFF) w/E5-Series v4	UCS VIC 1227 10Gbps 2 port CNA SFP+	vSphere 6.0 U2	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 20, 31, 52, 53, 54
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1227 10Gbps 2 port CNA SFP+	vSphere 6.0 U2	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 20, 31, 52, 53, 54

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C220 M4(SFF/LFF) w/E5-Series v4, C240 M4(SFF/LFF) w/E5-Series v4	UCS VIC 1227 10Gbps 2 port CNA SFP+	vSphere 6.5	1.6.0.28 (FNIC) / 1.0.0.2 (nenic)	4.1(1)	11, 12, 20, 31, 52, 53, 59
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1227 10Gbps 2 port CNA SFP+	Windows Server 2008 R2 SP1	2.1.0.34 (FNIC) / 2.4.0.21 (ENIC) / 2.1.0.12 (NIC Teaming Driver)	4.1(1)	12, 20, 21, 25, 53, 55
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1227 10Gbps 2 port CNA SFP+	Windows Server 2008 R2 SP1	2.1.0.34 (FNIC) / 2.4.0.21 (ENIC) / 2.1.0.12 (NIC Teaming Driver)	4.1(1)	12, 20, 21, 25, 53, 55
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1227 10Gbps 2 port CNA SFP+	Windows Server 2012	2.4.0.19 (FNIC) / 3.5.0.17 (ENIC)	4.1(1)	12, 20, 21, 35, 56, 57
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1227 10Gbps 2 port CNA SFP+	Windows Server 2012	2.4.0.19 (FNIC) / 3.5.0.17 (ENIC)	4.1(1)	12, 20, 21, 35, 56, 57
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C220 M4(SFF/LFF) w/E5-Series v4, C240 M4(SFF/LFF) w/E5-Series v4	UCS VIC 1227 10Gbps 2 port CNA SFP+	Windows Server 2012 R2	2.4.0.19 (FNIC) / 3.5.0.17 (ENIC)	4.1(1)	10, 12, 20, 21, 35, 56, 57

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1227 10Gbps 2 port CNA SFP+	Windows Server 2012 R2	2.4.0.19 (FNIC) / 3.5.0.17 (ENIC)	4.1(1)	10, 12, 20, 21, 35, 56, 57
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1227 10Gbps 2 port CNA SFP+	Red Hat Enterprise Linux 6.5	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1227 10Gbps 2 port CNA SFP+	Red Hat Enterprise Linux 6.5	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1227 10Gbps 2 port CNA SFP+	Red Hat Enterprise Linux 6.6	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1227 10Gbps 2 port CNA SFP+	Red Hat Enterprise Linux 6.6	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C220 M4(SFF/LFF) w/E5-Series v4, C240 M4(SFF/LFF) w/E5-Series v4	UCS VIC 1227 10Gbps 2 port CNA SFP+	Red Hat Enterprise Linux 6.7	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1227 10Gbps 2 port CNA SFP+	Red Hat Enterprise Linux 6.7	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C220 M4(SFF/LFF) w/E5-Series v4, C240 M4(SFF/LFF) w/E5-Series v4	UCS VIC 1227 10Gbps 2 port CNA SFP+	Red Hat Enterprise Linux 6.8	1.6.0.27 (FNIC) / 2.3.0.27 (ENIC)	4.1(1)	20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1227 10Gbps 2 port CNA SFP+	Red Hat Enterprise Linux 6.8	1.6.0.27 (FNIC) / 2.3.0.27 (ENIC)	4.1(1)	20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1227 10Gbps 2 port CNA SFP+	Red Hat Enterprise Linux 7.0	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1227 10Gbps 2 port CNA SFP+	Red Hat Enterprise Linux 7.0	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1227 10Gbps 2 port CNA SFP+	Red Hat Enterprise Linux 7.1	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1227 10Gbps 2 port CNA SFP+	Red Hat Enterprise Linux 7.1	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C220 M4(SFF/LFF) w/E5-Series v4, C240 M4(SFF/LFF) w/E5-Series v4	UCS VIC 1227 10Gbps 2 port CNA SFP+	Red Hat Enterprise Linux 7.2	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1227 10Gbps 2 port CNA SFP+	Red Hat Enterprise Linux 7.2	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1227 10Gbps 2 port CNA SFP+	CentOS 6.6	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21, 39, 40
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1227 10Gbps 2 port CNA SFP+	CentOS 6.6	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21, 39, 40
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C220 M4(SFF/LFF) w/E5-Series v4, C240 M4(SFF/LFF) w/E5-Series v4	UCS VIC 1227 10Gbps 2 port CNA SFP+	CentOS 6.7	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21, 39, 40
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1227 10Gbps 2 port CNA SFP+	CentOS 6.7	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21, 39, 40

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C220 M4(SFF/LFF) w/E5-Series v4, C240 M4(SFF/LFF) w/E5-Series v4	UCS VIC 1227 10Gbps 2 port CNA SFP+	CentOS 7.1	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21, 39, 40
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1227 10Gbps 2 port CNA SFP+	CentOS 7.1	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21, 39, 40
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C220 M4(SFF/LFF) w/E5-Series v4, C240 M4(SFF/LFF) w/E5-Series v4	UCS VIC 1227 10Gbps 2 port CNA SFP+	CentOS 7.2	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21, 39, 40
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1227 10Gbps 2 port CNA SFP+	CentOS 7.2	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21, 39, 40
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1227 10Gbps 2 port CNA SFP+	UEK R3 U1 (3.8.13-26.x)	1.6.0.25 (FNIC) / 2.1.1.39 (ENIC)	4.1(1)	20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1227 10Gbps 2 port CNA SFP+	UEK R3 U1 (3.8.13-26.x)	1.6.0.25 (FNIC) / 2.1.1.39 (ENIC)	4.1(1)	20, 21

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1227 10Gbps 2 port CNA SFP+	UEK R3 U3 (3.8.13-44.x)	1.6.0.25 (FNIC) / 2.1.1.50 (ENIC)	4.1(1)	20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1227 10Gbps 2 port CNA SFP+	UEK R3 U3 (3.8.13-44.x)	1.6.0.25 (FNIC) / 2.1.1.50 (ENIC)	4.1(1)	20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1227 10Gbps 2 port CNA SFP+	UEK R3 U5 (3.8.13-68.x)	1.6.0.25 (FNIC) / 2.1.1.67 (ENIC)	4.1(1)	20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1227 10Gbps 2 port CNA SFP+	UEK R3 U5 (3.8.13-68.x)	1.6.0.25 (FNIC) / 2.1.1.67 (ENIC)	4.1(1)	20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1227 10Gbps 2 port CNA SFP+	UEK R3 U6 (3.8.13-98.x)	1.6.0.25 (FNIC) / 2.1.1.67 (ENIC)	4.1(1)	20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1227 10Gbps 2 port CNA SFP+	UEK R3 U7 (3.8.13-118)	1.6.0.25 (FNIC) / 2.1.1.67 (ENIC)	4.1(1)	20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1227 10Gbps 2 port CNA SFP+	UEK R4 (4.1.12-32.x)	1.6.0.22 (FNIC) / 2.1.1.67 (ENIC)	4.1(1)	20, 43
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1227 10Gbps 2 port CNA SFP+	OVM 3.3.1	1.6.0.9 (FNIC) / 2.1.1.39 (ENIC)	4.1(1)	20, 43

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1227 10Gbps 2 port CNA SFP+	OVM 3.3.1	1.6.0.9 (FNIC) / 2.1.1.39 (ENIC)	4.1(1)	20, 43
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1227 10Gbps 2 port CNA SFP+	OVM 3.3.2	1.6.0.10 (FNIC) / 2.1.1.50 (ENIC)	4.1(1)	20, 43
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1227 10Gbps 2 port CNA SFP+	OVM 3.3.2	1.6.0.10 (FNIC) / 2.1.1.50 (ENIC)	4.1(1)	20, 43
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1227 10Gbps 2 port CNA SFP+	OVM 3.3.3	1.6.0.10 (FNIC) / 2.1.1.67 (ENIC)	4.1(1)	20, 43
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1227 10Gbps 2 port CNA SFP+	OVM 3.3.3	1.6.0.10 (FNIC) / 2.1.1.67 (ENIC)	4.1(1)	20, 43
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1227 10Gbps 2 port CNA SFP+	OVM 3.4.1	1.6.0.22 (FNIC) / 2.3.0.12 (ENIC)	4.1(1)	20, 43
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1227 10Gbps 2 port CNA SFP+	SUSE Linux Enterprise Server 11.3	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1227 10Gbps 2 port CNA SFP+	SUSE Linux Enterprise Server 11.3	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1227 10Gbps 2 port CNA SFP+	SUSE Linux Enterprise Server 11.4	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1227 10Gbps 2 port CNA SFP+	SUSE Linux Enterprise Server 11.4	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C220 M4(SFF/LFF) w/E5-Series v4, C240 M4(SFF/LFF) w/E5-Series v4	UCS VIC 1227 10Gbps 2 port CNA SFP+	SUSE Linux Enterprise Server 12	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1227 10Gbps 2 port CNA SFP+	SUSE Linux Enterprise Server 12	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C220 M4(SFF/LFF) w/E5-Series v4, C240 M4(SFF/LFF) w/E5-Series v4	UCS VIC 1227 10Gbps 2 port CNA SFP+	SUSE Linux Enterprise Server 12.1	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	12, 20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1227 10Gbps 2 port CNA SFP+	SUSE Linux Enterprise Server 12.1	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	12, 20, 21

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1227 10Gbps 2 port CNA SFP+	XenServer 6.2	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	4, 20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1227 10Gbps 2 port CNA SFP+	XenServer 6.2	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	4, 20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1227 10Gbps 2 port CNA SFP+	XenServer 6.5	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21, 41
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1227 10Gbps 2 port CNA SFP+	XenServer 6.5	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21, 41
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1227 10Gbps 2 port CNA SFP+	Ubuntu 12.04.5	2.1.1.50 (ENIC)	4.1(1)	3, 20, 43
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1227 10Gbps 2 port CNA SFP+	Ubuntu 14.04.1	2.1.1.50 (ENIC)	4.1(1)	3, 20, 43
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1227 10Gbps 2 port CNA SFP+	Ubuntu 14.04.1	2.1.1.50 (ENIC)	4.1(1)	3, 20, 43
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1227 10Gbps 2 port CNA SFP+	Ubuntu 14.04.2	2.3.0.20 (ENIC)	4.1(1)	3, 20, 21

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1227 10Gbps 2 port CNA SFP+	Ubuntu 14.04.2	2.3.0.20 (ENIC)	4.1(1)	3, 20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1227 10Gbps 2 port CNA SFP+	Ubuntu 14.04.3	2.3.0.20 (ENIC)	4.1(1)	3, 20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1227 10Gbps 2 port CNA SFP+	Ubuntu 14.04.3	2.3.0.20 (ENIC)	4.1(1)	3, 20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C220 M4(SFF/LFF) w/E5-Series v4, C240 M4(SFF/LFF) w/E5-Series v4	UCS VIC 1227 10Gbps 2 port CNA SFP+	Ubuntu 14.04.4	2.3.0.27 (ENIC)	4.1(1)	3, 20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1227 10Gbps 2 port CNA SFP+	Ubuntu 14.04.4	2.3.0.27 (ENIC)	4.1(1)	3, 20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C220 M4(SFF/LFF) w/E5-Series v4, C240 M4(SFF/LFF) w/E5-Series v4	UCS VIC 1227 10Gbps 2 port CNA SFP+	Ubuntu 16.04	2.3.0.27 (ENIC)	4.1(1)	3, 20, 21

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1227 10Gbps 2 port CNA SFP+	Ubuntu 16.04	2.3.0.27 (ENIC)	4.1(1)	3, 20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1227T 10-Gbase-T 2 port CNA	vSphere 5.1 U2	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 20, 31, 52, 53, 54
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1227T 10-Gbase-T 2 port CNA	vSphere 5.1 U2	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 20, 31, 52, 53, 54
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1227T 10-Gbase-T 2 port CNA	vSphere 5.1 U3	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 20, 31, 52, 53, 54
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1227T 10-Gbase-T 2 port CNA	vSphere 5.1 U3	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 20, 31, 52, 53, 54
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1227T 10-Gbase-T 2 port CNA	vSphere 5.5 U2	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 20, 31, 52, 53, 54
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1227T 10-Gbase-T 2 port CNA	vSphere 5.5 U2	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 20, 31, 52, 53, 54

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C220 M4(SFF/LFF) w/E5-Series v4, C240 M4(SFF/LFF) w/E5-Series v4	UCS VIC 1227T 10-Gbase-T 2 port CNA	vSphere 5.5 U3	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 20, 31, 52, 53, 54
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1227T 10-Gbase-T 2 port CNA	vSphere 5.5 U3	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 20, 31, 52, 53, 54
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1227T 10-Gbase-T 2 port CNA	vSphere 6.0	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 20, 31, 52, 53, 54
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1227T 10-Gbase-T 2 port CNA	vSphere 6.0	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 20, 31, 52, 53, 54
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C220 M4(SFF/LFF) w/E5-Series v4, C240 M4(SFF/LFF) w/E5-Series v4	UCS VIC 1227T 10-Gbase-T 2 port CNA	vSphere 6.0 U1	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 20, 31, 52, 53, 54
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1227T 10-Gbase-T 2 port CNA	vSphere 6.0 U1	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 20, 31, 52, 53, 54

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C220 M4(SFF/LFF) w/E5-Series v4, C240 M4(SFF/LFF) w/E5-Series v4	UCS VIC 1227T 10-Gbase-T 2 port CNA	vSphere 6.0 U2	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 20, 31, 52, 53, 54
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1227T 10-Gbase-T 2 port CNA	vSphere 6.0 U2	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 20, 31, 52, 53, 54
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C220 M4(SFF/LFF) w/E5-Series v4, C240 M4(SFF/LFF) w/E5-Series v4	UCS VIC 1227T 10-Gbase-T 2 port CNA	vSphere 6.5	1.6.0.28 (FNIC) / 1.0.0.2 (nenic)	4.1(1)	11, 12, 20, 31, 52, 53, 59
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1227T 10-Gbase-T 2 port CNA	Windows Server 2008 R2 SP1	2.1.0.34 (FNIC) / 2.4.0.21 (ENIC) / 2.1.0.12 (NIC Teaming Driver)	4.1(1)	12, 20, 21, 25, 53, 55
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1227T 10-Gbase-T 2 port CNA	Windows Server 2012	2.4.0.19 (FNIC) / 3.5.0.17 (ENIC)	4.1(1)	12, 20, 21, 35, 56, 57
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1227T 10-Gbase-T 2 port CNA	Windows Server 2012	2.4.0.19 (FNIC) / 3.5.0.17 (ENIC)	4.1(1)	12, 20, 21, 35, 56, 57

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C220 M4(SFF/LFF) w/E5-Series v4, C240 M4(SFF/LFF) w/E5-Series v4	UCS VIC 1227T 10-Gbase-T 2 port CNA	Windows Server 2012 R2	2.4.0.19 (FNIC) / 3.5.0.17 (ENIC)	4.1(1)	10, 12, 20, 21, 35, 56, 57
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1227T 10-Gbase-T 2 port CNA	Windows Server 2012 R2	2.4.0.19 (FNIC) / 3.5.0.17 (ENIC)	4.1(1)	10, 12, 20, 21, 35, 56, 57
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1227T 10-Gbase-T 2 port CNA	Red Hat Enterprise Linux 6.5	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1227T 10-Gbase-T 2 port CNA	Red Hat Enterprise Linux 6.5	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1227T 10-Gbase-T 2 port CNA	Red Hat Enterprise Linux 6.6	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1227T 10-Gbase-T 2 port CNA	Red Hat Enterprise Linux 6.6	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C220 M4(SFF/LFF) w/E5-Series v4, C240 M4(SFF/LFF) w/E5-Series v4	UCS VIC 1227T 10-Gbase-T 2 port CNA	Red Hat Enterprise Linux 6.7	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1227T 10-Gbase-T 2 port CNA	Red Hat Enterprise Linux 6.7	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C220 M4(SFF/LFF) w/E5-Series v4, C240 M4(SFF/LFF) w/E5-Series v4	UCS VIC 1227T 10-Gbase-T 2 port CNA	Red Hat Enterprise Linux 6.8	1.6.0.27 (FNIC) / 2.3.0.27 (ENIC)	4.1(1)	20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1227T 10-Gbase-T 2 port CNA	Red Hat Enterprise Linux 6.8	1.6.0.27 (FNIC) / 2.3.0.27 (ENIC)	4.1(1)	20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1227T 10-Gbase-T 2 port CNA	Red Hat Enterprise Linux 7.0	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1227T 10-Gbase-T 2 port CNA	Red Hat Enterprise Linux 7.0	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1227T 10-Gbase-T 2 port CNA	Red Hat Enterprise Linux 7.1	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1227T 10-Gbase-T 2 port CNA	Red Hat Enterprise Linux 7.1	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C220 M4(SFF/LFF) w/E5-Series v4, C240 M4(SFF/LFF) w/E5-Series v4	UCS VIC 1227T 10-Gbase-T 2 port CNA	Red Hat Enterprise Linux 7.2	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1227T 10-Gbase-T 2 port CNA	Red Hat Enterprise Linux 7.2	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1227T 10-Gbase-T 2 port CNA	CentOS 6.6	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21, 39, 40
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1227T 10-Gbase-T 2 port CNA	CentOS 6.6	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21, 39, 40

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C220 M4(SFF/LFF) w/E5-Series v4, C240 M4(SFF/LFF) w/E5-Series v4	UCS VIC 1227T 10-Gbase-T 2 port CNA	CentOS 6.7	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21, 39, 40
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1227T 10-Gbase-T 2 port CNA	CentOS 6.7	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21, 39, 40
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C220 M4(SFF/LFF) w/E5-Series v4, C240 M4(SFF/LFF) w/E5-Series v4	UCS VIC 1227T 10-Gbase-T 2 port CNA	CentOS 7.1	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21, 39, 40
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1227T 10-Gbase-T 2 port CNA	CentOS 7.1	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21, 39, 40
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v4, C240 M4(SFF/LFF) w/E5-Series v4	UCS VIC 1227T 10-Gbase-T 2 port CNA	CentOS 7.2	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21, 39, 40
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1227T 10-Gbase-T 2 port CNA	CentOS 7.2	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21, 39, 40

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1227T 10-Gbase-T 2 port CNA	UEK R3 U1 (3.8.13-26.x)	1.6.0.25 (FNIC) / 2.1.1.39 (ENIC)	4.1(1)	20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1227T 10-Gbase-T 2 port CNA	UEK R3 U1 (3.8.13-26.x)	1.6.0.25 (FNIC) / 2.1.1.39 (ENIC)	4.1(1)	20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1227T 10-Gbase-T 2 port CNA	UEK R3 U3 (3.8.13-44.x)	1.6.0.25 (FNIC) / 2.1.1.50 (ENIC)	4.1(1)	20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1227T 10-Gbase-T 2 port CNA	UEK R3 U3 (3.8.13-44.x)	1.6.0.25 (FNIC) / 2.1.1.50 (ENIC)	4.1(1)	20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1227T 10-Gbase-T 2 port CNA	UEK R3 U5 (3.8.13-68.x)	1.6.0.25 (FNIC) / 2.1.1.67 (ENIC)	4.1(1)	20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1227T 10-Gbase-T 2 port CNA	UEK R3 U5 (3.8.13-68.x)	1.6.0.25 (FNIC) / 2.1.1.67 (ENIC)	4.1(1)	20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1227T 10-Gbase-T 2 port CNA	UEK R3 U6 (3.8.13-98.x)	1.6.0.25 (FNIC) / 2.1.1.67 (ENIC)	4.1(1)	20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1227T 10-Gbase-T 2 port CNA	UEK R4 (4.1.12-32.x)	1.6.0.22 (FNIC) / 2.3.0.12 (ENIC)	4.1(1)	20, 43

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1227T 10-Gbase-T 2 port CNA	OVM 3.3.1	1.6.0.9 (FNIC) / 2.1.1.39 (ENIC)	4.1(1)	20, 43
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1227T 10-Gbase-T 2 port CNA	OVM 3.3.1	1.6.0.9 (FNIC) / 2.1.1.39 (ENIC)	4.1(1)	20, 43
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1227T 10-Gbase-T 2 port CNA	OVM 3.3.2	1.6.0.10 (FNIC) / 2.1.1.50 (ENIC)	4.1(1)	20, 43
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1227T 10-Gbase-T 2 port CNA	OVM 3.3.2	1.6.0.10 (FNIC) / 2.1.1.50 (ENIC)	4.1(1)	20, 43
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1227T 10-Gbase-T 2 port CNA	OVM 3.3.3	1.6.0.10 (FNIC) / 2.1.1.67 (ENIC)	4.1(1)	20, 43
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1227T 10-Gbase-T 2 port CNA	OVM 3.3.3	1.6.0.10 (FNIC) / 2.1.1.67 (ENIC)	4.1(1)	20, 43
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1227T 10-Gbase-T 2 port CNA	OVM 3.4.1	1.6.0.22 (FNIC) / 2.3.0.12 (ENIC)	4.1(1)	20, 43
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1227T 10-Gbase-T 2 port CNA	SUSE Linux Enterprise Server 11.3	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1227T 10-Gbase-T 2 port CNA	SUSE Linux Enterprise Server 11.3	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1227T 10-Gbase-T 2 port CNA	SUSE Linux Enterprise Server 11.4	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1227T 10-Gbase-T 2 port CNA	SUSE Linux Enterprise Server 11.4	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C220 M4(SFF/LFF) w/E5-Series v4, C240 M4(SFF/LFF) w/E5-Series v4	UCS VIC 1227T 10-Gbase-T 2 port CNA	SUSE Linux Enterprise Server 12	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1227T 10-Gbase-T 2 port CNA	SUSE Linux Enterprise Server 12	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C220 M4(SFF/LFF) w/E5-Series v4, C240 M4(SFF/LFF) w/E5-Series v4	UCS VIC 1227T 10-Gbase-T 2 port CNA	SUSE Linux Enterprise Server 12.1	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	12, 20, 21

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1227T 10-Gbase-T 2 port CNA	SUSE Linux Enterprise Server 12.1	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	12, 20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1227T 10-Gbase-T 2 port CNA	XenServer 6.2	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	4, 20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1227T 10-Gbase-T 2 port CNA	XenServer 6.2	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	4, 20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1227T 10-Gbase-T 2 port CNA	XenServer 6.5	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21, 41
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1227T 10-Gbase-T 2 port CNA	XenServer 6.5	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21, 41
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1227T 10-Gbase-T 2 port CNA	Ubuntu 12.04.5	2.1.1.50 (ENIC)	4.1(1)	3, 20, 43
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1227T 10-Gbase-T 2 port CNA	Ubuntu 14.04.1	2.1.1.50 (ENIC)	4.1(1)	3, 20, 43
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1227T 10-Gbase-T 2 port CNA	Ubuntu 14.04.1	2.1.1.50 (ENIC)	4.1(1)	3, 20, 43

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1227T 10-Gbase-T 2 port CNA	Ubuntu 14.04.2	2.3.0.20 (ENIC)	4.1(1)	3, 20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1227T 10-Gbase-T 2 port CNA	Ubuntu 14.04.2	2.3.0.20 (ENIC)	4.1(1)	3, 20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1227T 10-Gbase-T 2 port CNA	Ubuntu 14.04.3	2.3.0.20 (ENIC)	4.1(1)	3, 20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1227T 10-Gbase-T 2 port CNA	Ubuntu 14.04.3	2.3.0.20 (ENIC)	4.1(1)	3, 20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C220 M4(SFF/LFF) w/E5-Series v4, C240 M4(SFF/LFF) w/E5-Series v4	UCS VIC 1227T 10-Gbase-T 2 port CNA	Ubuntu 14.04.4	2.3.0.27 (ENIC)	4.1(1)	3, 20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1227T 10-Gbase-T 2 port CNA	Ubuntu 14.04.4	2.3.0.27 (ENIC)	4.1(1)	3, 20, 21

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C220 M4(SFF/LFF) w/E5-Series v4, C240 M4(SFF/LFF) w/E5-Series v4	UCS VIC 1227T 10-Gbase-T 2 port CNA	Ubuntu 16.04	2.3.0.27 (ENIC)	4.1(1)	3, 20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1227T 10-Gbase-T 2 port CNA	Ubuntu 16.04	2.3.0.27 (ENIC)	4.1(1)	3, 20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1225 10-Gbps 2 port CNA SFP+	vSphere 5.1 U2	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 20, 31, 52, 53, 54
C220 M3(SFF/LFF) w/E5-Series, C240 M3(SFF/LFF) w/E5-Series, C240 M3 w/E5-Series, C22 M3 (SFF/LFF) w/E5-Series, C24 M3 (SFF/LFF) w/E5-Series, C220 M3 (SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C22 M3(SFF/LFF) w/E5-Series v2, C24 M3(SFF/LFF) w/E5-Series v2, C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2	UCS VIC 1225 10-Gbps 2 port CNA SFP+	vSphere 5.1 U2	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 20, 31, 52, 53, 54

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
C260 M2 w/E7-Series, C460 M2 w/E7-Series, C420 M3 w/E5-Series	UCS VIC 1225 10-Gbps 2 port CNA SFP+	vSphere 5.1 U3	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 20, 31, 52, 53, 54
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1225 10-Gbps 2 port CNA SFP+	vSphere 5.1 U3	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 20, 31, 52, 53, 54
C220 M3(SFF/LFF) w/E5-Series, C240 M3(SFF/LFF) w/E5-Series, C240 M3 w/E5-Series, C22 M3 (SFF/LFF) w/E5-Series, C24 M3 (SFF/LFF) w/E5-Series, C220 M3 (SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C22 M3(SFF/LFF) w/E5-Series v2, C24 M3(SFF/LFF) w/E5-Series v2, C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2	UCS VIC 1225 10-Gbps 2 port CNA SFP+	vSphere 5.1 U3	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 20, 31, 52, 53, 54

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
C220 M3(SFF/LFF) w/E5-Series, C240 M3(SFF/LFF) w/E5-Series, C240 M3 w/E5-Series, C22 M3 (SFF/LFF) w/E5-Series, C24 M3 (SFF/LFF) w/E5-Series, C220 M3 (SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C22 M3(SFF/LFF) w/E5-Series v2, C24 M3(SFF/LFF) w/E5-Series v2, C460 M4 w/E7-Series v2	UCS VIC 1225 10-Gbps 2 port CNA SFP+	vSphere 5.5	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 20, 31, 52, 53, 54
C220 M3(SFF/LFF) w/E5-Series, C240 M3(SFF/LFF) w/E5-Series, C240 M3 w/E5-Series, C22 M3 (SFF/LFF) w/E5-Series, C24 M3 (SFF/LFF) w/E5-Series, C220 M3 (SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C22 M3(SFF/LFF) w/E5-Series v2, C24 M3(SFF/LFF) w/E5-Series v2, C460 M4 w/E7-Series v2	UCS VIC 1225 10-Gbps 2 port CNA SFP+	vSphere 5.5 U1	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 20, 31, 52, 53, 54
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1225 10-Gbps 2 port CNA SFP+	vSphere 5.5 U2	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 20, 31, 52, 53, 54

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
C220 M3(SFF/LFF) w/E5-Series, C240 M3(SFF/LFF) w/E5-Series, C240 M3 w/E5-Series, C22 M3 (SFF/LFF) w/E5-Series, C24 M3 (SFF/LFF) w/E5-Series, C220 M3 (SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C22 M3(SFF/LFF) w/E5-Series v2, C24 M3(SFF/LFF) w/E5-Series v2, C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	UCS VIC 1225 10-Gbps 2 port CNA SFP+	vSphere 5.5 U2	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 20, 31, 52, 53, 54
C260 M2 w/E7-Series, C460 M2 w/E7-Series, C420 M3 w/E5-Series	UCS VIC 1225 10-Gbps 2 port CNA SFP+	vSphere 5.5 U3	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 20, 31, 52, 53, 54
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C220 M4(SFF/LFF) w/E5-Series v4, C240 M4(SFF/LFF) w/E5-Series v4	UCS VIC 1225 10-Gbps 2 port CNA SFP+	vSphere 5.5 U3	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 20, 31, 52, 53, 54

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
C220 M3(SFF/LFF) w/E5-Series, C240 M3(SFF/LFF) w/E5-Series, C240 M3 w/E5-Series, C22 M3 (SFF/LFF) w/E5-Series, C24 M3 (SFF/LFF) w/E5-Series, C220 M3 (SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C22 M3(SFF/LFF) w/E5-Series v2, C24 M3(SFF/LFF) w/E5-Series v2, C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	UCS VIC 1225 10-Gbps 2 port CNA SFP+	vSphere 5.5 U3	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 20, 31, 52, 53, 54
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1225 10-Gbps 2 port CNA SFP+	vSphere 6.0	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 20, 31, 52, 53, 54

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
C220 M3(SFF/LFF) w/E5-Series, C240 M3(SFF/LFF) w/E5-Series, C240 M3 w/E5-Series, C22 M3 (SFF/LFF) w/E5-Series, C24 M3 (SFF/LFF) w/E5-Series, C220 M3 (SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C22 M3(SFF/LFF) w/E5-Series v2, C24 M3(SFF/LFF) w/E5-Series v2, C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	UCS VIC 1225 10-Gbps 2 port CNA SFP+	vSphere 6.0	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 20, 31, 52, 53, 54
C260 M2 w/E7-Series, C460 M2 w/E7-Series, C420 M3 w/E5-Series	UCS VIC 1225 10-Gbps 2 port CNA SFP+	vSphere 6.0 U1	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 20, 31, 52, 53, 54
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C220 M4(SFF/LFF) w/E5-Series v4, C240 M4(SFF/LFF) w/E5-Series v4	UCS VIC 1225 10-Gbps 2 port CNA SFP+	vSphere 6.0 U1	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 20, 31, 52, 53, 54

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
C220 M3(SFF/LFF) w/E5-Series, C240 M3(SFF/LFF) w/E5-Series, C240 M3 w/E5-Series, C22 M3 (SFF/LFF) w/E5-Series, C24 M3 (SFF/LFF) w/E5-Series, C220 M3 (SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C22 M3(SFF/LFF) w/E5-Series v2, C24 M3(SFF/LFF) w/E5-Series v2, C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	UCS VIC 1225 10-Gbps 2 port CNA SFP+	vSphere 6.0 U1	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 20, 31, 52, 53, 54
C260 M2 w/E7-Series, C460 M2 w/E7-Series, C420 M3 w/E5-Series	UCS VIC 1225 10-Gbps 2 port CNA SFP+	vSphere 6.0 U2	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 20, 31, 52, 53, 54
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C220 M4(SFF/LFF) w/E5-Series v4, C240 M4(SFF/LFF) w/E5-Series v4	UCS VIC 1225 10-Gbps 2 port CNA SFP+	vSphere 6.0 U2	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 20, 31, 52, 53, 54

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
C220 M3(SFF/LFF) w/E5-Series, C240 M3(SFF/LFF) w/E5-Series, C240 M3 w/E5-Series, C22 M3 (SFF/LFF) w/E5-Series, C24 M3 (SFF/LFF) w/E5-Series, C220 M3 (SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C22 M3(SFF/LFF) w/E5-Series v2, C24 M3(SFF/LFF) w/E5-Series v2, C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	UCS VIC 1225 10-Gbps 2 port CNA SFP+	vSphere 6.0 U2	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 20, 31, 52, 53, 54

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
C220 M3(SFF/LFF) w/E5-Series, C240 M3(SFF/LFF) w/E5-Series, C240 M3 w/E5-Series, C22 M3 (SFF/LFF) w/E5-Series, C24 M3 (SFF/LFF) w/E5-Series, C220 M3 (SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C22 M3(SFF/LFF) w/E5-Series v2, C24 M3(SFF/LFF) w/E5-Series v2, C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C220 M4(SFF/LFF) w/E5-Series v4, C240 M4(SFF/LFF) w/E5-Series v4, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3, C460 M4 w/E7-Series v4	UCS VIC 1225 10-Gbps 2 port CNA SFP+	vSphere 6.5	1.6.0.28 (FNIC) / 1.0.0.2 (nenic)	4.1(1)	11, 12, 20, 31, 52, 53, 59
C260 M2 w/E7-Series, C460 M2 w/E7-Series, C420 M3 w/E5-Series	UCS VIC 1225 10-Gbps 2 port CNA SFP+	Windows Server 2008 R2 SP1	2.1.0.34 (FNIC) / 2.4.0.21 (ENIC) / 2.1.0.12 (NIC Teaming Driver)	4.1(1)	12, 20, 21, 25, 53, 55
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1225 10-Gbps 2 port CNA SFP+	Windows Server 2008 R2 SP1	2.1.0.34 (FNIC) / 2.4.0.21 (ENIC) / 2.1.0.12 (NIC Teaming Driver)	4.1(1)	12, 20, 21, 25, 53, 55

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
C220 M3(SFF/LFF) w/E5-Series, C240 M3(SFF/LFF) w/E5-Series, C240 M3 w/E5-Series, C22 M3 (SFF/LFF) w/E5-Series, C24 M3 (SFF/LFF) w/E5-Series, C220 M3 (SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C22 M3(SFF/LFF) w/E5-Series v2, C24 M3(SFF/LFF) w/E5-Series v2, C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	UCS VIC 1225 10-Gbps 2 port CNA SFP+	Windows Server 2008 R2 SP1	2.1.0.34 (FNIC) / 2.4.0.21 (ENIC) / 2.1.0.12 (NIC Teaming Driver)	4.1(1)	12, 20, 21, 25, 53, 55
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1225 10-Gbps 2 port CNA SFP+	Windows Server 2012	2.4.0.19 (FNIC) / 3.5.0.17 (ENIC)	4.1(1)	12, 20, 21, 35, 56, 57

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
C220 M3(SFF/LFF) w/E5-Series, C240 M3(SFF/LFF) w/E5-Series, C240 M3 w/E5-Series, C22 M3 (SFF/LFF) w/E5-Series, C24 M3 (SFF/LFF) w/E5-Series, C220 M3 (SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C22 M3(SFF/LFF) w/E5-Series v2, C24 M3(SFF/LFF) w/E5-Series v2, C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	UCS VIC 1225 10-Gbps 2 port CNA SFP+	Windows Server 2012	2.4.0.19 (FNIC) / 3.5.0.17 (ENIC)	4.1(1)	12, 20, 21, 35, 56, 57
C260 M2 w/E7-Series, C460 M2 w/E7-Series, C420 M3 w/E5-Series	UCS VIC 1225 10-Gbps 2 port CNA SFP+	Windows Server 2012 R2	2.4.0.19 (FNIC) / 3.5.0.17 (ENIC)	4.1(1)	10, 20, 21, 35, 56, 57
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C220 M4(SFF/LFF) w/E5-Series v4, C240 M4(SFF/LFF) w/E5-Series v4	UCS VIC 1225 10-Gbps 2 port CNA SFP+	Windows Server 2012 R2	2.4.0.19 (FNIC) / 3.5.0.17 (ENIC)	4.1(1)	10, 12, 20, 21, 35, 56, 57

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
C220 M3(SFF/LFF) w/E5-Series, C240 M3(SFF/LFF) w/E5-Series, C240 M3 w/E5-Series, C22 M3 (SFF/LFF) w/E5-Series, C24 M3 (SFF/LFF) w/E5-Series, C220 M3 (SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C22 M3(SFF/LFF) w/E5-Series v2, C24 M3(SFF/LFF) w/E5-Series v2, C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	UCS VIC 1225 10-Gbps 2 port CNA SFP+	Windows Server 2012 R2	2.4.0.19 (FNIC) / 3.5.0.17 (ENIC)	4.1(1)	10, 12, 20, 21, 35, 56, 57
C220 M3(SFF/LFF) w/E5-Series, C240 M3(SFF/LFF) w/E5-Series, C240 M3 w/E5-Series, C22 M3 (SFF/LFF) w/E5-Series, C24 M3 (SFF/LFF) w/E5-Series, C220 M3 (SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C22 M3(SFF/LFF) w/E5-Series v2, C24 M3(SFF/LFF) w/E5-Series v2	UCS VIC 1225 10-Gbps 2 port CNA SFP+	Red Hat Enterprise Linux 5.10	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
C220 M3(SFF/LFF) w/E5-Series, C240 M3(SFF/LFF) w/E5-Series, C240 M3 w/E5-Series, C22 M3 (SFF/LFF) w/E5-Series, C24 M3 (SFF/LFF) w/E5-Series, C220 M3 (SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C22 M3(SFF/LFF) w/E5-Series v2, C24 M3(SFF/LFF) w/E5-Series v2	UCS VIC 1225 10-Gbps 2 port CNA SFP+	Red Hat Enterprise Linux 5.11	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21
C220 M3(SFF/LFF) w/E5-Series, C240 M3(SFF/LFF) w/E5-Series, C240 M3 w/E5-Series, C22 M3 (SFF/LFF) w/E5-Series, C24 M3 (SFF/LFF) w/E5-Series, C220 M3 (SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C22 M3(SFF/LFF) w/E5-Series v2, C24 M3(SFF/LFF) w/E5-Series v2	UCS VIC 1225 10-Gbps 2 port CNA SFP+	Red Hat Enterprise Linux 6.4	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1225 10-Gbps 2 port CNA SFP+	Red Hat Enterprise Linux 6.5	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
C220 M3(SFF/LFF) w/E5-Series, C240 M3(SFF/LFF) w/E5-Series, C240 M3 w/E5-Series, C22 M3 (SFF/LFF) w/E5-Series, C24 M3 (SFF/LFF) w/E5-Series, C220 M3 (SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C22 M3(SFF/LFF) w/E5-Series v2, C24 M3(SFF/LFF) w/E5-Series v2, C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	UCS VIC 1225 10-Gbps 2 port CNA SFP+	Red Hat Enterprise Linux 6.5	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1225 10-Gbps 2 port CNA SFP+	Red Hat Enterprise Linux 6.6	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
C220 M3(SFF/LFF) w/E5-Series, C240 M3(SFF/LFF) w/E5-Series, C240 M3 w/E5-Series, C22 M3 (SFF/LFF) w/E5-Series, C24 M3 (SFF/LFF) w/E5-Series, C220 M3 (SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C22 M3(SFF/LFF) w/E5-Series v2, C24 M3(SFF/LFF) w/E5-Series v2, C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	UCS VIC 1225 10-Gbps 2 port CNA SFP+	Red Hat Enterprise Linux 6.6	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21
C260 M2 w/E7-Series, C460 M2 w/E7-Series, C420 M3 w/E5-Series	UCS VIC 1225 10-Gbps 2 port CNA SFP+	Red Hat Enterprise Linux 6.7	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C220 M4(SFF/LFF) w/E5-Series v4, C240 M4(SFF/LFF) w/E5-Series v4	UCS VIC 1225 10-Gbps 2 port CNA SFP+	Red Hat Enterprise Linux 6.7	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
C220 M3(SFF/LFF) w/E5-Series, C240 M3(SFF/LFF) w/E5-Series, C240 M3 w/E5-Series, C22 M3 (SFF/LFF) w/E5-Series, C24 M3 (SFF/LFF) w/E5-Series, C220 M3 (SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C22 M3(SFF/LFF) w/E5-Series v2, C24 M3(SFF/LFF) w/E5-Series v2, C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	UCS VIC 1225 10-Gbps 2 port CNA SFP+	Red Hat Enterprise Linux 6.7	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21
C260 M2 w/E7-Series, C460 M2 w/E7-Series, C420 M3 w/E5-Series	UCS VIC 1225 10-Gbps 2 port CNA SFP+	Red Hat Enterprise Linux 6.8	1.6.0.27 (FNIC) / 2.3.0.27 (ENIC)	4.1(1)	20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C220 M4(SFF/LFF) w/E5-Series v4, C240 M4(SFF/LFF) w/E5-Series v4	UCS VIC 1225 10-Gbps 2 port CNA SFP+	Red Hat Enterprise Linux 6.8	1.6.0.27 (FNIC) / 2.3.0.27 (ENIC)	4.1(1)	20, 21

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
C220 M3(SFF/LFF) w/E5-Series, C240 M3(SFF/LFF) w/E5-Series, C240 M3 w/E5-Series, C22 M3 (SFF/LFF) w/E5-Series, C24 M3 (SFF/LFF) w/E5-Series, C220 M3 (SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C22 M3(SFF/LFF) w/E5-Series v2, C24 M3(SFF/LFF) w/E5-Series v2, C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	UCS VIC 1225 10-Gbps 2 port CNA SFP+	Red Hat Enterprise Linux 6.8	1.6.0.27 (FNIC) / 2.3.0.27 (ENIC)	4.1(1)	20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1225 10-Gbps 2 port CNA SFP+	Red Hat Enterprise Linux 7.0	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
C220 M3(SFF/LFF) w/E5-Series, C240 M3(SFF/LFF) w/E5-Series, C240 M3 w/E5-Series, C22 M3 (SFF/LFF) w/E5-Series, C24 M3 (SFF/LFF) w/E5-Series, C220 M3 (SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C22 M3(SFF/LFF) w/E5-Series v2, C24 M3(SFF/LFF) w/E5-Series v2, C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	UCS VIC 1225 10-Gbps 2 port CNA SFP+	Red Hat Enterprise Linux 7.0	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21
C260 M2 w/E7-Series, C460 M2 w/E7-Series, C420 M3 w/E5-Series	UCS VIC 1225 10-Gbps 2 port CNA SFP+	Red Hat Enterprise Linux 7.1	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1225 10-Gbps 2 port CNA SFP+	Red Hat Enterprise Linux 7.1	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	UCS VIC 1225 10-Gbps 2 port CNA SFP+	Red Hat Enterprise Linux 7.1	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
C220 M3(SFF/LFF) w/E5-Series, C240 M3(SFF/LFF) w/E5-Series, C240 M3 w/E5-Series, C22 M3 (SFF/LFF) w/E5-Series, C24 M3 (SFF/LFF) w/E5-Series, C220 M3 (SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C22 M3(SFF/LFF) w/E5-Series v2, C24 M3(SFF/LFF) w/E5-Series v2	UCS VIC 1225 10-Gbps 2 port CNA SFP+	Red Hat Enterprise Linux 7.1	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21
C260 M2 w/E7-Series, C460 M2 w/E7-Series, C420 M3 w/E5-Series	UCS VIC 1225 10-Gbps 2 port CNA SFP+	Red Hat Enterprise Linux 7.2	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C220 M4(SFF/LFF) w/E5-Series v4, C240 M4(SFF/LFF) w/E5-Series v4	UCS VIC 1225 10-Gbps 2 port CNA SFP+	Red Hat Enterprise Linux 7.2	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
C220 M3(SFF/LFF) w/E5-Series, C240 M3(SFF/LFF) w/E5-Series, C240 M3 w/E5-Series, C22 M3 (SFF/LFF) w/E5-Series, C24 M3 (SFF/LFF) w/E5-Series, C220 M3 (SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C22 M3(SFF/LFF) w/E5-Series v2, C24 M3(SFF/LFF) w/E5-Series v2, C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	UCS VIC 1225 10-Gbps 2 port CNA SFP+	Red Hat Enterprise Linux 7.2	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1225 10-Gbps 2 port CNA SFP+	CentOS 6.6	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21, 39, 40
C240 M3 w/E5-Series, C220 M3 (SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	UCS VIC 1225 10-Gbps 2 port CNA SFP+	CentOS 6.6	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21, 39, 40

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
C420 M3 w/E5-Series	UCS VIC 1225 10-Gbps 2 port CNA SFP+	CentOS 6.7	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21, 39, 40
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C220 M4(SFF/LFF) w/E5-Series v4, C240 M4(SFF/LFF) w/E5-Series v4	UCS VIC 1225 10-Gbps 2 port CNA SFP+	CentOS 6.7	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21, 39, 40
C240 M3 w/E5-Series, C220 M3 (SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	UCS VIC 1225 10-Gbps 2 port CNA SFP+	CentOS 6.7	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21, 39, 40
C420 M3 w/E5-Series	UCS VIC 1225 10-Gbps 2 port CNA SFP+	CentOS 7.1	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21, 39, 40
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C220 M4(SFF/LFF) w/E5-Series v4, C240 M4(SFF/LFF) w/E5-Series v4	UCS VIC 1225 10-Gbps 2 port CNA SFP+	CentOS 7.1	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21, 39, 40

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
C240 M3 w/E5-Series, C220 M3 (SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	UCS VIC 1225 10-Gbps 2 port CNA SFP+	CentOS 7.1	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21, 39, 40
C420 M3 w/E5-Series	UCS VIC 1225 10-Gbps 2 port CNA SFP+	CentOS 7.2	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21, 39, 40
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C220 M4(SFF/LFF) w/E5-Series v4, C240 M4(SFF/LFF) w/E5-Series v4	UCS VIC 1225 10-Gbps 2 port CNA SFP+	CentOS 7.2	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21, 39, 40
C240 M3 w/E5-Series, C220 M3 (SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	UCS VIC 1225 10-Gbps 2 port CNA SFP+	CentOS 7.2	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21, 39, 40
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1225 10-Gbps 2 port CNA SFP+	UEK R3 U1 (3.8.13-26.x)	1.6.0.25 (FNIC) / 2.1.1.39 (ENIC)	4.1(1)	20, 21

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
C220 M3(SFF/LFF) w/E5-Series, C240 M3(SFF/LFF) w/E5-Series, C240 M3 w/E5-Series, C22 M3 (SFF/LFF) w/E5-Series, C24 M3 (SFF/LFF) w/E5-Series, C220 M3 (SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C22 M3(SFF/LFF) w/E5-Series v2, C24 M3(SFF/LFF) w/E5-Series v2, C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	UCS VIC 1225 10-Gbps 2 port CNA SFP+	UEK R3 U1 (3.8.13-26.x)	1.6.0.25 (FNIC) / 2.1.1.39 (ENIC)	4.1(1)	20, 21
C260 M2 w/E7-Series, C460 M2 w/E7-Series, C420 M3 w/E5-Series	UCS VIC 1225 10-Gbps 2 port CNA SFP+	UEK R3 U3 (3.8.13-44.x)	1.6.0.25 (FNIC) / 2.1.1.50 (ENIC)	4.1(1)	20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1225 10-Gbps 2 port CNA SFP+	UEK R3 U3 (3.8.13-44.x)	1.6.0.25 (FNIC) / 2.1.1.50 (ENIC)	4.1(1)	20, 21

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
C220 M3(SFF/LFF) w/E5-Series, C240 M3(SFF/LFF) w/E5-Series, C240 M3 w/E5-Series, C22 M3 (SFF/LFF) w/E5-Series, C24 M3 (SFF/LFF) w/E5-Series, C220 M3 (SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C22 M3(SFF/LFF) w/E5-Series v2, C24 M3(SFF/LFF) w/E5-Series v2, C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	UCS VIC 1225 10-Gbps 2 port CNA SFP+	UEK R3 U3 (3.8.13-44.x)	1.6.0.25 (FNIC) / 2.1.1.50 (ENIC)	4.1(1)	20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1225 10-Gbps 2 port CNA SFP+	UEK R3 U5 (3.8.13-68.x)	1.6.0.25 (FNIC) / 2.1.1.67 (ENIC)	4.1(1)	20, 21

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
C220 M3(SFF/LFF) w/E5-Series, C240 M3(SFF/LFF) w/E5-Series, C240 M3 w/E5-Series, C22 M3 (SFF/LFF) w/E5-Series, C24 M3 (SFF/LFF) w/E5-Series, C220 M3 (SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C22 M3(SFF/LFF) w/E5-Series v2, C24 M3(SFF/LFF) w/E5-Series v2, C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	UCS VIC 1225 10-Gbps 2 port CNA SFP+	UEK R3 U5 (3.8.13-68.x)	1.6.0.25 (FNIC) / 2.1.1.67 (ENIC)	4.1(1)	20, 21

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
C220 M3(SFF/LFF) w/E5-Series, C240 M3(SFF/LFF) w/E5-Series, C240 M3 w/E5-Series, C22 M3 (SFF/LFF) w/E5-Series, C24 M3 (SFF/LFF) w/E5-Series, C220 M3 (SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C22 M3(SFF/LFF) w/E5-Series v2, C24 M3(SFF/LFF) w/E5-Series v2, C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	UCS VIC 1225 10-Gbps 2 port CNA SFP+	UEK R3 U7 (3.8.13-118)	1.6.0.25 (FNIC) / 2.1.1.67 (ENIC)	4.1(1)	20, 21
C260 M2 w/E7-Series, C460 M2 w/E7-Series, C420 M3 w/E5-Series	UCS VIC 1225 10-Gbps 2 port CNA SFP+	UEK R4 (4.1.12-32.x)	1.6.0.22 (FNIC) / 2.3.0.12 (ENIC)	4.1(1)	20, 43

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
C220 M3(SFF/LFF) w/E5-Series, C240 M3(SFF/LFF) w/E5-Series, C240 M3 w/E5-Series, C22 M3 (SFF/LFF) w/E5-Series, C24 M3 (SFF/LFF) w/E5-Series, C220 M3 (SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C22 M3(SFF/LFF) w/E5-Series v2, C24 M3(SFF/LFF) w/E5-Series v2, C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	UCS VIC 1225 10-Gbps 2 port CNA SFP+	UEK R4 (4.1.12-32.x)	1.6.0.22 (FNIC) / 2.3.0.12 (ENIC)	4.1(1)	20, 43
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C220 M4(SFF/LFF) w/E5-Series v4, C240 M4(SFF/LFF) w/E5-Series v4	UCS VIC 1225 10-Gbps 2 port CNA SFP+	UEK R4 (4.1.12-32.x)	1.6.0.22 (FNIC) / 2.3.0.12 (ENIC)	4.1(1)	20, 43
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1225 10-Gbps 2 port CNA SFP+	OVM 3.3.1	1.6.0.9 (FNIC) / 2.1.1.39 (ENIC)	4.1(1)	20, 43

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
C220 M3(SFF/LFF) w/E5-Series, C240 M3(SFF/LFF) w/E5-Series, C240 M3 w/E5-Series, C22 M3 (SFF/LFF) w/E5-Series, C24 M3 (SFF/LFF) w/E5-Series, C220 M3 (SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C22 M3(SFF/LFF) w/E5-Series v2, C24 M3(SFF/LFF) w/E5-Series v2, C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2	UCS VIC 1225 10-Gbps 2 port CNA SFP+	OVM 3.3.1	1.6.0.9 (FNIC) / 2.1.1.39 (ENIC)	4.1(1)	20, 43
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1225 10-Gbps 2 port CNA SFP+	OVM 3.3.2	1.6.0.10 (FNIC) / 2.1.1.50 (ENIC)	4.1(1)	20, 43

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
C220 M3(SFF/LFF) w/E5-Series, C240 M3(SFF/LFF) w/E5-Series, C240 M3 w/E5-Series, C22 M3 (SFF/LFF) w/E5-Series, C24 M3 (SFF/LFF) w/E5-Series, C220 M3 (SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C22 M3(SFF/LFF) w/E5-Series v2, C24 M3(SFF/LFF) w/E5-Series v2, C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	UCS VIC 1225 10-Gbps 2 port CNA SFP+	OVM 3.3.2	1.6.0.10 (FNIC) / 2.1.1.50 (ENIC)	4.1(1)	20, 43
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1225 10-Gbps 2 port CNA SFP+	OVM 3.3.3	1.6.0.10 (FNIC) / 2.1.1.67 (ENIC)	4.1(1)	20, 43

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
C220 M3(SFF/LFF) w/E5-Series, C240 M3(SFF/LFF) w/E5-Series, C240 M3 w/E5-Series, C22 M3 (SFF/LFF) w/E5-Series, C24 M3 (SFF/LFF) w/E5-Series, C220 M3 (SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C22 M3(SFF/LFF) w/E5-Series v2, C24 M3(SFF/LFF) w/E5-Series v2, C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	UCS VIC 1225 10-Gbps 2 port CNA SFP+	OVM 3.3.3	1.6.0.10 (FNIC) / 2.1.1.67 (ENIC)	4.1(1)	20, 43

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
C220 M3(SFF/LFF) w/E5-Series, C240 M3(SFF/LFF) w/E5-Series, C240 M3 w/E5-Series, C22 M3 (SFF/LFF) w/E5-Series, C24 M3 (SFF/LFF) w/E5-Series, C220 M3 (SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C22 M3(SFF/LFF) w/E5-Series v2, C24 M3(SFF/LFF) w/E5-Series v2, C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	UCS VIC 1225 10-Gbps 2 port CNA SFP+	OVM 3.4.1	1.6.0.22 (FNIC) / 2.3.0.12 (ENIC)	4.1(1)	20, 43
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1225 10-Gbps 2 port CNA SFP+	SUSE Linux Enterprise Server 11.3	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
C220 M3(SFF/LFF) w/E5-Series, C240 M3(SFF/LFF) w/E5-Series, C240 M3 w/E5-Series, C22 M3 (SFF/LFF) w/E5-Series, C24 M3 (SFF/LFF) w/E5-Series, C220 M3 (SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C22 M3(SFF/LFF) w/E5-Series v2, C24 M3(SFF/LFF) w/E5-Series v2, C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	UCS VIC 1225 10-Gbps 2 port CNA SFP+	SUSE Linux Enterprise Server 11.3	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21
C260 M2 w/E7-Series, C460 M2 w/E7-Series, C420 M3 w/E5-Series	UCS VIC 1225 10-Gbps 2 port CNA SFP+	SUSE Linux Enterprise Server 11.4	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1225 10-Gbps 2 port CNA SFP+	SUSE Linux Enterprise Server 11.4	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
C220 M3(SFF/LFF) w/E5-Series, C240 M3(SFF/LFF) w/E5-Series, C240 M3 w/E5-Series, C22 M3 (SFF/LFF) w/E5-Series, C24 M3 (SFF/LFF) w/E5-Series, C220 M3 (SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C22 M3(SFF/LFF) w/E5-Series v2, C24 M3(SFF/LFF) w/E5-Series v2, C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	UCS VIC 1225 10-Gbps 2 port CNA SFP+	SUSE Linux Enterprise Server 11.4	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C220 M4(SFF/LFF) w/E5-Series v4, C240 M4(SFF/LFF) w/E5-Series v4	UCS VIC 1225 10-Gbps 2 port CNA SFP+	SUSE Linux Enterprise Server 12	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
C220 M3(SFF/LFF) w/E5-Series, C240 M3(SFF/LFF) w/E5-Series, C240 M3 w/E5-Series, C22 M3 (SFF/LFF) w/E5-Series, C24 M3 (SFF/LFF) w/E5-Series, C220 M3 (SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C22 M3(SFF/LFF) w/E5-Series v2, C24 M3(SFF/LFF) w/E5-Series v2, C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	UCS VIC 1225 10-Gbps 2 port CNA SFP+	SUSE Linux Enterprise Server 12	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21
C260 M2 w/E7-Series, C460 M2 w/E7-Series, C420 M3 w/E5-Series	UCS VIC 1225 10-Gbps 2 port CNA SFP+	SUSE Linux Enterprise Server 12.1	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C220 M4(SFF/LFF) w/E5-Series v4, C240 M4(SFF/LFF) w/E5-Series v4	UCS VIC 1225 10-Gbps 2 port CNA SFP+	SUSE Linux Enterprise Server 12.1	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	12, 20, 21

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
C220 M3(SFF/LFF) w/E5-Series, C240 M3(SFF/LFF) w/E5-Series, C240 M3 w/E5-Series, C22 M3 (SFF/LFF) w/E5-Series, C24 M3 (SFF/LFF) w/E5-Series, C220 M3 (SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C22 M3(SFF/LFF) w/E5-Series v2, C24 M3(SFF/LFF) w/E5-Series v2, C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	UCS VIC 1225 10-Gbps 2 port CNA SFP+	SUSE Linux Enterprise Server 12.1	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	12, 20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1225 10-Gbps 2 port CNA SFP+	XenServer 6.2	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	4, 20, 21

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
C220 M3(SFF/LFF) w/E5-Series, C240 M3(SFF/LFF) w/E5-Series, C240 M3 w/E5-Series, C22 M3 (SFF/LFF) w/E5-Series, C24 M3 (SFF/LFF) w/E5-Series, C220 M3 (SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C22 M3(SFF/LFF) w/E5-Series v2, C24 M3(SFF/LFF) w/E5-Series v2, C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2	UCS VIC 1225 10-Gbps 2 port CNA SFP+	XenServer 6.2	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	4, 20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1225 10-Gbps 2 port CNA SFP+	XenServer 6.5	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21, 41

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
C220 M3(SFF/LFF) w/E5-Series, C240 M3(SFF/LFF) w/E5-Series, C240 M3 w/E5-Series, C22 M3 (SFF/LFF) w/E5-Series, C24 M3 (SFF/LFF) w/E5-Series, C220 M3 (SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C22 M3(SFF/LFF) w/E5-Series v2, C24 M3(SFF/LFF) w/E5-Series v2, C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	UCS VIC 1225 10-Gbps 2 port CNA SFP+	XenServer 6.5	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21, 41
C420 M3 w/E5-Series	UCS VIC 1225 10-Gbps 2 port CNA SFP+	Ubuntu 12.04.5	2.1.1.50 (ENIC)	4.1(1)	3, 20, 43
C220 M3(SFF/LFF) w/E5-Series, C240 M3(SFF/LFF) w/E5-Series, C240 M3 w/E5-Series, C220 M3 (SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	UCS VIC 1225 10-Gbps 2 port CNA SFP+	Ubuntu 12.04.5	2.1.1.50 (ENIC)	4.1(1)	3, 20, 43

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
C220 M3(SFF/LFF) w/E5-Series, C240 M3(SFF/LFF) w/E5-Series, C240 M3 w/E5-Series, C220 M3 (SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C460 M4 w/E7-Series v2	UCS VIC 1225 10-Gbps 2 port CNA SFP+	Ubuntu 14.04	2.1.1.50 (ENIC)	4.1(1)	3, 43
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1225 10-Gbps 2 port CNA SFP+	Ubuntu 14.04.1	2.1.1.50 (ENIC)	4.1(1)	3, 20, 43
C220 M3(SFF/LFF) w/E5-Series, C240 M3(SFF/LFF) w/E5-Series, C240 M3 w/E5-Series, C220 M3 (SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	UCS VIC 1225 10-Gbps 2 port CNA SFP+	Ubuntu 14.04.1	2.1.1.50 (ENIC)	4.1(1)	3, 20, 43
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1225 10-Gbps 2 port CNA SFP+	Ubuntu 14.04.2	2.3.0.20 (ENIC)	4.1(1)	3, 20, 21

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
C220 M3(SFF/LFF) w/E5-Series, C240 M3(SFF/LFF) w/E5-Series, C240 M3 w/E5-Series, C220 M3 (SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	UCS VIC 1225 10-Gbps 2 port CNA SFP+	Ubuntu 14.04.2	2.3.0.20 (ENIC)	4.1(1)	3, 20, 21
C420 M3 w/E5-Series	UCS VIC 1225 10-Gbps 2 port CNA SFP+	Ubuntu 14.04.3	2.3.0.20 (ENIC)	4.1(1)	3, 20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1225 10-Gbps 2 port CNA SFP+	Ubuntu 14.04.3	2.3.0.20 (ENIC)	4.1(1)	3, 20, 21
C220 M3(SFF/LFF) w/E5-Series, C240 M3(SFF/LFF) w/E5-Series, C240 M3 w/E5-Series, C220 M3 (SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	UCS VIC 1225 10-Gbps 2 port CNA SFP+	Ubuntu 14.04.3	2.3.0.20 (ENIC)	4.1(1)	3, 20, 21

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
C420 M3 w/E5-Series	UCS VIC 1225 10-Gbps 2 port CNA SFP+	Ubuntu 14.04.4	2.3.0.27 (ENIC)	4.1(1)	3, 20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C220 M4(SFF/LFF) w/E5-Series v4, C240 M4(SFF/LFF) w/E5-Series v4	UCS VIC 1225 10-Gbps 2 port CNA SFP+	Ubuntu 14.04.4	2.3.0.27 (ENIC)	4.1(1)	3, 20, 21
C220 M3(SFF/LFF) w/E5-Series, C240 M3(SFF/LFF) w/E5-Series, C240 M3 w/E5-Series, C220 M3 (SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	UCS VIC 1225 10-Gbps 2 port CNA SFP+	Ubuntu 14.04.4	2.3.0.27 (ENIC)	4.1(1)	3, 20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C220 M4(SFF/LFF) w/E5-Series v4, C240 M4(SFF/LFF) w/E5-Series v4	UCS VIC 1225 10-Gbps 2 port CNA SFP+	Ubuntu 16.04	2.3.0.27 (ENIC)	4.1(1)	3, 20, 21

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
C220 M3(SFF/LFF) w/E5-Series, C240 M3(SFF/LFF) w/E5-Series, C240 M3 w/E5-Series, C220 M3 (SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	UCS VIC 1225 10-Gbps 2 port CNA SFP+	Ubuntu 16.04	2.3.0.27 (ENIC)	4.1(1)	3, 20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1225T 10-Gbase-T 2 port CNA	vSphere 5.1 U2	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 20, 31, 52, 53, 54
C220 M3(SFF/LFF) w/E5-Series, C240 M3(SFF/LFF) w/E5-Series, C22 M3(SFF/LFF) w/E5-Series, C24 M3(SFF/LFF) w/E5-Series, C220 M3(SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C22 M3(SFF/LFF) w/E5-Series v2, C24 M3(SFF/LFF) w/E5-Series v2, C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2	UCS VIC 1225T 10-Gbase-T 2 port CNA	vSphere 5.1 U2	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 20, 31, 52, 53, 54

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
C260 M2 w/E7-Series, C460 M2 w/E7-Series, C420 M3 w/E5-Series	UCS VIC 1225T 10-Gbase-T 2 port CNA	vSphere 5.1 U3	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 20, 31, 52, 53, 54
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1225T 10-Gbase-T 2 port CNA	vSphere 5.1 U3	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 20, 31, 52, 53, 54
C220 M3(SFF/LFF) w/E5-Series, C240 M3(SFF/LFF) w/E5-Series, C24 M3(SFF/LFF) w/E5-Series, C220 M3(SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C22 M3(SFF/LFF) w/E5-Series v2, C24 M3(SFF/LFF) w/E5-Series v2, C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2	UCS VIC 1225T 10-Gbase-T 2 port CNA	vSphere 5.1 U3	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 20, 31, 52, 53, 54

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
C220 M3(SFF/LFF) w/E5-Series, C240 M3(SFF/LFF) w/E5-Series, C22 M3(SFF/LFF) w/E5-Series, C24 M3(SFF/LFF) w/E5-Series, C220 M3(SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C22 M3(SFF/LFF) w/E5-Series v2, C24 M3(SFF/LFF) w/E5-Series v2, C460 M4 w/E7-Series v2	UCS VIC 1225T 10-Gbase-T 2 port CNA	vSphere 5.5	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 20, 31, 52, 53, 54
C220 M3(SFF/LFF) w/E5-Series, C240 M3(SFF/LFF) w/E5-Series, C22 M3(SFF/LFF) w/E5-Series, C24 M3(SFF/LFF) w/E5-Series, C220 M3(SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C22 M3(SFF/LFF) w/E5-Series v2, C24 M3(SFF/LFF) w/E5-Series v2, C460 M4 w/E7-Series v2	UCS VIC 1225T 10-Gbase-T 2 port CNA	vSphere 5.5 U1	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 20, 31, 52, 53, 54
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1225T 10-Gbase-T 2 port CNA	vSphere 5.5 U2	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 20, 31, 52, 53, 54

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
C220 M3(SFF/LFF) w/E5-Series, C240 M3(SFF/LFF) w/E5-Series, C22 M3(SFF/LFF) w/E5-Series, C24 M3(SFF/LFF) w/E5-Series, C220 M3(SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C22 M3(SFF/LFF) w/E5-Series v2, C24 M3(SFF/LFF) w/E5-Series v2, C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	UCS VIC 1225T 10-Gbase-T 2 port CNA	vSphere 5.5 U2	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 20, 31, 52, 53, 54
C260 M2 w/E7-Series, C460 M2 w/E7-Series, C420 M3 w/E5-Series	UCS VIC 1225T 10-Gbase-T 2 port CNA	vSphere 5.5 U3	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 20, 31, 52, 53, 54
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C220 M4(SFF/LFF) w/E5-Series v4, C240 M4(SFF/LFF) w/E5-Series v4	UCS VIC 1225T 10-Gbase-T 2 port CNA	vSphere 5.5 U3	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 20, 31, 52, 53, 54

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
C220 M3(SFF/LFF) w/E5-Series, C240 M3(SFF/LFF) w/E5-Series, C22 M3(SFF/LFF) w/E5-Series, C24 M3(SFF/LFF) w/E5-Series, C220 M3(SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C22 M3(SFF/LFF) w/E5-Series v2, C24 M3(SFF/LFF) w/E5-Series v2, C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	UCS VIC 1225T 10-Gbase-T 2 port CNA	vSphere 5.5 U3	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 20, 31, 52, 53, 54
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1225T 10-Gbase-T 2 port CNA	vSphere 6.0	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 20, 31, 52, 53, 54

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
C220 M3(SFF/LFF) w/E5-Series, C240 M3(SFF/LFF) w/E5-Series, C22 M3(SFF/LFF) w/E5-Series, C24 M3(SFF/LFF) w/E5-Series, C220 M3(SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C22 M3(SFF/LFF) w/E5-Series v2, C24 M3(SFF/LFF) w/E5-Series v2, C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	UCS VIC 1225T 10-Gbase-T 2 port CNA	vSphere 6.0	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 20, 31, 52, 53, 54
C260 M2 w/E7-Series, C460 M2 w/E7-Series, C420 M3 w/E5-Series	UCS VIC 1225T 10-Gbase-T 2 port CNA	vSphere 6.0 U1	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 20, 31, 52, 53, 54
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C220 M4(SFF/LFF) w/E5-Series v4, C240 M4(SFF/LFF) w/E5-Series v4	UCS VIC 1225T 10-Gbase-T 2 port CNA	vSphere 6.0 U1	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 20, 31, 52, 53, 54

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
C220 M3(SFF/LFF) w/E5-Series, C240 M3(SFF/LFF) w/E5-Series, C22 M3(SFF/LFF) w/E5-Series, C24 M3(SFF/LFF) w/E5-Series, C220 M3(SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C22 M3(SFF/LFF) w/E5-Series v2, C24 M3(SFF/LFF) w/E5-Series v2, C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	UCS VIC 1225T 10-Gbase-T 2 port CNA	vSphere 6.0 U1	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 20, 31, 52, 53, 54
C260 M2 w/E7-Series, C460 M2 w/E7-Series, C420 M3 w/E5-Series	UCS VIC 1225T 10-Gbase-T 2 port CNA	vSphere 6.0 U2	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 20, 31, 52, 53, 54
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C220 M4(SFF/LFF) w/E5-Series v4, C240 M4(SFF/LFF) w/E5-Series v4	UCS VIC 1225T 10-Gbase-T 2 port CNA	vSphere 6.0 U2	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 20, 31, 52, 53, 54

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
C220 M3(SFF/LFF) w/E5-Series, C240 M3(SFF/LFF) w/E5-Series, C22 M3(SFF/LFF) w/E5-Series, C24 M3(SFF/LFF) w/E5-Series, C220 M3(SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C22 M3(SFF/LFF) w/E5-Series v2, C24 M3(SFF/LFF) w/E5-Series v2, C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	UCS VIC 1225T 10-Gbase-T 2 port CNA	vSphere 6.0 U2	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 20, 31, 52, 53, 54

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
C220 M3(SFF/LFF) w/E5-Series, C240 M3(SFF/LFF) w/E5-Series, C240 M3 w/E5-Series, C22 M3 (SFF/LFF) w/E5-Series, C24 M3 (SFF/LFF) w/E5-Series, C220 M3 (SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C22 M3(SFF/LFF) w/E5-Series v2, C24 M3(SFF/LFF) w/E5-Series v2, C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C220 M4(SFF/LFF) w/E5-Series v4, C240 M4(SFF/LFF) w/E5-Series v4, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3, C460 M4 w/E7-Series v4	UCS VIC 1225T 10-Gbase-T 2 port CNA	vSphere 6.5	1.6.0.28 (FNIC) / 1.0.0.2 (nenic)	4.1(1)	11, 12, 20, 31, 52, 53, 59
C260 M2 w/E7-Series, C460 M2 w/E7-Series, C420 M3 w/E5-Series	UCS VIC 1225T 10-Gbase-T 2 port CNA	Windows Server 2008 R2 SP1	2.1.0.34 (FNIC) / 2.4.0.21 (ENIC) / 2.1.0.12 (NIC Teaming Driver)	4.1(1)	12, 20, 21, 25, 53, 55
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1225T 10-Gbase-T 2 port CNA	Windows Server 2008 R2 SP1	2.1.0.34 (FNIC) / 2.4.0.21 (ENIC) / 2.1.0.12 (NIC Teaming Driver)	4.1(1)	12, 20, 21, 25, 53, 55

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
C220 M3(SFF/LFF) w/E5-Series, C240 M3(SFF/LFF) w/E5-Series, C22 M3(SFF/LFF) w/E5-Series, C24 M3(SFF/LFF) w/E5-Series, C220 M3(SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C22 M3(SFF/LFF) w/E5-Series v2, C24 M3(SFF/LFF) w/E5-Series v2, C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	UCS VIC 1225T 10-Gbase-T 2 port CNA	Windows Server 2008 R2 SP1	2.1.0.34 (FNIC) / 2.4.0.21 (ENIC) / 2.1.0.12 (NIC Teaming Driver)	4.1(1)	12, 20, 21, 25, 53, 55
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1225T 10-Gbase-T 2 port CNA	Windows Server 2012	2.4.0.19 (FNIC) / 3.5.0.17 (ENIC)	4.1(1)	12, 20, 21, 35, 56, 57

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
C220 M3(SFF/LFF) w/E5-Series, C240 M3(SFF/LFF) w/E5-Series, C22 M3(SFF/LFF) w/E5-Series, C24 M3(SFF/LFF) w/E5-Series, C220 M3(SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C22 M3(SFF/LFF) w/E5-Series v2, C24 M3(SFF/LFF) w/E5-Series v2, C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	UCS VIC 1225T 10-Gbase-T 2 port CNA	Windows Server 2012	2.4.0.19 (FNIC) / 3.5.0.17 (ENIC)	4.1(1)	12, 20, 21, 35, 56, 57
C260 M2 w/E7-Series, C460 M2 w/E7-Series, C420 M3 w/E5-Series	UCS VIC 1225T 10-Gbase-T 2 port CNA	Windows Server 2012 R2	2.4.0.19 (FNIC) / 3.5.0.17 (ENIC)	4.1(1)	10, 20, 21, 35, 56, 57
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C220 M4(SFF/LFF) w/E5-Series v4, C240 M4(SFF/LFF) w/E5-Series v4	UCS VIC 1225T 10-Gbase-T 2 port CNA	Windows Server 2012 R2	2.4.0.19 (FNIC) / 3.5.0.17 (ENIC)	4.1(1)	10, 12, 20, 21, 35, 56, 57

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
C220 M3(SFF/LFF) w/E5-Series, C240 M3(SFF/LFF) w/E5-Series, C22 M3(SFF/LFF) w/E5-Series, C24 M3(SFF/LFF) w/E5-Series, C220 M3(SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C22 M3(SFF/LFF) w/E5-Series v2, C24 M3(SFF/LFF) w/E5-Series v2, C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	UCS VIC 1225T 10-Gbase-T 2 port CNA	Windows Server 2012 R2	2.4.0.19 (FNIC) / 3.5.0.17 (ENIC)	4.1(1)	10, 12, 20, 21, 35, 56, 57
C220 M3(SFF/LFF) w/E5-Series, C240 M3(SFF/LFF) w/E5-Series, C22 M3(SFF/LFF) w/E5-Series, C24 M3(SFF/LFF) w/E5-Series, C220 M3(SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C22 M3(SFF/LFF) w/E5-Series v2, C24 M3(SFF/LFF) w/E5-Series v2	UCS VIC 1225T 10-Gbase-T 2 port CNA	Red Hat Enterprise Linux 5.10	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
C220 M3(SFF/LFF) w/E5-Series, C240 M3(SFF/LFF) w/E5-Series, C22 M3(SFF/LFF) w/E5-Series, C24 M3(SFF/LFF) w/E5-Series, C220 M3(SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C22 M3(SFF/LFF) w/E5-Series v2, C24 M3(SFF/LFF) w/E5-Series v2	UCS VIC 1225T 10-Gbase-T 2 port CNA	Red Hat Enterprise Linux 5.11	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21
C220 M3(SFF/LFF) w/E5-Series, C240 M3(SFF/LFF) w/E5-Series, C22 M3(SFF/LFF) w/E5-Series, C24 M3(SFF/LFF) w/E5-Series, C220 M3(SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C22 M3(SFF/LFF) w/E5-Series v2, C24 M3(SFF/LFF) w/E5-Series v2	UCS VIC 1225T 10-Gbase-T 2 port CNA	Red Hat Enterprise Linux 6.4	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1225T 10-Gbase-T 2 port CNA	Red Hat Enterprise Linux 6.5	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
C220 M3(SFF/LFF) w/E5-Series, C240 M3(SFF/LFF) w/E5-Series, C22 M3(SFF/LFF) w/E5-Series, C24 M3(SFF/LFF) w/E5-Series, C220 M3(SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C22 M3(SFF/LFF) w/E5-Series v2, C24 M3(SFF/LFF) w/E5-Series v2, C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	UCS VIC 1225T 10-Gbase-T 2 port CNA	Red Hat Enterprise Linux 6.5	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1225T 10-Gbase-T 2 port CNA	Red Hat Enterprise Linux 6.6	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
C220 M3(SFF/LFF) w/E5-Series, C240 M3(SFF/LFF) w/E5-Series, C22 M3(SFF/LFF) w/E5-Series, C24 M3(SFF/LFF) w/E5-Series, C220 M3(SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C22 M3(SFF/LFF) w/E5-Series v2, C24 M3(SFF/LFF) w/E5-Series v2, C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	UCS VIC 1225T 10-Gbase-T 2 port CNA	Red Hat Enterprise Linux 6.6	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21
C260 M2 w/E7-Series, C460 M2 w/E7-Series, C420 M3 w/E5-Series	UCS VIC 1225T 10-Gbase-T 2 port CNA	Red Hat Enterprise Linux 6.7	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C220 M4(SFF/LFF) w/E5-Series v4, C240 M4(SFF/LFF) w/E5-Series v4	UCS VIC 1225T 10-Gbase-T 2 port CNA	Red Hat Enterprise Linux 6.7	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
C220 M3(SFF/LFF) w/E5-Series, C240 M3(SFF/LFF) w/E5-Series, C22 M3(SFF/LFF) w/E5-Series, C24 M3(SFF/LFF) w/E5-Series, C220 M3(SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C22 M3(SFF/LFF) w/E5-Series v2, C24 M3(SFF/LFF) w/E5-Series v2, C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	UCS VIC 1225T 10-Gbase-T 2 port CNA	Red Hat Enterprise Linux 6.7	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21
C260 M2 w/E7-Series, C460 M2 w/E7-Series, C420 M3 w/E5-Series	UCS VIC 1225T 10-Gbase-T 2 port CNA	Red Hat Enterprise Linux 6.8	1.6.0.27 (FNIC) / 2.3.0.27 (ENIC)	4.1(1)	20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C220 M4(SFF/LFF) w/E5-Series v4, C240 M4(SFF/LFF) w/E5-Series v4	UCS VIC 1225T 10-Gbase-T 2 port CNA	Red Hat Enterprise Linux 6.8	1.6.0.27 (FNIC) / 2.3.0.27 (ENIC)	4.1(1)	20, 21

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
C220 M3(SFF/LFF) w/E5-Series, C240 M3(SFF/LFF) w/E5-Series, C22 M3(SFF/LFF) w/E5-Series, C24 M3(SFF/LFF) w/E5-Series, C220 M3(SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C22 M3(SFF/LFF) w/E5-Series v2, C24 M3(SFF/LFF) w/E5-Series v2, C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	UCS VIC 1225T 10-Gbase-T 2 port CNA	Red Hat Enterprise Linux 6.8	1.6.0.27 (FNIC) / 2.3.0.27 (ENIC)	4.1(1)	20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1225T 10-Gbase-T 2 port CNA	Red Hat Enterprise Linux 7.0	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
C220 M3(SFF/LFF) w/E5-Series, C240 M3(SFF/LFF) w/E5-Series, C22 M3(SFF/LFF) w/E5-Series, C24 M3(SFF/LFF) w/E5-Series, C220 M3(SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C22 M3(SFF/LFF) w/E5-Series v2, C24 M3(SFF/LFF) w/E5-Series v2, C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	UCS VIC 1225T 10-Gbase-T 2 port CNA	Red Hat Enterprise Linux 7.0	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21
C260 M2 w/E7-Series, C460 M2 w/E7-Series, C420 M3 w/E5-Series	UCS VIC 1225T 10-Gbase-T 2 port CNA	Red Hat Enterprise Linux 7.1	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1225T 10-Gbase-T 2 port CNA	Red Hat Enterprise Linux 7.1	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
C220 M3(SFF/LFF) w/E5-Series, C240 M3(SFF/LFF) w/E5-Series, C22 M3(SFF/LFF) w/E5-Series, C24 M3(SFF/LFF) w/E5-Series, C220 M3(SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C22 M3(SFF/LFF) w/E5-Series v2, C24 M3(SFF/LFF) w/E5-Series v2	UCS VIC 1225T 10-Gbase-T 2 port CNA	Red Hat Enterprise Linux 7.1	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21
C260 M2 w/E7-Series, C460 M2 w/E7-Series, C420 M3 w/E5-Series	UCS VIC 1225T 10-Gbase-T 2 port CNA	Red Hat Enterprise Linux 7.2	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C220 M4(SFF/LFF) w/E5-Series v4, C240 M4(SFF/LFF) w/E5-Series v4	UCS VIC 1225T 10-Gbase-T 2 port CNA	Red Hat Enterprise Linux 7.2	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
C220 M3(SFF/LFF) w/E5-Series, C240 M3(SFF/LFF) w/E5-Series, C22 M3(SFF/LFF) w/E5-Series, C24 M3(SFF/LFF) w/E5-Series, C220 M3(SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C22 M3(SFF/LFF) w/E5-Series v2, C24 M3(SFF/LFF) w/E5-Series v2, C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	UCS VIC 1225T 10-Gbase-T 2 port CNA	Red Hat Enterprise Linux 7.2	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1225T 10-Gbase-T 2 port CNA	CentOS 6.6	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21, 39, 40
C220 M3(SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	UCS VIC 1225T 10-Gbase-T 2 port CNA	CentOS 6.6	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21, 39, 40
C420 M3 w/E5-Series	UCS VIC 1225T 10-Gbase-T 2 port CNA	CentOS 6.7	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21, 39, 40

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C220 M4(SFF/LFF) w/E5-Series v4, C240 M4(SFF/LFF) w/E5-Series v4	UCS VIC 1225T 10-Gbase-T 2 port CNA	CentOS 6.7	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21, 39, 40
C220 M3(SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	UCS VIC 1225T 10-Gbase-T 2 port CNA	CentOS 6.7	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21, 39, 40
C420 M3 w/E5-Series	UCS VIC 1225T 10-Gbase-T 2 port CNA	CentOS 7.1	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21, 39, 40
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C220 M4(SFF/LFF) w/E5-Series v4, C240 M4(SFF/LFF) w/E5-Series v4	UCS VIC 1225T 10-Gbase-T 2 port CNA	CentOS 7.1	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21, 39, 40
C220 M3(SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	UCS VIC 1225T 10-Gbase-T 2 port CNA	CentOS 7.1	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21, 39, 40

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
C420 M3 w/E5-Series	UCS VIC 1225T 10-Gbase-T 2 port CNA	CentOS 7.2	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21, 39, 40
C220 M4(SFF/ LFF) w/E5-Series v3, C240 M4(SFF/ LFF) w/E5-Series v3, C220 M4(SFF/ LFF) w/E5-Series v4, C240 M4(SFF/ LFF) w/E5-Series v4	UCS VIC 1225T 10-Gbase-T 2 port CNA	CentOS 7.2	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21, 39, 40
C220 M3(SFF/ LFF) w/E5-Series v2, C240 M3(SFF/ LFF) w/E5-Series v2, C220 M4(SFF/ LFF) w/E5-Series v3, C240 M4(SFF/ LFF) w/E5-Series v3, C460 M4 w/ E7-Series v2, C460 M4 w/E7-Series v3	UCS VIC 1225T 10-Gbase-T 2 port CNA	CentOS 7.2	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21, 39, 40
C220 M4(SFF/ LFF) w/E5-Series v3, C240 M4(SFF/ LFF) w/E5-Series v3	UCS VIC 1225T 10-Gbase-T 2 port CNA	UEK R3 U1 (3.8.13-26.x)	1.6.0.25 (FNIC) / 2.1.1.39 (ENIC)	4.1(1)	20, 21

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
C220 M3(SFF/LFF) w/E5-Series, C240 M3(SFF/LFF) w/E5-Series, C22 M3(SFF/LFF) w/E5-Series, C24 M3(SFF/LFF) w/E5-Series, C220 M3(SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C22 M3(SFF/LFF) w/E5-Series v2, C24 M3(SFF/LFF) w/E5-Series v2, C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	UCS VIC 1225T 10-Gbase-T 2 port CNA	UEK R3 U1 (3.8.13-26.x)	1.6.0.25 (FNIC) / 2.1.1.39 (ENIC)	4.1(1)	20, 21
C260 M2 w/E7-Series, C460 M2 w/E7-Series, C420 M3 w/E5-Series	UCS VIC 1225T 10-Gbase-T 2 port CNA	UEK R3 U3 (3.8.13-44.x)	1.6.0.25 (FNIC) / 2.1.1.50 (ENIC)	4.1(1)	20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1225T 10-Gbase-T 2 port CNA	UEK R3 U3 (3.8.13-44.x)	1.6.0.25 (FNIC) / 2.1.1.50 (ENIC)	4.1(1)	20, 21

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
C220 M3(SFF/LFF) w/E5-Series, C240 M3(SFF/LFF) w/E5-Series, C22 M3(SFF/LFF) w/E5-Series, C24 M3(SFF/LFF) w/E5-Series, C220 M3(SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C22 M3(SFF/LFF) w/E5-Series v2, C24 M3(SFF/LFF) w/E5-Series v2, C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	UCS VIC 1225T 10-Gbase-T 2 port CNA	UEK R3 U3 (3.8.13-44.x)	1.6.0.25 (FNIC) / 2.1.1.50 (ENIC)	4.1(1)	20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1225T 10-Gbase-T 2 port CNA	UEK R3 U5 (3.8.13-68.x)	1.6.0.25 (FNIC) / 2.1.1.67 (ENIC)	4.1(1)	20, 21

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
C220 M3(SFF/LFF) w/E5-Series, C240 M3(SFF/LFF) w/E5-Series, C22 M3(SFF/LFF) w/E5-Series, C24 M3(SFF/LFF) w/E5-Series, C220 M3(SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C22 M3(SFF/LFF) w/E5-Series v2, C24 M3(SFF/LFF) w/E5-Series v2, C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	UCS VIC 1225T 10-Gbase-T 2 port CNA	UEK R3 U5 (3.8.13-68.x)	1.6.0.25 (FNIC) / 2.1.1.67 (ENIC)	4.1(1)	20, 21
C220 M3(SFF/LFF) w/E5-Series, C240 M3(SFF/LFF) w/E5-Series, C22 M3(SFF/LFF) w/E5-Series, C24 M3(SFF/LFF) w/E5-Series, C220 M3(SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C22 M3(SFF/LFF) w/E5-Series v2, C24 M3(SFF/LFF) w/E5-Series v2, C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	UCS VIC 1225T 10-Gbase-T 2 port CNA	UEK R3 U6 (3.8.13-98.x)	1.6.0.25 (FNIC) / 2.1.1.67 (ENIC)	4.1(1)	20, 21

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
C220 M3(SFF/LFF) w/E5-Series, C240 M3(SFF/LFF) w/E5-Series, C22 M3(SFF/LFF) w/E5-Series, C24 M3(SFF/LFF) w/E5-Series, C220 M3(SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C22 M3(SFF/LFF) w/E5-Series v2, C24 M3(SFF/LFF) w/E5-Series v2, C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	UCS VIC 1225T 10-Gbase-T 2 port CNA	UEK R3 U7 (3.8.13-118)	1.6.0.25 (FNIC) / 2.1.1.67 (ENIC)	4.1(1)	20, 21
C260 M2 w/E7-Series, C460 M2 w/E7-Series, C420 M3 w/E5-Series	UCS VIC 1225T 10-Gbase-T 2 port CNA	UEK R4 (4.1.12-32.x)	1.6.0.22 (FNIC) / 2.3.0.12 (ENIC)	4.1(1)	20, 43

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
C220 M3(SFF/LFF) w/E5-Series, C240 M3(SFF/LFF) w/E5-Series, C22 M3(SFF/LFF) w/E5-Series, C24 M3(SFF/LFF) w/E5-Series, C220 M3(SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C22 M3(SFF/LFF) w/E5-Series v2, C24 M3(SFF/LFF) w/E5-Series v2, C24 M3(SFF/LFF) w/E5-Series v2, C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	UCS VIC 1225T 10-Gbase-T 2 port CNA	UEK R4 (4.1.12-32.x)	1.6.0.22 (FNIC) / 2.3.0.12 (ENIC)	4.1(1)	20, 43
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C220 M4(SFF/LFF) w/E5-Series v4, C240 M4(SFF/LFF) w/E5-Series v4	UCS VIC 1225T 10-Gbase-T 2 port CNA	UEK R4 (4.1.12-32.x)	1.6.0.22 (FNIC) / 2.3.0.12 (ENIC)	4.1(1)	20, 43
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1225T 10-Gbase-T 2 port CNA	OVM 3.3.1	1.6.0.9 (FNIC) / 2.1.1.39 (ENIC)	4.1(1)	20, 43

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
C220 M3(SFF/LFF) w/E5-Series, C240 M3(SFF/LFF) w/E5-Series, C22 M3(SFF/LFF) w/E5-Series, C24 M3(SFF/LFF) w/E5-Series, C220 M3(SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C22 M3(SFF/LFF) w/E5-Series v2, C24 M3(SFF/LFF) w/E5-Series v2, C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2	UCS VIC 1225T 10-Gbase-T 2 port CNA	OVM 3.3.1	1.6.0.9 (FNIC) / 2.1.1.39 (ENIC)	4.1(1)	20, 43
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1225T 10-Gbase-T 2 port CNA	OVM 3.3.2	1.6.0.10 (FNIC) / 2.1.1.50 (ENIC)	4.1(1)	20, 43

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
C220 M3(SFF/LFF) w/E5-Series, C240 M3(SFF/LFF) w/E5-Series, C22 M3(SFF/LFF) w/E5-Series, C24 M3(SFF/LFF) w/E5-Series, C220 M3(SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C22 M3(SFF/LFF) w/E5-Series v2, C24 M3(SFF/LFF) w/E5-Series v2, C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	UCS VIC 1225T 10-Gbase-T 2 port CNA	OVM 3.3.2	1.6.0.10 (FNIC) / 2.1.1.50 (ENIC)	4.1(1)	20, 43
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1225T 10-Gbase-T 2 port CNA	OVM 3.3.3	1.6.0.10 (FNIC) / 2.1.1.67 (ENIC)	4.1(1)	20, 43

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
C220 M3(SFF/LFF) w/E5-Series, C240 M3(SFF/LFF) w/E5-Series, C22 M3(SFF/LFF) w/E5-Series, C24 M3(SFF/LFF) w/E5-Series, C220 M3(SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C22 M3(SFF/LFF) w/E5-Series v2, C24 M3(SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	UCS VIC 1225T 10-Gbase-T 2 port CNA	OVM 3.3.3	1.6.0.10 (FNIC) / 2.1.1.67 (ENIC)	4.1(1)	20, 43
C220 M3(SFF/LFF) w/E5-Series, C240 M3(SFF/LFF) w/E5-Series, C22 M3(SFF/LFF) w/E5-Series, C24 M3(SFF/LFF) w/E5-Series, C220 M3(SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C22 M3(SFF/LFF) w/E5-Series v2, C24 M3(SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	UCS VIC 1225T 10-Gbase-T 2 port CNA	OVM 3.4.1	1.6.0.22 (FNIC) / 2.3.0.12 (ENIC)	4.1(1)	20, 43

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1225T 10-Gbase-T 2 port CNA	SUSE Linux Enterprise Server 11.3	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21
C220 M3(SFF/LFF) w/E5-Series, C240 M3(SFF/LFF) w/E5-Series, C22 M3(SFF/LFF) w/E5-Series, C24 M3(SFF/LFF) w/E5-Series, C220 M3(SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C22 M3(SFF/LFF) w/E5-Series v2, C24 M3(SFF/LFF) w/E5-Series v2, C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	UCS VIC 1225T 10-Gbase-T 2 port CNA	SUSE Linux Enterprise Server 11.3	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21
C260 M2 w/E7-Series, C460 M2 w/E7-Series, C420 M3 w/E5-Series	UCS VIC 1225T 10-Gbase-T 2 port CNA	SUSE Linux Enterprise Server 11.4	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1225T 10-Gbase-T 2 port CNA	SUSE Linux Enterprise Server 11.4	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
C220 M3(SFF/LFF) w/E5-Series, C240 M3(SFF/LFF) w/E5-Series, C22 M3(SFF/LFF) w/E5-Series, C24 M3(SFF/LFF) w/E5-Series, C220 M3(SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C22 M3(SFF/LFF) w/E5-Series v2, C24 M3(SFF/LFF) w/E5-Series v2, C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	UCS VIC 1225T 10-Gbase-T 2 port CNA	SUSE Linux Enterprise Server 11.4	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C220 M4(SFF/LFF) w/E5-Series v4, C240 M4(SFF/LFF) w/E5-Series v4	UCS VIC 1225T 10-Gbase-T 2 port CNA	SUSE Linux Enterprise Server 12	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
C220 M3(SFF/LFF) w/E5-Series, C240 M3(SFF/LFF) w/E5-Series, C22 M3(SFF/LFF) w/E5-Series, C24 M3(SFF/LFF) w/E5-Series, C220 M3(SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C22 M3(SFF/LFF) w/E5-Series v2, C24 M3(SFF/LFF) w/E5-Series v2, C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	UCS VIC 1225T 10-Gbase-T 2 port CNA	SUSE Linux Enterprise Server 12	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21
C260 M2 w/E7-Series, C460 M2 w/E7-Series, C420 M3 w/E5-Series	UCS VIC 1225T 10-Gbase-T 2 port CNA	SUSE Linux Enterprise Server 12.1	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C220 M4(SFF/LFF) w/E5-Series v4, C240 M4(SFF/LFF) w/E5-Series v4	UCS VIC 1225T 10-Gbase-T 2 port CNA	SUSE Linux Enterprise Server 12.1	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	12, 20, 21

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
C220 M3(SFF/LFF) w/E5-Series, C240 M3(SFF/LFF) w/E5-Series, C22 M3(SFF/LFF) w/E5-Series, C24 M3(SFF/LFF) w/E5-Series, C220 M3(SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C22 M3(SFF/LFF) w/E5-Series v2, C24 M3(SFF/LFF) w/E5-Series v2, C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	UCS VIC 1225T 10-Gbase-T 2 port CNA	SUSE Linux Enterprise Server 12.1	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	12, 20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1225T 10-Gbase-T 2 port CNA	XenServer 6.2	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	4, 20, 21

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
C220 M3(SFF/LFF) w/E5-Series, C240 M3(SFF/LFF) w/E5-Series, C22 M3(SFF/LFF) w/E5-Series, C24 M3(SFF/LFF) w/E5-Series, C220 M3(SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C22 M3(SFF/LFF) w/E5-Series v2, C24 M3(SFF/LFF) w/E5-Series v2, C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2	UCS VIC 1225T 10-Gbase-T 2 port CNA	XenServer 6.2	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	4, 20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1225T 10-Gbase-T 2 port CNA	XenServer 6.5	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21, 41

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
C220 M3(SFF/LFF) w/E5-Series, C240 M3(SFF/LFF) w/E5-Series, C22 M3(SFF/LFF) w/E5-Series, C24 M3(SFF/LFF) w/E5-Series, C220 M3(SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C22 M3(SFF/LFF) w/E5-Series v2, C24 M3(SFF/LFF) w/E5-Series v2, C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	UCS VIC 1225T 10-Gbase-T 2 port CNA	XenServer 6.5	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21, 41
C420 M3 w/E5-Series	UCS VIC 1225T 10-Gbase-T 2 port CNA	Ubuntu 12.04.5	2.1.1.50 (ENIC)	4.1(1)	3, 20, 43
C220 M3(SFF/LFF) w/E5-Series, C240 M3(SFF/LFF) w/E5-Series, C220 M3(SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	UCS VIC 1225T 10-Gbase-T 2 port CNA	Ubuntu 12.04.5	2.1.1.50 (ENIC)	4.1(1)	3, 20, 43

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
C220 M3(SFF/LFF) w/E5-Series, C240 M3(SFF/LFF) w/E5-Series, C220 M3(SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C460 M4 w/E7-Series v2	UCS VIC 1225T 10-Gbase-T 2 port CNA	Ubuntu 14.04	2.1.1.50 (ENIC)	4.1(1)	3, 43
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1225T 10-Gbase-T 2 port CNA	Ubuntu 14.04.1	2.1.1.50 (ENIC)	4.1(1)	3, 20, 43
C220 M3(SFF/LFF) w/E5-Series, C240 M3(SFF/LFF) w/E5-Series, C220 M3(SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	UCS VIC 1225T 10-Gbase-T 2 port CNA	Ubuntu 14.04.1	2.1.1.50 (ENIC)	4.1(1)	3, 20, 43
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1225T 10-Gbase-T 2 port CNA	Ubuntu 14.04.2	2.3.0.20 (ENIC)	4.1(1)	3, 20, 21

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
C220 M3(SFF/LFF) w/E5-Series, C240 M3(SFF/LFF) w/E5-Series, C220 M3(SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	UCS VIC 1225T 10-Gbase-T 2 port CNA	Ubuntu 14.04.2	2.3.0.20 (ENIC)	4.1(1)	3, 20, 21
C420 M3 w/E5-Series	UCS VIC 1225T 10-Gbase-T 2 port CNA	Ubuntu 14.04.3	2.3.0.20 (ENIC)	4.1(1)	3, 20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1225T 10-Gbase-T 2 port CNA	Ubuntu 14.04.3	2.3.0.20 (ENIC)	4.1(1)	3, 20, 21
C220 M3(SFF/LFF) w/E5-Series, C240 M3(SFF/LFF) w/E5-Series, C220 M3(SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	UCS VIC 1225T 10-Gbase-T 2 port CNA	Ubuntu 14.04.3	2.3.0.20 (ENIC)	4.1(1)	3, 20, 21
C420 M3 w/E5-Series	UCS VIC 1225T 10-Gbase-T 2 port CNA	Ubuntu 14.04.4	2.3.0.27 (ENIC)	4.1(1)	3, 20, 21

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C220 M4(SFF/LFF) w/E5-Series v4, C240 M4(SFF/LFF) w/E5-Series v4	UCS VIC 1225T 10-Gbase-T 2 port CNA	Ubuntu 14.04.4	2.3.0.27 (ENIC)	4.1(1)	3, 20, 21
C220 M3(SFF/LFF) w/E5-Series, C240 M3(SFF/LFF) w/E5-Series, C220 M3(SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	UCS VIC 1225T 10-Gbase-T 2 port CNA	Ubuntu 14.04.4	2.3.0.27 (ENIC)	4.1(1)	3, 20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C220 M4(SFF/LFF) w/E5-Series v4, C240 M4(SFF/LFF) w/E5-Series v4	UCS VIC 1225T 10-Gbase-T 2 port CNA	Ubuntu 16.04	2.3.0.27 (ENIC)	4.1(1)	3, 20, 21

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
C220 M3(SFF/LFF) w/E5-Series, C240 M3(SFF/LFF) w/E5-Series, C220 M3(SFF/LFF) w/E5-Series v2, C240 M3(SFF/LFF) w/E5-Series v2, C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	UCS VIC 1225T 10-Gbase-T 2 port CNA	Ubuntu 16.04	2.3.0.27 (ENIC)	4.1(1)	3, 20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1385 40G QSFP+ 2 port CNA	vSphere 5.1 U2	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 20, 31, 52, 53, 54
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2	UCS VIC 1385 40G QSFP+ 2 port CNA	vSphere 5.1 U2	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 20, 31, 52, 53, 54
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1385 40G QSFP+ 2 port CNA	vSphere 5.1 U3	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 20, 31, 52, 53, 54
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2	UCS VIC 1385 40G QSFP+ 2 port CNA	vSphere 5.1 U3	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 20, 31, 52, 53, 54
C460 M4 w/E7-Series v2	UCS VIC 1385 40G QSFP+ 2 port CNA	vSphere 5.5	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 20, 31, 52, 53, 54

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
C460 M4 w/E7-Series v2	UCS VIC 1385 40G QSFP+ 2 port CNA	vSphere 5.5 U1	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 20, 31, 52, 53, 54
C220 M4(SFF/ LFF) w/E5-Series v3, C240 M4(SFF/ LFF) w/E5-Series v3	UCS VIC 1385 40G QSFP+ 2 port CNA	vSphere 5.5 U2	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 20, 31, 52, 53, 54
C220 M4(SFF/ LFF) w/E5-Series v3, C240 M4(SFF/ LFF) w/E5-Series v3, C460 M4 w/ E7-Series v2, C460 M4 w/E7-Series v3	UCS VIC 1385 40G QSFP+ 2 port CNA	vSphere 5.5 U2	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 20, 31, 52, 53, 54
C220 M4(SFF/ LFF) w/E5-Series v3, C240 M4(SFF/ LFF) w/E5-Series v3, C220 M4(SFF/ LFF) w/E5-Series v4, C240 M4(SFF/ LFF) w/E5-Series v4	UCS VIC 1385 40G QSFP+ 2 port CNA	vSphere 5.5 U3	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 20, 31, 52, 53, 54
C220 M4(SFF/ LFF) w/E5-Series v3, C240 M4(SFF/ LFF) w/E5-Series v3, C460 M4 w/ E7-Series v2, C460 M4 w/E7-Series v3	UCS VIC 1385 40G QSFP+ 2 port CNA	vSphere 5.5 U3	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 20, 31, 52, 53, 54
C220 M4(SFF/ LFF) w/E5-Series v3, C240 M4(SFF/ LFF) w/E5-Series v3	UCS VIC 1385 40G QSFP+ 2 port CNA	vSphere 6.0	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 20, 31, 52, 53, 54

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	UCS VIC 1385 40G QSFP+ 2 port CNA	vSphere 6.0	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 20, 31, 52, 53, 54
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C220 M4(SFF/LFF) w/E5-Series v4, C240 M4(SFF/LFF) w/E5-Series v4	UCS VIC 1385 40G QSFP+ 2 port CNA	vSphere 6.0 U1	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 20, 31, 52, 53, 54
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	UCS VIC 1385 40G QSFP+ 2 port CNA	vSphere 6.0 U1	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 20, 31, 52, 53, 54
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C220 M4(SFF/LFF) w/E5-Series v4, C240 M4(SFF/LFF) w/E5-Series v4	UCS VIC 1385 40G QSFP+ 2 port CNA	vSphere 6.0 U2	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 20, 31, 52, 53, 54
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	UCS VIC 1385 40G QSFP+ 2 port CNA	vSphere 6.0 U2	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 20, 31, 52, 53, 54

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3, C460 M4 w/E7-Series v4	UCS VIC 1385 40G QSFP+ 2 port CNA	vSphere 6.5	1.6.0.28 (FNIC) / 1.0.0.2 (nenic)	4.1(1)	11, 12, 20, 31, 52, 53, 59
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1385 40G QSFP+ 2 port CNA	Windows Server 2008 R2 SP1	2.1.0.34 (FNIC) / 2.4.0.21 (ENIC) / 2.1.0.12 (NIC Teaming Driver)	4.1(1)	12, 20, 21, 25, 53, 55
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	UCS VIC 1385 40G QSFP+ 2 port CNA	Windows Server 2008 R2 SP1	2.1.0.34 (FNIC) / 2.4.0.21 (ENIC) / 2.1.0.12 (NIC Teaming Driver)	4.1(1)	12, 20, 21, 25, 53, 55
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1385 40G QSFP+ 2 port CNA	Windows Server 2012	2.4.0.19 (FNIC) / 3.5.0.17 (ENIC)	4.1(1)	12, 20, 21, 35, 56, 57
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	UCS VIC 1385 40G QSFP+ 2 port CNA	Windows Server 2012	2.4.0.19 (FNIC) / 3.5.0.17 (ENIC)	4.1(1)	12, 20, 21, 35, 56, 57
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C220 M4(SFF/LFF) w/E5-Series v4, C240 M4(SFF/LFF) w/E5-Series v4	UCS VIC 1385 40G QSFP+ 2 port CNA	Windows Server 2012 R2	2.4.0.19 (FNIC) / 3.5.0.17 (ENIC)	4.1(1)	10, 12, 20, 21, 35, 56, 57

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	UCS VIC 1385 40G QSFP+ 2 port CNA	Windows Server 2012 R2	2.4.0.19 (FNIC) / 3.5.0.17 (ENIC)	4.1(1)	10, 12, 20, 21, 35, 56, 57
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1385 40G QSFP+ 2 port CNA	Red Hat Enterprise Linux 6.5	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	UCS VIC 1385 40G QSFP+ 2 port CNA	Red Hat Enterprise Linux 6.5	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1385 40G QSFP+ 2 port CNA	Red Hat Enterprise Linux 6.6	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	UCS VIC 1385 40G QSFP+ 2 port CNA	Red Hat Enterprise Linux 6.6	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C220 M4(SFF/LFF) w/E5-Series v4, C240 M4(SFF/LFF) w/E5-Series v4	UCS VIC 1385 40G QSFP+ 2 port CNA	Red Hat Enterprise Linux 6.7	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	UCS VIC 1385 40G QSFP+ 2 port CNA	Red Hat Enterprise Linux 6.7	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C220 M4(SFF/LFF) w/E5-Series v4, C240 M4(SFF/LFF) w/E5-Series v4	UCS VIC 1385 40G QSFP+ 2 port CNA	Red Hat Enterprise Linux 6.8	1.6.0.27 (FNIC) / 2.3.0.27 (ENIC)	4.1(1)	20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	UCS VIC 1385 40G QSFP+ 2 port CNA	Red Hat Enterprise Linux 6.8	1.6.0.27 (FNIC) / 2.3.0.27 (ENIC)	4.1(1)	20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1385 40G QSFP+ 2 port CNA	Red Hat Enterprise Linux 7.0	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	UCS VIC 1385 40G QSFP+ 2 port CNA	Red Hat Enterprise Linux 7.0	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1385 40G QSFP+ 2 port CNA	Red Hat Enterprise Linux 7.1	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	UCS VIC 1385 40G QSFP+ 2 port CNA	Red Hat Enterprise Linux 7.1	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C220 M4(SFF/LFF) w/E5-Series v4, C240 M4(SFF/LFF) w/E5-Series v4	UCS VIC 1385 40G QSFP+ 2 port CNA	Red Hat Enterprise Linux 7.2	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	UCS VIC 1385 40G QSFP+ 2 port CNA	Red Hat Enterprise Linux 7.2	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1385 40G QSFP+ 2 port CNA	CentOS 6.6	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21, 39, 40
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	UCS VIC 1385 40G QSFP+ 2 port CNA	CentOS 6.6	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21, 39, 40

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C220 M4(SFF/LFF) w/E5-Series v4, C240 M4(SFF/LFF) w/E5-Series v4	UCS VIC 1385 40G QSFP+ 2 port CNA	CentOS 6.7	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21, 39, 40
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	UCS VIC 1385 40G QSFP+ 2 port CNA	CentOS 6.7	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21, 39, 40
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C220 M4(SFF/LFF) w/E5-Series v4, C240 M4(SFF/LFF) w/E5-Series v4	UCS VIC 1385 40G QSFP+ 2 port CNA	CentOS 7.1	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21, 39, 40
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	UCS VIC 1385 40G QSFP+ 2 port CNA	CentOS 7.1	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21, 39, 40
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C220 M4(SFF/LFF) w/E5-Series v4, C240 M4(SFF/LFF) w/E5-Series v4	UCS VIC 1385 40G QSFP+ 2 port CNA	CentOS 7.2	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21, 39, 40

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	UCS VIC 1385 40G QSFP+ 2 port CNA	CentOS 7.2	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21, 39, 40
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1385 40G QSFP+ 2 port CNA	UEK R3 U1 (3.8.13-26.x)	1.6.0.25 (FNIC) / 2.1.1.39 (ENIC)	4.1(1)	20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	UCS VIC 1385 40G QSFP+ 2 port CNA	UEK R3 U1 (3.8.13-26.x)	1.6.0.25 (FNIC) / 2.1.1.39 (ENIC)	4.1(1)	20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1385 40G QSFP+ 2 port CNA	UEK R3 U3 (3.8.13-44.x)	1.6.0.25 (FNIC) / 2.1.1.50 (ENIC)	4.1(1)	20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	UCS VIC 1385 40G QSFP+ 2 port CNA	UEK R3 U3 (3.8.13-44.x)	1.6.0.25 (FNIC) / 2.1.1.50 (ENIC)	4.1(1)	20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1385 40G QSFP+ 2 port CNA	UEK R3 U5 (3.8.13-68.x)	1.6.0.25 (FNIC) / 2.1.1.67 (ENIC)	4.1(1)	20, 21

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	UCS VIC 1385 40G QSFP+ 2 port CNA	UEK R3 U5 (3.8.13-68.x)	1.6.0.25 (FNIC) / 2.1.1.67 (ENIC)	4.1(1)	20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	UCS VIC 1385 40G QSFP+ 2 port CNA	UEK R3 U6 (3.8.13-98.x)	1.6.0.25 (FNIC) / 2.1.1.67 (ENIC)	4.1(1)	20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	UCS VIC 1385 40G QSFP+ 2 port CNA	UEK R3 U7 (3.8.13-118)	1.6.0.25 (FNIC) / 2.1.1.67 (ENIC)	4.1(1)	20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	UCS VIC 1385 40G QSFP+ 2 port CNA	UEK R4 (4.1.12-32.x)	1.6.0.22 (FNIC) / 2.3.0.12 (ENIC)	4.1(1)	20, 43
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C220 M4(SFF/LFF) w/E5-Series v4, C240 M4(SFF/LFF) w/E5-Series v4	UCS VIC 1385 40G QSFP+ 2 port CNA	UEK R4 (4.1.12-32.x)	1.6.0.22 (FNIC) / 2.3.0.12 (ENIC)	4.1(1)	20, 43
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1385 40G QSFP+ 2 port CNA	OVM 3.3.1	1.6.0.9 (FNIC) / 2.1.1.39 (ENIC)	4.1(1)	20, 43

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2	UCS VIC 1385 40G QSFP+ 2 port CNA	OVM 3.3.1	1.6.0.9 (FNIC) / 2.1.1.39 (ENIC)	4.1(1)	20, 43
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1385 40G QSFP+ 2 port CNA	OVM 3.3.2	1.6.0.10 (FNIC) / 2.1.1.50 (ENIC)	4.1(1)	20, 43
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	UCS VIC 1385 40G QSFP+ 2 port CNA	OVM 3.3.2	1.6.0.10 (FNIC) / 2.1.1.50 (ENIC)	4.1(1)	20, 43
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1385 40G QSFP+ 2 port CNA	OVM 3.3.3	1.6.0.10 (FNIC) / 2.1.1.67 (ENIC)	4.1(1)	20, 43
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	UCS VIC 1385 40G QSFP+ 2 port CNA	OVM 3.3.3	1.6.0.10 (FNIC) / 2.1.1.67 (ENIC)	4.1(1)	20, 43
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	UCS VIC 1385 40G QSFP+ 2 port CNA	OVM 3.4.1	1.6.0.22 (FNIC) / 2.3.0.12 (ENIC)	4.1(1)	20, 43
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1385 40G QSFP+ 2 port CNA	SUSE Linux Enterprise Server 11.3	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	UCS VIC 1385 40G QSFP+ 2 port CNA	SUSE Linux Enterprise Server 11.3	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1385 40G QSFP+ 2 port CNA	SUSE Linux Enterprise Server 11.4	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	UCS VIC 1385 40G QSFP+ 2 port CNA	SUSE Linux Enterprise Server 11.4	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C220 M4(SFF/LFF) w/E5-Series v4, C240 M4(SFF/LFF) w/E5-Series v4	UCS VIC 1385 40G QSFP+ 2 port CNA	SUSE Linux Enterprise Server 12	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	UCS VIC 1385 40G QSFP+ 2 port CNA	SUSE Linux Enterprise Server 12	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C220 M4(SFF/LFF) w/E5-Series v4, C240 M4(SFF/LFF) w/E5-Series v4	UCS VIC 1385 40G QSFP+ 2 port CNA	SUSE Linux Enterprise Server 12.1	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	12, 20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	UCS VIC 1385 40G QSFP+ 2 port CNA	SUSE Linux Enterprise Server 12.1	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	12, 20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1385 40G QSFP+ 2 port CNA	XenServer 6.2	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	4, 20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2	UCS VIC 1385 40G QSFP+ 2 port CNA	XenServer 6.2	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	4, 20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1385 40G QSFP+ 2 port CNA	XenServer 6.5	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21, 41
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	UCS VIC 1385 40G QSFP+ 2 port CNA	XenServer 6.5	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21, 41

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	UCS VIC 1385 40G QSFP+ 2 port CNA	Ubuntu 12.04.5	2.1.1.50 (ENIC)	4.1(1)	3, 20, 43
C460 M4 w/E7-Series v2	UCS VIC 1385 40G QSFP+ 2 port CNA	Ubuntu 14.04	2.1.1.50 (ENIC)	4.1(1)	3, 43
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1385 40G QSFP+ 2 port CNA	Ubuntu 14.04.1	2.1.1.50 (ENIC)	4.1(1)	3, 20, 43
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	UCS VIC 1385 40G QSFP+ 2 port CNA	Ubuntu 14.04.1	2.1.1.50 (ENIC)	4.1(1)	3, 20, 43
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1385 40G QSFP+ 2 port CNA	Ubuntu 14.04.2	2.3.0.20 (ENIC)	4.1(1)	3, 20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	UCS VIC 1385 40G QSFP+ 2 port CNA	Ubuntu 14.04.2	2.3.0.20 (ENIC)	4.1(1)	3, 20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1385 40G QSFP+ 2 port CNA	Ubuntu 14.04.3	2.3.0.20 (ENIC)	4.1(1)	3, 20, 21

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	UCS VIC 1385 40G QSFP+ 2 port CNA	Ubuntu 14.04.3	2.3.0.20 (ENIC)	4.1(1)	3, 20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C220 M4(SFF/LFF) w/E5-Series v4, C240 M4(SFF/LFF) w/E5-Series v4	UCS VIC 1385 40G QSFP+ 2 port CNA	Ubuntu 14.04.4	2.3.0.27 (ENIC)	4.1(1)	3, 20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	UCS VIC 1385 40G QSFP+ 2 port CNA	Ubuntu 14.04.4	2.3.0.27 (ENIC)	4.1(1)	3, 20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C220 M4(SFF/LFF) w/E5-Series v4, C240 M4(SFF/LFF) w/E5-Series v4	UCS VIC 1385 40G QSFP+ 2 port CNA	Ubuntu 16.04	2.3.0.27 (ENIC)	4.1(1)	3, 20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C460 M4 w/E7-Series v2, C460 M4 w/E7-Series v3	UCS VIC 1385 40G QSFP+ 2 port CNA	Ubuntu 16.04	2.3.0.27 (ENIC)	4.1(1)	3, 20, 21

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1387 40G QSFP+ 2 port CNA	vSphere 5.1 U2	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 20, 31, 52, 53, 54
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1387 40G QSFP+ 2 port CNA	vSphere 5.1 U2	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 20, 31, 52, 53, 54
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1387 40G QSFP+ 2 port CNA	vSphere 5.1 U3	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 20, 31, 52, 53, 54
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1387 40G QSFP+ 2 port CNA	vSphere 5.1 U3	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 20, 31, 52, 53, 54
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1387 40G QSFP+ 2 port CNA	vSphere 5.5 U2	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 20, 31, 52, 53, 54
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1387 40G QSFP+ 2 port CNA	vSphere 5.5 U2	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 20, 31, 52, 53, 54
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C220 M4(SFF/LFF) w/E5-Series v4, C240 M4(SFF/LFF) w/E5-Series v4	UCS VIC 1387 40G QSFP+ 2 port CNA	vSphere 5.5 U3	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 20, 31, 52, 53, 54

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1387 40G QSFP+ 2 port CNA	vSphere 5.5 U3	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 20, 31, 52, 53, 54
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1387 40G QSFP+ 2 port CNA	vSphere 6.0	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 20, 31, 52, 53, 54
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1387 40G QSFP+ 2 port CNA	vSphere 6.0	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 20, 31, 52, 53, 54
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C220 M4(SFF/LFF) w/E5-Series v4, C240 M4(SFF/LFF) w/E5-Series v4	UCS VIC 1387 40G QSFP+ 2 port CNA	vSphere 6.0 U1	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 20, 31, 52, 53, 54
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1387 40G QSFP+ 2 port CNA	vSphere 6.0 U1	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 20, 31, 52, 53, 54
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C220 M4(SFF/LFF) w/E5-Series v4, C240 M4(SFF/LFF) w/E5-Series v4	UCS VIC 1387 40G QSFP+ 2 port CNA	vSphere 6.0 U2	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 20, 31, 52, 53, 54

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1387 40G QSFP+ 2 port CNA	vSphere 6.0 U2	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	4.1(1)	11, 12, 20, 31, 52, 53, 54
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C220 M4(SFF/LFF) w/E5-Series v4, C240 M4(SFF/LFF) w/E5-Series v4	UCS VIC 1387 40G QSFP+ 2 port CNA	vSphere 6.5	1.6.0.28 (FNIC) / 1.0.0.2 (nenic)	4.1(1)	11, 12, 20, 31, 52, 53, 59
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1387 40G QSFP+ 2 port CNA	Windows Server 2008 R2 SP1	2.1.0.34 (FNIC) / 2.4.0.21 (ENIC) / 2.1.0.12 (NIC Teaming Driver)	4.1(1)	12, 20, 21, 25, 53, 55
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1387 40G QSFP+ 2 port CNA	Windows Server 2008 R2 SP1	2.1.0.34 (FNIC) / 2.4.0.21 (ENIC) / 2.1.0.12 (NIC Teaming Driver)	4.1(1)	12, 20, 21, 25, 53, 55
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1387 40G QSFP+ 2 port CNA	Windows Server 2012	2.4.0.19 (FNIC) / 3.5.0.17 (ENIC)	4.1(1)	12, 20, 21, 35, 56, 57
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1387 40G QSFP+ 2 port CNA	Windows Server 2012	2.4.0.19 (FNIC) / 3.5.0.17 (ENIC)	4.1(1)	12, 20, 21, 35, 56, 57

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C220 M4(SFF/LFF) w/E5-Series v4, C240 M4(SFF/LFF) w/E5-Series v4	UCS VIC 1387 40G QSFP+ 2 port CNA	Windows Server 2012 R2	2.4.0.19 (FNIC) / 3.5.0.17 (ENIC)	4.1(1)	10, 12, 20, 21, 35, 56, 57
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1387 40G QSFP+ 2 port CNA	Windows Server 2012 R2	2.4.0.19 (FNIC) / 3.5.0.17 (ENIC)	4.1(1)	10, 12, 20, 21, 35, 56, 57
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1387 40G QSFP+ 2 port CNA	Red Hat Enterprise Linux 6.5	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1387 40G QSFP+ 2 port CNA	Red Hat Enterprise Linux 6.5	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1387 40G QSFP+ 2 port CNA	Red Hat Enterprise Linux 6.6	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1387 40G QSFP+ 2 port CNA	Red Hat Enterprise Linux 6.6	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C220 M4(SFF/LFF) w/E5-Series v4, C240 M4(SFF/LFF) w/E5-Series v4	UCS VIC 1387 40G QSFP+ 2 port CNA	Red Hat Enterprise Linux 6.7	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1387 40G QSFP+ 2 port CNA	Red Hat Enterprise Linux 6.7	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C220 M4(SFF/LFF) w/E5-Series v4, C240 M4(SFF/LFF) w/E5-Series v4	UCS VIC 1387 40G QSFP+ 2 port CNA	Red Hat Enterprise Linux 6.8	1.6.0.27 (FNIC) / 2.3.0.27 (ENIC)	4.1(1)	20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1387 40G QSFP+ 2 port CNA	Red Hat Enterprise Linux 6.8	1.6.0.27 (FNIC) / 2.3.0.27 (ENIC)	4.1(1)	20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1387 40G QSFP+ 2 port CNA	Red Hat Enterprise Linux 7.0	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1387 40G QSFP+ 2 port CNA	Red Hat Enterprise Linux 7.0	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1387 40G QSFP+ 2 port CNA	Red Hat Enterprise Linux 7.1	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1387 40G QSFP+ 2 port CNA	Red Hat Enterprise Linux 7.1	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C220 M4(SFF/LFF) w/E5-Series v4, C240 M4(SFF/LFF) w/E5-Series v4	UCS VIC 1387 40G QSFP+ 2 port CNA	Red Hat Enterprise Linux 7.2	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1387 40G QSFP+ 2 port CNA	Red Hat Enterprise Linux 7.2	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1387 40G QSFP+ 2 port CNA	CentOS 6.6	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21, 39, 40
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1387 40G QSFP+ 2 port CNA	CentOS 6.6	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21, 39, 40

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C220 M4(SFF/LFF) w/E5-Series v4, C240 M4(SFF/LFF) w/E5-Series v4	UCS VIC 1387 40G QSFP+ 2 port CNA	CentOS 6.7	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21, 39, 40
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1387 40G QSFP+ 2 port CNA	CentOS 6.7	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21, 39, 40
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C220 M4(SFF/LFF) w/E5-Series v4, C240 M4(SFF/LFF) w/E5-Series v4	UCS VIC 1387 40G QSFP+ 2 port CNA	CentOS 7.1	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21, 39, 40
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1387 40G QSFP+ 2 port CNA	CentOS 7.1	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21, 39, 40
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v4, C240 M4(SFF/LFF) w/E5-Series v4	UCS VIC 1387 40G QSFP+ 2 port CNA	CentOS 7.2	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21, 39, 40
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1387 40G QSFP+ 2 port CNA	CentOS 7.2	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21, 39, 40

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1387 40G QSFP+ 2 port CNA	UEK R3 U1 (3.8.13-26.x)	1.6.0.25 (FNIC) / 2.1.1.39 (ENIC)	4.1(1)	20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1387 40G QSFP+ 2 port CNA	UEK R3 U3 (3.8.13-44.x)	1.6.0.25 (FNIC) / 2.1.1.50 (ENIC)	4.1(1)	20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1387 40G QSFP+ 2 port CNA	UEK R3 U5 (3.8.13-68.x)	1.6.0.25 (FNIC) / 2.1.1.67 (ENIC)	4.1(1)	20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1387 40G QSFP+ 2 port CNA	UEK R3 U6 (3.8.13-98.x)	1.6.0.25 (FNIC) / 2.1.1.67 (ENIC)	4.1(1)	20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1387 40G QSFP+ 2 port CNA	UEK R3 U7 (3.8.13-118)	1.6.0.25 (FNIC) / 2.1.1.67 (ENIC)	4.1(1)	20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C220 M4(SFF/LFF) w/E5-Series v4, C240 M4(SFF/LFF) w/E5-Series v4	UCS VIC 1387 40G QSFP+ 2 port CNA	UEK R4 (4.1.12- 32.x)	1.6.0.22 (FNIC) / 2.3.0.12 (ENIC)	4.1(1)	20, 43
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1387 40G QSFP+ 2 port CNA	OVM 3.3.1	1.6.0.9 (FNIC) / 2.1.1.39 (ENIC)	4.1(1)	20, 43

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1387 40G QSFP+ 2 port CNA	OVM 3.3.1	1.6.0.9 (FNIC) / 2.1.1.39 (ENIC)	4.1(1)	20, 43
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1387 40G QSFP+ 2 port CNA	OVM 3.3.2	1.6.0.10 (FNIC) / 2.1.1.50 (ENIC)	4.1(1)	20, 43
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1387 40G QSFP+ 2 port CNA	OVM 3.3.2	1.6.0.10 (FNIC) / 2.1.1.50 (ENIC)	4.1(1)	20, 43
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1387 40G QSFP+ 2 port CNA	OVM 3.3.3	1.6.0.10 (FNIC) / 2.1.1.67 (ENIC)	4.1(1)	20, 43
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1387 40G QSFP+ 2 port CNA	OVM 3.3.3	1.6.0.10 (FNIC) / 2.1.1.67 (ENIC)	4.1(1)	20, 43
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1387 40G QSFP+ 2 port CNA	OVM 3.4.1	1.6.0.22 (FNIC) / 2.3.0.12 (ENIC)	4.1(1)	20, 43
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1387 40G QSFP+ 2 port CNA	SUSE Linux Enterprise Server 11.3	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1387 40G QSFP+ 2 port CNA	SUSE Linux Enterprise Server 11.3	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1387 40G QSFP+ 2 port CNA	SUSE Linux Enterprise Server 11.4	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1387 40G QSFP+ 2 port CNA	SUSE Linux Enterprise Server 11.4	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C220 M4(SFF/LFF) w/E5-Series v4, C240 M4(SFF/LFF) w/E5-Series v4	UCS VIC 1387 40G QSFP+ 2 port CNA	SUSE Linux Enterprise Server 12	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1387 40G QSFP+ 2 port CNA	SUSE Linux Enterprise Server 12	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C220 M4(SFF/LFF) w/E5-Series v4, C240 M4(SFF/LFF) w/E5-Series v4	UCS VIC 1387 40G QSFP+ 2 port CNA	SUSE Linux Enterprise Server 12.1	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	12, 20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1387 40G QSFP+ 2 port CNA	SUSE Linux Enterprise Server 12.1	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	12, 20, 21

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1387 40G QSFP+ 2 port CNA	XenServer 6.2	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	4, 20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1387 40G QSFP+ 2 port CNA	XenServer 6.2	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	4, 20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1387 40G QSFP+ 2 port CNA	XenServer 6.5	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21, 41
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1387 40G QSFP+ 2 port CNA	XenServer 6.5	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	4.1(1)	20, 21, 41
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1387 40G QSFP+ 2 port CNA	Ubuntu 12.04.5	2.1.1.50 (ENIC)	4.1(1)	3, 20, 43
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1387 40G QSFP+ 2 port CNA	Ubuntu 14.04.1	2.1.1.50 (ENIC)	4.1(1)	3, 20, 43
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1387 40G QSFP+ 2 port CNA	Ubuntu 14.04.1	2.1.1.50 (ENIC)	4.1(1)	3, 20, 43
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1387 40G QSFP+ 2 port CNA	Ubuntu 14.04.2	2.3.0.20 (ENIC)	4.1(1)	3, 20, 21

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1387 40G QSFP+ 2 port CNA	Ubuntu 14.04.2	2.3.0.20 (ENIC)	4.1(1)	3, 20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1387 40G QSFP+ 2 port CNA	Ubuntu 14.04.3	2.3.0.20 (ENIC)	4.1(1)	3, 20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1387 40G QSFP+ 2 port CNA	Ubuntu 14.04.3	2.3.0.20 (ENIC)	4.1(1)	3, 20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C220 M4(SFF/LFF) w/E5-Series v4, C240 M4(SFF/LFF) w/E5-Series v4	UCS VIC 1387 40G QSFP+ 2 port CNA	Ubuntu 14.04.4	2.3.0.27 (ENIC)	4.1(1)	3, 20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1387 40G QSFP+ 2 port CNA	Ubuntu 14.04.4	2.3.0.27 (ENIC)	4.1(1)	3, 20, 21
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3, C220 M4(SFF/LFF) w/E5-Series v4, C240 M4(SFF/LFF) w/E5-Series v4	UCS VIC 1387 40G QSFP+ 2 port CNA	Ubuntu 16.04	2.3.0.27 (ENIC)	4.1(1)	3, 20, 21

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
C220 M4(SFF/LFF) w/E5-Series v3, C240 M4(SFF/LFF) w/E5-Series v3	UCS VIC 1387 40G QSFP+ 2 port CNA	Ubuntu 16.04	2.3.0.27 (ENIC)	4.1(1)	3, 20, 21
C260 M2 w/E7-Series, C460 M2 w/E7-Series	P81E Dual Port 10-Gbps Ethernet to PCIe Virtual Interface Card	vSphere 5.1 U3	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	2.2(3)	11, 12, 20, 31, 52, 53, 54
C260 M2 w/E7-Series, C460 M2 w/E7-Series	P81E Dual Port 10-Gbps Ethernet to PCIe Virtual Interface Card	vSphere 5.5 U3	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	2.2(3)	11, 12, 20, 31, 52, 53, 54
C260 M2 w/E7-Series, C460 M2 w/E7-Series	P81E Dual Port 10-Gbps Ethernet to PCIe Virtual Interface Card	vSphere 6.0 U1	1.6.0.28 (FNIC) / 2.3.0.7 (ENIC)	2.2(3)	11, 12, 20, 31, 52, 53, 54
C260 M2 w/E7-Series, C460 M2 w/E7-Series	P81E Dual Port 10-Gbps Ethernet to PCIe Virtual Interface Card	Windows Server 2012 R2	2.4.0.19 (FNIC) / 3.5.0.17 (ENIC)	2.2(3)	20, 21, 35, 56, 57
C260 M2 w/E7-Series, C460 M2 w/E7-Series	P81E Dual Port 10-Gbps Ethernet to PCIe Virtual Interface Card	Red Hat Enterprise Linux 6.7	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	2.2(3)	20, 21
C260 M2 w/E7-Series, C460 M2 w/E7-Series	P81E Dual Port 10-Gbps Ethernet to PCIe Virtual Interface Card	Red Hat Enterprise Linux 7.1	1.6.0.25 (FNIC) / 2.3.0.20 (ENIC)	2.2(3)	20, 21
B230 M2, B440 M2	UCS M73KR-E Converged Network Adapter	Red Hat Enterprise Linux 5.9	10.2.370.12 (FC) / 10.2.363.0 (ETH)	10.6.144.21	8
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS M73KR-E Converged Network Adapter	Red Hat Enterprise Linux 5.9	10.2.370.12 (FC) / 10.2.363.0 (ETH)	10.6.144.21	8

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS M73KR-E Converged Network Adapter	Red Hat Enterprise Linux 5.9	10.2.370.12 (FC) / 10.2.363.0 (ETH)	10.6.144.21	8
B230 M2, B440 M2	UCS M73KR-E Converged Network Adapter	Red Hat Enterprise Linux 5.10	10.2.370.12 (FC) / 10.2.363.0 (ETH)	10.6.144.21	8
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS M73KR-E Converged Network Adapter	Red Hat Enterprise Linux 5.10	10.2.370.12 (FC) / 10.2.363.0 (ETH)	10.6.144.21	8
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS M73KR-E Converged Network Adapter	Red Hat Enterprise Linux 5.10	10.2.370.12 (FC) / 10.2.363.0 (ETH)	10.6.144.21	8
B230 M2, B440 M2	UCS M73KR-E Converged Network Adapter	Red Hat Enterprise Linux 6.4	10.2.370.12 (FC) / 10.2.363.0 (ETH)	10.6.144.21	8
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS M73KR-E Converged Network Adapter	Red Hat Enterprise Linux 6.4	10.2.370.12 (FC) / 10.2.363.0 (ETH)	10.6.144.21	8
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS M73KR-E Converged Network Adapter	Red Hat Enterprise Linux 6.4	10.2.370.12 (FC) / 10.2.363.0 (ETH)	10.6.144.21	8
B230 M2, B440 M2	UCS M73KR-E Converged Network Adapter	Red Hat Enterprise Linux 6.5	10.2.370.12 (FC) / 10.2.363.0 (ETH)	10.6.144.21	8
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS M73KR-E Converged Network Adapter	Red Hat Enterprise Linux 6.5	10.2.370.12 (FC) / 10.2.363.0 (ETH)	10.6.144.21	8

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS M73KR-E Converged Network Adapter	Red Hat Enterprise Linux 6.5	10.2.370.12 (FC) / 10.2.363.0 (ETH)	10.6.144.21	8
B230 M2, B440 M2	UCS M73KR-E Converged Network Adapter	Red Hat Enterprise Linux 6.6	10.0.803.24 (FC) / 10.0.800.0 (ETH) Inbox	10.6.144.21	8, 43
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS M73KR-E Converged Network Adapter	Red Hat Enterprise Linux 6.6	10.0.803.24 (FC) / 10.0.800.0 (ETH) Inbox	10.6.144.21	8, 43
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS M73KR-E Converged Network Adapter	Red Hat Enterprise Linux 6.6	10.0.803.24 (FC) / 10.0.800.0 (ETH) Inbox	10.6.144.21	8, 43
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS M73KR-E Converged Network Adapter	Red Hat Enterprise Linux 7.0	10.2.370.12 (FC) / 10.2.363.0 (ETH)	10.6.144.21	8
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS M73KR-E Converged Network Adapter	Red Hat Enterprise Linux 7.0	10.2.370.12 (FC) / 10.2.363.0 (ETH)	10.6.144.21	8
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS M73KR-E Converged Network Adapter	Solaris 11 10/12 (U1)	20120210-2.70i (FC) / 4.1.369.1S (ETH)	10.6.144.21	8, 43
B230 M2, B440 M2	UCS M73KR-E Converged Network Adapter	vSphere 5.0 U2	10.2.292.0 (FC) / 10.2.293.0 (ETH)	10.6.144.21	8
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS M73KR-E Converged Network Adapter	vSphere 5.0 U2	10.2.292.0 (FC) / 10.2.293.0 (ETH)	10.6.144.21	8

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS M73KR-E Converged Network Adapter	vSphere 5.0 U2	10.2.292.0 (FC) / 10.2.293.0 (ETH)	10.6.144.21	8
B230 M2, B440 M2	UCS M73KR-E Converged Network Adapter	vSphere 5.0 U3	10.2.292.0 (FC) / 10.2.293.0 (ETH)	10.6.144.21	8
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS M73KR-E Converged Network Adapter	vSphere 5.0 U3	10.2.292.0 (FC) / 10.2.293.0 (ETH)	10.6.144.21	8
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS M73KR-E Converged Network Adapter	vSphere 5.0 U3	10.2.292.0 (FC) / 10.2.293.0 (ETH)	10.6.144.21	8
B230 M2, B440 M2	UCS M73KR-E Converged Network Adapter	vSphere 5.1 U1	10.2.292.0 (FC) / 10.2.293.0 (ETH)	10.6.144.21	8
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS M73KR-E Converged Network Adapter	vSphere 5.1 U1	10.2.292.0 (FC) / 10.2.293.0 (ETH)	10.6.144.21	8
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS M73KR-E Converged Network Adapter	vSphere 5.1 U1	10.2.292.0 (FC) / 10.2.293.0 (ETH)	10.6.144.21	8
B230 M2, B440 M2	UCS M73KR-E Converged Network Adapter	vSphere 5.1 U2	10.2.292.0 (FC) / 10.2.293.0 (ETH)	10.6.144.21	8
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS M73KR-E Converged Network Adapter	vSphere 5.1 U2	10.2.292.0 (FC) / 10.2.293.0 (ETH)	10.6.144.21	8

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS M73KR-E Converged Network Adapter	vSphere 5.1 U2	10.2.292.0 (FC) / 10.2.293.0 (ETH)	10.6.144.21	8
B230 M2, B440 M2	UCS M73KR-E Converged Network Adapter	vSphere 5.1 U3	10.2.292.0 (FC) / 10.2.293.0 (ETH)	10.6.144.21	8
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS M73KR-E Converged Network Adapter	vSphere 5.1 U3	10.2.292.0 (FC) / 10.2.293.0 (ETH)	10.6.144.21	8
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS M73KR-E Converged Network Adapter	vSphere 5.1 U3	10.2.292.0 (FC) / 10.2.293.0 (ETH)	10.6.144.21	8
B230 M2, B440 M2	UCS M73KR-E Converged Network Adapter	vSphere 5.5	10.2.340.18 (FC) / 10.2.298.5 (ETH)	10.6.144.21	8
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS M73KR-E Converged Network Adapter	vSphere 5.5	10.2.340.18 (FC) / 10.2.298.5 (ETH)	10.6.144.21	8
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS M73KR-E Converged Network Adapter	vSphere 5.5	10.2.340.18 (FC) / 10.2.298.5 (ETH)	10.6.144.21	8
B230 M2, B440 M2	UCS M73KR-E Converged Network Adapter	vSphere 5.5 U1	10.2.340.18 (FC) / 10.2.298.5 (ETH)	10.6.144.21	8
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS M73KR-E Converged Network Adapter	vSphere 5.5 U1	10.2.340.18 (FC) / 10.2.298.5 (ETH)	10.6.144.21	8

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS M73KR-E Converged Network Adapter	vSphere 5.5 U1	10.2.340.18 (FC) / 10.2.298.5 (ETH)	10.6.144.21	8
B230 M2, B440 M2	UCS M73KR-E Converged Network Adapter	vSphere 5.5 U2	10.2.340.18 (FC) / 10.2.298.5 (ETH)	10.6.144.21	8
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS M73KR-E Converged Network Adapter	vSphere 5.5 U2	10.2.340.18 (FC) / 10.2.298.5 (ETH)	10.6.144.21	8
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS M73KR-E Converged Network Adapter	vSphere 5.5 U2	10.2.340.18 (FC) / 10.2.298.5 (ETH)	10.6.144.21	8
B230 M2, B440 M2	UCS M73KR-E Converged Network Adapter	vSphere 5.5 U3	10.2.340.18 (FC) / 10.2.298.5 (ETH)	10.6.144.21	8
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS M73KR-E Converged Network Adapter	vSphere 5.5 U3	10.2.340.18 (FC) / 10.2.298.5 (ETH)	10.6.144.21	8
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS M73KR-E Converged Network Adapter	vSphere 5.5 U3	10.2.340.18 (FC) / 10.2.298.5 (ETH)	10.6.144.21	8
B230 M2, B440 M2	UCS M73KR-E Converged Network Adapter	Windows Server 2008 R2 SP1	10.2.370.8 (FC) / 10.2.370.18 (ETH), 2.8.5-5 (NIC Teaming Driver)	10.6.144.21	8
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS M73KR-E Converged Network Adapter	Windows Server 2008 R2 SP1	10.2.370.8 (FC) / 10.2.370.18 (ETH), 2.8.5-5 (NIC Teaming Driver)	10.6.144.21	8

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS M73KR-E Converged Network Adapter	Windows Server 2008 R2 SP1	10.2.370.8 (FC) / 10.2.370.18 (ETH), 2.8.5-5 (NIC Teaming Driver)	10.6.144.21	8
B230 M2, B440 M2	UCS M73KR-E Converged Network Adapter	Windows Server 2012	10.2.370.8 (FC) / 10.2.370.18 (ETH)	10.6.144.21	8
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS M73KR-E Converged Network Adapter	Windows Server 2012	10.2.370.8 (FC) / 10.2.370.18 (ETH)	10.6.144.21	8
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS M73KR-E Converged Network Adapter	Windows Server 2012	10.2.370.8 (FC) / 10.2.370.18 (ETH)	10.6.144.21	8
B230 M2, B440 M2	UCS M73KR-E Converged Network Adapter	Windows Server 2012 R2	10.2.370.8 (FC) / 10.2.370.18 (ETH)	10.6.144.21	8
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS M73KR-E Converged Network Adapter	Windows Server 2012 R2	10.2.370.8 (FC) / 10.2.370.18 (ETH)	10.6.144.21	8
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS M73KR-E Converged Network Adapter	Windows Server 2012 R2	10.2.370.8 (FC) / 10.2.370.18 (ETH)	10.6.144.21	8
B200 M2 w/E5-Series, B250 M2, B230 M1 & M2, B440 M1 & M2	UCS M72KR-E Converged Network Adapter	Red Hat Enterprise Linux 5.9	10.2.370.12 (FC) / 10.2.363.0 (ETH)	10.0.803.19	8
B200 M2 w/E5-Series, B250 M2, B230 M1 & M2, B440 M1 & M2	UCS M72KR-E Converged Network Adapter	Red Hat Enterprise Linux 5.10	10.2.370.12 (FC) / 10.2.363.0 (ETH)	10.0.803.19	8

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B200 M2 w/E5-Series, B250 M2, B230 M1 & M2, B440 M1 & M2	UCS M72KR-E Converged Network Adapter	Red Hat Enterprise Linux 6.4	10.2.370.12 (FC) / 10.2.363.0 (ETH)	10.0.803.19	8
B200 M2 w/E5-Series, B250 M2, B230 M1 & M2, B440 M1 & M2	UCS M72KR-E Converged Network Adapter	Red Hat Enterprise Linux 6.5	10.2.370.12 (FC) / 10.2.363.0 (ETH)	10.0.803.19	8
B200 M2 w/E5-Series, B250 M2, B230 M1 & M2, B440 M1 & M2	UCS M72KR-E Converged Network Adapter	Red Hat Enterprise Linux 6.6	10.0.803.24 (FC) / 10.0.800.0 (ETH)	10.0.803.19	8, 43
B200 M1 w/E5-Series, B230 M1 & M2, B250 M1 & M2, B440 M1 & M2	UCS M72KR-E Converged Network Adapter	vSphere 5.0 U2	10.2.292.0 (FC) / 10.2.293.0 (ETH)	10.0.803.19	8, 11
B200 M1 w/E5-Series, B230 M1 & M2, B250 M1 & M2, B440 M1 & M2	UCS M72KR-E Converged Network Adapter	vSphere 5.0 U3	10.2.292.0 (FC) / 10.2.293.0 (ETH)	10.0.803.19	8, 11
B200 M2 w/E5-Series, B230 M2, B250 M2, B440 M2	UCS M72KR-E Converged Network Adapter	vSphere 5.1 U1	10.2.292.0 (FC) / 10.2.293.0 (ETH)	10.0.803.19	8, 11
B200 M2 w/E5-Series, B230 M2, B250 M2, B440 M2	UCS M72KR-E Converged Network Adapter	vSphere 5.1 U2	10.2.292.0 (FC) / 10.2.293.0 (ETH)	10.0.803.19	8, 11
B200 M2 w/E5-Series, B230 M2, B250 M2, B440 M2	UCS M72KR-E Converged Network Adapter	vSphere 5.1 U3	10.2.292.0 (FC) / 10.2.293.0 (ETH)	10.0.803.19	8, 11
B200 M1 w/E5-Series, B230 M1 & M2, B250 M1 & M2, B440 M1 & M2	UCS M72KR-E Converged Network Adapter	Windows Server 2008 R2 SP1	10.2.370.8 (FC) / 10.2.370.18 (ETH), 2.8.5-5 (NIC Teaming Driver)	10.0.803.19	8

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B200 M2 w/E5-Series, B230 M2, B250 M2, B440 M2	UCS M72KR-E Converged Network Adapter	Windows Server 2012	10.2.370.8 (FC) / 10.2.370.18 (ETH)	10.0.803.19	8
B200 M1 w/E5-Series, B230 M1 & M2, B250 M1 & M2, B440 M1 & M2	UCS M71KR-E Converged Network Adapter	Windows Server 2008 R2 SP1	7.2.41.002 (FC)	2.80A4	8
B230 M2, B440 M2	UCS M73KR-Q Converged Network Adapter	Red Hat Enterprise Linux 5.9	8.06.00.11.5.6 (FC) / 5.2.46.1 (ETH)	2.50.11	8
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS M73KR-Q Converged Network Adapter	Red Hat Enterprise Linux 5.9	8.06.00.11.5.6 (FC) / 5.2.46.1 (ETH)	2.50.11	8
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS M73KR-Q Converged Network Adapter	Red Hat Enterprise Linux 5.9	8.06.00.11.5.6 (FC) / 5.2.46.1 (ETH)	2.50.11	8
B230 M2, B440 M2	UCS M73KR-Q Converged Network Adapter	Red Hat Enterprise Linux 5.10	8.06.00.11.5.6 (FC) / 5.2.46.1 (ETH)	2.50.11	8
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS M73KR-Q Converged Network Adapter	Red Hat Enterprise Linux 5.10	8.06.00.11.5.6 (FC) / 5.2.46.1 (ETH)	2.50.11	8
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS M73KR-Q Converged Network Adapter	Red Hat Enterprise Linux 5.10	8.06.00.11.5.6 (FC) / 5.2.46.1 (ETH)	2.50.11	8
B230 M2, B440 M2	UCS M73KR-Q Converged Network Adapter	Red Hat Enterprise Linux 6.4	8.06.00.10.06.0 (FC) / 5.2.46.1 (ETH)	2.50.11	8

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS M73KR-Q Converged Network Adapter	Red Hat Enterprise Linux 6.4	8.06.00.10.06.0 (FC) / 5.2.46.1 (ETH)	2.50.11	8
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS M73KR-Q Converged Network Adapter	Red Hat Enterprise Linux 6.4	8.06.00.10.06.0 (FC) / 5.2.46.1 (ETH)	2.50.11	8
B230 M2, B440 M2	UCS M73KR-Q Converged Network Adapter	Red Hat Enterprise Linux 6.5	8.05.00.03.06.5-k2 (FC) / 5.2.43 (ETH)	2.50.11	8, 43
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS M73KR-Q Converged Network Adapter	Red Hat Enterprise Linux 6.5	8.05.00.03.06.5-k2 (FC) / 5.2.43 (ETH)	2.50.11	8, 43
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS M73KR-Q Converged Network Adapter	Red Hat Enterprise Linux 6.5	8.05.00.03.06.5-k2 (FC) / 5.2.43 (ETH)	2.50.11	8, 43
B230 M2, B440 M2	UCS M73KR-Q Converged Network Adapter	Red Hat Enterprise Linux 6.6	8.05.00.03.06.5-k2 (FC) / 5.2.43 (ETH)	2.50.11	8, 43
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS M73KR-Q Converged Network Adapter	Red Hat Enterprise Linux 6.6	8.05.00.03.06.5-k2 (FC) / 5.2.43 (ETH)	2.50.11	8, 43
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS M73KR-Q Converged Network Adapter	Red Hat Enterprise Linux 6.6	8.05.00.03.06.5-k2 (FC) / 5.2.43 (ETH)	2.50.11	8, 43
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS M73KR-Q Converged Network Adapter	Red Hat Enterprise Linux 7.0	8.06.00.08.07.0-k2 (FC) / 5.3.48.2 (ETH)	2.50.11	8, 43

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS M73KR-Q Converged Network Adapter	Red Hat Enterprise Linux 7.0	8.06.00.08.07.0-k2 (FC) / 5.3.48.2 (ETH)	2.50.11	8, 43
B230 M2, B440 M2	UCS M73KR-Q Converged Network Adapter	vSphere 5.0 U2	934.5.29.0-1vmw (FC) / 5.1.178 (ETH)	2.50.11	8
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS M73KR-Q Converged Network Adapter	vSphere 5.0 U2	934.5.29.0-1vmw (FC) / 5.1.178 (ETH)	2.50.11	8
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS M73KR-Q Converged Network Adapter	vSphere 5.0 U2	934.5.29.0-1vmw (FC) / 5.1.178 (ETH)	2.50.11	8
B230 M2, B440 M2	UCS M73KR-Q Converged Network Adapter	vSphere 5.0 U3	934.5.29.0-1vmw (FC) / 5.1.178 (ETH)	2.50.11	8
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS M73KR-Q Converged Network Adapter	vSphere 5.0 U3	934.5.29.0-1vmw (FC) / 5.1.178 (ETH)	2.50.11	8
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS M73KR-Q Converged Network Adapter	vSphere 5.0 U3	934.5.29.0-1vmw (FC) / 5.1.178 (ETH)	2.50.11	8
B230 M2, B440 M2	UCS M73KR-Q Converged Network Adapter	vSphere 5.1 U1	934.5.29.0-1vmw (FC) / 5.1.178 (ETH)	2.50.11	8
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS M73KR-Q Converged Network Adapter	vSphere 5.1 U1	934.5.29.0-1vmw (FC) / 5.1.178 (ETH)	2.50.11	8

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS M73KR-Q Converged Network Adapter	vSphere 5.1 U1	934.5.29.0-1vmw (FC) / 5.1.178 (ETH)	2.50.11	8
B230 M2, B440 M2	UCS M73KR-Q Converged Network Adapter	vSphere 5.1 U2	934.5.29.0-1vmw (FC) / 5.1.178 (ETH)	2.50.11	8
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS M73KR-Q Converged Network Adapter	vSphere 5.1 U2	934.5.29.0-1vmw (FC) / 5.1.178 (ETH)	2.50.11	8
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS M73KR-Q Converged Network Adapter	vSphere 5.1 U2	934.5.29.0-1vmw (FC) / 5.1.178 (ETH)	2.50.11	8
B230 M2, B440 M2	UCS M73KR-Q Converged Network Adapter	vSphere 5.1 U3	934.5.29.0-1vmw (FC) / 5.1.178 (ETH)	2.50.11	8
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS M73KR-Q Converged Network Adapter	vSphere 5.1 U3	934.5.29.0-1vmw (FC) / 5.1.178 (ETH)	2.50.11	8
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS M73KR-Q Converged Network Adapter	vSphere 5.1 U3	934.5.29.0-1vmw (FC) / 5.1.178 (ETH)	2.50.11	8
B230 M2, B440 M2	UCS M73KR-Q Converged Network Adapter	vSphere 5.5	1.1.14.0-1 (FC) / 5.5.177 (ETH)	2.50.11	8
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS M73KR-Q Converged Network Adapter	vSphere 5.5	1.1.14.0-1 (FC) / 5.5.177 (ETH)	2.50.11	8

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS M73KR-Q Converged Network Adapter	vSphere 5.5	1.1.14.0-1 (FC) / 5.5.177 (ETH)	2.50.11	8
B230 M2, B440 M2	UCS M73KR-Q Converged Network Adapter	vSphere 5.5 U1	1.1.14.0-1 (FC) / 5.5.177 (ETH)	2.50.11	8
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS M73KR-Q Converged Network Adapter	vSphere 5.5 U1	1.1.14.0-1 (FC) / 5.5.177 (ETH)	2.50.11	8
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS M73KR-Q Converged Network Adapter	vSphere 5.5 U1	1.1.14.0-1 (FC) / 5.5.177 (ETH)	2.50.11	8
B230 M2, B440 M2	UCS M73KR-Q Converged Network Adapter	vSphere 5.5 U2	1.1.14.0-1 (FC) / 5.5.177 (ETH)	2.50.11	8
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS M73KR-Q Converged Network Adapter	vSphere 5.5 U2	1.1.14.0-1 (FC) / 5.5.177 (ETH)	2.50.11	8
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS M73KR-Q Converged Network Adapter	vSphere 5.5 U2	1.1.14.0-1 (FC) / 5.5.177 (ETH)	2.50.11	8
B230 M2, B440 M2	UCS M73KR-Q Converged Network Adapter	vSphere 5.5 U3	1.1.14.0-1 (FC) / 5.5.177 (ETH)	2.50.11	8
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS M73KR-Q Converged Network Adapter	vSphere 5.5 U3	1.1.14.0-1 (FC) / 5.5.177 (ETH)	2.50.11	8

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS M73KR-Q Converged Network Adapter	vSphere 5.5 U3	1.1.14.0-1 (FC) / 5.5.177 (ETH)	2.50.11	8
B230 M2, B440 M2	UCS M73KR-Q Converged Network Adapter	Windows Server 2008 R2 SP1	9.1.11.12 (FC) / 5.3.12.0925 (ETH), 5.3.12.0925 (NIC Teaming Driver)	2.50.11	8
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS M73KR-Q Converged Network Adapter	Windows Server 2008 R2 SP1	9.1.11.12 (FC) / 5.3.12.0925 (ETH), 5.3.12.0925 (NIC Teaming Driver)	2.50.11	8
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS M73KR-Q Converged Network Adapter	Windows Server 2008 R2 SP1	9.1.11.12 (FC) / 5.3.12.0925 (ETH), 5.3.12.0925 (NIC Teaming Driver)	2.50.11	8
B230 M2, B440 M2	UCS M73KR-Q Converged Network Adapter	Windows Server 2012	9.1.11.12 (FC) / 5.3.12.0925 (ETH)	2.50.11	8
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS M73KR-Q Converged Network Adapter	Windows Server 2012	9.1.11.12 (FC) / 5.3.12.0925 (ETH)	2.50.11	8
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS M73KR-Q Converged Network Adapter	Windows Server 2012	9.1.11.12 (FC) / 5.3.12.0925 (ETH)	2.50.11	8
B230 M2, B440 M2	UCS M73KR-Q Converged Network Adapter	Windows Server 2012 R2	9.1.11.12 (FC) / 5.3.12.0925 (ETH)	2.50.11	8
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS M73KR-Q Converged Network Adapter	Windows Server 2012 R2	9.1.11.12 (FC) / 5.3.12.0925 (ETH)	2.50.11	8

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS M73KR-Q Converged Network Adapter	Windows Server 2012 R2	9.1.11.12 (FC) / 5.3.12.0925 (ETH)	2.50.11	8
B200 M2 w/E5-Series, B250 M2, B230 M1 & M2, B440 M1 & M2	UCS M72KR-Q Converged Network Adapter	Red Hat Enterprise Linux 5.9	8.03.07.15.05.09-k (FC) / 1.0.00.30 (ETH)	2.00.77	8, 43
B200 M2 w/E5-Series, B250 M2, B230 M1 & M2, B440 M1 & M2	UCS M72KR-Q Converged Network Adapter	Red Hat Enterprise Linux 5.10	8.03.07.15.05.09-k (FC) / 1.0.00.30 (ETH)	2.00.77	8, 43
B200 M2 w/E5-Series, B250 M2, B230 M1 & M2, B440 M1 & M2	UCS M72KR-Q Converged Network Adapter	Red Hat Enterprise Linux 6.4	8.04.00.08.06.4-k (FC) / 1.00.00.31 (ETH)	2.00.77	8, 43
B200 M2 w/E5-Series, B250 M2, B230 M1 & M2, B440 M1 & M2	UCS M72KR-Q Converged Network Adapter	Red Hat Enterprise Linux 6.5	8.05.00.03.06.5-k2 (FC) / 1.00.00.32 (ETH)	2.00.77	8, 43
B200 M2 w/E5-Series, B250 M2, B230 M1 & M2, B440 M1 & M2	UCS M72KR-Q Converged Network Adapter	Red Hat Enterprise Linux 6.6	8.05.00.03.06.5-k2 (FC) / 1.00.00.32 (ETH)	2.00.77	8, 43
B200 M1 w/E5-Series, B230 M1 & M2, B250 M1 & M2, B440 M1 & M2	UCS M72KR-Q Converged Network Adapter	vSphere 5.0 U2	934.5.4.0-1vmw (FC) / 2.0.0.54 (ETH)	2.00.77	8, 11
B200 M1 w/E5-Series, B230 M1 & M2, B250 M1 & M2, B440 M1 & M2	UCS M72KR-Q Converged Network Adapter	vSphere 5.0 U3	934.5.4.0-1vmw (FC) / 2.0.0.54 (ETH)	2.00.77	8, 11
B200 M2 w/E5-Series, B230 M2, B250 M2, B440 M2	UCS M72KR-Q Converged Network Adapter	vSphere 5.1 U1	934.5.4.0-1vmw (FC) / 2.0.0.54 (ETH)	2.00.77	8, 11

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B200 M2 w/E5-Series, B230 M2, B250 M2, B440 M2	UCS M72KR-Q Converged Network Adapter	vSphere 5.1 U2	934.5.4.0-1vmw (FC) / 2.0.0.54 (ETH)	2.00.77	8, 11
B200 M2 w/E5-Series, B230 M2, B250 M2, B440 M2	UCS M72KR-Q Converged Network Adapter	vSphere 5.1 U3	934.5.4.0-1vmw (FC) / 2.0.0.54 (ETH)	2.00.77	8, 11
B200 M1 w/E5-Series, B230 M1 & M2, B250 M1 & M2, B440 M1 & M2	UCS M72KR-Q Converged Network Adapter	Windows Server 2008 R2 SP1	9.1.8.27 (FC) / 1.0.1.12 (ETH), 4.6.6.1213 (NIC Teaming Driver)	2.00.77	8
B200 M2 w/E5-Series, B230 M2, B250 M2, B440 M2	UCS M72KR-Q Converged Network Adapter	Windows Server 2012	9.1.10.15 (FC) / 1.0.1.15 (ETH)	2.00.77	8
B200 M1 w/E5-Series, B230 M1 & M2, B250 M1 & M2, B440 M1 & M2	UCS M71KR-Q Converged Network Adapter	Windows Server 2008 R2 SP1	9.1.8.27 (FC)	2.2(4)	8, 13

Network Interface Card Interoperability Matrix

Table 6 lists the network interface cards that the Unified Computing System B Series Servers support.

Table 6: Network Interface Cards

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B200 M2 w/E5-Series, B250 M2, B230 M1 & M2, B440 M1 & M2	UCS M51KR-B 10-Gigabit Ethernet Adapter	Red Hat Enterprise Linux 5.9	1.72.51-0 (ETH)	6.2.15.23.7.1	43
B200 M2 w/E5-Series, B250 M2, B230 M1 & M2, B440 M1 & M2	UCS M51KR-B 10-Gigabit Ethernet Adapter	Red Hat Enterprise Linux 5.10	1.72.51-0 (ETH)	6.2.15.23.7.1	43

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B200 M1 w/E5-Series, B230 M1 & M2, B250 M1 & M2, B440 M1 & M2	UCS M51KR-B 10-Gigabit Ethernet Adapter	Windows Server 2008 R2 SP1	6.2.9.0 (ETH) / 6.2.7.0 (iSCSI) / 1.4.10.0 (NIC Teaming Driver)	6.2.15.23.7.1	12, 17
B200 M2 w/E5-Series, B250 M2, B230 M1 & M2, B440 M1 & M2	UCS M61KR-I 10-Gigabit Ethernet Adapter	Red Hat Enterprise Linux 5.9	3.4.8-k (ETH)	2.1.60.1.1	43
B200 M2 w/E5-Series, B250 M2, B230 M1 & M2, B440 M1 & M2	UCS M61KR-I 10-Gigabit Ethernet Adapter	Red Hat Enterprise Linux 5.10	3.4.8-k (ETH)	2.1.60.1.1	43
B200 M1 w/E5-Series, B230 M1 & M2, B250 M1 & M2, B440 M1 & M2	UCS M61KR-I 10-Gigabit Ethernet Adapter	Windows Server 2008 R2 SP1	2.7.28.0 (ETH), 8.6.30.0 (NIC Teaming Driver)	2.1.60.1.1	
B200 M1 w/E5-Series, B230 M1 & M2, B250 M1 & M2, B440 M1 & M2	UCS 82598KR-CI 10-Gigabit Ethernet Adapter	Windows Server 2008 R2 SP1	2.4.29.1 (ETH), 8.6.30.0 (NIC Teaming Driver)	2.1.11 (pxe)	

RAID Controller on Motherboard Interoperability Matrix

Table 7 lists the RAID controllers on motherboard that the Unified Computing System B Series Servers support.

Table 7: RAID Controller on Motherboard

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B200 M2 w/E5-Series	LSI Logic SAS1064E PCI-Express Fusion-MPT	UEK R2 U5 (2.6.39-400.x)	4.28.20.02	1.32.09.00	43
B200 M2 w/E5-Series	LSI Logic SAS1064E PCI-Express Fusion-MPT	UEK R3 U1 (3.8.13-26.x)	4.28.20.02	1.32.09.00	43

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B200 M2 w/E5-Series	LSI Logic SAS1064E PCI-Express Fusion-MPT	UEK R3 U3 (3.8.13-44.x)	4.28.20.02	1.32.09.00	43
B200 M2 w/E5-Series	LSI Logic SAS1064E PCI-Express Fusion-MPT	UEK R3 U5 (3.8.13-68.x)	4.28.20.02	1.32.09.00	43
B200 M2 w/E5-Series	LSI Logic SAS1064E PCI-Express Fusion-MPT	UEK R3 U6 (3.8.13-98.x)	4.28.20.02	1.32.09.00	43
B200 M2 w/E5-Series	LSI Logic SAS1064E PCI-Express Fusion-MPT	UEK R4 (4.1.12-32.x)	4.28.20.02	1.32.09.00	43
B200 M2 w/E5-Series	LSI Logic SAS1064E PCI-Express Fusion-MPT	UEK R4 U1 (4.1.12-37.x)	4.28.20.02	1.32.09.00	43
B200 M2 w/E5-Series	LSI Logic SAS1064E PCI-Express Fusion-MPT	UEK R4 U2 (4.1.12-61.x)	4.28.20.02	1.32.09.00	43
B200 M2 w/E5-Series	LSI Logic SAS1064E PCI-Express Fusion-MPT	OVM 3.3.1	4.28.20.02	1.32.09.00	43
B200 M2 w/E5-Series	LSI Logic SAS1064E PCI-Express Fusion-MPT	OVM 3.3.2	4.28.20.02	1.32.09.00	43
B200 M2 w/E5-Series	LSI Logic SAS1064E PCI-Express Fusion-MPT	OVM 3.3.3	4.28.20.03	1.32.09.00	43

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B200 M2 w/E5-Series	LSI Logic SAS1064E PCI-Express Fusion-MPT	OVM 3.3.4	4.28.20.03	1.32.09.00	43
B200 M2 w/E5-Series	LSI Logic SAS1064E PCI-Express Fusion-MPT	OVM 3.4.1	4.28.20.03	1.32.09.00	43
B200 M2 w/E5-Series	LSI Logic SAS1064E PCI-Express Fusion-MPT	OVM 3.4.2	4.28.20.03	1.32.09.00	43
B200 M2 w/E5-Series, B250 M2	LSI Logic SAS1064E PCI-Express Fusion-MPT	Red Hat Enterprise Linux 5.9	3.04.20rh1	1.32.09.00	43
B200 M2 w/E5-Series, B250 M2	LSI Logic SAS1064E PCI-Express Fusion-MPT	Red Hat Enterprise Linux 5.10	3.04.20rh1	1.32.09.00	43
B200 M2 w/E5-Series, B250 M2	LSI Logic SAS1064E PCI-Express Fusion-MPT	Red Hat Enterprise Linux 5.11	3.04.20rh1	1.32.09.00	43
B200 M2 w/E5-Series, B250 M2	LSI Logic SAS1064E PCI-Express Fusion-MPT	Red Hat Enterprise Linux 6.4	3.04.20rh1	1.32.09.00	43
B200 M2 w/E5-Series, B250 M2	LSI Logic SAS1064E PCI-Express Fusion-MPT	Red Hat Enterprise Linux 6.5	3.04.20rh1	1.32.09.00	43
B200 M2 w/E5-Series, B250 M2	LSI Logic SAS1064E PCI-Express Fusion-MPT	Red Hat Enterprise Linux 6.6	3.04.20rh1	1.32.09.00	43

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B200 M2 w/E5-Series, B250 M2	LSI Logic SAS1064E PCI-Express Fusion-MPT	Red Hat Enterprise Linux 6.7	3.04.20rh1	1.32.09.00	43
B200 M2 w/E5-Series, B250 M2	LSI Logic SAS1064E PCI-Express Fusion-MPT	Red Hat Enterprise Linux 6.8	3.04.20rh1	1.32.09.00	43
B200 M2 w/E5-Series	LSI Logic SAS1064E PCI-Express Fusion-MPT	Red Hat Enterprise Linux 7.0	3.04.20rh1	1.32.09.00	43
B200 M2 w/E5-Series	LSI Logic SAS1064E PCI-Express Fusion-MPT	Red Hat Enterprise Linux 7.1	3.04.20rh1	1.32.09.00	43
B200 M2 w/E5-Series	LSI Logic SAS1064E PCI-Express Fusion-MPT	Red Hat Enterprise Linux 7.2	3.04.20rh1	1.32.09.00	43
B200 M2 w/E5-Series	LSI Logic SAS1064E PCI-Express Fusion-MPT	Red Hat Enterprise Linux 7.3	3.04.20rh1	1.32.09.00	43
B200 M2 w/E5-Series, B250 M2	LSI Logic SAS1064E PCI-Express Fusion-MPT	SUSE Linux Enterprise Server 11.2	4.28.00.00	1.32.09.00	43
B200 M2 w/E5-Series, B250 M2	LSI Logic SAS1064E PCI-Express Fusion-MPT	SUSE Linux Enterprise Server 11.3	4.28.00.01	1.32.09.00	43
B200 M2 w/E5-Series, B250 M2	LSI Logic SAS1064E PCI-Express Fusion-MPT	SUSE Linux Enterprise Server 11.4	4.28.00.01	1.32.09.00	43

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B200 M2 w/E5-Series	LSI Logic SAS1064E PCI-Express Fusion-MPT	SUSE Linux Enterprise Server 12	3.04.20	1.32.09.00	43
B200 M2 w/E5-Series	LSI Logic SAS1064E PCI-Express Fusion-MPT	SUSE Linux Enterprise Server 12.1	3.04.20	1.32.09.00	43
B200 M2 w/E5-Series	LSI Logic SAS1064E PCI-Express Fusion-MPT	SUSE Linux Enterprise Server 12.2	3.04.20	1.32.09.00	43
B200 M1 w/E5-Series, B250 M1 & M2	LSI Logic SAS1064E PCI-Express Fusion-MPT	vSphere 5.0 U2	4.23.01.00-5	1.32.09.00	
B200 M1 w/E5-Series, B250 M1 & M2	LSI Logic SAS1064E PCI-Express Fusion-MPT	vSphere 5.0 U3	4.23.01.00-5	1.32.09.00	
B200 M2 w/E5-Series, B250 M2	LSI Logic SAS1064E PCI-Express Fusion-MPT	vSphere 5.1 U1	4.23.01.00-5	1.32.09.00	
B200 M2 w/E5-Series, B250 M2	LSI Logic SAS1064E PCI-Express Fusion-MPT	vSphere 5.1 U2	4.23.01.00-6vmw	1.32.09.00	43
B200 M2 w/E5-Series, B250 M2	LSI Logic SAS1064E PCI-Express Fusion-MPT	vSphere 5.1 U3	4.23.01.00-6vmw	1.32.09.00	43
B200 M2 w/E5-Series	LSI Logic SAS1064E PCI-Express Fusion-MPT	vSphere 5.5	4.23.01.00-9vmw	1.32.09.00	43

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B200 M2 w/E5-Series	LSI Logic SAS1064E PCI-Express Fusion-MPT	vSphere 5.5 U1	4.23.01.00-9vmw	1.32.09.00	43
B200 M2 w/E5-Series	LSI Logic SAS1064E PCI-Express Fusion-MPT	vSphere 5.5 U2	4.23.01.00-9vmw	1.32.09.00	43
B200 M2 w/E5-Series	LSI Logic SAS1064E PCI-Express Fusion-MPT	vSphere 5.5 U3	4.23.01.00-9vmw	1.32.09.00	43
B200 M2 w/E5-Series	LSI Logic SAS1064E PCI-Express Fusion-MPT	vSphere 6.0	4.23.01.00-9vmw	1.32.09.00	43
B200 M2 w/E5-Series	LSI Logic SAS1064E PCI-Express Fusion-MPT	vSphere 6.0 U1	4.23.01.00-9vmw	1.32.09.00	43
B200 M2 w/E5-Series	LSI Logic SAS1064E PCI-Express Fusion-MPT	vSphere 6.0 U2	4.23.01.00-9vmw	1.32.09.00	43
B200 M2 w/E5-Series	LSI Logic SAS1064E PCI-Express Fusion-MPT	vSphere 6.5	4.23.01.00-10vmw	1.32.09.00	43
B200 M1 w/E5-Series, B250 M1 & M2	LSI Logic SAS1064E PCI-Express Fusion-MPT	Windows Server 2008 R2 SP1	1.34.02.00	1.32.09.00	
B200 M2 w/E5-Series, B250 M2	LSI Logic SAS1064E PCI-Express Fusion-MPT	Windows Server 2012	1.34.2.6	1.32.09.00	

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B200 M2 w/E5-Series	LSI Logic SAS1064E PCI-Express Fusion-MPT	Windows Server 2012 R2	1.34.3.82	1.32.09.00	
B200 M2 w/E5-Series	LSI Logic SAS1064E PCI-Express Fusion-MPT	Windows Server 2016	1.34.3.83	1.32.09.00	43
B200 M2 w/E5-Series, B250 M2	LSI Logic SAS1064E PCI-Express Fusion-MPT	XenServer 6.1	4.28.00.00	1.32.09.00	43
B200 M2 w/E5-Series	LSI Logic SAS1064E PCI-Express Fusion-MPT	XenServer 6.2	4.28.00.00	1.32.09.00	43
B200 M2 w/E5-Series	LSI Logic SAS1064E PCI-Express Fusion-MPT	XenServer 6.5	3.04.20	1.32.09.00	43
B200 M2 w/E5-Series	LSI Logic SAS1064E PCI-Express Fusion-MPT	XenServer 7.0	3.04.20	1.32.09.00	43
B230 M2	LSI Logic MegaSAS 2008 (9240)	UEK R2 U5 (2.6.39-400.x)	6.600.18.00	20.12.1-0250	43
B230 M2	LSI Logic MegaSAS 2008 (9240)	UEK R3 U1 (3.8.13-26.x)	6.700.06.00-rc1	20.12.1-0250	43
B230 M2	LSI Logic MegaSAS 2008 (9240)	UEK R3 U3 (3.8.13-44.x)	6.803.02.00-rc1	20.12.1-0250	43
B230 M2	LSI Logic MegaSAS 2008 (9240)	UEK R3 U5 (3.8.13-68.x)	6.803.02.00-rc1	20.12.1-0250	43

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B230 M2	LSI Logic MegaSAS 2008 (9240)	UEK R3 U6 (3.8.13-98.x)	6.803.02.00-rc1	20.12.1-0250	43
B230 M2	LSI Logic MegaSAS 2008 (9240)	UEK R4 (4.1.12- 32.x)	6.803.02.00-rc1	20.12.1-0250	43
B230 M2	LSI Logic MegaSAS 2008 (9240)	UEK R4 U1 (4.1.12-37.x)	6.810.09.00-rc1	20.12.1-0250	43
B230 M2	LSI Logic MegaSAS 2008 (9240)	UEK R4 U2 (4.1.12-61.x)	6.810.09.00-rc1	20.12.1-0250	43
B230 M2	LSI Logic MegaSAS 2008 (9240)	OVM 3.3.1	6.700.06.00-rc1	20.12.1-0250	43
B230 M2	LSI Logic MegaSAS 2008 (9240)	OVM 3.3.2	6.803.02.00-rc1	20.12.1-0250	43
B230 M2	LSI Logic MegaSAS 2008 (9240)	OVM 3.3.3	6.803.02.00-rc1	20.12.1-0250	43
B230 M2	LSI Logic MegaSAS 2008 (9240)	OVM 3.3.4	6.803.02.00-rc1	20.12.1-0250	43
B230 M2	LSI Logic MegaSAS 2008 (9240)	OVM 3.4.1	6.807.10.00-rc1	20.12.1-0250	43
B230 M2	LSI Logic MegaSAS 2008 (9240)	OVM 3.4.2	6.810.09.00-rc1	20.12.1-0250	43
B230 M1 & M2	LSI Logic MegaSAS 2008 (9240)	Red Hat Enterprise Linux 5.9	00.00.06.15-rh	20.12.1-0250	43
B230 M1 & M2	LSI Logic MegaSAS 2008 (9240)	Red Hat Enterprise Linux 5.10	00.00.06.15-rh	20.12.1-0250	43

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B230 M1 & M2	LSI Logic MegaSAS 2008 (9240)	Red Hat Enterprise Linux 5.11	00.00.06.15-rh1	20.12.1-0250	43
B230 M1 & M2	LSI Logic MegaSAS 2008 (9240)	Red Hat Enterprise Linux 6.4	6.504.01.00-rh1	20.12.1-0250	43
B230 M1 & M2	LSI Logic MegaSAS 2008 (9240)	Red Hat Enterprise Linux 6.5	6.700.06.00-rh1	20.12.1-0250	43
B230 M1 & M2	LSI Logic MegaSAS 2008 (9240)	Red Hat Enterprise Linux 6.6	6.700.06.00-rh1	20.12.1-0250	43
B230 M1 & M2	LSI Logic MegaSAS 2008 (9240)	Red Hat Enterprise Linux 6.7	6.806.08.00-rh3	20.12.1-0250	43
B230 M1 & M2	LSI Logic MegaSAS 2008 (9240)	Red Hat Enterprise Linux 6.8	6.810.09.00-rh1	20.12.1-0250	43
B230 M2	LSI Logic MegaSAS 2008 (9240)	Red Hat Enterprise Linux 7.0	6.700.06.00-rh1	20.12.1-0250	43
B230 M2	LSI Logic MegaSAS 2008 (9240)	Red Hat Enterprise Linux 7.1	6.806.09.00	20.12.1-0250	43
B230 M2	LSI Logic MegaSAS 2008 (9240)	Red Hat Enterprise Linux 7.2	6.807.10.00-rh1	20.12.1-0250	43
B230 M2	LSI Logic MegaSAS 2008 (9240)	Red Hat Enterprise Linux 7.3	6.811.02.00-rh1	20.12.1-0250	43
B230 M2	LSI Logic MegaSAS 2008 (9240)	SUSE Linux Enterprise Server 11.2	6.506.00.00	20.12.1-0250	43
B230 M2	LSI Logic MegaSAS 2008 (9240)	SUSE Linux Enterprise Server 11.3	6.506.00.00-rc1	20.12.1-0250	43

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B230 M2	LSI Logic MegaSAS 2008 (9240)	SUSE Linux Enterprise Server 11.4	6.506.00.00-rc1	20.12.1-0250	43
B230 M2	LSI Logic MegaSAS 2008 (9240)	SUSE Linux Enterprise Server 12	6.803.01.00-rc1	20.12.1-0250	43
B230 M2	LSI Logic MegaSAS 2008 (9240)	SUSE Linux Enterprise Server 12.1	6.807.10.00-rc1	20.12.1-0250	43
B230 M2	LSI Logic MegaSAS 2008 (9240)	SUSE Linux Enterprise Server 12.2	6.810.09.00-rc1	20.12.1-0250	43
B230 M1 & M2	LSI Logic MegaSAS 2008 (9240)	vSphere 5.0 U2	6.608.16.00-1(scsi- megaraid-sas)	20.12.1-0250	11
B230 M1 & M2	LSI Logic MegaSAS 2008 (9240)	vSphere 5.0 U3	6.608.16.00-1(scsi- megaraid-sas)	20.12.1-0250	11
B230 M2	LSI Logic MegaSAS 2008 (9240)	vSphere 5.1 U1	6.608.16.00-1(scsi- megaraid-sas)	20.12.1-0250	11
B230 M2	LSI Logic MegaSAS 2008 (9240)	vSphere 5.1 U2	6.608.16.00-1(scsi- megaraid-sas)	20.12.1-0250	11
B230 M2	LSI Logic MegaSAS 2008 (9240)	vSphere 5.1 U3	6.608.16.00-1(scsi- megaraid-sas)	20.12.1-0250	11
B230 M2	LSI Logic MegaSAS 2008 (9240)	vSphere 5.5	6.608.16.00-1(scsi- megaraid-sas)	20.12.1-0250	11
B230 M2	LSI Logic MegaSAS 2008 (9240)	vSphere 5.5 U1	6.608.16.00-1(scsi- megaraid-sas)	20.12.1-0250	11
B230 M2	LSI Logic MegaSAS 2008 (9240)	vSphere 5.5 U2	6.608.16.00-1(scsi- megaraid-sas)	20.12.1-0250	11

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B230 M2	LSI Logic MegaSAS 2008 (9240)	vSphere 5.5 U3	6.608.16.00-1(scsi-megaraid-sas)	20.12.1-0250	11
B230 M2	LSI Logic MegaSAS 2008 (9240)	vSphere 6.0	6.608.16.00-1(scsi-megaraid-sas)	20.12.1-0250	
B230 M2	LSI Logic MegaSAS 2008 (9240)	vSphere 6.0 U1	6.608.16.00-1(scsi-megaraid-sas)	20.12.1-0250	
B230 M2	LSI Logic MegaSAS 2008 (9240)	vSphere 6.0 U2	6.608.16.00-1(scsi-megaraid-sas)	20.12.1-0250	
B230 M2	LSI Logic MegaSAS 2008 (9240)	vSphere 6.5	6.610.15.00-1(scsi-megaraid-sas)	20.12.1-0250	
B230 M1 & M2	LSI Logic MegaSAS 2008 (9240)	Windows Server 2008 R2 SP1	6.506.01.00	20.12.1-0250	
B230 M2	LSI Logic MegaSAS 2008 (9240)	Windows Server 2012	6.506.02.00	20.12.1-0250	
B230 M2	LSI Logic MegaSAS 2008 (9240)	Windows Server 2012 R2	6.600.21.8	20.12.1-0250	
B230 M2	LSI Logic MegaSAS 2008 (9240)	Windows Server 2016	6.706.6.00	20.12.1-0250	43
B230 M2	LSI Logic MegaSAS 2008 (9240)	XenServer 6.1	6.15	20.12.1-0250	43
B230 M2	LSI Logic MegaSAS 2008 (9240)	XenServer 6.2	6.506	20.12.1-0250	43
B230 M2	LSI Logic MegaSAS 2008 (9240)	XenServer 6.5	6.803.02.00-rc1	20.12.1-0250	43

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B230 M2	LSI Logic MegaSAS 2008 (9240)	XenServer 7.0	6.810.09.00-rc1	20.12.1-0250	43
B440 M2	LSI Logic MegaSAS 2108 (9260)	UEK R2 U5 (2.6.39-400.x)	6.600.18.00	12.14.0-0247	43
B440 M2	LSI Logic MegaSAS 2108 (9260)	UEK R3 U1 (3.8.13-26.x)	6.700.06.00-rc1	12.14.0-0247	43
B440 M2	LSI Logic MegaSAS 2108 (9260)	UEK R3 U3 (3.8.13-44.x)	6.803.02.00-rc1	12.14.0-0247	43
B440 M2	LSI Logic MegaSAS 2108 (9260)	UEK R3 U5 (3.8.13-68.x)	6.803.02.00-rc1	12.14.0-0247	43
B440 M2	LSI Logic MegaSAS 2108 (9260)	UEK R3 U6 (3.8.13-98.x)	6.803.02.00-rc1	12.14.0-0247	43
B440 M2	LSI Logic MegaSAS 2108 (9260)	UEK R4 (4.1.12- 32.x)	6.803.02.00-rc1	12.14.0-0247	43
B440 M2	LSI Logic MegaSAS 2108 (9260)	UEK R4 U1 (4.1.12-37.x)	6.810.09.00-rc1	12.14.0-0247	43
B440 M2	LSI Logic MegaSAS 2108 (9260)	UEK R4 U2 (4.1.12-61.x)	6.810.09.00-rc1	12.14.0-0247	43
B440 M2	LSI Logic MegaSAS 2108 (9260)	OVM 3.3.1	6.700.06.00-rc1	12.14.0-0247	43
B440 M2	LSI Logic MegaSAS 2108 (9260)	OVM 3.3.2	6.803.02.00-rc1	12.14.0-0247	43
B440 M2	LSI Logic MegaSAS 2108 (9260)	OVM 3.3.3	6.803.02.00-rc1	12.14.0-0247	43

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B440 M2	LSI Logic MegaSAS 2108 (9260)	OVM 3.3.4	6.803.02.00-rc1	12.14.0-0247	43
B440 M2	LSI Logic MegaSAS 2108 (9260)	OVM 3.4.1	6.807.10.00-rc1	12.14.0-0247	43
B440 M2	LSI Logic MegaSAS 2108 (9260)	OVM 3.4.2	6.810.09.00-rc1	12.14.0-0247	43
B440 M1 & M2	LSI Logic MegaSAS 2108 (9260)	Red Hat Enterprise Linux 5.9	00.00.06.15-rh	12.14.0-0247	43
B440 M1 & M2	LSI Logic MegaSAS 2108 (9260)	Red Hat Enterprise Linux 5.10	00.00.06.15-rh	12.14.0-0247	43
B440 M1 & M2	LSI Logic MegaSAS 2108 (9260)	Red Hat Enterprise Linux 5.11	00.00.06.15-rh1	12.14.0-0247	43
B440 M1 & M2	LSI Logic MegaSAS 2108 (9260)	Red Hat Enterprise Linux 6.4	6.504.01.00-rh1	12.14.0-0247	43
B440 M1 & M2	LSI Logic MegaSAS 2108 (9260)	Red Hat Enterprise Linux 6.5	6.700.06.00-rh1	12.14.0-0247	43
B440 M1 & M2	LSI Logic MegaSAS 2108 (9260)	Red Hat Enterprise Linux 6.6	6.700.06.00-rh1	12.14.0-0247	43
B440 M1 & M2	LSI Logic MegaSAS 2108 (9260)	Red Hat Enterprise Linux 6.7	6.806.08.00-rh3	12.14.0-0247	43
B440 M1 & M2	LSI Logic MegaSAS 2108 (9260)	Red Hat Enterprise Linux 6.8	6.810.09.00-rh1	12.14.0-0247	43
B440 M2	LSI Logic MegaSAS 2108 (9260)	Red Hat Enterprise Linux 7.0	6.700.06.00-rh1	12.14.0-0247	43

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B440 M2	LSI Logic MegaSAS 2108 (9260)	Red Hat Enterprise Linux 7.1	6.806.09.00	12.14.0-0247	43
B440 M2	LSI Logic MegaSAS 2108 (9260)	Red Hat Enterprise Linux 7.2	6.807.10.00-rh1	12.14.0-0247	43
B440 M2	LSI Logic MegaSAS 2108 (9260)	Red Hat Enterprise Linux 7.3	6.811.02.00-rh1	12.14.0-0247	43
B440 M2	LSI Logic MegaSAS 2108 (9260)	SUSE Linux Enterprise Server 11.2	6.506.00.00	12.14.0-0247	43
B440 M2	LSI Logic MegaSAS 2108 (9260)	SUSE Linux Enterprise Server 11.3	6.506.00.00-rc1	12.14.0-0247	43
B440 M2	LSI Logic MegaSAS 2108 (9260)	SUSE Linux Enterprise Server 11.4	6.506.00.00-rc1	12.14.0-0247	43
B440 M2	LSI Logic MegaSAS 2108 (9260)	SUSE Linux Enterprise Server 12	6.803.01.00-rc1	12.14.0-0247	43
B440 M2	LSI Logic MegaSAS 2108 (9260)	SUSE Linux Enterprise Server 12.1	6.807.10.00-rc1	12.14.0-0247	43
B440 M2	LSI Logic MegaSAS 2108 (9260)	SUSE Linux Enterprise Server 12.2	6.810.09.00-rc1	12.14.0-0247	43
B440 M1 & M2	LSI Logic MegaSAS 2108 (9260)	vSphere 5.0 U2	6.608.16.00-1(scsi- megaraid-sas)	12.14.0-0247	11
B440 M1 & M2	LSI Logic MegaSAS 2108 (9260)	vSphere 5.0 U3	6.608.16.00-1(scsi- megaraid-sas)	12.14.0-0247	11
B440 M2	LSI Logic MegaSAS 2108 (9260)	vSphere 5.1 U1	6.608.16.00-1(scsi- megaraid-sas)	12.14.0-0247	11

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B440 M2	LSI Logic MegaSAS 2108 (9260)	vSphere 5.1 U2	6.608.16.00-1(scsi-megaraid-sas)	12.14.0-0247	11
B440 M2	LSI Logic MegaSAS 2108 (9260)	vSphere 5.1 U3	6.608.16.00-1(scsi-megaraid-sas)	12.14.0-0247	11
B440 M2	LSI Logic MegaSAS 2108 (9260)	vSphere 5.5	6.608.16.00-1(scsi-megaraid-sas)	12.14.0-0247	11
B440 M2	LSI Logic MegaSAS 2108 (9260)	vSphere 5.5 U1	6.608.16.00-1(scsi-megaraid-sas)	12.14.0-0247	11
B440 M2	LSI Logic MegaSAS 2108 (9260)	vSphere 5.5 U2	6.608.16.00-1(scsi-megaraid-sas)	12.14.0-0247	11
B440 M2	LSI Logic MegaSAS 2108 (9260)	vSphere 5.5 U3	6.608.16.00-1(scsi-megaraid-sas)	12.14.0-0247	11
B440 M2	LSI Logic MegaSAS 2108 (9260)	vSphere 6.0	6.608.16.00-1(scsi-megaraid-sas)	12.14.0-0247	
B440 M2	LSI Logic MegaSAS 2108 (9260)	vSphere 6.0 U1	6.608.16.00-1(scsi-megaraid-sas)	12.14.0-0247	
B440 M2	LSI Logic MegaSAS 2108 (9260)	vSphere 6.0 U2	6.608.16.00-1(scsi-megaraid-sas)	12.14.0-0247	
B440 M2	LSI Logic MegaSAS 2108 (9260)	vSphere 6.5	6.610.15.00-1(scsi-megaraid-sas)	12.14.0-0247	
B440 M1 & M2	LSI Logic MegaSAS 2108 (9260)	Windows Server 2008 R2 SP1	6.506.01.00	12.14.0-0247	
B440 M2	LSI Logic MegaSAS 2108 (9260)	Windows Server 2012	6.506.02.00	12.14.0-0247	

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B440 M2	LSI Logic MegaSAS 2108 (9260)	Windows Server 2012 R2	6.600.21.8	12.14.0-0247	
B440 M2	LSI Logic MegaSAS 2108 (9260)	Windows Server 2016	6.706.6.00	12.14.0-0247	43
B440 M2	LSI Logic MegaSAS 2108 (9260)	XenServer 6.1	6.15	12.14.0-0247	43
B440 M2	LSI Logic MegaSAS 2108 (9260)	XenServer 6.2	6.506	12.14.0-0247	43
B440 M2	LSI Logic MegaSAS 2108 (9260)	XenServer 6.5	6.803.02.00-rc1	12.14.0-0247	43
B440 M2	LSI Logic MegaSAS 2108 (9260)	XenServer 7.0	6.810.09.00-rc1	12.14.0-0247	43
B200 M3 w/E5- Series	LSI Logic MegaRAID SAS 2004	CentOS 6.5	6.700.06.00-rh1	20.12.1-0250	39, 40, 43
B200 M3 w/E5- Series v2	LSI Logic MegaRAID SAS 2004	CentOS 6.5	6.700.06.00-rh1	20.12.1-0250	39, 40, 43
B200 M3 w/E5- Series v2	LSI Logic MegaRAID SAS 2004	CentOS 6.6	6.803.01.00-rh1	20.12.1-0250	39, 40, 43
B200 M3 w/E5- Series v2	LSI Logic MegaRAID SAS 2004	CentOS 6.7	6.806.08.00-rh3	20.12.1-0250	39, 40, 43
B200 M3 w/E5- Series v2	LSI Logic MegaRAID SAS 2004	CentOS 6.8	6.810.10.00-1	20.12.1-0250	39, 40, 43
B200 M3 w/E5- Series v2	LSI Logic MegaRAID SAS 2004	CentOS 7.1	6.805.06.01-rc1	20.12.1-0250	39, 40, 43

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B200 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2004	CentOS 7.2	6.807.10.00-rh1	20.12.1-0250	39, 40, 43
B200 M3 w/E5-Series	LSI Logic MegaRAID SAS 2004	UEK R2 U5 (2.6.39-400.x)	6.602.03.00	20.12.1-0250	43
B200 M3 w/E5-Series	LSI Logic MegaRAID SAS 2004	UEK R3 U1 (3.8.13-26.x)	6.700.06.00-rc1	20.12.1-0250	43
B200 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2004	UEK R3 U1 (3.8.13-26.x)	6.700.06.00-rc1	20.12.1-0250	43
B200 M3 w/E5-Series	LSI Logic MegaRAID SAS 2004	UEK R3 U3 (3.8.13-44.x)	6.803.02.00-rc1	20.12.1-0250	43
B200 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2004	UEK R3 U3 (3.8.13-44.x)	6.803.02.00-rc1	20.12.1-0250	43
B200 M3 w/E5-Series	LSI Logic MegaRAID SAS 2004	UEK R3 U5 (3.8.13-68.x)	6.803.02.00-rc1	20.12.1-0250	43
B200 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2004	UEK R3 U5 (3.8.13-68.x)	6.803.02.00-rc1	20.12.1-0250	43
B200 M3 w/E5-Series	LSI Logic MegaRAID SAS 2004	UEK R3 U6 (3.8.13-98.x)	6.803.02.00-rc1	20.12.1-0250	43
B200 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2004	UEK R3 U6 (3.8.13-98.x)	6.803.02.00-rc1	20.12.1-0250	43
B200 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2004	UEK R3 U7 (3.8.13-118)	6.803.02.00-rc1	20.12.1-0250	43
B200 M3 w/E5-Series	LSI Logic MegaRAID SAS 2004	UEK R4 (4.1.12-32.x)	6.803.02.00-rc1	20.12.1-0250	43

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B200 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2004	UEK R4 (4.1.12-32.x)	6.803.02.00-rc1	20.12.1-0250	43
B200 M3 w/E5-Series	LSI Logic MegaRAID SAS 2004	UEK R4 U1 (4.1.12-37.x)	6.810.09.00-rc1	20.12.1-0250	43
B200 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2004	UEK R4 U1 (4.1.12-37.x)	6.810.09.00-rc1	20.12.1-0250	43
B200 M3 w/E5-Series	LSI Logic MegaRAID SAS 2004	UEK R4 U2 (4.1.12-61.x)	6.810.09.00-rc1	20.12.1-0250	43
B200 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2004	UEK R4 U2 (4.1.12-61.x)	6.810.09.00-rc1	20.12.1-0250	43
B200 M3 w/E5-Series	LSI Logic MegaRAID SAS 2004	OVM 3.3.1	6.700.06.00-rc1	20.12.1-0250	43
B200 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2004	OVM 3.3.1	6.700.06.00-rc1	20.12.1-0250	43
B200 M3 w/E5-Series	LSI Logic MegaRAID SAS 2004	OVM 3.3.2	6.803.02.00-rc1	20.12.1-0250	43
B200 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2004	OVM 3.3.2	6.803.02.00-rc1	20.12.1-0250	43
B200 M3 w/E5-Series	LSI Logic MegaRAID SAS 2004	OVM 3.3.3	6.803.02.00-rc1	20.12.1-0250	43
B200 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2004	OVM 3.3.3	6.803.02.00-rc1	20.12.1-0250	43
B200 M3 w/E5-Series	LSI Logic MegaRAID SAS 2004	OVM 3.3.4	6.803.02.00-rc1	20.12.1-0250	43

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B200 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2004	OVM 3.3.4	6.803.02.00-rc1	20.12.1-0250	43
B200 M3 w/E5-Series	LSI Logic MegaRAID SAS 2004	OVM 3.4.1	6.807.10.00-rc1	20.12.1-0250	43
B200 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2004	OVM 3.4.1	6.807.10.00-rc1	20.12.1-0250	43
B200 M3 w/E5-Series	LSI Logic MegaRAID SAS 2004	OVM 3.4.2	6.810.09.00-rc1	20.12.1-0250	43
B200 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2004	OVM 3.4.2	6.810.09.00-rc1	20.12.1-0250	43
B200 M3 w/E5-Series	LSI Logic MegaRAID SAS 2004	Red Hat Enterprise Linux 5.9	6.602.03.00	20.12.1-0250	43
B200 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2004	Red Hat Enterprise Linux 5.9	6.602.03.00	20.12.1-0250	43
B200 M3 w/E5-Series	LSI Logic MegaRAID SAS 2004	Red Hat Enterprise Linux 5.10	00.00.06.15-rh	20.12.1-0250	43
B200 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2004	Red Hat Enterprise Linux 5.10	00.00.06.15-rh	20.12.1-0250	43
B200 M3 w/E5-Series	LSI Logic MegaRAID SAS 2004	Red Hat Enterprise Linux 5.11	00.00.06.15-rh1	20.12.1-0250	43
B200 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2004	Red Hat Enterprise Linux 5.11	00.00.06.15-rh1	20.12.1-0250	43
B200 M3 w/E5-Series	LSI Logic MegaRAID SAS 2004	Red Hat Enterprise Linux 6.4	6.602.03.00	20.12.1-0250	43

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B200 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2004	Red Hat Enterprise Linux 6.4	6.602.03.00	20.12.1-0250	43
B200 M3 w/E5-Series	LSI Logic MegaRAID SAS 2004	Red Hat Enterprise Linux 6.5	6.700.06.00-rh1	20.12.1-0250	43
B200 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2004	Red Hat Enterprise Linux 6.5	6.700.06.00-rh1	20.12.1-0250	43
B200 M3 w/E5-Series	LSI Logic MegaRAID SAS 2004	Red Hat Enterprise Linux 6.6	6.700.06.00-rh1	20.12.1-0250	43
B200 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2004	Red Hat Enterprise Linux 6.6	6.700.06.00-rh1	20.12.1-0250	43
B200 M3 w/E5-Series	LSI Logic MegaRAID SAS 2004	Red Hat Enterprise Linux 6.7	6.806.08.00-rh3	20.12.1-0250	43
B200 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2004	Red Hat Enterprise Linux 6.7	6.806.08.00-rh3	20.12.1-0250	43
B200 M3 w/E5-Series	LSI Logic MegaRAID SAS 2004	Red Hat Enterprise Linux 6.8	6.810.09.00-rh1	20.12.1-0250	43
B200 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2004	Red Hat Enterprise Linux 6.8	6.810.09.00-rh1	20.12.1-0250	43
B200 M3 w/E5-Series	LSI Logic MegaRAID SAS 2004	Red Hat Enterprise Linux 7.0	6.700.06.00-rh1	20.12.1-0250	43
B200 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2004	Red Hat Enterprise Linux 7.0	6.700.06.00-rh1	20.12.1-0250	43
B200 M3 w/E5-Series	LSI Logic MegaRAID SAS 2004	Red Hat Enterprise Linux 7.1	6.806.09.00	20.12.1-0250	43

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B200 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2004	Red Hat Enterprise Linux 7.1	6.806.09.00	20.12.1-0250	43
B200 M3 w/E5-Series	LSI Logic MegaRAID SAS 2004	Red Hat Enterprise Linux 7.2	6.807.10.00-rh1	20.12.1-0250	43
B200 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2004	Red Hat Enterprise Linux 7.2	6.807.10.00-rh1	20.12.1-0250	43
B200 M3 w/E5-Series	LSI Logic MegaRAID SAS 2004	Red Hat Enterprise Linux 7.3	6.811.02.00-rh1	20.12.1-0250	43
B200 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2004	Red Hat Enterprise Linux 7.3	6.811.02.00-rh1	20.12.1-0250	43
B200 M3 w/E5-Series	LSI Logic MegaRAID SAS 2004	Solaris 11 10/12 (U1)	6.602.01.00	20.12.1-0250	
B200 M3 w/E5-Series	LSI Logic MegaRAID SAS 2004	SUSE Linux Enterprise Server 11.2	6.602.03.00	20.12.1-0250	43
B200 M3 w/E5-Series	LSI Logic MegaRAID SAS 2004	SUSE Linux Enterprise Server 11.3	6.602.03.00	20.12.1-0250	43
B200 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2004	SUSE Linux Enterprise Server 11.3	6.602.03.00	20.12.1-0250	43
B200 M3 w/E5-Series	LSI Logic MegaRAID SAS 2004	SUSE Linux Enterprise Server 11.4	6.806.08.00-rc1	20.12.1-0250	43
B200 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2004	SUSE Linux Enterprise Server 11.4	6.806.08.00-rc1	20.12.1-0250	43
B200 M3 w/E5-Series	LSI Logic MegaRAID SAS 2004	SUSE Linux Enterprise Server 12	6.803.01.00-rc1	20.12.1-0250	43

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B200 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2004	SUSE Linux Enterprise Server 12	6.803.01.00-rc1	20.12.1-0250	43
B200 M3 w/E5-Series	LSI Logic MegaRAID SAS 2004	SUSE Linux Enterprise Server 12.1	6.807.10.00-rc1	20.12.1-0250	43
B200 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2004	SUSE Linux Enterprise Server 12.1	6.807.10.00-rc1	20.12.1-0250	43
B200 M3 w/E5-Series	LSI Logic MegaRAID SAS 2004	SUSE Linux Enterprise Server 12.2	6.810.09.00-rc1	20.12.1-0250	43
B200 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2004	SUSE Linux Enterprise Server 12.2	6.810.09.00-rc1	20.12.1-0250	43
B200 M3 w/E5-Series	LSI Logic MegaRAID SAS 2004	Ubuntu 12.04.4	6.600.18	20.12.1-0250	43
B200 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2004	Ubuntu 12.04.4	6.600.18	20.12.1-0250	43
B200 M3 w/E5-Series	LSI Logic MegaRAID SAS 2004	Ubuntu 14.04	6.700.06.00	20.12.1-0250	43
B200 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2004	Ubuntu 14.04	6.700.06.00	20.12.1-0250	43
B200 M3 w/E5-Series	LSI Logic MegaRAID SAS 2004	Ubuntu 14.04.1	6.700.06.00	20.12.1-0250	43
B200 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2004	Ubuntu 14.04.1	6.700.06.00	20.12.1-0250	43
B200 M3 w/E5-Series	LSI Logic MegaRAID SAS 2004	Ubuntu 14.04.2	6.803.01.01	20.12.1-0250	43

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B200 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2004	Ubuntu 14.04.2	6.803.01.01	20.12.1-0250	43
B200 M3 w/E5-Series	LSI Logic MegaRAID SAS 2004	Ubuntu 14.04.3	6.805.06.01-rc1	20.12.1-0250	43
B200 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2004	Ubuntu 14.04.3	6.805.06.01-rc1	20.12.1-0250	43
B200 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2004	Ubuntu 14.04.4	6.807.10.00-rc1	20.12.1-0250	43
B200 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2004	Ubuntu 14.04.5	6.810.09.00-rc1	20.12.1-0250	43
B200 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2004	Ubuntu 16.04	6.810.09.00-rc1	20.12.1-0250	43
B200 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2004	Ubuntu 16.04.1	6.810.09.00-rc1	20.12.1-0250	43
B200 M3 w/E5-Series	LSI Logic MegaRAID SAS 2004	vSphere 5.0 U2	6.608.16.00-1(scsi-megaraid-sas)	20.12.1-0250	
B200 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2004	vSphere 5.0 U2	6.608.16.00-1(scsi-megaraid-sas)	20.12.1-0250	
B200 M3 w/E5-Series	LSI Logic MegaRAID SAS 2004	vSphere 5.0 U3	6.608.16.00-1(scsi-megaraid-sas)	20.12.1-0250	
B200 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2004	vSphere 5.0 U3	6.608.16.00-1(scsi-megaraid-sas)	20.12.1-0250	
B200 M3 w/E5-Series	LSI Logic MegaRAID SAS 2004	vSphere 5.1 U1	6.608.16.00-1(scsi-megaraid-sas)	20.12.1-0250	

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B200 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2004	vSphere 5.1 U1	6.608.16.00-1(scsi-megaraid-sas)	20.12.1-0250	
B200 M3 w/E5-Series	LSI Logic MegaRAID SAS 2004	vSphere 5.1 U2	6.608.16.00-1(scsi-megaraid-sas)	20.12.1-0250	
B200 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2004	vSphere 5.1 U2	6.608.16.00-1(scsi-megaraid-sas)	20.12.1-0250	
B200 M3 w/E5-Series	LSI Logic MegaRAID SAS 2004	vSphere 5.1 U3	6.608.16.00-1(scsi-megaraid-sas)	20.12.1-0250	
B200 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2004	vSphere 5.1 U3	6.608.16.00-1(scsi-megaraid-sas)	20.12.1-0250	
B200 M3 w/E5-Series	LSI Logic MegaRAID SAS 2004	vSphere 5.5	6.608.16.00-1(scsi-megaraid-sas)	20.12.1-0250	
B200 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2004	vSphere 5.5	6.608.16.00-1(scsi-megaraid-sas)	20.12.1-0250	
B200 M3 w/E5-Series	LSI Logic MegaRAID SAS 2004	vSphere 5.5 U1	6.608.16.00-1(scsi-megaraid-sas)	20.12.1-0250	
B200 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2004	vSphere 5.5 U1	6.608.16.00-1(scsi-megaraid-sas)	20.12.1-0250	
B200 M3 w/E5-Series	LSI Logic MegaRAID SAS 2004	vSphere 5.5 U2	6.608.16.00-1(scsi-megaraid-sas)	20.12.1-0250	
B200 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2004	vSphere 5.5 U2	6.608.16.00-1(scsi-megaraid-sas)	20.12.1-0250	
B200 M3 w/E5-Series	LSI Logic MegaRAID SAS 2004	vSphere 5.5 U3	6.608.16.00-1(scsi-megaraid-sas)	20.12.1-0250	

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B200 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2004	vSphere 5.5 U3	6.608.16.00-1(scsi-megaraid-sas)	20.12.1-0250	
B200 M3 w/E5-Series	LSI Logic MegaRAID SAS 2004	vSphere 6.0	6.608.16.00-1(scsi-megaraid-sas)	20.12.1-0250	
B200 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2004	vSphere 6.0	6.608.16.00-1(scsi-megaraid-sas)	20.12.1-0250	
B200 M3 w/E5-Series	LSI Logic MegaRAID SAS 2004	vSphere 6.0 U1	6.608.16.00-1(scsi-megaraid-sas)	20.12.1-0250	
B200 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2004	vSphere 6.0 U1	6.608.16.00-1(scsi-megaraid-sas)	20.12.1-0250	
B200 M3 w/E5-Series	LSI Logic MegaRAID SAS 2004	vSphere 6.0 U2	6.608.16.00-1(scsi-megaraid-sas)	20.12.1-0250	
B200 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2004	vSphere 6.0 U2	6.608.16.00-1(scsi-megaraid-sas)	20.12.1-0250	
B200 M3 w/E5-Series	LSI Logic MegaRAID SAS 2004	vSphere 6.5	6.610.15.00-1(scsi-megaraid-sas)	20.12.1-0250	
B200 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2004	vSphere 6.5	6.610.15.00-1(scsi-megaraid-sas)	20.12.1-0250	
B200 M3 w/E5-Series	LSI Logic MegaRAID SAS 2004	Windows Server 2008 R2 SP1	6.702.04.00	20.12.1-0250	
B200 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2004	Windows Server 2008 R2 SP1	6.702.04.00	20.12.1-0250	
B200 M3 w/E5-Series	LSI Logic MegaRAID SAS 2004	Windows Server 2012	6.702.04.00	20.12.1-0250	

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B200 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2004	Windows Server 2012	6.702.04.00	20.12.1-0250	
B200 M3 w/E5-Series	LSI Logic MegaRAID SAS 2004	Windows Server 2012 R2	6.702.04.00	20.12.1-0250	
B200 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2004	Windows Server 2012 R2	6.702.04.00	20.12.1-0250	
B200 M3 w/E5-Series	LSI Logic MegaRAID SAS 2004	Windows Server 2016	6.706.6.00	20.12.1-0250	43
B200 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2004	Windows Server 2016	6.706.6.00	20.12.1-0250	43
B200 M3 w/E5-Series	LSI Logic MegaRAID SAS 2004	XenServer 6.1	6.602.03.00	20.12.1-0250	
B200 M3 w/E5-Series	LSI Logic MegaRAID SAS 2004	XenServer 6.2	6.506	20.12.1-0250	43
B200 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2004	XenServer 6.2	6.506	20.12.1-0250	43
B200 M3 w/E5-Series	LSI Logic MegaRAID SAS 2004	XenServer 6.5	6.803.02.00-rc1	20.12.1-0250	43
B200 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2004	XenServer 6.5	6.803.02.00-rc1	20.12.1-0250	43
B200 M3 w/E5-Series	LSI Logic MegaRAID SAS 2004	XenServer 7.0	6.810.09.00-rc1	20.12.1-0250	43
B200 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2004	XenServer 7.0	6.810.09.00-rc1	20.12.1-0250	43

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B22 M3 w/E5-Series	LSI Logic MegaRAID SAS 2002	UEK R2 U5 (2.6.39-400.x)	6.602.03.00	20.12.1-0250	43
B22 M3 w/E5-Series	LSI Logic MegaRAID SAS 2002	UEK R3 U1 (3.8.13-26.x)	6.700.06.00-rc1	20.12.1-0250	43
B22 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2002	UEK R3 U1 (3.8.13-26.x)	6.700.06.00-rc1	20.12.1-0250	43
B22 M3 w/E5-Series	LSI Logic MegaRAID SAS 2002	UEK R3 U3 (3.8.13-44.x)	6.803.02.00-rc1	20.12.1-0250	43
B22 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2002	UEK R3 U3 (3.8.13-44.x)	6.803.02.00-rc1	20.12.1-0250	43
B22 M3 w/E5-Series	LSI Logic MegaRAID SAS 2002	UEK R3 U5 (3.8.13-68.x)	6.803.02.00-rc1	20.12.1-0250	43
B22 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2002	UEK R3 U5 (3.8.13-68.x)	6.803.02.00-rc1	20.12.1-0250	43
B22 M3 w/E5-Series	LSI Logic MegaRAID SAS 2002	UEK R3 U6 (3.8.13-98.x)	6.803.02.00-rc1	20.12.1-0250	43
B22 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2002	UEK R3 U6 (3.8.13-98.x)	6.803.02.00-rc1	20.12.1-0250	43
B22 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2002	UEK R3 U7 (3.8.13-118)	6.803.02.00-rc1	20.12.1-0250	43
B22 M3 w/E5-Series	LSI Logic MegaRAID SAS 2002	UEK R4 (4.1.12-32.x)	6.803.02.00-rc1	20.12.1-0250	43
B22 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2002	UEK R4 (4.1.12-32.x)	6.803.02.00-rc1	20.12.1-0250	43

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B22 M3 w/E5-Series	LSI Logic MegaRAID SAS 2002	UEK R4 U1 (4.1.12-37.x)	6.810.09.00-rc1	20.12.1-0250	43
B22 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2002	UEK R4 U1 (4.1.12-37.x)	6.810.09.00-rc1	20.12.1-0250	43
B22 M3 w/E5-Series	LSI Logic MegaRAID SAS 2002	UEK R4 U2 (4.1.12-61.x)	6.810.09.00-rc1	20.12.1-0250	43
B22 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2002	UEK R4 U2 (4.1.12-61.x)	6.810.09.00-rc1	20.12.1-0250	43
B22 M3 w/E5-Series	LSI Logic MegaRAID SAS 2002	OVM 3.3.1	6.700.06.00-rc1	20.12.1-0250	43
B22 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2002	OVM 3.3.1	6.700.06.00-rc1	20.12.1-0250	43
B22 M3 w/E5-Series	LSI Logic MegaRAID SAS 2002	OVM 3.3.2	6.803.02.00-rc1	20.12.1-0250	43
B22 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2002	OVM 3.3.2	6.803.02.00-rc1	20.12.1-0250	43
B22 M3 w/E5-Series	LSI Logic MegaRAID SAS 2002	OVM 3.3.3	6.803.02.00-rc1	20.12.1-0250	43
B22 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2002	OVM 3.3.3	6.803.02.00-rc1	20.12.1-0250	43
B22 M3 w/E5-Series	LSI Logic MegaRAID SAS 2002	OVM 3.3.4	6.803.02.00-rc1	20.12.1-0250	43
B22 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2002	OVM 3.3.4	6.803.02.00-rc1	20.12.1-0250	43

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B22 M3 w/E5-Series	LSI Logic MegaRAID SAS 2002	OVM 3.4.1	6.807.10.00-rc1	20.12.1-0250	43
B22 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2002	OVM 3.4.1	6.807.10.00-rc1	20.12.1-0250	43
B22 M3 w/E5-Series	LSI Logic MegaRAID SAS 2002	OVM 3.4.2	6.810.09.00-rc1	20.12.1-0250	43
B22 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2002	OVM 3.4.2	6.810.09.00-rc1	20.12.1-0250	43
B22 M3 w/E5-Series	LSI Logic MegaRAID SAS 2002	Red Hat Enterprise Linux 5.9	6.602.03.00	20.12.1-0250	43
B22 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2002	Red Hat Enterprise Linux 5.9	6.602.03.00	20.12.1-0250	43
B22 M3 w/E5-Series	LSI Logic MegaRAID SAS 2002	Red Hat Enterprise Linux 5.10	00.00.06.15-rh	20.12.1-0250	43
B22 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2002	Red Hat Enterprise Linux 5.10	00.00.06.15-rh	20.12.1-0250	43
B22 M3 w/E5-Series	LSI Logic MegaRAID SAS 2002	Red Hat Enterprise Linux 5.11	00.00.06.15-rh1	20.12.1-0250	43
B22 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2002	Red Hat Enterprise Linux 5.11	00.00.06.15-rh1	20.12.1-0250	43
B22 M3 w/E5-Series	LSI Logic MegaRAID SAS 2002	Red Hat Enterprise Linux 6.4	6.602.03.00	20.12.1-0250	43
B22 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2002	Red Hat Enterprise Linux 6.4	6.602.03.00	20.12.1-0250	43

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B22 M3 w/E5-Series	LSI Logic MegaRAID SAS 2002	Red Hat Enterprise Linux 6.5	6.700.06.00-rh1	20.12.1-0250	43
B22 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2002	Red Hat Enterprise Linux 6.5	6.700.06.00-rh1	20.12.1-0250	43
B22 M3 w/E5-Series	LSI Logic MegaRAID SAS 2002	Red Hat Enterprise Linux 6.6	6.700.06.00-rh1	20.12.1-0250	43
B22 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2002	Red Hat Enterprise Linux 6.6	6.700.06.00-rh1	20.12.1-0250	43
B22 M3 w/E5-Series	LSI Logic MegaRAID SAS 2002	Red Hat Enterprise Linux 6.7	6.806.08.00-rh3	20.12.1-0250	43
B22 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2002	Red Hat Enterprise Linux 6.7	6.806.08.00-rh3	20.12.1-0250	43
B22 M3 w/E5-Series	LSI Logic MegaRAID SAS 2002	Red Hat Enterprise Linux 6.8	6.810.09.00-rh1	20.12.1-0250	43
B22 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2002	Red Hat Enterprise Linux 6.8	6.810.09.00-rh1	20.12.1-0250	43
B22 M3 w/E5-Series	LSI Logic MegaRAID SAS 2002	Red Hat Enterprise Linux 7.0	6.700.06.00-rh1	20.12.1-0250	43
B22 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2002	Red Hat Enterprise Linux 7.0	6.700.06.00-rh1	20.12.1-0250	43
B22 M3 w/E5-Series	LSI Logic MegaRAID SAS 2002	Red Hat Enterprise Linux 7.1	6.806.09.00	20.12.1-0250	43
B22 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2002	Red Hat Enterprise Linux 7.1	6.806.09.00	20.12.1-0250	43

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B22 M3 w/E5-Series	LSI Logic MegaRAID SAS 2002	Red Hat Enterprise Linux 7.2	6.807.10.00-rh1	20.12.1-0250	43
B22 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2002	Red Hat Enterprise Linux 7.2	6.807.10.00-rh1	20.12.1-0250	43
B22 M3 w/E5-Series	LSI Logic MegaRAID SAS 2002	Red Hat Enterprise Linux 7.3	6.811.02.00-rh1	20.12.1-0250	43
B22 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2002	Red Hat Enterprise Linux 7.3	6.811.02.00-rh1	20.12.1-0250	43
B22 M3 w/E5-Series	LSI Logic MegaRAID SAS 2002	Solaris 11 10/12 (U1)	6.602.01.00	20.12.1-0250	
B22 M3 w/E5-Series	LSI Logic MegaRAID SAS 2002	SUSE Linux Enterprise Server 11.2	6.602.03.00	20.12.1-0250	43
B22 M3 w/E5-Series	LSI Logic MegaRAID SAS 2002	SUSE Linux Enterprise Server 11.3	6.602.03.00	20.12.1-0250	43
B22 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2002	SUSE Linux Enterprise Server 11.3	6.602.03.00	20.12.1-0250	43
B22 M3 w/E5-Series	LSI Logic MegaRAID SAS 2002	SUSE Linux Enterprise Server 11.4	6.806.08.00-rc1	20.12.1-0250	43
B22 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2002	SUSE Linux Enterprise Server 11.4	6.806.08.00-rc1	20.12.1-0250	43
B22 M3 w/E5-Series	LSI Logic MegaRAID SAS 2002	SUSE Linux Enterprise Server 12	6.803.01.00-rc1	20.12.1-0250	43
B22 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2002	SUSE Linux Enterprise Server 12	6.803.01.00-rc1	20.12.1-0250	43

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B22 M3 w/E5-Series	LSI Logic MegaRAID SAS 2002	SUSE Linux Enterprise Server 12.1	6.807.10.00-rc1	20.12.1-0250	43
B22 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2002	SUSE Linux Enterprise Server 12.1	6.807.10.00-rc1	20.12.1-0250	43
B22 M3 w/E5-Series	LSI Logic MegaRAID SAS 2002	SUSE Linux Enterprise Server 12.2	6.810.09.00-rc1	20.12.1-0250	43
B22 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2002	SUSE Linux Enterprise Server 12.2	6.810.09.00-rc1	20.12.1-0250	43
B22 M3 w/E5-Series	LSI Logic MegaRAID SAS 2002	vSphere 5.0 U2	6.608.16.00-1(scsi-megaraid-sas)	20.12.1-0250	
B22 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2002	vSphere 5.0 U2	6.608.16.00-1(scsi-megaraid-sas)	20.12.1-0250	
B22 M3 w/E5-Series	LSI Logic MegaRAID SAS 2002	vSphere 5.0 U3	6.608.16.00-1(scsi-megaraid-sas)	20.12.1-0250	
B22 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2002	vSphere 5.0 U3	6.608.16.00-1(scsi-megaraid-sas)	20.12.1-0250	
B22 M3 w/E5-Series	LSI Logic MegaRAID SAS 2002	vSphere 5.1 U1	6.608.16.00-1(scsi-megaraid-sas)	20.12.1-0250	
B22 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2002	vSphere 5.1 U1	6.608.16.00-1(scsi-megaraid-sas)	20.12.1-0250	
B22 M3 w/E5-Series	LSI Logic MegaRAID SAS 2002	vSphere 5.1 U2	6.608.16.00-1(scsi-megaraid-sas)	20.12.1-0250	
B22 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2002	vSphere 5.1 U2	6.608.16.00-1(scsi-megaraid-sas)	20.12.1-0250	

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B22 M3 w/E5-Series	LSI Logic MegaRAID SAS 2002	vSphere 5.1 U3	6.608.16.00-1(scsi-megaraid-sas)	20.12.1-0250	
B22 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2002	vSphere 5.1 U3	6.608.16.00-1(scsi-megaraid-sas)	20.12.1-0250	
B22 M3 w/E5-Series	LSI Logic MegaRAID SAS 2002	vSphere 5.5	6.608.16.00-1(scsi-megaraid-sas)	20.12.1-0250	
B22 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2002	vSphere 5.5	6.608.16.00-1(scsi-megaraid-sas)	20.12.1-0250	
B22 M3 w/E5-Series	LSI Logic MegaRAID SAS 2002	vSphere 5.5 U1	6.608.16.00-1(scsi-megaraid-sas)	20.12.1-0250	
B22 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2002	vSphere 5.5 U1	6.608.16.00-1(scsi-megaraid-sas)	20.12.1-0250	
B22 M3 w/E5-Series	LSI Logic MegaRAID SAS 2002	vSphere 5.5 U2	6.608.16.00-1(scsi-megaraid-sas)	20.12.1-0250	
B22 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2002	vSphere 5.5 U2	6.608.16.00-1(scsi-megaraid-sas)	20.12.1-0250	
B22 M3 w/E5-Series	LSI Logic MegaRAID SAS 2002	vSphere 5.5 U3	6.608.16.00-1(scsi-megaraid-sas)	20.12.1-0250	
B22 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2002	vSphere 5.5 U3	6.608.16.00-1(scsi-megaraid-sas)	20.12.1-0250	
B22 M3 w/E5-Series	LSI Logic MegaRAID SAS 2002	vSphere 6.0	6.608.16.00-1(scsi-megaraid-sas)	20.12.1-0250	
B22 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2002	vSphere 6.0	6.608.16.00-1(scsi-megaraid-sas)	20.12.1-0250	

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B22 M3 w/E5-Series	LSI Logic MegaRAID SAS 2002	vSphere 6.0 U1	6.608.16.00-1(scsi-megaraid-sas)	20.12.1-0250	
B22 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2002	vSphere 6.0 U1	6.608.16.00-1(scsi-megaraid-sas)	20.12.1-0250	
B22 M3 w/E5-Series	LSI Logic MegaRAID SAS 2002	vSphere 6.0 U2	6.608.16.00-1(scsi-megaraid-sas)	20.12.1-0250	
B22 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2002	vSphere 6.0 U2	6.608.16.00-1(scsi-megaraid-sas)	20.12.1-0250	
B22 M3 w/E5-Series	LSI Logic MegaRAID SAS 2002	vSphere 6.5	6.610.15.00-1(scsi-megaraid-sas)	20.12.1-0250	
B22 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2002	vSphere 6.5	6.610.15.00-1(scsi-megaraid-sas)	20.12.1-0250	
B22 M3 w/E5-Series	LSI Logic MegaRAID SAS 2002	Windows Server 2008 R2 SP1	6.702.04.00	20.12.1-0250	
B22 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2002	Windows Server 2008 R2 SP1	6.702.04.00	20.12.1-0250	
B22 M3 w/E5-Series	LSI Logic MegaRAID SAS 2002	Windows Server 2012	6.702.04.00	20.12.1-0250	
B22 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2002	Windows Server 2012	6.702.04.00	20.12.1-0250	
B22 M3 w/E5-Series	LSI Logic MegaRAID SAS 2002	Windows Server 2012 R2	6.702.04.00	20.12.1-0250	
B22 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2002	Windows Server 2012 R2	6.702.04.00	20.12.1-0250	

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B22 M3 w/E5-Series	LSI Logic MegaRAID SAS 2002	Windows Server 2016	6.706.6.00	20.12.1-0250	43
B22 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2002	Windows Server 2016	6.706.6.00	20.12.1-0250	43
B22 M3 w/E5-Series	LSI Logic MegaRAID SAS 2002	XenServer 6.1	6.602.03.00	20.12.1-0250	
B22 M3 w/E5-Series	LSI Logic MegaRAID SAS 2002	XenServer 6.2	6.506	20.12.1-0250	43
B22 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2002	XenServer 6.2	6.506	20.12.1-0250	43
B22 M3 w/E5-Series	LSI Logic MegaRAID SAS 2002	XenServer 6.5	6.803.02.00-rc1	20.12.1-0250	43
B22 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2002	XenServer 6.5	6.803.02.00-rc1	20.12.1-0250	43
B22 M3 w/E5-Series	LSI Logic MegaRAID SAS 2002	XenServer 7.0	6.810.09.00-rc1	20.12.1-0250	43
B22 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2002	XenServer 7.0	6.810.09.00-rc1	20.12.1-0250	43
B420 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2208	CentOS 6.5	6.700.06.00-rh1	23.12.0-0029	39, 40, 43
B420 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2208	CentOS 6.6	6.803.01.00-rh1	23.12.0-0029	39, 40, 43
B420 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2208	CentOS 6.7	6.806.08.00-rh3	23.12.0-0029	39, 40, 43

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B420 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2208	CentOS 6.8	6.810.10.00-1	23.12.0-0029	39, 40, 43
B420 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2208	CentOS 7.1	6.805.06.01-rc1	23.12.0-0029	39, 40, 43
B420 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2208	CentOS 7.2	6.807.10.00-rh1	23.12.0-0029	39, 40, 43
B420 M3 w/E5-Series	LSI Logic MegaRAID SAS 2208	UEK R2 U5 (2.6.39-400.x)	6.602.03.00	23.12.0-0029	43
B420 M3 w/E5-Series	LSI Logic MegaRAID SAS 2208	UEK R3 U1 (3.8.13-26.x)	6.700.06.00-rc1	23.12.0-0029	43
B420 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2208	UEK R3 U1 (3.8.13-26.x)	6.700.06.00-rc1	23.12.0-0029	43
B420 M3 w/E5-Series	LSI Logic MegaRAID SAS 2208	UEK R3 U3 (3.8.13-44.x)	6.803.02.00-rc1	23.12.0-0029	43
B420 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2208	UEK R3 U3 (3.8.13-44.x)	6.803.02.00-rc1	23.12.0-0029	43
B420 M3 w/E5-Series	LSI Logic MegaRAID SAS 2208	UEK R3 U5 (3.8.13-68.x)	6.803.02.00-rc1	23.12.0-0029	43
B420 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2208	UEK R3 U5 (3.8.13-68.x)	6.803.02.00-rc1	23.12.0-0029	43
B420 M3 w/E5-Series	LSI Logic MegaRAID SAS 2208	UEK R3 U6 (3.8.13-98.x)	6.803.02.00-rc1	23.12.0-0029	43
B420 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2208	UEK R3 U6 (3.8.13-98.x)	6.803.02.00-rc1	23.12.0-0029	43

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B420 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2208	UEK R3 U7 (3.8.13-118)	6.803.02.00-rc1	23.12.0-0029	43
B420 M3 w/E5-Series	LSI Logic MegaRAID SAS 2208	UEK R4 (4.1.12-32.x)	6.803.02.00-rc1	23.12.0-0029	43
B420 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2208	UEK R4 (4.1.12-32.x)	6.803.02.00-rc1	23.12.0-0029	43
B420 M3 w/E5-Series	LSI Logic MegaRAID SAS 2208	UEK R4 U1 (4.1.12-37.x)	6.810.09.00-rc1	23.12.0-0029	43
B420 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2208	UEK R4 U1 (4.1.12-37.x)	6.810.09.00-rc1	23.12.0-0029	43
B420 M3 w/E5-Series	LSI Logic MegaRAID SAS 2208	UEK R4 U2 (4.1.12-61.x)	6.810.09.00-rc1	23.12.0-0029	43
B420 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2208	UEK R4 U2 (4.1.12-61.x)	6.810.09.00-rc1	23.12.0-0029	43
B420 M3 w/E5-Series	LSI Logic MegaRAID SAS 2208	OVM 3.3.1	6.700.06.00-rc1	23.12.0-0029	43
B420 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2208	OVM 3.3.1	6.700.06.00-rc1	23.12.0-0029	43
B420 M3 w/E5-Series	LSI Logic MegaRAID SAS 2208	OVM 3.3.2	6.803.02.00-rc1	23.12.0-0029	43
B420 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2208	OVM 3.3.2	6.803.02.00-rc1	23.12.0-0029	43
B420 M3 w/E5-Series	LSI Logic MegaRAID SAS 2208	OVM 3.3.3	6.803.02.00-rc1	23.12.0-0029	43

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B420 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2208	OVM 3.3.3	6.803.02.00-rc1	23.12.0-0029	43
B420 M3 w/E5-Series	LSI Logic MegaRAID SAS 2208	OVM 3.3.4	6.803.02.00-rc1	23.12.0-0029	43
B420 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2208	OVM 3.3.4	6.803.02.00-rc1	23.12.0-0029	43
B420 M3 w/E5-Series	LSI Logic MegaRAID SAS 2208	OVM 3.4.1	6.807.10.00-rc1	23.12.0-0029	43
B420 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2208	OVM 3.4.1	6.807.10.00-rc1	23.12.0-0029	43
B420 M3 w/E5-Series	LSI Logic MegaRAID SAS 2208	OVM 3.4.2	6.810.09.00-rc1	23.12.0-0029	43
B420 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2208	OVM 3.4.2	6.810.09.00-rc1	23.12.0-0029	43
B420 M3 w/E5-Series	LSI Logic MegaRAID SAS 2208	Red Hat Enterprise Linux 5.9	6.602.03.00	23.12.0-0029	43
B420 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2208	Red Hat Enterprise Linux 5.9	6.602.03.00	23.12.0-0029	43
B420 M3 w/E5-Series	LSI Logic MegaRAID SAS 2208	Red Hat Enterprise Linux 5.10	00.00.06.15-rh	23.12.0-0029	43
B420 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2208	Red Hat Enterprise Linux 5.10	00.00.06.15-rh	23.12.0-0029	43
B420 M3 w/E5-Series	LSI Logic MegaRAID SAS 2208	Red Hat Enterprise Linux 5.11	00.00.06.15-rh1	23.12.0-0029	43

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B420 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2208	Red Hat Enterprise Linux 5.11	00.00.06.15-rh1	23.12.0-0029	43
B420 M3 w/E5-Series	LSI Logic MegaRAID SAS 2208	Red Hat Enterprise Linux 6.4	6.602.03.00	23.12.0-0029	43
B420 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2208	Red Hat Enterprise Linux 6.4	6.602.03.00	23.12.0-0029	43
B420 M3 w/E5-Series	LSI Logic MegaRAID SAS 2208	Red Hat Enterprise Linux 6.5	6.700.06.00-rh1	23.12.0-0029	43
B420 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2208	Red Hat Enterprise Linux 6.5	6.700.06.00-rh1	23.12.0-0029	43
B420 M3 w/E5-Series	LSI Logic MegaRAID SAS 2208	Red Hat Enterprise Linux 6.6	6.700.06.00-rh1	23.12.0-0029	43
B420 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2208	Red Hat Enterprise Linux 6.6	6.700.06.00-rh1	23.12.0-0029	43
B420 M3 w/E5-Series	LSI Logic MegaRAID SAS 2208	Red Hat Enterprise Linux 6.7	6.806.08.00-rh3	23.12.0-0029	43
B420 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2208	Red Hat Enterprise Linux 6.7	6.806.08.00-rh3	23.12.0-0029	43
B420 M3 w/E5-Series	LSI Logic MegaRAID SAS 2208	Red Hat Enterprise Linux 6.8	6.810.09.00-rh1	23.12.0-0029	43
B420 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2208	Red Hat Enterprise Linux 6.8	6.810.09.00-rh1	23.12.0-0029	43
B420 M3 w/E5-Series	LSI Logic MegaRAID SAS 2208	Red Hat Enterprise Linux 7.0	6.700.06.00-rh1	23.12.0-0029	43

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B420 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2208	Red Hat Enterprise Linux 7.0	6.700.06.00-rh1	23.12.0-0029	43
B420 M3 w/E5-Series	LSI Logic MegaRAID SAS 2208	Red Hat Enterprise Linux 7.1	6.806.09.00	23.12.0-0029	43
B420 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2208	Red Hat Enterprise Linux 7.1	6.806.09.00	23.12.0-0029	43
B420 M3 w/E5-Series	LSI Logic MegaRAID SAS 2208	Red Hat Enterprise Linux 7.2	6.807.10.00-rh1	23.12.0-0029	43
B420 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2208	Red Hat Enterprise Linux 7.2	6.807.10.00-rh1	23.12.0-0029	43
B420 M3 w/E5-Series	LSI Logic MegaRAID SAS 2208	Red Hat Enterprise Linux 7.3	6.811.02.00-rh1	23.12.0-0029	43
B420 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2208	Red Hat Enterprise Linux 7.3	6.811.02.00-rh1	23.12.0-0029	43
B420 M3 w/E5-Series	LSI Logic MegaRAID SAS 2208	Solaris 11 10/12 (U1)	6.602.01.00	23.12.0-0029	
B420 M3 w/E5-Series	LSI Logic MegaRAID SAS 2208	SUSE Linux Enterprise Server 11.2	6.602.03.00	23.12.0-0029	43
B420 M3 w/E5-Series	LSI Logic MegaRAID SAS 2208	SUSE Linux Enterprise Server 11.3	6.602.03.00	23.12.0-0029	43
B420 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2208	SUSE Linux Enterprise Server 11.3	6.602.03.00	23.12.0-0029	43
B420 M3 w/E5-Series	LSI Logic MegaRAID SAS 2208	SUSE Linux Enterprise Server 11.4	6.806.08.00-rc1	23.12.0-0029	43

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B420 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2208	SUSE Linux Enterprise Server 11.4	6.806.08.00-rc1	23.12.0-0029	43
B420 M3 w/E5-Series	LSI Logic MegaRAID SAS 2208	SUSE Linux Enterprise Server 12	6.803.01.00-rc1	23.12.0-0029	43
B420 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2208	SUSE Linux Enterprise Server 12	6.803.01.00-rc1	23.12.0-0029	43
B420 M3 w/E5-Series	LSI Logic MegaRAID SAS 2208	SUSE Linux Enterprise Server 12.1	6.807.10.00-rc1	23.12.0-0029	43
B420 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2208	SUSE Linux Enterprise Server 12.1	6.807.10.00-rc1	23.12.0-0029	43
B420 M3 w/E5-Series	LSI Logic MegaRAID SAS 2208	SUSE Linux Enterprise Server 12.2	6.810.09.00-rc1	23.12.0-0029	43
B420 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2208	SUSE Linux Enterprise Server 12.2	6.810.09.00-rc1	23.12.0-0029	43
B420 M3 w/E5-Series	LSI Logic MegaRAID SAS 2208	vSphere 5.0 U2	6.608.16.00-1(scsi-megaraid-sas)	23.12.0-0029	
B420 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2208	vSphere 5.0 U2	6.608.16.00-1(scsi-megaraid-sas)	23.12.0-0029	
B420 M3 w/E5-Series	LSI Logic MegaRAID SAS 2208	vSphere 5.0 U3	6.608.16.00-1(scsi-megaraid-sas)	23.12.0-0029	
B420 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2208	vSphere 5.0 U3	6.608.16.00-1(scsi-megaraid-sas)	23.12.0-0029	
B420 M3 w/E5-Series	LSI Logic MegaRAID SAS 2208	vSphere 5.1 U1	6.608.16.00-1(scsi-megaraid-sas)	23.12.0-0029	

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B420 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2208	vSphere 5.1 U1	6.608.16.00-1(scsi-megaraid-sas)	23.12.0-0029	
B420 M3 w/E5-Series	LSI Logic MegaRAID SAS 2208	vSphere 5.1 U2	6.608.16.00-1(scsi-megaraid-sas)	23.12.0-0029	
B420 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2208	vSphere 5.1 U2	6.608.16.00-1(scsi-megaraid-sas)	23.12.0-0029	
B420 M3 w/E5-Series	LSI Logic MegaRAID SAS 2208	vSphere 5.1 U3	6.608.16.00-1(scsi-megaraid-sas)	23.12.0-0029	
B420 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2208	vSphere 5.1 U3	6.608.16.00-1(scsi-megaraid-sas)	23.12.0-0029	
B420 M3 w/E5-Series	LSI Logic MegaRAID SAS 2208	vSphere 5.5	6.608.16.00-1(scsi-megaraid-sas)	23.12.0-0029	
B420 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2208	vSphere 5.5	6.608.16.00-1(scsi-megaraid-sas)	23.12.0-0029	
B420 M3 w/E5-Series	LSI Logic MegaRAID SAS 2208	vSphere 5.5 U1	6.608.16.00-1(scsi-megaraid-sas)	23.12.0-0029	
B420 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2208	vSphere 5.5 U1	6.608.16.00-1(scsi-megaraid-sas)	23.12.0-0029	
B420 M3 w/E5-Series	LSI Logic MegaRAID SAS 2208	vSphere 5.5 U2	6.608.16.00-1(scsi-megaraid-sas)	23.12.0-0029	
B420 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2208	vSphere 5.5 U2	6.608.16.00-1(scsi-megaraid-sas)	23.12.0-0029	
B420 M3 w/E5-Series	LSI Logic MegaRAID SAS 2208	vSphere 5.5 U3	6.608.16.00-1(scsi-megaraid-sas)	23.12.0-0029	

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B420 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2208	vSphere 5.5 U3	6.608.16.00-1(scsi-megaraid-sas)	23.12.0-0029	
B420 M3 w/E5-Series	LSI Logic MegaRAID SAS 2208	vSphere 6.0	6.608.16.00-1(scsi-megaraid-sas)	23.12.0-0029	
B420 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2208	vSphere 6.0	6.608.16.00-1(scsi-megaraid-sas)	23.12.0-0029	
B420 M3 w/E5-Series	LSI Logic MegaRAID SAS 2208	vSphere 6.0 U1	6.608.16.00-1(scsi-megaraid-sas)	23.12.0-0029	
B420 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2208	vSphere 6.0 U1	6.608.16.00-1(scsi-megaraid-sas)	23.12.0-0029	
B420 M3 w/E5-Series	LSI Logic MegaRAID SAS 2208	vSphere 6.0 U2	6.608.16.00-1(scsi-megaraid-sas)	23.12.0-0029	
B420 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2208	vSphere 6.0 U2	6.608.16.00-1(scsi-megaraid-sas)	23.12.0-0029	
B420 M3 w/E5-Series	LSI Logic MegaRAID SAS 2208	vSphere 6.5	6.610.15.00-1(scsi-megaraid-sas)	23.12.0-0029	
B420 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2208	vSphere 6.5	6.610.15.00-1(scsi-megaraid-sas)	23.12.0-0029	
B420 M3 w/E5-Series	LSI Logic MegaRAID SAS 2208	Windows Server 2008 R2 SP1	6.702.04.00	23.12.0-0029	
B420 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2208	Windows Server 2008 R2 SP1	6.702.04.00	23.12.0-0029	
B420 M3 w/E5-Series	LSI Logic MegaRAID SAS 2208	Windows Server 2012	6.702.04.00	23.12.0-0029	

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B420 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2208	Windows Server 2012	6.702.04.00	23.12.0-0029	
B420 M3 w/E5-Series	LSI Logic MegaRAID SAS 2208	Windows Server 2012 R2	6.702.04.00	23.12.0-0029	
B420 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2208	Windows Server 2012 R2	6.702.04.00	23.12.0-0029	
B420 M3 w/E5-Series	LSI Logic MegaRAID SAS 2208	Windows Server 2016	6.706.6.00	23.12.0-0029	43
B420 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2208	Windows Server 2016	6.706.6.00	23.12.0-0029	43
B420 M3 w/E5-Series	LSI Logic MegaRAID SAS 2208	XenServer 6.1	6.602.03.00	23.12.0-0029	
B420 M3 w/E5-Series	LSI Logic MegaRAID SAS 2208	XenServer 6.2	6.506	23.12.0-0029	43
B420 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2208	XenServer 6.2	6.506	23.12.0-0029	43
B420 M3 w/E5-Series	LSI Logic MegaRAID SAS 2208	XenServer 6.5	6.803.02.00-rc1	23.12.0-0029	43
B420 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2208	XenServer 6.5	6.803.02.00-rc1	23.12.0-0029	43
B420 M3 w/E5-Series	LSI Logic MegaRAID SAS 2208	XenServer 7.0	6.810.09.00-rc1	23.12.0-0029	43
B420 M3 w/E5-Series v2	LSI Logic MegaRAID SAS 2208	XenServer 7.0	6.810.09.00-rc1	23.12.0-0029	43

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3	LSI Logic MegaRAID SAS 3008	CentOS 7.1	6.805.06.01-rc1	24.2.1-0066	39, 40, 43
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	LSI Logic MegaRAID SAS 3008	UEK R3 U1 (3.8.13-26.x)	6.700.06.00-rc1	24.2.1-0066	43
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	LSI Logic MegaRAID SAS 3008	UEK R3 U3 (3.8.13-44.x)	6.803.02.00-rc1	24.2.1-0066	43
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2, B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3	LSI Logic MegaRAID SAS 3008	UEK R3 U5 (3.8.13-68.x)	6.803.02.00-rc1	24.2.1-0066	43
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2, B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3	LSI Logic MegaRAID SAS 3008	UEK R3 U6 (3.8.13-98.x)	6.803.02.00-rc1	24.2.1-0066	43
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2, B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3	LSI Logic MegaRAID SAS 3008	UEK R4 (4.1.12-32.x)	6.803.02.00-rc1	24.2.1-0066	43
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2, B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3	LSI Logic MegaRAID SAS 3008	UEK R4 U1 (4.1.12-37.x)	6.810.09.00-rc1	24.2.1-0066	43
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2, B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3	LSI Logic MegaRAID SAS 3008	UEK R4 U2 (4.1.12-61.x)	6.810.09.00-rc1	24.2.1-0066	43

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	LSI Logic MegaRAID SAS 3008	OVM 3.3.1	6.700.06.00-rc1	24.2.1-0066	43
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2, B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3	LSI Logic MegaRAID SAS 3008	OVM 3.3.2	6.803.02.00-rc1	24.2.1-0066	43
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2, B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3	LSI Logic MegaRAID SAS 3008	OVM 3.3.3	6.803.02.00-rc1	24.2.1-0066	43
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2, B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3	LSI Logic MegaRAID SAS 3008	OVM 3.3.4	6.803.02.00-rc1	24.2.1-0066	43
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2, B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3	LSI Logic MegaRAID SAS 3008	OVM 3.4.1	6.807.10.00-rc1	24.2.1-0066	43
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2, B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3	LSI Logic MegaRAID SAS 3008	OVM 3.4.2	6.810.09.00-rc1	24.2.1-0066	43
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	LSI Logic MegaRAID SAS 3008	Red Hat Enterprise Linux 6.5	06.806.09.00	24.2.1-0066	43

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2, B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3	LSI Logic MegaRAID SAS 3008	Red Hat Enterprise Linux 6.6	06.806.09.00	24.2.1-0066	43
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2, B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3	LSI Logic MegaRAID SAS 3008	Red Hat Enterprise Linux 6.7	6.806.08.00-rh3	24.2.1-0066	43
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2, B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3	LSI Logic MegaRAID SAS 3008	Red Hat Enterprise Linux 6.8	6.810.09.00-rh1	24.2.1-0066	43
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	LSI Logic MegaRAID SAS 3008	Red Hat Enterprise Linux 7.0	06.806.09.00	24.2.1-0066	43
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2, B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3	LSI Logic MegaRAID SAS 3008	Red Hat Enterprise Linux 7.1	6.806.09.00	24.2.1-0066	43
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2, B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3	LSI Logic MegaRAID SAS 3008	Red Hat Enterprise Linux 7.2	6.807.10.00-rh1	24.2.1-0066	43
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2, B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3	LSI Logic MegaRAID SAS 3008	Red Hat Enterprise Linux 7.3	6.811.02.00-rh1	24.2.1-0066	43

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2, B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3	LSI Logic MegaRAID SAS 3008	SUSE Linux Enterprise Server 11.3	06.806.09.00	24.2.1-0066	4
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2, B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3	LSI Logic MegaRAID SAS 3008	SUSE Linux Enterprise Server 11.4	6.806.08.00-rc1	24.2.1-0066	4
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2, B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3	LSI Logic MegaRAID SAS 3008	SUSE Linux Enterprise Server 12	06.806.09.00	24.2.1-0066	4
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2, B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3	LSI Logic MegaRAID SAS 3008	SUSE Linux Enterprise Server 12.1	6.807.10.00-rc1	24.2.1-0066	43
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2, B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3	LSI Logic MegaRAID SAS 3008	SUSE Linux Enterprise Server 12.2	6.810.09.00-rc1	24.2.1-0066	43
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	LSI Logic MegaRAID SAS 3008	Ubuntu 12.04.4	6.600.18	24.2.1-0066	43
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	LSI Logic MegaRAID SAS 3008	Ubuntu 14.04	6.700.06.00	24.2.1-0066	43
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	LSI Logic MegaRAID SAS 3008	Ubuntu 14.04.1	6.700.06.00	24.2.1-0066	43

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2, B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3	LSI Logic MegaRAID SAS 3008	Ubuntu 14.04.2	6.803.01.01	24.2.1-0066	43
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2, B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3	LSI Logic MegaRAID SAS 3008	Ubuntu 14.04.3	6.805.06.01-rc1	24.2.1-0066	43
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2, B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3	LSI Logic MegaRAID SAS 3008	Ubuntu 14.04.4	6.807.10.00-rc1	24.2.1-0066	43
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2, B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3	LSI Logic MegaRAID SAS 3008	Ubuntu 14.04.5	6.810.09.00-rc1	24.2.1-0066	43
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2, B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3	LSI Logic MegaRAID SAS 3008	Ubuntu 16.04	6.810.09.00-rc1	24.2.1-0066	43
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2, B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3	LSI Logic MegaRAID SAS 3008	Ubuntu 16.04.1	6.810.09.00-rc1	24.2.1-0066	43
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	LSI Logic MegaRAID SAS 3008	vSphere 5.1 U2	6.608.16.00-1(scsi-megaraid-sas)	24.2.1-0066	11

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	LSI Logic MegaRAID SAS 3008	vSphere 5.1 U3	6.608.16.00-1(scsi-megaraid-sas)	24.2.1-0066	11
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	LSI Logic MegaRAID SAS 3008	vSphere 5.5	6.608.16.00-1(scsi-megaraid-sas)	24.2.1-0066	11
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	LSI Logic MegaRAID SAS 3008	vSphere 5.5 U1	6.608.16.00-1(scsi-megaraid-sas)	24.2.1-0066	11
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2, B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3	LSI Logic MegaRAID SAS 3008	vSphere 5.5 U2	6.608.16.00-1(scsi-megaraid-sas)	24.2.1-0066	11
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2, B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3	LSI Logic MegaRAID SAS 3008	vSphere 5.5 U3	6.608.16.00-1(scsi-megaraid-sas), 6.608.12.00-1(Isi-mr3)	24.2.1-0066	11
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2, B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3	LSI Logic MegaRAID SAS 3008	vSphere 6.0	6.608.16.00-1(scsi-megaraid-sas), 6.608.12.00-1(Isi-mr3)	24.2.1-0066	11
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2, B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3	LSI Logic MegaRAID SAS 3008	vSphere 6.0 U1	6.608.16.00-1(scsi-megaraid-sas), 6.608.12.00-1(Isi-mr3)	24.2.1-0066	11
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2, B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3	LSI Logic MegaRAID SAS 3008	vSphere 6.0 U2	6.608.16.00-1(scsi-megaraid-sas), 6.608.12.00-1(Isi-mr3)	24.2.1-0066	11

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2, B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3	LSI Logic MegaRAID SAS 3008	vSphere 6.5	6.610.15.00-1(scsi-megaraid-sas), 6.610.18.00-1(lsi-mr3)	24.2.1-0066	11
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2, B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3	LSI Logic MegaRAID SAS 3008	Windows Server 2008 R2 SP1	6.706.06.00	24.2.1-0066	4
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2, B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3	LSI Logic MegaRAID SAS 3008	Windows Server 2012	6.706.06.00	24.2.1-0066	4
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2, B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3	LSI Logic MegaRAID SAS 3008	Windows Server 2012 R2	6.706.06.00	24.2.1-0066	
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2, B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3	LSI Logic MegaRAID SAS 3008	Windows Server 2016	6.706.6.00	24.2.1-0066	43
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	LSI Logic MegaRAID SAS 3008	XenServer 6.2	06.806.09.00	24.2.1-0066	
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2, B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3	LSI Logic MegaRAID SAS 3008	XenServer 6.5	6.803.02.00-rc1	24.2.1-0066	43

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2, B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3	LSI Logic MegaRAID SAS 3008	XenServer 7.0	6.810.09.00-rc1	24.2.1-0066	43
B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G)	CentOS 6.6	6.803.01.00-rh1	24.5.0-0043	39, 40, 43
B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G)	CentOS 6.7	6.806.08.00-rh3	24.5.0-0043	39, 40, 43
B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G)	CentOS 6.7	6.806.08.00-rh3	24.5.0-0043	39, 40, 43
B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G)	CentOS 6.8	6.810.10.00-1	24.5.0-0043	39, 40, 43
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G)	CentOS 6.8	6.810.10.00-1	24.5.0-0043	39, 40, 43
B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G)	CentOS 7.1	6.805.06.01-rc1	24.5.0-0043	39, 40, 43
B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G)	CentOS 7.2	6.807.10.00-rh1	24.5.0-0043	39, 40, 43

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G)	CentOS 7.2	6.807.10.00-rh1	24.5.0-0043	39, 40, 43
B200 M4 w/E5-Series v3	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G)	UEK R3 U1 (3.8.13-26.x)	6.700.06.00-rc1	24.5.0-0043	43
B200 M4 w/E5-Series v3	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G)	UEK R3 U3 (3.8.13-44.x)	6.803.02.00-rc1	24.5.0-0043	43
B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G)	UEK R3 U5 (3.8.13-68.x)	6.803.02.00-rc1	24.5.0-0043	43
B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G)	UEK R3 U6 (3.8.13-98.x)	6.803.02.00-rc1	24.5.0-0043	43
B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G)	UEK R3 U7 (3.8.13-118)	6.803.02.00-rc1	24.5.0-0043	43
B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G)	UEK R4 (4.1.12-32.x)	6.803.02.00-rc1	24.5.0-0043	43
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G)	UEK R4 (4.1.12-32.x)	6.803.02.00-rc1	24.5.0-0043	43
B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G)	UEK R4 U1 (4.1.12-37.x)	6.810.09.00-rc1	24.5.0-0043	43

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G)	UEK R4 U1 (4.1.12-37.x)	6.810.09.00-rc1	24.5.0-0043	43
B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G)	UEK R4 U2 (4.1.12-61.x)	6.810.09.00-rc1	24.5.0-0043	43
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G)	UEK R4 U2 (4.1.12-61.x)	6.810.09.00-rc1	24.5.0-0043	43
B200 M4 w/E5-Series v3	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G)	OVM 3.3.1	6.700.06.00-rc1	24.5.0-0043	43
B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G)	OVM 3.3.2	6.803.02.00-rc1	24.5.0-0043	43
B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G)	OVM 3.3.3	6.803.02.00-rc1	24.5.0-0043	43
B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G)	OVM 3.3.4	6.803.02.00-rc1	24.5.0-0043	43
B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G)	OVM 3.4.1	6.807.10.00-rc1	24.5.0-0043	43

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G)	OVM 3.4.1	6.807.10.00-rc1	24.5.0-0043	43
B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G)	OVM 3.4.2	6.810.09.00-rc1	24.5.0-0043	43
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G)	OVM 3.4.2	6.810.09.00-rc1	24.5.0-0043	43
B200 M4 w/E5-Series v3	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G)	Red Hat Enterprise Linux 6.5	06.806.09.00	24.5.0-0043	43
B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G)	Red Hat Enterprise Linux 6.6	06.806.09.00	24.5.0-0043	43
B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G)	Red Hat Enterprise Linux 6.7	6.806.08.00-rh3	24.5.0-0043	43
B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G)	Red Hat Enterprise Linux 6.7	6.806.08.00-rh3	24.5.0-0043	43
B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G)	Red Hat Enterprise Linux 6.8	6.810.09.00-rh1	24.5.0-0043	43

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G)	Red Hat Enterprise Linux 6.8	6.810.09.00-rh1	24.5.0-0043	43
B200 M4 w/E5-Series v3	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G)	Red Hat Enterprise Linux 7.0	06.806.09.00	24.5.0-0043	43
B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G)	Red Hat Enterprise Linux 7.1	6.806.09.00	24.5.0-0043	43
B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G)	Red Hat Enterprise Linux 7.2	6.807.10.00-rh1	24.5.0-0043	43
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G)	Red Hat Enterprise Linux 7.2	6.807.10.00-rh1	24.5.0-0043	43
B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G)	Red Hat Enterprise Linux 7.3	6.811.02.00-rh1	24.5.0-0043	43
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G)	Red Hat Enterprise Linux 7.3	6.811.02.00-rh1	24.5.0-0043	43
B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G)	SUSE Linux Enterprise Server 11.3	06.806.09.00	24.5.0-0043	4

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G)	SUSE Linux Enterprise Server 11.4	6.806.08.00-rc1	24.5.0-0043	4
B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G)	SUSE Linux Enterprise Server 12	06.806.09.00	24.5.0-0043	4
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G)	SUSE Linux Enterprise Server 12	06.806.09.00	24.5.0-0043	4
B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G)	SUSE Linux Enterprise Server 12.1	6.807.10.00-rc1	24.5.0-0043	43
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G)	SUSE Linux Enterprise Server 12.1	6.807.10.00-rc1	24.5.0-0043	43
B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G)	SUSE Linux Enterprise Server 12.2	6.810.09.00-rc1	24.5.0-0043	43
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G)	SUSE Linux Enterprise Server 12.2	6.810.09.00-rc1	24.5.0-0043	43
B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G)	vSphere 5.1 U2	6.608.16.00-1(scsi-megaraid-sas)	24.5.0-0043	4, 11

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G)	vSphere 5.1 U3	6.608.16.00-1(scsi-megaraid-sas)	24.5.0-0043	4, 11
B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G)	vSphere 5.5 U2	6.608.16.00-1(scsi-megaraid-sas)	24.5.0-0043	4, 11
B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G)	vSphere 5.5 U3	6.608.16.00-1(scsi-megaraid-sas), 6.608.12.00-1(Isi-mr3)	24.5.0-0043	4, 11
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G)	vSphere 5.5 U3	6.608.16.00-1(scsi-megaraid-sas), 6.608.12.00-1(Isi-mr3)	24.5.0-0043	4, 11
B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G)	vSphere 6.0	6.608.16.00-1(scsi-megaraid-sas), 6.608.12.00-1(Isi-mr3)	24.5.0-0043	4, 11
B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G)	vSphere 6.0 U1	6.608.16.00-1(scsi-megaraid-sas), 6.608.12.00-1(Isi-mr3)	24.5.0-0043	4, 11
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G)	vSphere 6.0 U1	6.608.16.00-1(scsi-megaraid-sas), 6.608.12.00-1(Isi-mr3)	24.5.0-0043	4, 11
B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G)	vSphere 6.0 U2	6.608.16.00-1(scsi-megaraid-sas), 6.608.12.00-1(Isi-mr3)	24.5.0-0043	4, 11

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G)	vSphere 6.0 U2	6.608.16.00-1(scsi-megaraid-sas), 6.608.12.00-1(lsi-mr3)	24.5.0-0043	4, 11
B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G)	vSphere 6.5	6.610.15.00-1(scsi-megaraid-sas), 6.610.18.00-1(lsi-mr3)	24.5.0-0043	4, 11
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G)	vSphere 6.5	6.610.15.00-1(scsi-megaraid-sas), 6.610.18.00-1(lsi-mr3)	24.5.0-0043	4, 11
B200 M4 w/E5-Series v3	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G)	Ubuntu 14.04.1	6.700.06.00	24.5.0-0043	43
B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G)	Ubuntu 14.04.2	6.803.01.01	24.5.0-0043	43
B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G)	Ubuntu 14.04.3	6.805.06.01-rc1	24.5.0-0043	43
B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G)	Ubuntu 14.04.4	6.807.10.00-rc1	24.5.0-0043	43
B200 M4 w/E5-Series v4	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G)	Ubuntu 14.04.4	6.807.10.00-rc1	24.5.0-0043	43
B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G)	Ubuntu 14.04.5	6.810.09.00-rc1	24.5.0-0043	43

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B200 M4 w/E5-Series v4	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G)	Ubuntu 14.04.5	6.810.09.00-rc1	24.5.0-0043	43
B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G)	Ubuntu 16.04	6.810.09.00-rc1	24.5.0-0043	43
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G)	Ubuntu 16.04	6.810.09.00-rc1	24.5.0-0043	43
B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G)	Ubuntu 16.04.1	6.810.09.00-rc1	24.5.0-0043	43
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G)	Ubuntu 16.04.1	6.810.09.00-rc1	24.5.0-0043	43
B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G)	Windows Server 2008 R2 SP1	6.706.06.00	24.5.0-0043	4
B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G)	Windows Server 2012	6.706.06.00	24.5.0-0043	4
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G)	Windows Server 2012	6.706.06.00	24.5.0-0043	4

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G)	Windows Server 2012 R2	6.706.06.00	24.5.0-0043	
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G)	Windows Server 2012 R2	6.706.06.00	24.5.0-0043	
B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G)	Windows Server 2016	6.706.6.00	24.5.0-0043	43
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G)	Windows Server 2016	6.706.6.00	24.5.0-0043	43
B200 M4 w/E5-Series v3	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G)	XenServer 6.2	6.704.15.00	24.5.0-0043	
B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G)	XenServer 6.5	6.803.02.00-rc1	24.5.0-0043	43
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G)	XenServer 6.5	6.803.02.00-rc1	24.5.0-0043	43
B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G)	XenServer 7.0	6.810.09.00-rc1	24.5.0-0043	43

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G)	XenServer 7.0	6.810.09.00-rc1	24.5.0-0043	43
B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G-HE)	CentOS 6.6	6.803.01.00-rh1	24.7.0-0063	39, 40, 43
B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G-HE)	CentOS 6.7	6.806.08.00-rh3	24.7.0-0063	39, 40, 43
B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G-HE)	CentOS 6.7	6.806.08.00-rh3	24.7.0-0063	39, 40, 43
B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G-HE)	CentOS 6.8	6.810.10.00-1	24.7.0-0063	39, 40, 43
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G-HE)	CentOS 6.8	6.810.10.00-1	24.7.0-0063	39, 40, 43
B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G-HE)	CentOS 7.2	6.807.10.00-rh1	24.7.0-0063	39, 40, 43
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G-HE)	CentOS 7.2	6.807.10.00-rh1	24.7.0-0063	39, 40, 43

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B200 M4 w/E5-Series v3	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G-HE)	UEK R3 U1 (3.8.13-26.x)	6.700.06.00-rc1	24.7.0-0063	43
B200 M4 w/E5-Series v3	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G-HE)	UEK R3 U3 (3.8.13-44.x)	6.803.02.00-rc1	24.7.0-0063	43
B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G-HE)	UEK R3 U5 (3.8.13-68.x)	6.803.02.00-rc1	24.7.0-0063	43
B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G-HE)	UEK R3 U6 (3.8.13-98.x)	6.803.02.00-rc1	24.7.0-0063	43
B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G-HE)	UEK R3 U7 (3.8.13-118)	6.803.02.00-rc1	24.7.0-0063	43
B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G-HE)	UEK R4 (4.1.12-32.x)	6.803.02.00-rc1	24.7.0-0063	43
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G-HE)	UEK R4 (4.1.12-32.x)	6.803.02.00-rc1	24.7.0-0063	43
B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G-HE)	UEK R4 U1 (4.1.12-37.x)	6.810.09.00-rc1	24.7.0-0063	43
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G-HE)	UEK R4 U1 (4.1.12-37.x)	6.810.09.00-rc1	24.7.0-0063	43

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G-HE)	UEK R4 U2 (4.1.12-61.x)	6.810.09.00-rc1	24.7.0-0063	43
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G-HE)	UEK R4 U2 (4.1.12-61.x)	6.810.09.00-rc1	24.7.0-0063	43
B200 M4 w/E5-Series v3	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G-HE)	OVM 3.3.1	6.700.06.00-rc1	24.7.0-0063	43
B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G-HE)	OVM 3.3.2	6.803.02.00-rc1	24.7.0-0063	43
B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G-HE)	OVM 3.3.3	6.803.02.00-rc1	24.7.0-0063	43
B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G-HE)	OVM 3.3.4	6.803.02.00-rc1	24.7.0-0063	43
B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G-HE)	OVM 3.4.1	6.807.10.00-rc1	24.7.0-0063	43
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G-HE)	OVM 3.4.1	6.807.10.00-rc1	24.7.0-0063	43
B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G-HE)	OVM 3.4.2	6.810.09.00-rc1	24.7.0-0063	43

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G-HE)	OVM 3.4.2	6.810.09.00-rc1	24.7.0-0063	43
B200 M4 w/E5-Series v3	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G-HE)	Red Hat Enterprise Linux 6.5	06.806.09.00	24.7.0-0063	43
B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G-HE)	Red Hat Enterprise Linux 6.6	06.806.09.00	24.7.0-0063	43
B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G-HE)	Red Hat Enterprise Linux 6.7	6.806.08.00-rh3	24.7.0-0063	43
B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G-HE)	Red Hat Enterprise Linux 6.7	6.806.08.00-rh3	24.7.0-0063	43
B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G-HE)	Red Hat Enterprise Linux 6.8	6.810.09.00-rh1	24.7.0-0063	43
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G-HE)	Red Hat Enterprise Linux 6.8	6.810.09.00-rh1	24.7.0-0063	43
B200 M4 w/E5-Series v3	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G-HE)	Red Hat Enterprise Linux 7.0	06.806.09.00	24.7.0-0063	43
B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G-HE)	Red Hat Enterprise Linux 7.1	6.806.09.00	24.7.0-0063	43

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G-HE)	Red Hat Enterprise Linux 7.2	6.807.10.00-rh1	24.7.0-0063	43
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G-HE)	Red Hat Enterprise Linux 7.2	6.807.10.00-rh1	24.7.0-0063	43
B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G-HE)	Red Hat Enterprise Linux 7.3	6.811.02.00-rh1	24.7.0-0063	43
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G-HE)	Red Hat Enterprise Linux 7.3	6.811.02.00-rh1	24.7.0-0063	43
B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G-HE)	SUSE Linux Enterprise Server 11.3	06.806.09.00	24.7.0-0063	4
B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G-HE)	SUSE Linux Enterprise Server 11.4	6.806.08.00-rc1	24.7.0-0063	4
B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G-HE)	SUSE Linux Enterprise Server 12	06.806.09.00	24.7.0-0063	4
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G-HE)	SUSE Linux Enterprise Server 12	06.806.09.00	24.7.0-0063	4

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G-HE)	SUSE Linux Enterprise Server 12.1	6.807.10.00-rc1	24.7.0-0063	43
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G-HE)	SUSE Linux Enterprise Server 12.1	6.807.10.00-rc1	24.7.0-0063	43
B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G-HE)	SUSE Linux Enterprise Server 12.2	6.810.09.00-rc1	24.7.0-0063	43
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G-HE)	SUSE Linux Enterprise Server 12.2	6.810.09.00-rc1	24.7.0-0063	43
B200 M4 w/E5-Series v3	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G-HE)	vSphere 5.1 U2	6.608.16.00-1(scsi-megaraid-sas)	24.7.0-0063	4, 11
B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G-HE)	vSphere 5.1 U3	6.608.16.00-1(scsi-megaraid-sas)	24.7.0-0063	4, 11
B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G-HE)	vSphere 5.5 U2	6.608.16.00-1(scsi-megaraid-sas)	24.7.0-0063	4, 11
B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G-HE)	vSphere 5.5 U3	6.608.16.00-1(scsi-megaraid-sas), 6.608.12.00-1(lsi-mr3)	24.7.0-0063	4, 11

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G-HE)	vSphere 5.5 U3	6.608.16.00-1(scsi-megaraid-sas), 6.608.12.00-1(Isi-mr3)	24.7.0-0063	4, 11
B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G-HE)	vSphere 6.0	6.608.16.00-1(scsi-megaraid-sas), 6.608.12.00-1(Isi-mr3)	24.7.0-0063	4, 11
B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G-HE)	vSphere 6.0 U1	6.608.16.00-1(scsi-megaraid-sas), 6.608.12.00-1(Isi-mr3)	24.7.0-0063	4, 11
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G-HE)	vSphere 6.0 U1	6.608.16.00-1(scsi-megaraid-sas), 6.608.12.00-1(Isi-mr3)	24.7.0-0063	4, 11
B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G-HE)	vSphere 6.0 U2	6.608.16.00-1(scsi-megaraid-sas), 6.608.12.00-1(Isi-mr3)	24.7.0-0063	4, 11
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G-HE)	vSphere 6.0 U2	6.608.16.00-1(scsi-megaraid-sas), 6.608.12.00-1(Isi-mr3)	24.7.0-0063	4, 11
B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G-HE)	vSphere 6.5	6.610.15.00-1(scsi-megaraid-sas), 6.610.18.00-1(Isi-mr3)	24.7.0-0063	4, 11
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G-HE)	vSphere 6.5	6.610.15.00-1(scsi-megaraid-sas), 6.610.18.00-1(Isi-mr3)	24.7.0-0063	4, 11

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B200 M4 w/E5-Series v3	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G-HE)	Ubuntu 14.04.1	6.700.06.00	24.7.0-0063	43
B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G-HE)	Ubuntu 14.04.2	6.803.01.01	24.7.0-0063	43
B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G-HE)	Ubuntu 14.04.3	6.805.06.01-rc1	24.7.0-0063	43
B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G-HE)	Ubuntu 14.04.4	6.807.10.00-rc1	24.7.0-0063	43
B200 M4 w/E5-Series v4	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G-HE)	Ubuntu 14.04.4	6.807.10.00-rc1	24.7.0-0063	43
B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G-HE)	Ubuntu 14.04.5	6.810.09.00-rc1	24.7.0-0063	43
B200 M4 w/E5-Series v4	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G-HE)	Ubuntu 14.04.5	6.810.09.00-rc1	24.7.0-0063	43
B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G-HE)	Ubuntu 16.04	6.810.09.00-rc1	24.7.0-0063	43
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G-HE)	Ubuntu 16.04	6.810.09.00-rc1	24.7.0-0063	43

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G-HE)	Ubuntu 16.04.1	6.810.09.00-rc1	24.7.0-0063	43
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G-HE)	Ubuntu 16.04.1	6.810.09.00-rc1	24.7.0-0063	43
B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G-HE)	Windows Server 2008 R2 SP1	6.706.06.00	24.7.0-0063	4
B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G-HE)	Windows Server 2012	6.706.06.00	24.7.0-0063	4
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G-HE)	Windows Server 2012	6.706.06.00	24.7.0-0063	4
B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G-HE)	Windows Server 2012 R2	6.706.06.00	24.7.0-0063	
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G-HE)	Windows Server 2012 R2	6.706.06.00	24.7.0-0063	
B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G-HE)	Windows Server 2016	6.706.6.00	24.7.0-0063	43

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G-HE)	Windows Server 2016	6.706.6.00	24.7.0-0063	43
B200 M4 w/E5-Series v3	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G-HE)	XenServer 6.2	6.704.15.00	24.7.0-0063	
B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G-HE)	XenServer 6.5	6.803.02.00-rc1	24.7.0-0063	43
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G-HE)	XenServer 6.5	6.803.02.00-rc1	24.7.0-0063	43
B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G-HE)	XenServer 7.0	6.810.09.00-rc1	24.7.0-0063	43
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	Cisco FlexStorage 12G SAS RAID controller (UCSB-MRAID12G-HE)	XenServer 7.0	6.810.09.00-rc1	24.7.0-0063	43

UCS Storage Accelerator Interoperability Matrix

Table 8 lists the UCS storage accelerators that are supported with this version of the Unified Computing System.

Table 8: UCS Storage Accelerators

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B200 M4 w/E5-Series v3	HGST SN100 w/ UCSB-LSTOR-PT PCI Passthrough Adapter	Red Hat Enterprise Linux 6.5	1.1.1508.1410	KMCCP101	21, 49
B200 M4 w/E5-Series v3	HGST SN100 w/ UCSB-LSTOR-PT PCI Passthrough Adapter	Red Hat Enterprise Linux 6.6	1.1.1508.1410	KMCCP101	21, 49
B200 M4 w/E5-Series v3	HGST SN100 w/ UCSB-LSTOR-PT PCI Passthrough Adapter	Red Hat Enterprise Linux 6.7	1.1.1508.1410	KMCCP101	21, 49
B200 M4 w/E5-Series v4	HGST SN100 w/ UCSB-LSTOR-PT PCI Passthrough Adapter	Red Hat Enterprise Linux 6.7	1.1.1508.1410	KMCCP101	21, 49
B200 M4 w/E5-Series v3	HGST SN100 w/ UCSB-LSTOR-PT PCI Passthrough Adapter	Red Hat Enterprise Linux 7.0	1.1.1508.1410	KMCCP101	21, 49
B200 M4 w/E5-Series v3	HGST SN100 w/ UCSB-LSTOR-PT PCI Passthrough Adapter	Red Hat Enterprise Linux 7.1	1.1.1508.1410	KMCCP101	21, 49
B200 M4 w/E5-Series v3	HGST SN100 w/ UCSB-LSTOR-PT PCI Passthrough Adapter	SUSE Linux Enterprise Server 11.3	1.1.1508.1410	KMCCP101	21, 49
B200 M4 w/E5-Series v3	HGST SN100 w/ UCSB-LSTOR-PT PCI Passthrough Adapter	SUSE Linux Enterprise Server 11.4	1.1.1508.1410	KMCCP101	21, 49
B200 M4 w/E5-Series v3	HGST SN100 w/ UCSB-LSTOR-PT PCI Passthrough Adapter	SUSE Linux Enterprise Server 12	1.1.1508.1410	KMCCP101	21, 49

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B200 M4 w/E5-Series v4	HGST SN100 w/UCSB-LSTOR-PT PCI Passthrough Adapter	SUSE Linux Enterprise Server 12	1.1.1508.1410	KMCCP101	21, 49
B200 M4 w/E5-Series v3	HGST SN100 w/UCSB-LSTOR-PT PCI Passthrough Adapter	vSphere 6.0	1.1.1508.1410	KMCCP101	21, 49
B200 M4 w/E5-Series v3	HGST SN100 w/UCSB-LSTOR-PT PCI Passthrough Adapter	vSphere 6.0 U1	1.1.1508.1410	KMCCP101	21, 49
B200 M4 w/E5-Series v4	HGST SN100 w/UCSB-LSTOR-PT PCI Passthrough Adapter	vSphere 6.0 U1	1.1.1508.1410	KMCCP101	21, 49
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1300GB MLC Fusion ioMemory PX	Red Hat Enterprise Linux 5.10	4.2.4.1178	8.9.1	21
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS 1300GB MLC Fusion ioMemory PX	Red Hat Enterprise Linux 5.10	4.2.4.1178	8.9.1	21
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1300GB MLC Fusion ioMemory PX	Red Hat Enterprise Linux 5.11	4.2.4.1178	8.9.1	21
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS 1300GB MLC Fusion ioMemory PX	Red Hat Enterprise Linux 5.11	4.2.4.1178	8.9.1	21
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1300GB MLC Fusion ioMemory PX	Red Hat Enterprise Linux 6.4	4.2.4.1178	8.9.1	21

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS 1300GB MLC Fusion ioMemory PX	Red Hat Enterprise Linux 6.4	4.2.4.1178	8.9.1	21
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1300GB MLC Fusion ioMemory PX	Red Hat Enterprise Linux 6.5	4.2.4.1178	8.9.1	21
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS 1300GB MLC Fusion ioMemory PX	Red Hat Enterprise Linux 6.5	4.2.4.1178	8.9.1	21
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1300GB MLC Fusion ioMemory PX	Red Hat Enterprise Linux 6.5	4.2.4.1178	8.9.1	21
B200 M4 w/E5-Series v3	UCS 1300GB MLC Fusion ioMemory PX	Red Hat Enterprise Linux 6.5	4.2.4.1178	8.9.1	21
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1300GB MLC Fusion ioMemory PX	Red Hat Enterprise Linux 6.6	4.2.4.1178	8.9.1	21
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS 1300GB MLC Fusion ioMemory PX	Red Hat Enterprise Linux 6.6	4.2.4.1178	8.9.1	21
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1300GB MLC Fusion ioMemory PX	Red Hat Enterprise Linux 6.6	4.2.4.1178	8.9.1	21
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1300GB MLC Fusion ioMemory PX	Red Hat Enterprise Linux 6.6	4.2.4.1178	8.9.1	21

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1300GB MLC Fusion ioMemory PX	Red Hat Enterprise Linux 6.7	4.2.4.1178	8.9.1	21
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS 1300GB MLC Fusion ioMemory PX	Red Hat Enterprise Linux 6.7	4.2.4.1178	8.9.1	21
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1300GB MLC Fusion ioMemory PX	Red Hat Enterprise Linux 6.7	4.2.4.1178	8.9.1	21
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1300GB MLC Fusion ioMemory PX	Red Hat Enterprise Linux 6.7	4.2.4.1178	8.9.1	21
B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	UCS 1300GB MLC Fusion ioMemory PX	Red Hat Enterprise Linux 6.7	4.2.4.1178	8.9.1	21
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1300GB MLC Fusion ioMemory PX	Red Hat Enterprise Linux 7.0	4.2.4.1178	8.9.1	21
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS 1300GB MLC Fusion ioMemory PX	Red Hat Enterprise Linux 7.0	4.2.4.1178	8.9.1	21
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1300GB MLC Fusion ioMemory PX	Red Hat Enterprise Linux 7.0	4.2.4.1178	8.9.1	21
B200 M4 w/E5-Series v3	UCS 1300GB MLC Fusion ioMemory PX	Red Hat Enterprise Linux 7.0	4.2.4.1178	8.9.1	21

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1300GB MLC Fusion ioMemory PX	Red Hat Enterprise Linux 7.1	4.2.4.1178	8.9.1	21
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS 1300GB MLC Fusion ioMemory PX	Red Hat Enterprise Linux 7.1	4.2.4.1178	8.9.1	21
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1300GB MLC Fusion ioMemory PX	Red Hat Enterprise Linux 7.1	4.2.4.1178	8.9.1	21
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1300GB MLC Fusion ioMemory PX	Red Hat Enterprise Linux 7.1	4.2.4.1178	8.9.1	21
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1300GB MLC Fusion ioMemory PX	Red Hat Enterprise Linux 7.2	4.2.4.1178	8.9.1	21
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS 1300GB MLC Fusion ioMemory PX	Red Hat Enterprise Linux 7.2	4.2.4.1178	8.9.1	21
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1300GB MLC Fusion ioMemory PX	Red Hat Enterprise Linux 7.2	4.2.4.1178	8.9.1	21
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1300GB MLC Fusion ioMemory PX	Red Hat Enterprise Linux 7.2	4.2.4.1178	8.9.1	21
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1300GB MLC Fusion ioMemory PX	SUSE Linux Enterprise Server 11.3	4.2.4.1178	8.9.1	21

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS 1300GB MLC Fusion ioMemory PX	SUSE Linux Enterprise Server 11.3	4.2.4.1178	8.9.1	21
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1300GB MLC Fusion ioMemory PX	SUSE Linux Enterprise Server 11.3	4.2.4.1178	8.9.1	21
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1300GB MLC Fusion ioMemory PX	SUSE Linux Enterprise Server 11.3	4.2.4.1178	8.9.1	21
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1300GB MLC Fusion ioMemory PX	SUSE Linux Enterprise Server 11.4	4.2.4.1178	8.9.1	21
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS 1300GB MLC Fusion ioMemory PX	SUSE Linux Enterprise Server 11.4	4.2.4.1178	8.9.1	21
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1300GB MLC Fusion ioMemory PX	SUSE Linux Enterprise Server 11.4	4.2.4.1178	8.9.1	21
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1300GB MLC Fusion ioMemory PX	SUSE Linux Enterprise Server 11.4	4.2.4.1178	8.9.1	21
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1300GB MLC Fusion ioMemory PX	SUSE Linux Enterprise Server 12	4.2.4.1178	8.9.1	21

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS 1300GB MLC Fusion ioMemory PX	SUSE Linux Enterprise Server 12	4.2.4.1178	8.9.1	21
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1300GB MLC Fusion ioMemory PX	SUSE Linux Enterprise Server 12	4.2.4.1178	8.9.1	21
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1300GB MLC Fusion ioMemory PX	SUSE Linux Enterprise Server 12	4.2.4.1178	8.9.1	21
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	UCS 1300GB MLC Fusion ioMemory PX	SUSE Linux Enterprise Server 12	4.2.4.1178	8.9.1	21
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1300GB MLC Fusion ioMemory PX	SUSE Linux Enterprise Server 12.1	4.2.4.1178	8.9.1	21
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS 1300GB MLC Fusion ioMemory PX	SUSE Linux Enterprise Server 12.1	4.2.4.1178	8.9.1	21
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1300GB MLC Fusion ioMemory PX	SUSE Linux Enterprise Server 12.1	4.2.4.1178	8.9.1	21
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1300GB MLC Fusion ioMemory PX	SUSE Linux Enterprise Server 12.1	4.2.4.1178	8.9.1	21

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	UCS 1300GB MLC Fusion ioMemory PX	SUSE Linux Enterprise Server 12.1	4.2.4.1178	8.9.1	21
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1300GB MLC Fusion ioMemory PX	vSphere 5.1 U2	4.2.4.1178	8.9.1	
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS 1300GB MLC Fusion ioMemory PX	vSphere 5.1 U2	4.2.4.1178	8.9.1	
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1300GB MLC Fusion ioMemory PX	vSphere 5.1 U2	4.2.4.1178	8.9.1	
B200 M4 w/E5-Series v3	UCS 1300GB MLC Fusion ioMemory PX	vSphere 5.1 U2	4.2.4.1178	8.9.1	
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1300GB MLC Fusion ioMemory PX	vSphere 5.1 U3	4.2.4.1178	8.9.1	
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS 1300GB MLC Fusion ioMemory PX	vSphere 5.1 U3	4.2.4.1178	8.9.1	
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1300GB MLC Fusion ioMemory PX	vSphere 5.1 U3	4.2.4.1178	8.9.1	
B200 M4 w/E5-Series v3	UCS 1300GB MLC Fusion ioMemory PX	vSphere 5.1 U3	4.2.4.1178	8.9.1	

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1300GB MLC Fusion ioMemory PX	vSphere 5.5	4.2.4.1178	8.9.1	
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS 1300GB MLC Fusion ioMemory PX	vSphere 5.5	4.2.4.1178	8.9.1	
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1300GB MLC Fusion ioMemory PX	vSphere 5.5	4.2.4.1178	8.9.1	
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1300GB MLC Fusion ioMemory PX	vSphere 5.5 U1	4.2.4.1178	8.9.1	
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS 1300GB MLC Fusion ioMemory PX	vSphere 5.5 U1	4.2.4.1178	8.9.1	
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1300GB MLC Fusion ioMemory PX	vSphere 5.5 U1	4.2.4.1178	8.9.1	
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1300GB MLC Fusion ioMemory PX	vSphere 5.5 U2	4.2.4.1178	8.9.1	
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS 1300GB MLC Fusion ioMemory PX	vSphere 5.5 U2	4.2.4.1178	8.9.1	
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1300GB MLC Fusion ioMemory PX	vSphere 5.5 U2	4.2.4.1178	8.9.1	

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1300GB MLC Fusion ioMemory PX	vSphere 5.5 U2	4.2.4.1178	8.9.1	
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1300GB MLC Fusion ioMemory PX	vSphere 5.5 U3	4.2.4.1178	8.9.1	
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS 1300GB MLC Fusion ioMemory PX	vSphere 5.5 U3	4.2.4.1178	8.9.1	
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1300GB MLC Fusion ioMemory PX	vSphere 5.5 U3	4.2.4.1178	8.9.1	
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1300GB MLC Fusion ioMemory PX	vSphere 5.5 U3	4.2.4.1178	8.9.1	
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	UCS 1300GB MLC Fusion ioMemory PX	vSphere 5.5 U3	4.2.4.1178	8.9.1	
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1300GB MLC Fusion ioMemory PX	vSphere 6.0	4.2.4.1178	8.9.1	
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS 1300GB MLC Fusion ioMemory PX	vSphere 6.0	4.2.4.1178	8.9.1	

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1300GB MLC Fusion ioMemory PX	vSphere 6.0	4.2.4.1178	8.9.1	
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1300GB MLC Fusion ioMemory PX	vSphere 6.0	4.2.4.1178	8.9.1	
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1300GB MLC Fusion ioMemory PX	vSphere 6.0 U1	4.2.4.1178	8.9.1	
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS 1300GB MLC Fusion ioMemory PX	vSphere 6.0 U1	4.2.4.1178	8.9.1	
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1300GB MLC Fusion ioMemory PX	vSphere 6.0 U1	4.2.4.1178	8.9.1	
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1300GB MLC Fusion ioMemory PX	vSphere 6.0 U1	4.2.4.1178	8.9.1	
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	UCS 1300GB MLC Fusion ioMemory PX	vSphere 6.0 U1	4.2.4.1178	8.9.1	
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1300GB MLC Fusion ioMemory PX	Windows Server 2012	4.2.4.1178	8.9.1	21

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS 1300GB MLC Fusion ioMemory PX	Windows Server 2012	4.2.4.1178	8.9.1	21
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1300GB MLC Fusion ioMemory PX	Windows Server 2012	4.2.4.1178	8.9.1	21
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1300GB MLC Fusion ioMemory PX	Windows Server 2012	4.2.4.1178	8.9.1	21
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	UCS 1300GB MLC Fusion ioMemory PX	Windows Server 2012	4.2.4.1178	8.9.1	21
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1300GB MLC Fusion ioMemory PX	Windows Server 2012 R2	4.2.4.1178	8.9.1	21
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS 1300GB MLC Fusion ioMemory PX	Windows Server 2012 R2	4.2.4.1178	8.9.1	21
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1300GB MLC Fusion ioMemory PX	Windows Server 2012 R2	4.2.4.1178	8.9.1	21
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1300GB MLC Fusion ioMemory PX	Windows Server 2012 R2	4.2.4.1178	8.9.1	21

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	UCS 1300GB MLC Fusion ioMemory PX	Windows Server 2012 R2	4.2.4.1178	8.9.1	21
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1600GB MLC Fusion ioMemory SX	Red Hat Enterprise Linux 5.10	4.2.4.1178	8.9.1	21
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS 1600GB MLC Fusion ioMemory SX	Red Hat Enterprise Linux 5.10	4.2.4.1178	8.9.1	21
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1600GB MLC Fusion ioMemory SX	Red Hat Enterprise Linux 5.11	4.2.4.1178	8.9.1	21
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS 1600GB MLC Fusion ioMemory SX	Red Hat Enterprise Linux 5.11	4.2.4.1178	8.9.1	21
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1600GB MLC Fusion ioMemory SX	Red Hat Enterprise Linux 6.4	4.2.4.1178	8.9.1	21
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS 1600GB MLC Fusion ioMemory SX	Red Hat Enterprise Linux 6.4	4.2.4.1178	8.9.1	21
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1600GB MLC Fusion ioMemory SX	Red Hat Enterprise Linux 6.5	4.2.4.1178	8.9.1	21

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS 1600GB MLC Fusion ioMemory SX	Red Hat Enterprise Linux 6.5	4.2.4.1178	8.9.1	21
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1600GB MLC Fusion ioMemory SX	Red Hat Enterprise Linux 6.5	4.2.4.1178	8.9.1	21
B200 M4 w/E5-Series v3	UCS 1600GB MLC Fusion ioMemory SX	Red Hat Enterprise Linux 6.5	4.2.4.1178	8.9.1	21
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1600GB MLC Fusion ioMemory SX	Red Hat Enterprise Linux 6.6	4.2.4.1178	8.9.1	21
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS 1600GB MLC Fusion ioMemory SX	Red Hat Enterprise Linux 6.6	4.2.4.1178	8.9.1	21
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1600GB MLC Fusion ioMemory SX	Red Hat Enterprise Linux 6.6	4.2.4.1178	8.9.1	21
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1600GB MLC Fusion ioMemory SX	Red Hat Enterprise Linux 6.6	4.2.4.1178	8.9.1	21
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1600GB MLC Fusion ioMemory SX	Red Hat Enterprise Linux 6.7	4.2.4.1178	8.9.1	21
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS 1600GB MLC Fusion ioMemory SX	Red Hat Enterprise Linux 6.7	4.2.4.1178	8.9.1	21

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1600GB MLC Fusion ioMemory SX	Red Hat Enterprise Linux 6.7	4.2.4.1178	8.9.1	21
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1600GB MLC Fusion ioMemory SX	Red Hat Enterprise Linux 6.7	4.2.4.1178	8.9.1	21
B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	UCS 1600GB MLC Fusion ioMemory SX	Red Hat Enterprise Linux 6.7	4.2.4.1178	8.9.1	21
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1600GB MLC Fusion ioMemory SX	Red Hat Enterprise Linux 7.0	4.2.4.1178	8.9.1	21
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS 1600GB MLC Fusion ioMemory SX	Red Hat Enterprise Linux 7.0	4.2.4.1178	8.9.1	21
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1600GB MLC Fusion ioMemory SX	Red Hat Enterprise Linux 7.0	4.2.4.1178	8.9.1	21
B200 M4 w/E5-Series v3	UCS 1600GB MLC Fusion ioMemory SX	Red Hat Enterprise Linux 7.0	4.2.4.1178	8.9.1	21
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1600GB MLC Fusion ioMemory SX	Red Hat Enterprise Linux 7.1	4.2.4.1178	8.9.1	21
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS 1600GB MLC Fusion ioMemory SX	Red Hat Enterprise Linux 7.1	4.2.4.1178	8.9.1	21
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1600GB MLC Fusion ioMemory SX	Red Hat Enterprise Linux 7.1	4.2.4.1178	8.9.1	21

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1600GB MLC Fusion ioMemory SX	Red Hat Enterprise Linux 7.1	4.2.4.1178	8.9.1	21
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1600GB MLC Fusion ioMemory SX	Red Hat Enterprise Linux 7.2	4.2.4.1178	8.9.1	21
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS 1600GB MLC Fusion ioMemory SX	Red Hat Enterprise Linux 7.2	4.2.4.1178	8.9.1	21
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1600GB MLC Fusion ioMemory SX	Red Hat Enterprise Linux 7.2	4.2.4.1178	8.9.1	21
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1600GB MLC Fusion ioMemory SX	Red Hat Enterprise Linux 7.2	4.2.4.1178	8.9.1	21
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1600GB MLC Fusion ioMemory SX	SUSE Linux Enterprise Server 11.3	4.2.4.1178	8.9.1	21
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS 1600GB MLC Fusion ioMemory SX	SUSE Linux Enterprise Server 11.3	4.2.4.1178	8.9.1	21
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1600GB MLC Fusion ioMemory SX	SUSE Linux Enterprise Server 11.3	4.2.4.1178	8.9.1	21

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1600GB MLC Fusion ioMemory SX	SUSE Linux Enterprise Server 11.3	4.2.4.1178	8.9.1	21
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1600GB MLC Fusion ioMemory SX	SUSE Linux Enterprise Server 11.4	4.2.4.1178	8.9.1	21
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS 1600GB MLC Fusion ioMemory SX	SUSE Linux Enterprise Server 11.4	4.2.4.1178	8.9.1	21
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1600GB MLC Fusion ioMemory SX	SUSE Linux Enterprise Server 11.4	4.2.4.1178	8.9.1	21
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1600GB MLC Fusion ioMemory SX	SUSE Linux Enterprise Server 11.4	4.2.4.1178	8.9.1	21
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1600GB MLC Fusion ioMemory SX	SUSE Linux Enterprise Server 12	4.2.4.1178	8.9.1	21
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS 1600GB MLC Fusion ioMemory SX	SUSE Linux Enterprise Server 12	4.2.4.1178	8.9.1	21
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1600GB MLC Fusion ioMemory SX	SUSE Linux Enterprise Server 12	4.2.4.1178	8.9.1	21

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1600GB MLC Fusion ioMemory SX	SUSE Linux Enterprise Server 12	4.2.4.1178	8.9.1	21
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	UCS 1600GB MLC Fusion ioMemory SX	SUSE Linux Enterprise Server 12	4.2.4.1178	8.9.1	21
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1600GB MLC Fusion ioMemory SX	SUSE Linux Enterprise Server 12.1	4.2.4.1178	8.9.1	21
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS 1600GB MLC Fusion ioMemory SX	SUSE Linux Enterprise Server 12.1	4.2.4.1178	8.9.1	21
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1600GB MLC Fusion ioMemory SX	SUSE Linux Enterprise Server 12.1	4.2.4.1178	8.9.1	21
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1600GB MLC Fusion ioMemory SX	SUSE Linux Enterprise Server 12.1	4.2.4.1178	8.9.1	21
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	UCS 1600GB MLC Fusion ioMemory SX	SUSE Linux Enterprise Server 12.1	4.2.4.1178	8.9.1	21
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1600GB MLC Fusion ioMemory SX	vSphere 5.1 U2	4.2.4.1178	8.9.1	

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS 1600GB MLC Fusion ioMemory SX	vSphere 5.1 U2	4.2.4.1178	8.9.1	
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1600GB MLC Fusion ioMemory SX	vSphere 5.1 U2	4.2.4.1178	8.9.1	
B200 M4 w/E5-Series v3	UCS 1600GB MLC Fusion ioMemory SX	vSphere 5.1 U2	4.2.4.1178	8.9.1	
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1600GB MLC Fusion ioMemory SX	vSphere 5.1 U3	4.2.4.1178	8.9.1	
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS 1600GB MLC Fusion ioMemory SX	vSphere 5.1 U3	4.2.4.1178	8.9.1	
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1600GB MLC Fusion ioMemory SX	vSphere 5.1 U3	4.2.4.1178	8.9.1	
B200 M4 w/E5-Series v3	UCS 1600GB MLC Fusion ioMemory SX	vSphere 5.1 U3	4.2.4.1178	8.9.1	
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1300GB MLC Fusion ioMemory PX	vSphere 5.5	4.2.4.1178	8.9.1	
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS 1300GB MLC Fusion ioMemory PX	vSphere 5.5	4.2.4.1178	8.9.1	
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1300GB MLC Fusion ioMemory PX	vSphere 5.5	4.2.4.1178	8.9.1	

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1600GB MLC Fusion ioMemory SX	vSphere 5.5 U1	4.2.4.1178	8.9.1	
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS 1600GB MLC Fusion ioMemory SX	vSphere 5.5 U1	4.2.4.1178	8.9.1	
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1600GB MLC Fusion ioMemory SX	vSphere 5.5 U1	4.2.4.1178	8.9.1	
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1600GB MLC Fusion ioMemory SX	vSphere 5.5 U2	4.2.4.1178	8.9.1	
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS 1600GB MLC Fusion ioMemory SX	vSphere 5.5 U2	4.2.4.1178	8.9.1	
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1600GB MLC Fusion ioMemory SX	vSphere 5.5 U2	4.2.4.1178	8.9.1	
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1600GB MLC Fusion ioMemory SX	vSphere 5.5 U2	4.2.4.1178	8.9.1	
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1600GB MLC Fusion ioMemory SX	vSphere 5.5 U3	4.2.4.1178	8.9.1	
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS 1600GB MLC Fusion ioMemory SX	vSphere 5.5 U3	4.2.4.1178	8.9.1	

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1600GB MLC Fusion ioMemory SX	vSphere 5.5 U3	4.2.4.1178	8.9.1	
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1600GB MLC Fusion ioMemory SX	vSphere 5.5 U3	4.2.4.1178	8.9.1	
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	UCS 1600GB MLC Fusion ioMemory SX	vSphere 5.5 U3	4.2.4.1178	8.9.1	
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1600GB MLC Fusion ioMemory SX	vSphere 6.0	4.2.4.1178	8.9.1	
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS 1600GB MLC Fusion ioMemory SX	vSphere 6.0	4.2.4.1178	8.9.1	
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1600GB MLC Fusion ioMemory SX	vSphere 6.0	4.2.4.1178	8.9.1	
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1600GB MLC Fusion ioMemory SX	vSphere 6.0	4.2.4.1178	8.9.1	
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1600GB MLC Fusion ioMemory SX	vSphere 6.0 U1	4.2.4.1178	8.9.1	

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS 1600GB MLC Fusion ioMemory SX	vSphere 6.0 U1	4.2.4.1178	8.9.1	
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1600GB MLC Fusion ioMemory SX	vSphere 6.0 U1	4.2.4.1178	8.9.1	
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1600GB MLC Fusion ioMemory SX	vSphere 6.0 U1	4.2.4.1178	8.9.1	
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	UCS 1600GB MLC Fusion ioMemory SX	vSphere 6.0 U1	4.2.4.1178	8.9.1	
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1600GB MLC Fusion ioMemory SX	Windows Server 2012	4.2.4.1178	8.9.1	21
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS 1600GB MLC Fusion ioMemory SX	Windows Server 2012	4.2.4.1178	8.9.1	21
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1600GB MLC Fusion ioMemory SX	Windows Server 2012	4.2.4.1178	8.9.1	21
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1600GB MLC Fusion ioMemory SX	Windows Server 2012	4.2.4.1178	8.9.1	21

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	UCS 1600GB MLC Fusion ioMemory SX	Windows Server 2012	4.2.4.1178	8.9.1	21
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 1600GB MLC Fusion ioMemory SX	Windows Server 2012 R2	4.2.4.1178	8.9.1	21
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS 1600GB MLC Fusion ioMemory SX	Windows Server 2012 R2	4.2.4.1178	8.9.1	21
B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 1600GB MLC Fusion ioMemory SX	Windows Server 2012 R2	4.2.4.1178	8.9.1	21
B260 M4 w/E7-Series v3, B460 M4 w/E7-Series v3, B200 M4 w/E5-Series v3, B420 M4 w/E5-Series v3	UCS 1600GB MLC Fusion ioMemory SX	Windows Server 2012 R2	4.2.4.1178	8.9.1	21
B260 M4 w/E7-Series v4, B460 M4 w/E7-Series v4, B200 M4 w/E5-Series v4, B420 M4 w/E5-Series v4	UCS 1600GB MLC Fusion ioMemory SX	Windows Server 2012 R2	4.2.4.1178	8.9.1	21
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	LSI 400GB SLC WarpDrive	Red Hat Enterprise Linux 5.9	17.00.04.00	11.65.40.00	21
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	LSI 400GB SLC WarpDrive	Red Hat Enterprise Linux 5.9	17.00.04.00	11.65.40.00	21

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	LSI 400GB SLC WarpDrive	Red Hat Enterprise Linux 5.10	17.00.04.00	11.65.40.00	21
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	LSI 400GB SLC WarpDrive	Red Hat Enterprise Linux 5.10	17.00.04.00	11.65.40.00	21
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	LSI 400GB SLC WarpDrive	Red Hat Enterprise Linux 6.4	17.00.04.00	11.65.40.00	21
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	LSI 400GB SLC WarpDrive	Red Hat Enterprise Linux 6.4	17.00.04.00	11.65.40.00	21
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	LSI 400GB SLC WarpDrive	SUSE Linux Enterprise Server 11.2	17.00.04.00	11.65.40.00	21
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	LSI 400GB SLC WarpDrive	vSphere 5.0 U2	17.00.01.00.1	11.65.40.00	
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	LSI 400GB SLC WarpDrive	vSphere 5.0 U2	17.00.01.00.1	11.65.40.00	
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	LSI 400GB SLC WarpDrive	vSphere 5.0 U3	17.00.01.00.1	11.65.40.00	
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	LSI 400GB SLC WarpDrive	vSphere 5.0 U3	17.00.01.00.1	11.65.40.00	

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	LSI 400GB SLC WarpDrive	vSphere 5.1 U1	17.00.01.00.1	11.65.40.00	
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	LSI 400GB SLC WarpDrive	vSphere 5.1 U1	17.00.01.00.1	11.65.40.00	
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	LSI 400GB SLC WarpDrive	vSphere 5.1 U2	17.00.01.00.1	11.65.40.00	
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	LSI 400GB SLC WarpDrive	vSphere 5.1 U2	17.00.01.00.1	11.65.40.00	
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	LSI 400GB SLC WarpDrive	vSphere 5.1 U3	17.00.01.00.1	11.65.40.00	
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	LSI 400GB SLC WarpDrive	vSphere 5.1 U3	17.00.01.00.1	11.65.40.00	
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	LSI 400GB SLC WarpDrive	vSphere 5.5	17.00.01.00.1	11.65.40.00	

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	LSI 400GB SLC WarpDrive	vSphere 5.5	17.00.01.00.1	11.65.40.00	
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	LSI 400GB SLC WarpDrive	vSphere 5.5 U1	17.00.01.00.1	11.65.40.00	
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	LSI 400GB SLC WarpDrive	vSphere 5.5 U1	17.00.01.00.1	11.65.40.00	
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	LSI 400GB SLC WarpDrive	vSphere 5.5 U2	17.00.01.00.1	11.65.40.00	
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	LSI 400GB SLC WarpDrive	vSphere 5.5 U2	17.00.01.00.1	11.65.40.00	
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	LSI 400GB SLC WarpDrive	vSphere 5.5 U3	17.00.01.00.1	11.65.40.00	

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	LSI 400GB SLC WarpDrive	vSphere 5.5 U3	17.00.01.00.1	11.65.40.00	
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	LSI 400GB SLC WarpDrive	Windows Server 2008 R2 SP1	2.10.66.00	11.65.40.00	
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	LSI 400GB SLC WarpDrive	Windows Server 2008 R2 SP1	2.10.66.00	11.65.40.00	
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	LSI 400GB SLC WarpDrive	Windows Server 2012	2.10.66.00	11.65.40.00	
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	LSI 400GB SLC WarpDrive	Windows Server 2012	2.10.66.00	11.65.40.00	
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 365GB MLC Fusion-io ioDrive2	Red Hat Enterprise Linux 5.9	3.2.11.1581 (Block)	7.1.17	21
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS 365GB MLC Fusion-io ioDrive2	Red Hat Enterprise Linux 5.9	3.2.11.1581 (Block)	7.1.17	21

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 365GB MLC Fusion-io ioDrive2	Red Hat Enterprise Linux 6.4	3.2.11.1581 (Block)	7.1.17	21
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS 365GB MLC Fusion-io ioDrive2	Red Hat Enterprise Linux 6.4	3.2.11.1581 (Block)	7.1.17	21
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 365GB MLC Fusion-io ioDrive2	SUSE Linux Enterprise Server 11.2	3.2.11.1581 (Block)	7.1.17	21
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 365GB MLC Fusion-io ioDrive2	vSphere 5.0 U2	3.2.6.1219 (Block / SCSI)	7.1.17	
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS 365GB MLC Fusion-io ioDrive2	vSphere 5.0 U2	3.2.6.1219 (Block / SCSI)	7.1.17	
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 365GB MLC Fusion-io ioDrive2	vSphere 5.0 U3	3.2.6.1219 (Block / SCSI)	7.1.17	
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS 365GB MLC Fusion-io ioDrive2	vSphere 5.0 U3	3.2.6.1219 (Block / SCSI)	7.1.17	
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 365GB MLC Fusion-io ioDrive2	vSphere 5.1 U1	3.2.6.1219 (Block / SCSI)	7.1.17	
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS 365GB MLC Fusion-io ioDrive2	vSphere 5.1 U1	3.2.6.1219 (Block / SCSI)	7.1.17	

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 365GB MLC Fusion-io ioDrive2	vSphere 5.1 U2	3.2.6.1219 (Block / SCSI)	7.1.17	
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 365GB MLC Fusion-io ioDrive2	vSphere 5.1 U2	3.2.6.1219 (Block / SCSI)	7.1.17	
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 365GB MLC Fusion-io ioDrive2	vSphere 5.1 U3	3.2.6.1219 (Block / SCSI)	7.1.17	
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 365GB MLC Fusion-io ioDrive2	vSphere 5.1 U3	3.2.6.1219 (Block / SCSI)	7.1.17	
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 365GB MLC Fusion-io ioDrive2	vSphere 5.5	3.2.6.1219 (Block / SCSI)	7.1.17	
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 365GB MLC Fusion-io ioDrive2	vSphere 5.5	3.2.6.1219 (Block / SCSI)	7.1.17	
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 365GB MLC Fusion-io ioDrive2	vSphere 5.5 U1	3.2.6.1219 (Block / SCSI)	7.1.17	

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 365GB MLC Fusion-io ioDrive2	vSphere 5.5 U1	3.2.6.1219 (Block / SCSI)	7.1.17	
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 365GB MLC Fusion-io ioDrive2	vSphere 5.5 U2	3.2.6.1219 (Block / SCSI)	7.1.17	
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 365GB MLC Fusion-io ioDrive2	vSphere 5.5 U2	3.2.6.1219 (Block / SCSI)	7.1.17	
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 365GB MLC Fusion-io ioDrive2	vSphere 5.5 U3	3.2.6.1219 (Block / SCSI)	7.1.17	
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 365GB MLC Fusion-io ioDrive2	vSphere 5.5 U3	3.2.6.1219 (Block / SCSI)	7.1.17	
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 365GB MLC Fusion-io ioDrive2	Windows Server 2008 R2 SP1	3.2.11.1581 (Block)	7.1.17	

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 365GB MLC Fusion-io ioDrive2	Windows Server 2008 R2 SP1	3.2.11.1581 (Block)	7.1.17	
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 365GB MLC Fusion-io ioDrive2	Windows Server 2012	3.2.11.1581 (Block)	7.1.17	
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 365GB MLC Fusion-io ioDrive2	Windows Server 2012	3.2.11.1581 (Block)	7.1.17	
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 365GB MLC Fusion-io ioDrive2	Windows Server 2012 R2	3.2.11.1581 (Block)	7.1.17	
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 365GB MLC Fusion-io ioDrive2	Windows Server 2012 R2	3.2.11.1581 (Block)	7.1.17	
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 785GB MLC Fusion-io ioDrive2	Red Hat Enterprise Linux 5.9	3.2.11.1581 (Block)	7.1.17	23
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS 785GB MLC Fusion-io ioDrive2	Red Hat Enterprise Linux 5.9	3.2.11.1581 (Block)	7.1.17	23

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 785GB MLC Fusion-io ioDrive2	Red Hat Enterprise Linux 6.4	3.2.11.1581 (Block)	7.1.17	23
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS 785GB MLC Fusion-io ioDrive2	Red Hat Enterprise Linux 6.4	3.2.11.1581 (Block)	7.1.17	23
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 785GB MLC Fusion-io ioDrive2	SUSE Linux Enterprise Server 11.2	3.2.11.1581 (Block)	7.1.17	21, 23
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 785GB MLC Fusion-io ioDrive2	vSphere 5.0 U2	3.2.6.1219 (Block / SCSI)	7.1.17	23
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS 785GB MLC Fusion-io ioDrive2	vSphere 5.0 U2	3.2.6.1219 (Block / SCSI)	7.1.17	23
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 785GB MLC Fusion-io ioDrive2	vSphere 5.0 U3	3.2.6.1219 (Block / SCSI)	7.1.17	23
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS 785GB MLC Fusion-io ioDrive2	vSphere 5.0 U3	3.2.6.1219 (Block / SCSI)	7.1.17	23
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 785GB MLC Fusion-io ioDrive2	vSphere 5.1 U1	3.2.6.1219 (Block / SCSI)	7.1.17	23
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2	UCS 785GB MLC Fusion-io ioDrive2	vSphere 5.1 U1	3.2.6.1219 (Block / SCSI)	7.1.17	23

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 785GB MLC Fusion-io ioDrive2	vSphere 5.1 U2	3.2.6.1219 (Block / SCSI)	7.1.17	23
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 785GB MLC Fusion-io ioDrive2	vSphere 5.1 U2	3.2.6.1219 (Block / SCSI)	7.1.17	23
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 785GB MLC Fusion-io ioDrive2	vSphere 5.1 U3	3.2.6.1219 (Block / SCSI)	7.1.17	23
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 785GB MLC Fusion-io ioDrive2	vSphere 5.1 U3	3.2.6.1219 (Block / SCSI)	7.1.17	23
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 785GB MLC Fusion-io ioDrive2	vSphere 5.5	3.2.6.1219 (Block / SCSI)	7.1.17	23
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 785GB MLC Fusion-io ioDrive2	vSphere 5.5	3.2.6.1219 (Block / SCSI)	7.1.17	23
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 785GB MLC Fusion-io ioDrive2	vSphere 5.5 U1	3.2.6.1219 (Block / SCSI)	7.1.17	23

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 785GB MLC Fusion-io ioDrive2	vSphere 5.5 U1	3.2.6.1219 (Block / SCSI)	7.1.17	23
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 785GB MLC Fusion-io ioDrive2	vSphere 5.5 U2	3.2.6.1219 (Block / SCSI)	7.1.17	23
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 785GB MLC Fusion-io ioDrive2	vSphere 5.5 U2	3.2.6.1219 (Block / SCSI)	7.1.17	23
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 785GB MLC Fusion-io ioDrive2	vSphere 5.5 U3	3.2.6.1219 (Block / SCSI)	7.1.17	23
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 785GB MLC Fusion-io ioDrive2	vSphere 5.5 U3	3.2.6.1219 (Block / SCSI)	7.1.17	23
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 785GB MLC Fusion-io ioDrive2	Windows Server 2008 R2 SP1	3.2.11.1581 (Block)	7.1.17	23

UCS Blade Server	Adapter Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 785GB MLC Fusion-io ioDrive2	Windows Server 2008 R2 SP1	3.2.11.1581 (Block)	7.1.17	23
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 785GB MLC Fusion-io ioDrive2	Windows Server 2012	3.2.11.1581 (Block)	7.1.17	23
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 785GB MLC Fusion-io ioDrive2	Windows Server 2012	3.2.11.1581 (Block)	7.1.17	23
B22 M3 w/E5-Series, B200 M3 w/E5-Series, B420 M3 w/E5-Series	UCS 785GB MLC Fusion-io ioDrive2	Windows Server 2012 R2	3.2.11.1581 (Block)	7.1.17	23
B22 M3 w/E5-Series v2, B200 M3 w/E5-Series v2, B420 M3 w/E5-Series v2, B260 M4 w/E7-Series v2, B460 M4 w/E7-Series v2	UCS 785GB MLC Fusion-io ioDrive2	Windows Server 2012 R2	3.2.11.1581 (Block)	7.1.17	23

Storage Array Interoperability Matrix

Table 9 lists the storage array models that are supported with this version of the Unified Computing System.

Cisco's interoperability guidelines in this table apply to the following topologies and protocols:

- FC/FCoE-attached storage arrays (Fabric Interconnects in NPV mode or FC Switching Mode); unless otherwise indicated FCoE NPV connections are supported to the devices listed in the FC switch table
- UCSM-configured iSCSI boot
- iSCSI data LUN access if the storage array is directly connected to UCS Fabric Interconnects using Appliance Ports

- NFS or CIFS data access if the storage array is directly connected to UCS Fabric Interconnects using Appliance Ports



Note Cisco UCS has no interoperability requirements for storage arrays configured to use iSCSI (Data Only), NFS, or CIFS when connected through UCS Fabric Interconnect Uplink Port.

Table 9: Storage Array

Vendor	Storage Array Model	Array Firmware	Notes
Dell EMC	SC/SCv Series	Refer to storage vendors support list, http://en.community.dell.com/techcenter/storage/w/wiki/5069.dell-storage-compatibility-matrix-ps-series-sc-series-fs-series	2, 5, 6
Dell EMC	EMC Symmetrix Family (VMAX & DMX), EMC CLARiiON (AX & CX), EMC Unified Storage VNX/VNXe, EMC Celerra (Native Block), EMC Isilon (NFS/CIFS), EMC VPLEX	Refer to storage vendor's support list, https://elabnavigator.emc.com	2, 6, 12, 26
Dell EMC	XtremIO	Refer to storage vendor's support list, https://elabnavigator.emc.com	6, 7, 12
HDS	USP-V, USP-VM, VSP, HUS100 Series, HUS-VM, VSP G1000, AMS 1000, 2000 Series: AMS 2100, AMS 2300, AMS 2500	Refer to storage vendor's support list, http://www.hds.com/products/interoperability/	2, 6, 12
HP	HP9500	Refer to storage vendor's support list, https://h20272.www2.hp.com/SPOCK/	2, 5, 6
HP	HP 3PAR StorServ 7000 Series storage, HP/HPE 3PAR StorServ 8000 Series Storage, HP 3PAR StorServ 10000 Series Storage, HP/HPE 3PAR StorServ 20000 Series Storage	Refer to storage vendor's support list, https://h20272.www2.hp.com/SPOCK/	2, 6
IBM	DS 8100, DS 8800, DS 8870, SVC, XIV(Gen 2), XIV(Gen3), Storwize: v3500, v3700, v5000, v7000, FlashSystem: 840, 900, V840, V9000	Refer to storage vendor's support list, http://www-03.ibm.com/systems/support/storage/ssic/interoperability.wss	2, 6, 28
InfiniDat	InfiniBox F-Series	Refer to storage vendor's support list, https://support.infinidat.com/hc/en-us/articles/206973969-Interoperability-Matrix	2, 5, 16

Vendor	Storage Array Model	Array Firmware	Notes
Netapp	FAS2000 Series, FAS2500 Series, FAS3000 Series, FAS3100 Series, FAS3200 Series, FAS6000 Series, FAS6200 Series, FAS8000 Series, V3000 Series, V6000 Series, AFF8000 Series	Refer to storage vendor's support list, http://support.netapp.com/	2, 6, 12
Netapp	E5400 Series, E5500 Series, E5600 Series, EF540 Series, EF550 Series, EF560 Series, E2700 Series, E2800 Series	Refer to storage vendor's support list, http://support.netapp.com/	2, 6, 12
Tintri	VMstore: T-540, T-620, T-650, T-680, T-820, T-850, T-880	Refer to storage vendor's support list, http://www.tintri.com/sites/default/files/field/pdf/whitepapers/755-0001-0001-n_tintri_os_and_external_compatibility.pdf	2, 26

Enterprise Backup Interoperability Matrix

Table 10 lists the tape library models that are supported with this version of the Unified Computing System.

Table 10: Tape Libraries

Vendor	Tape Library Model	Backup Application	Firmware	Notes
IBM	TS3310, IBM3576, IBM LTO4, IBM LTO5, IBM LTO6, IBM LTO7	Please check with the hw vendor for supported Backup Applications.	Refer to storage vendor's support list, http://www-03.ibm.com/systems/support/storage/ssic/interoperability.wss	24
Oracle	SL150: HH LTO5, LTO6, SL500: HP LTO3, HP LTO4, HP LTO5, IBM LTO3, IBM LTO4, IBM LTO5, SL3000: HP LTO3, HP LTO4, HP LTO5, HP LTO6, IBM LTO3, IBM LTO4, IBM LTO5, IBM LTO6, STK-T10000B, T10000C, T10000D, STK-9840D, SL8500: HP LTO3, HP LTO4, HP LTO5, HP LTO6, IBM LTO3, IBM LTO4, IBM LTO5, IBM LTO6, STK-T10000B, T10000C, T10000D, STK-9840D	Please check with Oracle support for OS and Backup Application support	Please check with Oracle support for current Library / Tape drive firmware leaves	24, 30

Vendor	Tape Library Model	Backup Application	Firmware	Notes
Quantum	Scalar i40: HP LTO4, HP LTO5, HP LTO6, IBM LTO4, IBM LTO5, IBM LTO6, Scalar i80: HP LTO4, HP LTO5, HP LTO6, IBM LTO4, IBM LTO5, IBM LTO6, Scalar i500: HP LTO4, HP LTO5, HP LTO6, IBM LTO4, IBM LTO5, IBM LTO6, Scalar i6000: HP LTO4, HP LTO5, HP LTO6, IBM LTO4, IBM LTO5, IBM LTO6	Please check with the hw vendor for supported Backup Applications, http://www.quantum.com/	Please check with the HW vendor for current firmware leaves, http://www.quantum.com/	24
Quantum	VTL Libraries: DXi6702, DXi4701, DXi6802, DXi6900	Please check with the HW vendor for OS, Backup Application support, http://www.quantum.com/	Please check with the HW vendor for current firmware leaves, http://www.quantum.com/	24
Spectra Logic	T50e: IBM LTO5, IBM LTO6 (Half Height), T120: IBM LTO5, IBM LTO6 (Half Height)	Please check with the hw vendor for supported Backup Applications, https://support.spectralogic.com/	Please check with the HW vendor for current firmware versions, https://support.spectralogic.com/	24

Switch Interoperability Matrix

Table 11 lists the switch models that are supported with this version of the Unified Computing System.



Note Cisco UCS has no interoperability requirement for switch configured to use Ethernet when connected through UCS Fabric Interconnect Uplink Port or Appliance Port.

Table 11: Switch

Vendor	Switch Model	Notes
Brocade	6004, 6505, 6510, 6520, 8510: 7.1.x, 7.2.x, 7.3.x, 7.4.x	2, 16, 34
Brocade	300: 7.1.x, 7.2.x, 7.3.x, 7.4.x	2, 16, 34
Brocade	DCX-4S: 7.1.x, 7.2.x, 7.3.x, 7.4.x	2, 16, 34
Brocade	DCX: 7.1.x, 7.2.x, 7.3.x, 7.4.x	2, 16, 34
Cisco	MDS 9100, 9200, 9500 Series: 4.2.1.b	1, 2, 9, 15

Vendor	Switch Model	Notes
Cisco	MDS 9700 Series: 6.2.1	1, 2, 9, 15
Cisco	MDS 9396s: 6.2(13), 7.3(0)D1(1)	1, 2, 9
Cisco	Nexus 5000: 5.2(1)N1(2)	1, 2, 9, 15
Cisco	Nexus 5500: 6.0(2)N1(1)	1, 2, 9, 15
Cisco	Nexus 5600: 7.0(1)N1(1)	1, 2, 9, 15
Cisco	Nexus 6000: 6.0(2)N2(1)	1, 2, 9
Cisco	Nexus 7000: 6.2(12)	1, 2, 9

Graphics Processing Unit Interoperability Matrix

Table 12 lists the graphics processing units that the Unified Computing System B Series Servers support.

Table 12: Graphics Processing Units

UCS Blade Server	GPU Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B200 M4 w/E5-Series v3	UCSB-GPU-M6	Red Hat Enterprise Linux 6.5	352.56	84.0.89.00.01-2754.0200.01.02	21
B200 M4 w/E5-Series v3	UCSB-GPU-M6	Red Hat Enterprise Linux 6.6	352.56	84.0.89.00.01-2754.0200.01.02	21
B200 M4 w/E5-Series v3, B200 M4 w/E5-Series v4	UCSB-GPU-M6	Red Hat Enterprise Linux 6.7	352.56	84.0.89.00.01-2754.0200.01.02	21
B200 M4 w/E5-Series v3	UCSB-GPU-M6	Red Hat Enterprise Linux 7.0	352.56	84.0.89.00.01-2754.0200.01.02	21
B200 M4 w/E5-Series v3	UCSB-GPU-M6	Red Hat Enterprise Linux 7.1	352.56	84.0.89.00.01-2754.0200.01.02	21
B200 M4 w/E5-Series v3	UCSB-GPU-M6	Red Hat Enterprise Linux 7.1	GRID 2.0	84.0.89.00.01-2754.0200.01.02	48
B200 M4 w/E5-Series v3	UCSB-GPU-M6	vSphere 5.1 U2	GRID 2.0	84.0.89.00.01-2754.0200.01.02	48
B200 M4 w/E5-Series v3	UCSB-GPU-M6	vSphere 5.1 U3	GRID 2.0	84.0.89.00.01-2754.0200.01.02	48

UCS Blade Server	GPU Model	Operating System	Adapter Driver	Adapter Firmware	Notes
B200 M4 w/E5-Series v3	UCSB-GPU-M6	vSphere 5.5	GRID 2.0	84.0.89.00.01-2754.0200.01.02	48
B200 M4 w/E5-Series v3	UCSB-GPU-M6	vSphere 5.5 U1	GRID 2.0	84.0.89.00.01-2754.0200.01.02	48
B200 M4 w/E5-Series v3	UCSB-GPU-M6	vSphere 5.5 U2	GRID 2.0	84.0.89.00.01-2754.0200.01.02	48
B200 M4 w/E5-Series v3, B200 M4 w/E5-Series v4	UCSB-GPU-M6	vSphere 5.5 U3	GRID 2.0	84.0.89.00.01-2754.0200.01.02	48
B200 M4 w/E5-Series v3	UCSB-GPU-M6	vSphere 6.0	GRID 2.0	84.0.89.00.01-2754.0200.01.02	48
B200 M4 w/E5-Series v3, B200 M4 w/E5-Series v4	UCSB-GPU-M6	vSphere 6.0 U1	GRID 2.0	84.0.89.00.01-2754.0200.01.02	48
B200 M4 w/E5-Series v3, B200 M4 w/E5-Series v4	UCSB-GPU-M6	Windows Server 2012 R2	354.35	84.0.89.00.01-2754.0200.01.02	21
B200 M4 w/E5-Series v3, B200 M4 w/E5-Series v4	UCSB-GPU-M6	XenServer 6.5 SP1	GRID 2.0	84.0.89.00.01-2754.0200.01.02	48

Notes

- 1 Code levels greater than or equal to these listed versions are deemed by Cisco to be interoperable
- 2 The storage vendor's interoperability matrix should be consulted for information regarding which software and hardware (arrays and switches) versions are supported
- 3 ENIC driver only supported at this time
- 4 Driver required for installation not included in OS image or not supported, download driver from cisco.com
- 5 Direct Connect mode is not supported
- 6 Non-default adapter settings are typically required by storage vendors and found on their support list
- 7 Multiple array and switch models supported with UCS by the storage vendor are on their support list

- 8 Fiber Channel Storage that supports equivalent adapters and drivers is supported by UCS. UCS M71KR-E is equivalent to Emulex LP2100x, UCS M71KR-Q is equivalent to QLogic QLE804x, UCS M72KR-Q is equivalent to QLogic QLE8142/QLE8152, UCS M72KR-E is equivalent to Emulex OCe10102-F, UCS M73KR-Q is equivalent to QLogic QLE8242, UCS M73KR-E is equivalent to Emulex Oce11102-F
- 9 Specific switch features must be supported on all switches used, please consult release notes for each switch product to determine support for the desired feature
- 10 If running in MS Cluster mode and Ethernet and FC traffic on VM's with NPIV enabled, please see CDETs CSCuj20256 or driver README notes
- 11 A Cisco OEM Customized ESX ISO maybe required for installation. Custom ISO's contain the minimum driver level for installation, please check the Cisco HCL for the supported driver versions. Custom ISO's are available from VMware.com > Downloads > VMware vSphere > Drivers and Tools > Custom ISOs
- 12 iSCSI Boot is supported. Both Appliance and Uplink ports are supported unless otherwise noted
- 13 Refer to the UCS 82598KR-CI 10-Gigabit Ethernet Adapter for the supported Ethernet driver on this Converged Network Adapter
- 14 The 2104XP fabric extender is not compatible when the 1240 and 1280 or 1240 and VIC Port Expander are combined on the same blade. Applies to B22 M3 and B200 M3 as well as B420 with 1240 and adapter slot 2 populated
- 15 Certain Cisco Fabric Interconnects of the 6200 series have an OUI which will prevent FC port channels from connecting. This issue is outlined in CSCty04686 and can be mitigated by having your upstream Nexus 5000 code at a minimum version 6.0(2)N1(2), or MDS as minimum version 5.2(6)N1(4).
- 16 UCS Fabric Interconnect must be in FC End Host mode and upstream switch NPIV enabled
- 17 iSCSI Boot is not supported on Windows Server Core
- 18 All variations of OS are supported for this version, including Windows Server Core, Full and Hyper-V Standalone
- 19 Cluster-on-Die feature is not supported. For VmWare, please see <http://kb.vmware.com/kb/2087032>
- 20 For C-Series servers managed by UCSM, unless stated in this document, the supported firmware and drivers will be in the 2.0(12), 2.0(10), 2.0(9) and 1.5(9) Standalone C-Series Compatibility guide. 2.0(12) for C460 M4, 2.0(10) for C220 M4/C240 M4, 1.5(9) for C420-M3, C260-M2, C460-M2 and 2.0(9) for all other platforms.
- 21 Drivers can be found on the latest 2.2(8) B-Series Driver ISO
- 22 Listed support is for the UEK Kernel only. For the Red Hat Enterprise Linux compatible kernel, please refer to the Red Hat Enterprise Linux versions
- 23 Only UCS 785GB MLC Fusion-io ioDrive2, serial numbers FIO1717xxxx and newer, are supported on the B420 M3
- 24 Enable FCP error recovery in the service profile adapter policy
- 25 NIC Teaming driver is not currently supported with Hyper-V
- 26 Supported for NFS/CIFS access via appliance ports on the Fabric Interconnect
- 27 Requires Errata RHSA-2013:0168, reference bugzilla 884740
- 28 Direct attach virtual appliances connecting to external storage are not supported. Qualified direct attach virtual appliances with internal storage only are supported
- 29 For SAN installations, requires Citrix Hotfix CTX137403 during the installation, after installation is complete, apply CTX138731
- 30 Libraries are supported while using Automated Cartridge System Library Software (ACSL) 8.3 and above or directly connected using Fibre Channel. The SL8500 requires ACSLS where the other libraries, ACSLS is optional.
- 31 ESX NPIV Host Feature is not supported

- 32 Virtual Port-Mode supported with UCS Fabric Interconnect NPV mode only. Legacy mode not supported
- 33 Only x64 bit version supported
- 34 Brocade Family FOS release trains, 7.1, 7.2, 7.3 and 7.4 and their updates, unless otherwise stated are supported
- 35 iSCSI boot with NIC Teaming is currently not supported. Reference CDET CSCul82285
- 36 To fully utilize this system in a MAAS environment, you will need to update your MAAS server to the latest update version available
- 37 B200 M4 and C220/C240 M4(SFF/LFF) requires ESX 5.1 U2 patch P05 Cisco Custom ISO
- 38 6100 Series Fabric Interconnects and 2100 Series Fabric Extender is not supported
- 39 Cisco has tested a pre-defined configuration of CentOS on its servers with UCS firmware and VIC drivers. Cisco is committed to providing support triage to UCS customers using these pre-defined configurations. Customized CentOS kernels and all CentOS issue resolution outside of the pre-defined configuration and non-cisco components is the responsibility of the partners or customers using The CentOS Project community-based resources. Any CentOS driver updates are subject to The CentOS Project community release cadence.
- 40 Cisco does not warrant CentOS or any support it may provide related to CentOS. Customers should review The CentOS Project existing terms and conditions at CentOS.org.
- 41 When installing the driver, must use these flags "rpm -i <driver rpm> --replacefiles --replacepkgs -- nodeps" Please refer to CSCuu37745 for details
- 42 VMFEX is not supported with ESX 5.0, 5.1 and it's updates on 13xx VIC adapters
- 43 Drivers are included in the OS
- 44 When using the KVM for display, the resolution must be changed, please refer to <https://wiki.ubuntu.com/X/Config/Resolution>
- 45 When applying the R3 U6 update or later, the FNIC driver is updated to version 1.6.0.18. This driver is fully supported
- 46 Requires minimum FW version 4.1.2d. Found in UCS patch release 2.2(8c) and later
- 47 B200 M4 w/E5-Series v4 requires patch 5.5 U3a or 6.0 U1b
- 48 To use the GPU in Grid mode, download the drivers from <https://nvidia.flexnetoperations.com/control/nvda/home>
- 49 Requires the UCSB-LSTOR-PT PCI Passthrough Adapter. Not supported with the UCSB-MRAID12G or UCSB-MRAID12G-HE Adapter
- 50 B420 M4 w/E5-Series v4 requires patch 5.5 U3b or 6.0 U1b
- 51 uEFI with Secure Boot is not supported at this time
- 52 Minimum FW is 4.1.1h, 2.2.3b for M81KR. VmWare's HCL may not always be in sync with Cisco's HCL. Please refer to VmWare's KB 2030818
- 53 The FNIC driver has been updated to resolve a known issue. It is recommended to update the driver. For more details, please refer to the VIC release notes: http://www.cisco.com/c/en/us/td/docs/unified_computing/ucs/release/notes/VIC/2-2/vicdrivers_22_rm.html
- 54 Previous FNIC versions are supported, 1.6.0.25
- 55 Previous FNIC versions are supported, 2.1.0.31
- 56 Previous ENIC versions are supported, 3.5.0.13
- 57 The ENIC driver has been updated to resolve a known issue. It is recommended to update the driver. For more details, please refer to the VIC release notes: http://www.cisco.com/c/en/us/td/docs/unified_computing/ucs/release/notes/VIC/2-2/vicdrivers_22_rm.html

58 For supported Oracle Linux (OL) and UEK combinations, please check with Oracle

59 NENIC is the native version of the ENIC included in the Operating system

Related Documentation

Links to the latest versions of related Cisco documentation are available in the *Cisco UCS Documentation Roadmap*, located at:

<http://www.cisco.com/go/unifiedcomputing/b-series-doc>

Cisco UCS B-Series Blade Server Software is available for download here:

<http://www.cisco.com/cisco/software/type.html?mdfid=283853163&flowid=25821>

Obtaining Documentation and Submitting a Service Request

For information on obtaining documentation, submitting a service request, and gathering additional information, see the monthly *What's New in Cisco Product Documentation*, which also lists all new and revised Cisco technical documentation, at:

<http://www.cisco.com/en/US/docs/general/whatsnew/whatsnew.html>

Subscribe to the *What's New in Cisco Product Documentation* as a Really Simple Syndication (RSS) feed and set content to be delivered directly to your desktop using a reader application. The RSS feeds are a free service and Cisco currently supports RSS version 2.0.

THE SPECIFICATIONS AND INFORMATION REGARDING THE PRODUCTS IN THIS MANUAL ARE SUBJECT TO CHANGE WITHOUT NOTICE. ALL STATEMENTS, INFORMATION, AND RECOMMENDATIONS IN THIS MANUAL ARE BELIEVED TO BE ACCURATE BUT ARE PRESENTED WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED. USERS MUST TAKE FULL RESPONSIBILITY FOR THEIR APPLICATION OF ANY PRODUCTS.

THE SOFTWARE LICENSE AND LIMITED WARRANTY FOR THE ACCOMPANYING PRODUCT ARE SET FORTH IN THE INFORMATION PACKET THAT SHIPPED WITH THE PRODUCT AND ARE INCORPORATED HEREIN BY THIS REFERENCE. IF YOU ARE UNABLE TO LOCATE THE SOFTWARE LICENSE OR LIMITED WARRANTY, CONTACT YOUR CISCO REPRESENTATIVE FOR A COPY.

The following information is for FCC compliance of Class A devices: This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio-frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference, in which case users will be required to correct the interference at their own expense.

The following information is for FCC compliance of Class B devices: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If the equipment causes interference to radio or television reception, which can be determined by turning the equipment off and on, users are encouraged to try to correct the interference by using one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Modifications to this product not authorized by Cisco could void the FCC approval and negate your authority to operate the product

The Cisco implementation of TCP header compression is an adaptation of a program developed by the University of California, Berkeley (UCB) as part of UCB's public domain version of the UNIX operating system. All rights reserved. Copyright © 1981, Regents of the University of California.

NOTWITHSTANDING ANY OTHER WARRANTY HEREIN, ALL DOCUMENT FILES AND SOFTWARE OF THESE SUPPLIERS ARE PROVIDED "AS IS" WITH ALL FAULTS. CISCO AND THE ABOVE-NAMED SUPPLIERS DISCLAIM ALL WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING, WITHOUT LIMITATION, THOSE OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT OR ARISING FROM A COURSE OF DEALING, USAGE, OR TRADE PRACTICE.

IN NO EVENT SHALL CISCO OR ITS SUPPLIERS BE LIABLE FOR ANY INDIRECT, SPECIAL, CONSEQUENTIAL, OR INCIDENTAL DAMAGES, INCLUDING, WITHOUT LIMITATION, LOST PROFITS OR LOSS OR DAMAGE TO DATA ARISING OUT OF THE USE OR INABILITY TO USE THIS MANUAL, EVEN IF CISCO OR ITS SUPPLIERS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Any Internet Protocol (IP) addresses and phone numbers used in this document are not intended to be actual addresses and phone numbers. Any examples, command display output, network topology diagrams, and other figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses or phone numbers in illustrative content is unintentional and coincidental.

Cisco and the Cisco logo are trademarks or registered trademarks of Cisco and/or its affiliates in the U.S. and other countries. To view a list of Cisco trademarks, go to this URL: <http://www.cisco.com/go/trademarks>. Third-party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1110R)

© 2016 Cisco Systems, Inc. All rights reserved.



Americas Headquarters
Cisco Systems, Inc.
San Jose, CA 95134-1706
USA

Asia Pacific Headquarters
Cisco Systems (USA) Pte. Ltd.
Singapore

Europe Headquarters
Cisco Systems International BV
Amsterdam, The Netherlands

Cisco has more than 200 offices worldwide. Addresses, phone numbers, and fax numbers are listed on the Cisco Website at www.cisco.com/go/offices.