

When there are multiple Catalyst 2960-S or 3750-X Series switches configured in a stack, one of the switches controls the operation of the stack and is called the stack master. When three or more switches are configured as a stack, configure the stack master switch functionality on a switch that does not have uplinks configured.

Figure 10 - Stack master placement in a switch stack

