

```
3rd-hp-3800# sh run
```

Running configuration:

```
; J9573A Configuration Editor; Created on release #KA.15.16.0006
```

```
; Ver #06:7c.fd.ff.ff.3f.ef:57
```

```
hostname "3rd-hp-3800"
```

```
module 1 type j9573x
```

```
dhcp-snooping
```

```
dhcp-snooping authorized-server 10.10.12.2
```

```
dhcp-snooping authorized-server 10.10.13.186
```

```
dhcp-snooping authorized-server 10.10.13.188
```

```
dhcp-snooping authorized-server 10.10.13.245
```

```
dhcp-snooping authorized-server 10.10.13.249
```

```
dhcp-snooping vlan 54-55 112
```

```
radius-server host 10.10.13.249 dyn-authorization
```

```
radius-server host 10.10.13.249 time-window 0
```

```
radius-server key "acsi"
```

```
timesync sntp
```

```
sntp unicast
```

```
sntp server priority 1 10.56.60.29
```

```
time timezone 180
```

```
ip access-list extended "PRE-AUTH"
```

```
exit
```

```
ip access-list extended "denyall"
```

```
10 deny ip 0.0.0.0 255.255.255.255 0.0.0.0 255.255.255.255
```

```
exit
```

```
ip access-list extended "fullaccess"  
    10 permit ip 0.0.0.0 255.255.255.255 0.0.0.0 255.255.255.255  
    exit  
ip default-gateway 10.10.54.253  
ip dns server-address priority 1 10.10.12.11  
interface 1  
    ip access-group "PRE-AUTH" in  
    dhcp-snooping trust  
    flow-control  
    exit  
interface 2  
    ip access-group "PRE-AUTH" in  
    dhcp-snooping trust  
    flow-control  
    exit  
interface 3  
    flow-control  
    exit  
interface 4  
    flow-control  
    exit  
interface 5  
    flow-control  
    exit  
interface 6  
    flow-control  
    exit  
interface 7  
    flow-control
```

```
exit
interface 8
  flow-control
  exit
interface 9
  flow-control
  exit
interface 11
  flow-control
  exit
interface 24
  dhcp-snooping trust
  flow-control
  exit
snmp-server community "public" unrestricted
snmp-server community "writeme" unrestricted
snmp-server host 10.10.13.33 community "writeme"
portal web-server "ISE" url "https://10.10.13.245/portal"
portal web-server "ise-cwa" url "https://10.10.13.186:8443/portal/g?p=ZqZ8lojgY8gRxf4JzRw7vIWmep"
portal web-server "ise-posture" url "https://ise-vm-
2.cisco.com:8443/portal/g?p=W74ro4r4MbPZeUXMk4Kg5D8Gx6"
aaa accounting update periodic 1
aaa accounting network start-stop radius
aaa accounting session-id common
aaa authentication port-access eap-radius
aaa port-access authenticator 1-2
aaa port-access authenticator 1 client-limit 1
aaa port-access authenticator 2 quiet-period 30
aaa port-access authenticator 2 logoff-period 862400
```

aaa port-access authenticator 2 client-limit 1

aaa port-access authenticator active

aaa port-access mac-based 1-2

aaa port-access mac-based 2 addr-limit 32

oobm

ip address dhcp-bootp

exit

vlan 1

name "DEFAULT_VLAN"

no untagged 2-24

untagged 1,25-26

no ip address

exit

vlan 5

name "VLAN5"

tagged 24

no ip address

exit

vlan 55

name "VLAN55"

untagged 2-24

ip address 10.10.54.250 255.255.255.0

portal web-server "ISE"

exit

vlan 100

name "VLAN100"

tagged 24

no ip address

exit

vlan 103

name "VLAN103"

tagged 24

no ip address

exit

vlan 104

name "VLAN104"

tagged 24

no ip address

exit

vlan 105

name "VLAN105"

tagged 24

no ip address

exit

vlan 112

name "VLAN112"

tagged 24

ip address 10.10.112.242 255.255.255.0

ip helper-address 10.10.12.2

exit

vlan 114

name "VLAN114"

tagged 24

no ip address

exit

3rd-hp-3800#