



Article ID: 4984

Access the CLI via PuTTY Using a Console Connection on 300 and 500 Series Managed Switches

Objective

Switches can be accessed and configured through the Command Line Interface (CLI). Accessing the CLI allows commands to be entered in a terminal based window. For a user who has had more experience with terminal commands, this may be an easier alternative to navigating the web configuration utility. Certain tasks such as recovering an administrator password can only be performed through the CLI. In order to access the CLI you must use an SSH client. PuTTY is a standard SSH client and can be found [here](#). This document assumes you are connecting to the switch using PuTTY.

The objective of this document is to show you how to access a switch's Command Line Interface (CLI) with a Standard 9-pin Serial Cable and a Secure Shell (SSH) client.

Note: Cisco 200 Series Small Business Managed Switches do not support the CLI.

Applicable Devices

- Cisco Small Business 300 Series Managed Switches
- Cisco Small Business 500 Series Managed Switches

Software Version


- v1.2.7.76

Accessing the CLI via PuTTY with a Console Connection


Step 1. Connect the switch to the computer using a standard 9-pin serial cable.

Note: The Cisco DB9 to RJ45 Console Cable also supports console connections, but only if the switch has an RJ45 Console port. An RJ45 Console port resembles an Ethernet port and is labeled CONSOLE on the back of the switch.


Step 2. Open the PuTTY application. The *PuTTY Configuration* window opens:




Step 3. Under the *Connection Type* field, click the **Serial** radio button.




Step 4. In the *Category* navigation field, choose **Serial**.



The *Options controlling local serial lines* page opens:



Step 5. In the *Serial line to connect to* field, enter the COM port that your device is connected to. The default COM port is COM1.




Step 6. In the *Speed (baud)* field, enter the digital transmission speed that is compatible with the switch. For 300 and 500 Series Managed Switches, the speed must be set to **115200**.

The screenshot shows a configuration window titled "Options controlling local serial lines". On the left is a tree view under "Category:" with "SSH" and "Serial" selected. The main area has a "Serial line to connect to" field set to "COM1". Under "Configure the serial line", the "Speed (baud)" field is highlighted with a red circle and contains "115200". Other fields include "Data bits" (8), "Stop bits" (1), "Parity" (None), and "Flow control" (XON/XOFF). Buttons for "About", "Open", and "Cancel" are at the bottom.


Step 7. In the *Data bits* field, enter the number of data bits used for each character. The recommended value is **8**.

This screenshot is similar to the previous one, but the "Data bits" field is highlighted with a red circle and contains the value "8". The "Speed (baud)" field now contains "115200". The "Flow control" dropdown menu is now set to "None". All other elements, including the tree view and buttons, remain the same.


Step 8. In the *Stop bits* field, enter the number of bits to be sent at the end of every character. The stop bit informs the machine that it has reached the end of a byte. The recommended value is **1**.




Step 9. In the *Parity* drop-down menu, select the method of detecting errors in transmission. The recommended method for detecting errors in transmission is **None**.




Step 10. In the *Flow Control* drop-down menu, select the method of preventing data overflow. The recommended method for preventing data overflow is **None**.




Step 11. (Optional) In order to save the connection settings for future use, go to the *Category* navigation pane and choose **Session**. If you do not wish to save the connection settings, skip to Step 14.




Step 12. Under the *Saved Sessions* field, enter a name for the settings to be saved as.



Step 13. Click **Save**.




Step 14. Click **Open**.



The *COM1 – PuTTY* console window opens.

Step 15. Hit **Enter** on the keyboard to activate the Command Line Interface (CLI). The log in prompt is displayed:



Step 16. Enter the User Name. The default username is *cisco*.

```
User Name:cisco█
```

Step 17. Enter the Password. The default password is *cisco*.

```
User Name:cisco  
Password:*****█
```